

USER MANUAL

MASTER-APRS Weather Station

Sends live temperature, humidity and pressure to the APRS network over Wi-Fi.

SETUP WI-FI NETWORK

Wi-Fi	**MASTER-APRS Wx**
Password	**mastersetup**
Open	**192.168.4.1**

Setup

1. Power on the unit. It creates its own setup Wi-Fi network using the details above.
2. Connect your phone to that network, then open 192.168.4.1 in a browser.
3. Enter your home Wi-Fi name and password so the station can get online.
4. Enter your callsign and an APRS-ID (for example, 14 forms VU2RCY-14), plus your APRS-IS passcode, location, icon and beacon interval.
5. Tap Save & Reboot. The station connects and starts beaconing your position and weather data to aprs.fi.



The configuration page at 192.168.4.1. Send Beacon, Status and Save Default Config are on the same page.

Not showing up on aprs.fi yet? Give it a couple of minutes, then search for your callsign with its APRS-ID (for example VU2RCY-14).

Need help? Message me.
Scan the code to message me on WhatsApp.

+91 73884 07388
vu2rcy+social@gmail.com
vu2rcy.com/products/master-aprs-weather-station