

USER MANUAL

LoRa CHAT

Point-to-point chat over LoRa. No internet, no SIM card.

SETUP WI-FI NETWORK

Wi-Fi	`LoRa_CHAT_A`
Password	`12345678`
Open	`192.168.4.1`

Setup

1. Turn on the LoRa CHAT unit and wait a few seconds for its Wi-Fi to start.
2. On your phone, open Wi-Fi settings and connect to LoRa_CHAT_A using the password above.
3. Open your phone's browser and go to 192.168.4.1. The LoRa Chat page opens.
4. Type your message and tap Send. It's carried over LoRa to the other unit, and replies show up on the same page.

This Wi-Fi network is created by the unit itself, so the chat works without an internet connection.

Need help? Message me.

Scan the code to message me on WhatsApp.

+91 73884 07388
vu2rcy+social@gmail.com
vu2rcy.com/products/lora-chat