

The service may be started by double clicking on the apcupsd "Start" icon and will be automatically be run the next time this machine is rebooted.

