AromaPro E200 Espresso Machine

1. Safety Instructions

Read this manual before using the AromaPro E200 espresso machine. Keep it for future reference.

Operate the machine only on a stable, level, heat-resistant surface. The machine is rated for 230 V, 50 Hz and consumes 1450 W. Never immerse the machine, the power cord or the plug in water or any other liquid.

The appliance may be used by children from 8 years of age only under supervision. Keep the machine and its cord out of reach of children younger than 8 years.

The ambient temperature during operation must not exceed 35 degrees Celsius. The steam wand and the brew group become very hot; do not touch them during use.

2. Daily Operation

Filling the water tank: remove the tank at the rear and fill it with fresh, cold water up to the MAX mark. The tank capacity is 1.8 litres.

Heat-up: after switching on, the machine needs approximately 25 seconds to heat up. The ready light turns steady when brewing is possible.

Brewing: press the single-shot button for 30 ml or the double-shot button for 60 ml. The pump pressure is 15 bar. The portafilter holds 8 g of ground coffee for a single shot and 16 g for a double shot.

Frothing milk: press the steam button and wait about 40 seconds until the steam light stays on. Purge the steam wand briefly before and after every use and wipe it with a damp cloth immediately after frothing.

3. Cleaning and Maintenance

Daily: empty the drip tray and rinse the portafilter and filter baskets with warm water.

Weekly: backflush the brew group. Insert the blind filter basket with one cleaning tablet and run 5 cycles of 10 seconds each, then rinse with clean water.

Descaling: descale the machine every 3 months, or immediately when the descale light blinks. Mix 1 litre of descaling solution at a ratio of 1:3 with water. The descaling programme takes about 20 minutes. Rinse the tank and run two full tanks of fresh water through the machine afterwards.

Water filter: replace the water filter cartridge every 2 months or after 60 litres, whichever comes first. Grinder: clean the burrs monthly with the supplied brush.

4. Troubleshooting and Warranty

Error E01: the water tank is empty or not seated correctly. Refill the tank and push it firmly into place.

Error E02: overheating protection (thermal fuse) triggered. Unplug the machine and let it cool down for 30 minutes before restarting.

Error E04: pump blockage, usually caused by limescale. Run the descaling programme. Error E07: the grinder is jammed. Switch the machine off, remove the beans from the hopper and clean the burrs.

Coffee tastes too weak: select a finer grind. The grinder has settings 1 to 12, where 1 is the finest; the factory default is 5.

Warranty: 24 months from the date of purchase. Contact customer service on +49 800 555 0101 (fictional number).