

Task-1

1.

- Common Issue: Keyboard or mouse not detected
- Possible Solution: Unplug the USB device and reconnect it to another USB port.

2.

- Common Issue: Keyboard/Mouse not responding
- Possible Solution: Restart the laptop and check if the USB device works afterward

3.

- Common Issue: USB connection Keeps disconnecting
- Possible Solution: Try a different USB port and check for loose or damaged cables

4.

- Common Issue: Mouse cursor moves slowly or erratically
- Possible Solution: Clean the mouse sensor and use it on a smooth, non-reflective surface

5.

- Common Issue: Some keyboard keys don't work
- Possible Solution: Clean around the affect keys and reconnect the keyboard; if the problem continues, try another keyboard.

Task-2

Check headphone Bluetooth Headphones Troubleshooting Flow

1. power
 - Turn on the headphones.
 - Check the battery indicator. Make sure they have enough charge.
 - If the battery is low, charge them for a few minutes.
2. Check Bluetooth on the phone
 - Open Settings - Bluetooth.
 - Make sure Bluetooth is ON.
 - Check whether the headphones appear under My Devices/Available Devices.
3. Put headphones into pairing mode
 - Press and hold the Bluetooth/Power button until the indicator light starts flashing, usually blue or blue/white.
 - This indicates that the headphones are ready to pair.
4. Try connecting
 - Select the headphones from the phone's Bluetooth device list.
 - Wait for the status to change to Connected.
5. Check if they are connected to another device
 - Turn Bluetooth off on nearby phones, laptops, tablets, or TVs that the headphones were previously connected to.
 - Then try pairing again.
6. Forget and re-pair the headphones
 - On the phone, go to Settings - Bluetooth -Settings next to the headphones - Forget This Device.
 - Put the headphones back into pairing mode.
 - Search for them again and reconnect.
7. Restart both devices
 - Turn the headphones off and on again.
 - Restart the phone.
 - Turn Bluetooth back on and try connecting.
8. Check the Bluetooth indicator
 - Flashing light: usually pairing mode.
 - Solid light: usually connected.
 - No light: headphones may be switched off or out of battery.
9. Test with another phone
 - Try connecting the headphones to another Bluetooth-enabled phone.

- If they connect, the problem is likely with the original phone's Bluetooth settings.
10. Last step: reset the headphones
- Perform the manufacturer's factory reset procedure.
 - Put them into pairing mode again and try connecting.

Task-3

External Webcam Not Detected in Zoom — Checklist

1. Check the USB connection
 - Unplug the webcam and connect it to another USB port.
 - Check if the webcam's indicator light turns on.
2. Check Device Manager
 - Press Windows + X → Device Manager.
 - Expand Cameras or Imaging Devices.
 - Make sure the webcam appears and is not showing a warning icon.
 - If necessary, right-click it and select Update driver.
3. Check Windows camera privacy settings
 - Go to Settings → Privacy → Camera.
 - Turn on Allow apps to access your camera.
4. Allow desktop apps to use the camera
 - In Settings → Privacy → Camera, enable Allow desktop apps to access your camera.
 - Zoom needs this permission on Windows 10.
5. Select the correct camera in Zoom
 - Open Zoom → Settings → Video.
 - Under Camera, select the external webcam instead of the laptop's built-in camera.
 - Check whether the preview displays the webcam video.
6. Close other apps and restart
 - Close apps such as Microsoft Teams, Skype, Camera, or Google Meet that may be using the webcam.
 - Restart Zoom and, if necessary, restart the computer.

Task-4

Using Windows Troubleshooter to Fix an Offline Printer

1. Open Windows Settings
 - Press Windows + I to open Settings.
2. Open Printer Settings
 - Go to Devices - Printers & scanners.
 - Select the printer showing Offline.
3. Run the Troubleshooter
 - Click Manage and look for the Troubleshoot option.
 - Follow the instructions shown by Windows.
4. Let Windows diagnose the printer
 - Windows checks common problems such as:
 - Printer connection
 - Printer driver problems
 - Print Spooler service
 - Printer configuration
 - Network/communication issues
5. Review the results
 - The trouble shooter tells you whether it found a problem.
 - It may also show the specific issue detected and recommend or automatically apply a fix.
6. Apply the recommended fix
 - If Windows offers a solution, select Apply this fix or follow its instructions.
 - Try printing a test page afterward.