

BRL-305 SERIAL COMMUNICATIONS (RS 232) SPECIFICATIONS

BRL 305 device can be connected with computer or barcode printer. BRL 305 can be direct print to the barcode printer.

Communications with Printer:

BRL 305 can be connected with printer with DB9 male connector. The cable must be with shield and must be shorter than 5 meters. The numbers are showed in DB9 male connectors.

DB9 Male	BRL 305
2	19(TX)
3	18(RX)
5	17(GND)

* Barcode printer must be Argox OS-214 and the communications protocol of printer must be PPLB.

Communications with Computer:

BRL 305 can be connected with computer with DB9 female connector. The cable must be with shield and must be shorter than 5 meters. The numbers are showed in DB9 female connectors.

DB9 Female	BRL 305
2	19(TX)
3	18(RX)
5	17(GND)

Computer communications adjustments:

PORT	COM1 or COM2
BAUD RATE	9600
DATA BITS	8
STOP BITS	1
PARITY	NONE
FLOW CONTROL	NONE

For reading meters value:

Please send R character for reading meters value. BRL305 will respond in 300 millisecond. The response will be a string and this string will be include meters value and dot position.

The length of this string 8 character. First 7 strings include meters value and the last string is Hex 13 character.

For reset meters value:

Please send S character for resetting meters value. BRL 305 is just reset meters value, it doesn't send a respond. For checking please read meters value, after resetting.

For reading weight value:

Please send T character for reading weight value. BRL305 will respond in 300 millisecond. The response will be a string and this string will be include weight value and dot position. The length of this string 8 character. First 7 strings include weight value and the last string is Hex 13 character.

BRL 305 contains preset value, it is used for starting from described meters value.

For adjusting Preset value please send 7 bytes data. First data must be U and the others must be preset value without dot position.(Exp. for 10.00 meters please send U001000) Please send all datas without waiting.

BRL 305 contains error code inputs. For reading error code quantities, please send W character. BRL305 will respond in 300 millisecond. The response will be a string and this string will be include error quantities.The length of this string 3 character. First 2 strings include error quantities value and the last string is Hex 13 character.

For reading error code and error details please send to BRL 305 (X + Error Number).
(Exp. BRL 305 have 20 errors quantities, and you want to see error 10. You will send to BRL 305 X10 message. Brl 305 will be send a response. Response details are described below.)

2 Byte	String (Errors code number)
16 Byte	String (Errors code details)
7 Byte	String (Errors meters value)
1 Byte	String (Hex 13 Character)

BRL 305 will be send this 26 byte without waiting.

User can be send error codes and error details from computer to BRL 305. The error codes will be described from number 1 to number 96. User can be write details for this 96 errors. The error details are for all error code is 16 character.

For definition error list;

V	This character is mean computer write BRL 305 error list.
2 Byte	Error number.(1.....96)
16 Byte	Error code details.

(Exp. Error code 5, Error details are BUREL ELEKTRONIK. Please send V05 BUREL ELEKTRONIK.)

Please dont send any message in 500 milisecond after definition error list.