

Helix Stadium Custom GPT Knowledge

Single-file PDF export for GPT Builder upload testing.
Generated on 2026-05-07T22:49:04.848484+00:00.

Source file: all-cabs-and-irs.md

All cabs and IRs

Upload-ready knowledge for guitar cabs, bass cabs, and IR cabs.

Generated from the installed Helix Stadium desktop app bundle on
2026-05-07T22:33:14.224003+00:00.

Use display values for normal user-facing answers. Use model keys, IDs, and raw ranges only when the user asks for automation or low-level control details.

Model count: 48

1x10 US Princess

- Model key: `HD2\_CabMicIr\_1x10USPrincessWithPan`
- Model ID: `434`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 8x10" Ampeg SVT 810AV Heritage
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `67 Cond`. Raw range `0` to `11`; raw default `11`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `2`. Raw range `1` to `12`; raw default `2`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `45`. Raw range `0` to `45`; raw default `45`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in

removing high end harshness.

- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

1x12 Blue Bell

- Model key: `HD2\_CabMicIr\_1x12BlueBellWithPan`
- Model ID: `453`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 1x12" Vox AC-15 Blue Alnico
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `67 Cond`. Raw range `0` to `11`; raw default `11`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `80`. Raw range `19.9` to `500`; raw default `80`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `10400`. Raw range `500` to `20100`; raw default `10400`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default

`0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")

- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

1x12 Cali EXT

- Model key: `HD2\_CabMicIr\_1x12CaliEXTWithPan`
- Model ID: `448`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: Custom 1x12" open-back cab EVM12L
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `12000`. Raw range `500` to `20100`; raw default `12000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely

impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

1x12 Cali IV

- Model key: `HD2\_CabMicIr\_1x12CaliIVWithPan`
- Model ID: `458`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 1x8" Fender Tweed Champ
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `414 Cond`. Raw range `0` to `11`; raw default `9`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `3`. Raw range `1` to `12`; raw default `3`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `11500`. Raw range `500` to `20100`; raw default `11500`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

1x12 Epicenter

- Model key: `HD2\_CabMicIr\_1x12EpicenterWithPan`
- Model ID: `450`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Bass
- DSP usage estimate: 1.5
- Based on: 2x12" Matchless DC-30 custom G12M-25
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `88 Dynamic`, `52 Dynamic`, `112 Dynamic`, `D6 Dynamic`, `40 Dynamic`, `4038 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `D6 Dynamic`. Raw range `0` to `11`; raw default `6`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `6.25`. Raw range `1` to `12`; raw default `6.25`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `45`. Raw range `0` to `45`; raw default `45`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `40`. Raw range `19.9` to `500`; raw default `40`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `14000`. Raw range `500` to `20100`; raw default `14000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

1x12 Fullerton

- Model key: `HD2\_CabMicIr\_1x12FullertonWithPan`
- Model ID: `460`

- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Hiwatt Fane
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `7 Dynamic`. Raw range `0` to `11`; raw default `2`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `1.9`. Raw range `0` to `1`; raw default `0.19`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `16000`. Raw range `500` to `20100`; raw default `16000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

1x12 Grammatico

- Model key: `HD2\_CabMicIr\_1x12GrammaticoWithPan`
- Model ID: `430`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Marshall 1960A T75

- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `67 Cond`. Raw range `0` to `11`; raw default `11`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `1.9`. Raw range `0` to `1`; raw default `0.19`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `7`. Raw range `1` to `12`; raw default `7`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

1x12 Open Cast

- Model key: `HD2\_CabMicIr\_1x12OpenCastWithPan`
- Model ID: `454`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 1x12" Fender Tweed Deluxe
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7

Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `906 Dynamic`. Raw range `0` to `11`; raw default `3`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.

- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `4`. Raw range `0` to `1`; raw default `0.4`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `2`. Raw range `1` to `12`; raw default `2`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

1x12 Open Cream

- Model key: `HD2\_CabMicIr\_1x12OpenCreamWithPan`
- Model ID: `455`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Marshall "Basketweave" Fill This In
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `906 Dynamic`. Raw range `0` to `11`; raw default `3`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.

- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `2`. Raw range `1` to `12`; raw default `2`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

1x12 US Deluxe

- Model key: `HD2\_CabMicIr\_1x12USDeluxeWithPan`
- Model ID: `428`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 1x10" Fender Princeton Reverb
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `1.9`. Raw range `0` to `1`; raw default `0.19`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless;

default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.

- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `45`. Raw range `0` to `45`; raw default `45`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

1x15 Ampeg B-15

- Model key: `HD2\_CabMicIr\_1x15AmpegB15WithPan`
- Model ID: `426`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Bass
- DSP usage estimate: 1.5
- Based on: 4x12" Park 75 G12H-30
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `88 Dynamic`, `52 Dynamic`, `112 Dynamic`, `D6 Dynamic`, `40 Dynamic`, `4038 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `47 Cond FET`. Raw range `0` to `11`; raw default `10`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `9`. Raw range `1` to `12`; raw default `9`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `45`. Raw range `0` to `45`; raw default `45`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is

pointing off-axis.

- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

1x8 Small Tweed

- Model key: `HD2\_CabMicIr\_1x8SmallTweedWithPan`
- Model ID: `464`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Soldano Eminence
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `160 Ribbon`. Raw range `0` to `11`; raw default `6`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `3`. Raw range `1` to `12`; raw default `3`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `45`. Raw range `0` to `45`; raw default `45`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.

- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `10000`. Raw range `500` to `20100`; raw default `10000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

2x12 Blue Bell

- Model key: `HD2\_CabMicIr\_2x12BlueBellWithPan`
- Model ID: `429`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" MESA/Boogie 4FB V30
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `90`. Raw range `19.9` to `500`; raw default `90`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `15000`. Raw range `500` to `20100`; raw default `15000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`.

Raw range ``-60`` to ``6``; raw default ``0``. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.

- ``Pan`` (``key: Pan``, ``id: 13``, ``type: f``): display range ``-100`` to ``100`` Left; default ``0.5``. Raw range ``0`` to ``1``; raw default ``0.5``. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- ``Delay`` (``key: Delay``, ``id: 14``, ``type: f``): display range ``-0.02`` to ``50`` ms; default ``0``. Raw range ``-2e-05`` to ``0.05``; raw default ``0``. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

2x12 Double C12N

- Model key: ``HD2_CabMicIr_2x12DoubleC12NwithPan``
- Model ID: ``437``
- Type: Cab
- Category: ``cab_ir_interp``
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 2x12" Roland JC-120
- Agoura model: No

Parameters

- ``Mic`` (``key: Mic``, ``id: 1``, ``type: i``): valid values ``57 Dynamic``, ``421 Dynamic``, ``7 Dynamic``, ``906 Dynamic``, ``30 Dynamic``, ``121 Ribbon``, ``160 Ribbon``, ``4038 Ribbon``, ``84 Ribbon``, ``414 Cond``, ``47 Cond FET``, ``67 Cond``; default ``57 Dynamic``. Raw range ``0`` to ``11``; raw default ``0``. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- ``Position`` (``key: Position``, ``id: 2``, ``type: f``): display range ``0`` to ``10`` Center; default ``1.6``. Raw range ``0`` to ``1``; raw default ``0.16``. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- ``Distance`` (``key: Distance``, ``id: 3``, ``type: f``): display range ``1`` to ``12`` unitless; default ``1``. Raw range ``1`` to ``12``; raw default ``1``. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- ``Angle`` (``key: Angle``, ``id: 4``, ``type: f``): display range ``0`` to ``45`` degrees; default ``0``. Raw range ``0`` to ``45``; raw default ``0``. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- ``Low Cut`` (``key: LowCut``, ``id: 10``, ``type: f``): display range ``19.9`` to ``500`` Off; default ``80``. Raw range ``19.9`` to ``500``; raw default ``80``. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- ``High Cut`` (``key: HighCut``, ``id: 11``, ``type: f``): display range ``500`` to ``20100`` Hz; default ``8000``. Raw range ``500`` to ``20100``; raw default ``8000``. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- ``Level`` (``key: Level``, ``id: 12``, ``type: f``): display range ``-60`` to ``6`` dB; default ``0``. Raw range ``-60`` to ``6``; raw default ``0``. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- ``Pan`` (``key: Pan``, ``id: 13``, ``type: f``): display range ``-100`` to ``100`` Left; default ``0.5``. Raw range ``0`` to ``1``; raw default ``0.5``. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two

sides are panned opposite of one another ("L 100" and "R 100")

- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range -0.02 to 50 ms; default 0 . Raw range $-2e-05$ to 0.05 ; raw default 0 . Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

2x12 Interstate

- Model key: `HD2\_CabMicIr\_2x12InterstateWithPan`
- Model ID: `459`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 1 6x9" Supro S6616
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values 57 Dynamic, 421 Dynamic, 7 Dynamic, 906 Dynamic, 30 Dynamic, 121 Ribbon, 160 Ribbon, 4038 Ribbon, 84 Ribbon, 414 Cond, 47 Cond FET, 67 Cond; default 906 Dynamic. Raw range 0 to 11 ; raw default 3 . Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range 0 to 10 Center; default 1.9 . Raw range 0 to 1 ; raw default 0.19 . Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range 1 to 12 unitless; default 1 . Raw range 1 to 12 ; raw default 1 . Sets the distance of the mic from the speaker cone. Choose from 1.00 " to 12.00 " in $1/4$ " increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range 0 to 45 degrees; default 0 . Raw range 0 to 45 ; raw default 0 . Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range 19.9 to 500 Off; default 19.9 . Raw range 19.9 to 500 ; raw default 19.9 . Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range 500 to 20100 Hz; default 11000 . Raw range 500 to 20100 ; raw default 11000 . Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range -60 to 6 dB; default 0 . Raw range -60 to 6 ; raw default 0 . Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range -100 to 100 Left; default 0.5 . Raw range 0 to 1 ; raw default 0.5 . Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range -0.02 to 50 ms; default 0 . Raw range $-2e-05$ to 0.05 ; raw default 0 . Delays the signals slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before

0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

2x12 Jazz Rivet

- Model key: `HD2\_CabMicIr\_2x12JazzRivetWithPan`
- Model ID: `443`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 2x12" Vox AC-30 Silver Alnico
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `2.3`. Raw range `0` to `1`; raw default `0.23`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

2x12 Mail C12Q

- Model key: `HD2\_CabMicIr\_2x12MailC12QWithPan`
- Model ID: `445`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Marshall "Basketweave" G12M-20
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `2.3`. Raw range `0` to `1`; raw default `0.23`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

2x12 Mandarin 30

- Model key: `HD2\_CabMicIr\_2x12MandarinWithPan`
- Model ID: `447`
- Type: Cab
- Category: `cab\_ir\_interp`

- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 1x12" Vox AC-15 Blue Alnico
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `67 Cond`. Raw range `0` to `11`; raw default `11`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `1.6`. Raw range `0` to `1`; raw default `0.16`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `12000`. Raw range `500` to `20100`; raw default `12000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

2x12 Match G25

- Model key: `HD2\_CabMicIr\_2x12MatchG25WithPan`
- Model ID: `456`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 2x15" Fender Silverface Bassman
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1.5`. Raw range `1` to `12`; raw default `1.5`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `60`. Raw range `19.9` to `500`; raw default `60`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `9000`. Raw range `500` to `20100`; raw default `9000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

2x12 Match H30

- Model key: `HD2\_CabMicIr\_2x12MatchH30WithPan`
- Model ID: `457`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 6x10" MESA/Boogie
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`;

raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.

- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `60`. Raw range `19.9` to `500`; raw default `60`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `9000`. Raw range `500` to `20100`; raw default `9000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

2x12 Silver Bell

- Model key: `HD2\_CabMicIr\_2x12SilverBellWithPan`
- Model ID: `449`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: Custom 1x12" open-back cab G12M-65
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `67 Cond`. Raw range `0` to `11`; raw default `11`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Sets the lateral location of the

mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.

- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1.25`. Raw range `1` to `12`; raw default `1.25`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `90`. Raw range `19.9` to `500`; raw default `90`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `5000`. Raw range `500` to `20100`; raw default `5000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

2x15 Brute

- Model key: `HD2\_CabMicIr\_2x15BruteWithPan`
- Model ID: `425`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Bass
- DSP usage estimate: 1.5
- Based on: 4x12" Marshall 1960AV V30
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `88 Dynamic`, `52 Dynamic`, `112 Dynamic`, `D6 Dynamic`, `40 Dynamic`, `4038 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `D6 Dynamic`. Raw range `0` to `11`; raw default `6`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `0.9`. Raw range `0` to `1`; raw default `0.09`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `4.25`. Raw range `1` to `12`; raw default `4.25`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.

- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `45`. Raw range `0` to `45`; raw default `45`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `25`. Raw range `19.9` to `500`; raw default `25`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `11500`. Raw range `500` to `20100`; raw default `11500`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

2x15 US Dripman

- Model key: `HD2\_CabMicIr\_2x15USDripmanWithPan`
- Model ID: `462`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Bass
- DSP usage estimate: 1.5
- Based on: Cab IR
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `88 Dynamic`, `52 Dynamic`, `112 Dynamic`, `D6 Dynamic`, `40 Dynamic`, `4038 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `67 Cond`. Raw range `0` to `11`; raw default `11`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `2.6`. Raw range `0` to `1`; raw default `0.26`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `4.25`. Raw range `1` to `12`; raw default `4.25`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default

`19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.

- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x10 Ampeg Pro

- Model key: `HD2\_CabMicIr\_4x10AmpegProWithPan`
- Model ID: `452`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Bass
- DSP usage estimate: 1.5
- Based on: 1x12" MESA/Boogie Mark IV
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `88 Dynamic`, `52 Dynamic`, `112 Dynamic`, `D6 Dynamic`, `40 Dynamic`, `4038 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `D6 Dynamic`. Raw range `0` to `11`; raw default `6`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `2.4`. Raw range `0` to `1`; raw default `0.24`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `45`. Raw range `0` to `45`; raw default `45`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `13800`. Raw range `500` to `20100`; raw default `13800`. Applies a high cut (low

pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.

- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x10 Garden

- Model key: `HD2\_CabMicIr\_4x10GardenWithPan`
- Model ID: `444`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Bass
- DSP usage estimate: 1.5
- Based on: 1x12" Epifani Ultralight series
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `88 Dynamic`, `52 Dynamic`, `112 Dynamic`, `D6 Dynamic`, `40 Dynamic`, `4038 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `421 Dynamic`. Raw range `0` to `11`; raw default `1`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `0`. Raw range `0` to `1`; raw default `0`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `3.75`. Raw range `1` to `12`; raw default `3.75`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.

- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x10 Tweed P10R

- Model key: `HD2\_CabMicIr\_4x10TweedP10RWithPan`
- Model ID: `442`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 1x12" MESA/Boogie Extension Cab
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `7 Dynamic`. Raw range `0` to `11`; raw default `2`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `2`. Raw range `0` to `1`; raw default `0.2`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default

`0`. Raw range ``-2e-05`` to ``0.05``; raw default ``0``. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x10 US Super

- Model key: ``HD2_CabMicIr_4x10USSuperWithPan``
- Model ID: ``469``
- Type: Cab
- Category: ``cab_ir_interp``
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x10" Fender Super Reverb
- Agoura model: No

Parameters

- ``Mic`` (``key: Mic``, ``id: 1``, ``type: i``): valid values ``57 Dynamic``, ``421 Dynamic``, ``7 Dynamic``, ``906 Dynamic``, ``30 Dynamic``, ``121 Ribbon``, ``160 Ribbon``, ``4038 Ribbon``, ``84 Ribbon``, ``414 Cond``, ``47 Cond FET``, ``67 Cond``; default ``57 Dynamic``. Raw range ``0`` to ``11``; raw default ``0``. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- ``Position`` (``key: Position``, ``id: 2``, ``type: f``): display range ``0`` to ``10`` Center; default ``0``. Raw range ``0`` to ``1``; raw default ``0``. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- ``Distance`` (``key: Distance``, ``id: 3``, ``type: f``): display range ``1`` to ``12`` unitless; default ``1``. Raw range ``1`` to ``12``; raw default ``1``. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- ``Angle`` (``key: Angle``, ``id: 4``, ``type: f``): display range ``0`` to ``45`` degrees; default ``0``. Raw range ``0`` to ``45``; raw default ``0``. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- ``Low Cut`` (``key: LowCut``, ``id: 10``, ``type: f``): display range ``19.9`` to ``500`` Off; default ``19.9``. Raw range ``19.9`` to ``500``; raw default ``19.9``. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- ``High Cut`` (``key: HighCut``, ``id: 11``, ``type: f``): display range ``500`` to ``20100`` Hz; default ``20100``. Raw range ``500`` to ``20100``; raw default ``20100``. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- ``Level`` (``key: Level``, ``id: 12``, ``type: f``): display range ``-60`` to ``6`` dB; default ``0``. Raw range ``-60`` to ``6``; raw default ``0``. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- ``Pan`` (``key: Pan``, ``id: 13``, ``type: f``): display range ``-100`` to ``100`` Left; default ``0.5``. Raw range ``0`` to ``1``; raw default ``0.5``. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- ``Delay`` (``key: Delay``, ``id: 14``, ``type: f``): display range ``-0.02`` to ``50`` ms; default ``0``. Raw range ``-2e-05`` to ``0.05``; raw default ``0``. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 1960A T75

- Model key: `HD2\_CabMicIr\_4x121960AT75WithPan`
- Model ID: `436`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x10" Fender Bassman P10R
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `3.2`. Raw range `0` to `1`; raw default `0.32`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `45`. Raw range `0` to `45`; raw default `45`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 Blackback H30

- Model key: `HD2\_CabMicIr\_4x12BlackbackH30WithPan`

- Model ID: `432`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Sunn G75T
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `906 Dynamic`. Raw range `0` to `11`; raw default `3`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `3.2`. Raw range `0` to `1`; raw default `0.32`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 Brit V30

- Model key: `HD2\_CabMicIr\_4x12BritV30WithPan`
- Model ID: `431`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5

- Based on: 2x12" Fender Twin
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `7 Dynamic`. Raw range `0` to `11`; raw default `2`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `1.5`. Raw range `0` to `1`; raw default `0.15`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `45`. Raw range `0` to `45`; raw default `45`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `12000`. Raw range `500` to `20100`; raw default `12000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 Cali V30

- Model key: `HD2\_CabMicIr\_4x12CaliV30WithPan`
- Model ID: `435`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Marshall "Basketweave" G12M-25
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `47 Cond FET`. Raw range `0` to `11`; raw default `10`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `2.3`. Raw range `0` to `1`; raw default `0.23`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 Cartog C90

- Model key: `HD2\_CabMicIr\_4x12CartogC90WithPan`
- Model ID: `471`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Cartographer Mesa C90 Black Shadow
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as

tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.

- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `0`. Raw range `0` to `1`; raw default `0`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 Cartog Guv

- Model key: `HD2\_CabMicIr\_4x12CartogGuvWithPan`
- Model ID: `472`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Cartographer Eminence Governor
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `0`. Raw range `0` to `1`; raw default `0`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.

- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 Greenback 20

- Model key: `HD2\_CabMicIr\_4x12Greenback20WithPan`
- Model ID: `451`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 2x12" Matchless DC-30 custom G12H-30
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `4038 Ribbon`. Raw range `0` to `11`; raw default `7`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `5`. Raw range `1` to `12`; raw default `5`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front

of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.

- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 Greenback 25

- Model key: `HD2\_CabMicIr\_4x12Greenback25WithPan`
- Model ID: `441`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 2x12" Orange PPC212 V30
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `2.4`. Raw range `0` to `1`; raw default `0.24`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing

undesirable low end rumble.

- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 Greenback 30

- Model key: `HD2\_CabMicIr\_4x12Greenback30WithPan`
- Model ID: `461`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Marshall "Basketweave" Fill This In
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `906 Dynamic`. Raw range `0` to `11`; raw default `3`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `4`. Raw range `0` to `1`; raw default `0.4`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `2`. Raw range `1` to `12`; raw default `2`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `45`. Raw range `0` to `45`; raw default `45`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `11000`. Raw range `500` to `20100`; raw default `11000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.

- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 M00)))N T75

- Model key: `HD2\_CabMicIr\_4x12M00NT75WithPan`
- Model ID: `438`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x10" Eden D410XLT
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `906 Dynamic`. Raw range `0` to `11`; raw default `3`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1.5`. Raw range `1` to `12`; raw default `1.5`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `45`. Raw range `0` to `45`; raw default `45`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `40`. Raw range `19.9` to `500`; raw default `40`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `12000`. Raw range `500` to `20100`; raw default `12000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the

left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")

- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range -0.02 to 50 ms; default 0 . Raw range $-2e-05$ to 0.05 ; raw default 0 . Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 Mandarin EM

- Model key: `HD2\_CabMicIr\_4x12MandarinWithPan`
- Model ID: `433`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Bogner Uberkab T75
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values 57 Dynamic, 421 Dynamic, 7 Dynamic, 906 Dynamic, 30 Dynamic, 121 Ribbon, 160 Ribbon, 4038 Ribbon, 84 Ribbon, 414 Cond, 47 Cond FET, 67 Cond; default 160 Ribbon. Raw range 0 to 11 ; raw default 6 . Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range 0 to 10 Center; default 2.3 . Raw range 0 to 1 ; raw default 0.23 . Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range 1 to 12 unitless; default 3.5 . Raw range 1 to 12 ; raw default 3.5 . Sets the distance of the mic from the speaker cone. Choose from 1.00 " to 12.00 " in $1/4$ " increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range 0 to 45 degrees; default 45 . Raw range 0 to 45 ; raw default 45 . Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range 19.9 to 500 Off; default 19.9 . Raw range 19.9 to 500 ; raw default 19.9 . Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range 500 to 20100 Hz; default 20100 . Raw range 500 to 20100 ; raw default 20100 . Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range -60 to 6 dB; default 0 . Raw range -60 to 6 ; raw default 0 . Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range -100 to 100 Left; default 0.5 . Raw range 0 to 1 ; raw default 0.5 . Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range -0.02 to 50 ms; default 0 . Raw range $-2e-05$ to 0.05 ; raw default 0 . Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent

stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 SoloLead EM

- Model key: `HD2\_CabMicIr\_4x12SoloLeadEMWithPan`
- Model ID: `470`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Soldano Eminence
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `0`. Raw range `0` to `1`; raw default `0`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 Uber T75

- Model key: `HD2\_CabMicIr\_4x12UberT75WithPan`
- Model ID: `439`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 2x12" Silvertone 1481
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 Uber V30

- Model key: `HD2\_CabMicIr\_4x12UberV30WithPan`
- Model ID: `446`
- Type: Cab

- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x10" Ampeg PR-410HLF
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `47 Cond FET`. Raw range `0` to `11`; raw default `10`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `2.7`. Raw range `0` to `1`; raw default `0.27`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `12000`. Raw range `500` to `20100`; raw default `12000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 WhoWatt 100

- Model key: `HD2\_CabMicIr\_4x12WhoWatt100WithPan`
- Model ID: `466`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Cartographer Eminence Governor
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `1`. Raw range `0` to `1`; raw default `0.1`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `10500`. Raw range `500` to `20100`; raw default `10500`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

4x12 XXL V30

- Model key: `HD2\_CabMicIr\_4x12XXLV30WithPan`
- Model ID: `427`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Orange Eminence
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84

Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `160 Ribbon`. Raw range `0` to `11`; raw default `6`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.

- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `2.7`. Raw range `0` to `1`; raw default `0.27`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `1`. Raw range `1` to `12`; raw default `1`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `40`. Raw range `19.9` to `500`; raw default `40`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `12000`. Raw range `500` to `20100`; raw default `12000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

6x10 Cali Power

- Model key: `HD2\_CabMicIr\_6x10CaliPowerWithPan`
- Model ID: `463`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Bass
- DSP usage estimate: 1.5
- Based on: 4x10" Fender Super Reverb
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `88 Dynamic`, `52 Dynamic`, `112 Dynamic`, `D6 Dynamic`, `40 Dynamic`, `4038 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `57 Dynamic`. Raw range `0` to `11`; raw default `0`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center;

default `0`. Raw range `0` to `1`; raw default `0`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.

- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `3.25`. Raw range `1` to `12`; raw default `3.25`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

8x10 SVT AV

- Model key: `HD2\_CabMicIr\_8x10SVTAVWithPan`
- Model ID: `440`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Bass
- DSP usage estimate: 1.5
- Based on: 4x12" Bogner Uberkab V30
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `88 Dynamic`, `52 Dynamic`, `112 Dynamic`, `D6 Dynamic`, `40 Dynamic`, `4038 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `88 Dynamic`. Raw range `0` to `11`; raw default `3`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `0`. Raw range `0` to `1`; raw default `0`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `5`. Raw range `1` to `12`; raw default `5`. Sets the distance of the mic from the

speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.

- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `45`. Raw range `0` to `45`; raw default `45`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is pointing off-axis.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `37`. Raw range `19.9` to `500`; raw default `37`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `8000`. Raw range `500` to `20100`; raw default `8000`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

IR

- Model key: `HX2\_ImpulseResponseWithPan`
- Model ID: `468`
- Type: IR
- Category: `ir`
- Class: IR
- DSP usage estimate: 0.0
- Based on: Unknown
- Agoura model: No

Parameters

- `Low Cut` (`key: LowCut`, `id: 11`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 12`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Polarity` (`key: Polarity`, `id: 13`, `type: b`): valid values `Normal`, `Inverted`; default `Normal`. Raw range `Off` to `On`; raw default `Off`. Inverts the polarity of the signal.
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `0` to `50` ms; default `0`. Raw range `0` to `0.05`; raw default `0`. Delays the signal slightly to time-align with the other side of the Cab block (helping to avoid phase issues). It can also be used to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here.
- `Mix` (`key: Mix`, `id: 15`, `type: f`): display range `0` to `100` %; default `100`. Raw

range `0` to `1`; raw default `1`. Controls the blend between the incoming "dry" signal and the Cab IR-processed "wet" signal. At 0%, no IR is heard; at 100%, no dry signal is heard. Normally, this should be left at 100%.

- `Level` (`key: Level`, `id: 16`, `type: f`): display range `-60` to `6` dB; default `-18`. Raw range `-60` to `6`; raw default `-18`. Sets the overall level of the IR.
- `Pan` (`key: Pan`, `id: 17`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the IR between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")

No Cab

- Model key: `HD2\_CabMicIr\_NoCab`
- Model ID: `467`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: No Cab
- DSP usage estimate: 1.5
- Based on: Unknown
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

Soup Pro Ellipse

- Model key: `HD2\_CabMicIr\_SoupProEllipseWithPan`
- Model ID: `465`
- Type: Cab
- Category: `cab\_ir\_interp`
- Class: Guitar
- DSP usage estimate: 1.5
- Based on: 4x12" Cartographer Mesa C90 Black Shadow
- Agoura model: No

Parameters

- `Mic` (`key: Mic`, `id: 1`, `type: i`): valid values `57 Dynamic`, `421 Dynamic`, `7 Dynamic`, `906 Dynamic`, `30 Dynamic`, `121 Ribbon`, `160 Ribbon`, `4038 Ribbon`, `84 Ribbon`, `414 Cond`, `47 Cond FET`, `67 Cond`; default `47 Cond FET`. Raw range `0` to `11`; raw default `10`. Selects the mic pointed at the cabinet. (Guitar and Bass cabs have different sets of mics available.) Mic selection can have as big an impact on your tone as tweaking the Amp's tonestack or even applying an EQ block, so experimentation is key here.
- `Position` (`key: Position`, `id: 2`, `type: f`): display range `0` to `10` Center; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Sets the lateral location of the mic in relation to the speaker cone, from center of the speaker to the edge. The "Cap Edge" value may appear in a different location depending on the selected cab.
- `Distance` (`key: Distance`, `id: 3`, `type: f`): display range `1` to `12` unitless; default `5.5`. Raw range `1` to `12`; raw default `5.5`. Sets the distance of the mic from the speaker cone. Choose from 1.00" to 12.00" in 1/4" increments.
- `Angle` (`key: Angle`, `id: 4`, `type: f`): display range `0` to `45` degrees; default `0`. Raw range `0` to `45`; raw default `0`. Sets the angle of the mic relative to the front of the speaker cabinet. 0 degrees is pointing directly at the speaker, 45 degrees is

pointing off-axis.

- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter, letting you remove all audio below a certain frequency. May be useful in removing undesirable low end rumble.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter, letting you remove all audio above a certain frequency. May be useful in removing high end harshness.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Cab. Use to adjust level against the other side of the Cab block.
- `Pan` (`key: Pan`, `id: 13`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the Cab between the left and right channels. For stereo setups, the Cab block can sound much wider if the two sides are panned opposite of one another ("L 100" and "R 100")
- `Delay` (`key: Delay`, `id: 14`, `type: f`): display range `-0.02` to `50` ms; default `0`. Raw range `-2e-05` to `0.05`; raw default `0`. Delays the signal slightly to purposely impart a bit of phase incoherence or at higher values, increase the Cab block's apparent stereo width. A little goes a long way here. When set to "Auto" (all the way left, before 0.0 ms), it approximates the delay through the air when changing the mic Distance parameter.

Source file: bass-amps-and-preamps.md

Bass amps and preamps

Upload-ready knowledge for bass amp and preamp blocks.

Generated from the installed Helix Stadium desktop app bundle on
2026-05-07T22:33:14.224003+00:00.

Use display values for normal user-facing answers. Use model keys, IDs, and raw ranges only when the user asks for automation or low-level control details.

Model count: 40

Agua 51

- Model key: `HD2\_AmpAgua51`
- Model ID: `663`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 9.6
- Based on: Aguilar DB51
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.5`.

Raw range `0` to `1`; raw default `0.55`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the Master Volume of the amplifier.
- `Level` (`key: Ch Vol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Deep` (`key: Deep`, `id: 7`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, applies a 5 dB boost at 30 Hz.
- `Bright` (`key: Bright`, `id: 8`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, applies a 5 dB boost at 5-7 kHz.

Agua 51

- Model key: `HD2\_PreampAgua51`
- Model ID: `664`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 9.4
- Based on: Aguilar DB51
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the Master Volume of the amplifier.
- `Level` (`key: Ch Vol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Deep` (`key: Deep`, `id: 7`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, applies a 5 dB boost at 30 Hz.
- `Bright` (`key: Bright`, `id: 8`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, applies a 5 dB boost at 5-7 kHz.

Agua 751

- Model key: `Agoura\_AmpAgua751`

- Model ID: `809`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 11.5
- Based on: Aguilar DB751
- Agoura model: Yes

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.7`. Raw range `0` to `1`; raw default `0.77`. Controls the high frequency EQ of the tonestack.
- `Deep` (`key: Deep`, `id: 5`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, applies a 5 dB boost at 30 Hz.
- `Bright` (`key: Bright`, `id: 6`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, applies a 5 dB boost at 5-7 kHz.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the Master Volume of the amplifier.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Hype` (`key: Hype`, `id: 9`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Agua Sledge

- Model key: `HD2\_AmpAguaSledge`
- Model ID: `726`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 4.8
- Based on: Aguilar Tone Hammer
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.2`. Raw range `0` to `1`; raw default `0.32`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Drive` (`key: Drive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adds saturation, a tighter low end, and a more

controlled high end, depending on how high the Gain knob is set. When Gain is set to 0.0, Drive does nothing.

- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency (40 Hz) EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency (4 kHz) EQ of the tonestack.
- `Level` (`key: Ch Vol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Mid Freq` (`key: Mid Freq`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the Mid band EQ frequency between 180 Hz (0.0) and 1 kHz (10.0).

Agua Sledge

- Model key: `HD2\_PreampAguaSledge`
- Model ID: `727`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 5.2
- Based on: Aguilar Tone Hammer
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.2`. Raw range `0` to `1`; raw default `0.32`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Drive` (`key: Drive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adds saturation, a tighter low end, and a more controlled high end, depending on how high the Gain knob is set. When Gain is set to 0.0, Drive does nothing.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency (40 Hz) EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency (4 kHz) EQ of the tonestack.
- `Level` (`key: Ch Vol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Mid Freq` (`key: Mid Freq`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the Mid band EQ frequency

between 180 Hz (0.0) and 1 kHz (10.0).

Ampeg B-15NF

- Model key: `HD2\_AmpTucknGo`
- Model ID: `542`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 11.2
- Based on: Ampeg B-15NF Portaflex
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the low frequency EQ of the tonestack.
- `Low Mid` (`key: LowMid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low midrange frequency EQ of the tonestack.
- `High Mid` (`key: HighMid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default

`5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Ampeg B-15NF

- Model key: `HD2\_PreampTucknGo`
- Model ID: `543`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 6.9
- Based on: Ampeg B-15NF Portaflex
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the low frequency EQ of the tonestack.
- `Low Mid` (`key: LowMid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low midrange frequency EQ of the tonestack.
- `High Mid` (`key: HighMid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Ampeg B15NF 66

- Model key: `Agoura\_AmpAmpegB15NF66`
- Model ID: `759`
- Type: Amp

- Category: `amp`
- Class: Bass
- DSP usage estimate: 13.6
- Based on: Ampeg B-15NF Portaflex
- Agoura model: Yes

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the low frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 5`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 6`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Hype` (`key: Hype`, `id: 9`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Ampeg SVT 50th

- Model key: `Agoura\_AmpAmpegSVT`
- Model ID: `805`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 25.0
- Based on: Ampeg Heritagea 50th Anniversary SVT (Ch 1 Normal, Ch1 Bright, Ch2 Normal, Ch2 Bright & Jumped channels)
- Agoura model: Yes

Parameters

- `Channel` (`key: Channel`, `id: 1`, `type: i`): valid values `Ch1 Normal`, `Ch1 Bright`, `Ch2 Normal`, `Ch2 Bright`, `Jumped`; default `Ch1 Normal`. Raw range `0` to `4`; raw default `0`. Selects the amp channel or which input is connected. "Jumped" jumps between the XXXXX and XXXXX channels.
- `1 Drive` (`key: 1Drive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Controls the amount of Channel 1 gain applied to the signal, which influences the level of distortion.
- `1 Bass` (`key: 1Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the low frequency EQ (40 Hz) of the tonestack for Channel 1.
- `1 Mid` (`key: 1Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the midrange frequency EQ of the tonestack for Channel 1.
- `1 Mid Freq` (`key: 1MidFreq`, `id: 5`, `type: i`): valid values `200 Hz`, `800 Hz`, `3 kHz`; default `3 kHz`. Raw range `0` to `2`; raw default `2`. Sets the frequency controlled by the 1 Mid parameter--200 Hz, 800 Hz, or 3 kHz.
- `1 Treble` (`key: 1Treble`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the high frequency EQ (4 kHz) of the tonestack for Channel 1.
- `1 Ultra Hi` (`key: 1UltraHi`, `id: 7`, `type: i`): valid values `Off`, `On`; default `Off`. Raw range `0` to `1`; raw default `0`. When On, boosts the high frequency of Channel 1.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-13`. Raw range `-40` to `10`; raw default `-13`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `1 Ultra Lo` (`key: 1UltraLo`, `id: 9`, `type: i`): valid values `Cut`, `Off`, `On`; default `On`. Raw range `0` to `2`; raw default `2`. When on, boosts the low frequency of Channel 1. When set to "Cut," decreases the low frequency of Channel 1.
- `2 Drive` (`key: 2Drive`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the amount of Channel 2 gain applied to the signal, which influences the level of distortion.
- `2 Bass` (`key: 2Bass`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ (40 Hz) of the tonestack for Channel 2.
- `2 Treble` (`key: 2Treble`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the high frequency EQ (4 kHz) of the tonestack for Channel 2.
- `2 Ultra Hi` (`key: 2UltraHi`, `id: 13`, `type: i`): valid values `Off`, `On`; default `Off`. Raw range `0` to `1`; raw default `0`. When on, boosts the high frequency of Channel 2.
- `2 Ultra Lo` (`key: 2UltraLo`, `id: 14`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts the low frequency of Channel 2.
- `Master` (`key: Master`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 16`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 17`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 18`, `type: f`): display range `0` to `10` unitless;

default `5`. Raw range `0` to `1`; raw default `0.5`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).

- `Hype` (`key: Hype`, `id: 19`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Ampeg SVT Brt

- Model key: `HD2\_AmpSVBeastBrt`
- Model ID: `554`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 14.0
- Based on: Ampeg SVT (bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.1`. Raw range `0` to `1`; raw default `0.41`. Controls the low frequency EQ (40 Hz) of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.9`. Raw range `0` to `1`; raw default `0.79`. Controls the midrange frequency EQ of the tonestack.
- `Mid Freq` (`key: MidFreq`, `id: 4`, `type: i`): valid values `220 Hz`, `800 Hz`, `3000 Hz`; default `3000 Hz`. Raw range `0` to `2`; raw default `2`. Sets the frequency controlled by the Mid parameter--220 Hz, 800 Hz, or 3 kHz.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.7`. Raw range `0` to `1`; raw default `0.77`. Controls the high frequency EQ (4 kHz) of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with

your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `7.4`. Raw range `0` to `1`; raw default `0.74`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Ampeg SVT Brt

- Model key: `HD2\_PreampSVBeastBrt`
- Model ID: `556`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 11.0
- Based on: Ampeg SVT (bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.1`. Raw range `0` to `1`; raw default `0.41`. Controls the low frequency EQ (40 Hz) of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.9`. Raw range `0` to `1`; raw default `0.79`. Controls the midrange frequency EQ of the tonestack.
- `Mid Freq` (`key: MidFreq`, `id: 4`, `type: i`): valid values `220 Hz`, `800 Hz`, `3000 Hz`; default `3000 Hz`. Raw range `0` to `2`; raw default `2`. Sets the frequency controlled by the Mid parameter--220 Hz, 800 Hz, or 3 kHz.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.7`. Raw range `0` to `1`; raw default `0.77`. Controls the high frequency EQ (4 kHz) of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Ampeg SVT Nrm

- Model key: `HD2\_AmpSVBeastNrm`
- Model ID: `555`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 14.0
- Based on: Ampeg SVT (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the low frequency EQ (40 Hz) of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the midrange frequency EQ of the tonestack.
- `Mid Freq` (`key: MidFreq`, `id: 4`, `type: i`): valid values `220 Hz`, `800 Hz`, `3000 Hz`; default `800 Hz`. Raw range `0` to `2`; raw default `1`. Sets the frequency controlled by the Mid parameter--220 Hz, 800 Hz, or 3 kHz.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the high frequency EQ (4 kHz) of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing

reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Ampeg SVT Nrm

- Model key: `HD2\_PreampSVBeastNrm`
- Model ID: `557`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 11.0
- Based on: Ampeg SVT (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the low frequency EQ (40 Hz) of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the midrange frequency EQ of the tonestack.
- `Mid Freq` (`key: MidFreq`, `id: 4`, `type: i`): valid values `220 Hz`, `800 Hz`, `3000 Hz`; default `800 Hz`. Raw range `0` to `2`; raw default `1`. Sets the frequency controlled by the Mid parameter--220 Hz, 800 Hz, or 3 kHz.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the high frequency EQ (4 kHz) of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Ampeg SVT-4 PRO

- Model key: `HD2\_AmpSVT4Pro`
- Model ID: `673`
- Type: Amp
- Category: `amp`

- Class: Bass
- DSP usage estimate: 8.5
- Based on: Ampeg SVT-4 PRO
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ (50 Hz) of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Mid Freq` (`key: MidFreq`, `id: 4`, `type: i`): valid values `1`, `2`, `3`, `4`, `5`; default `2`. Raw range `0` to `4`; raw default `1`. Sets the frequency controlled by the Mid parameter--1 (220 Hz), 2 (450 Hz), 3 (800 Hz), 4 (1.6 kHz), or 5 (3 kHz).
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ (5 kHz) of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the Master Volume of the amplifier.
- `Ultra Lo` (`key: UltraLo`, `id: 8`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts the low end (40 Hz) output by 2 dB and simultaneously cuts the midrange (500 Hz) by 10dB.
- `Ultra Hi` (`key: UltraHi`, `id: 9`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts the high end (5 kHz) output by 6 dB.
- `Bright` (`key: Bright`, `id: 10`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts the high end response (2 kHz) of the input signal by 6 dB.
- `EQ` (`key: EQ`, `id: 11`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, enables the 9-band graphic EQ.
- `33 Hz` (`key: 33Hz`, `id: 12`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 12 dB.
- `80 Hz` (`key: 80Hz`, `id: 13`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Boost or cut up to 12 dB.
- `150 Hz` (`key: 150Hz`, `id: 14`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Boost or cut up to 12 dB.
- `300 Hz` (`key: 300Hz`, `id: 15`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Boost or cut up to 12 dB.
- `600 Hz` (`key: 600Hz`, `id: 16`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Boost or cut up to 12 dB.
- `900 Hz` (`key: 900Hz`, `id: 17`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 12 dB.
- `2 kHz` (`key: 2kHz`, `id: 18`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Boost or cut up to 12 dB.
- `5 kHz` (`key: 5kHz`, `id: 19`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Boost or cut up to 12 dB.
- `8 kHz` (`key: 8kHz`, `id: 20`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Boost or cut up to 12 dB.
- `EQ Level` (`key: EQLevel`, `id: 21`, `type: f`): display range `-12` to `12` dB; default

`0`. Raw range `-12` to `12`; raw default `0`. Controls the output level of the 9-band graphic EQ. If the EQ'd signal is too soft, turn EQ Level up; if it's too loud, turn EQ Level down.

Ampeg SVT-4 PRO

- Model key: `HD2\_PreamplSVT4Pro`
- Model ID: `674`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 7.6
- Based on: Ampeg SVT-4 PRO
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ (50 Hz) of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Mid Freq` (`key: MidFreq`, `id: 4`, `type: i`): valid values `1`, `2`, `3`, `4`, `5`; default `2`. Raw range `0` to `4`; raw default `1`. Sets the frequency controlled by the Mid parameter--1 (220 Hz), 2 (450 Hz), 3 (800 Hz), 4 (1.6 kHz), or 5 (3 kHz).
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ (5 kHz) of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the Master Volume of the amplifier.
- `Ultra Lo` (`key: UltraLo`, `id: 8`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts the low end (40 Hz) output by 2 dB and simultaneously cuts the midrange (500 Hz) by 10dB.
- `Ultra Hi` (`key: UltraHi`, `id: 9`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts the high end (5 kHz) output by 6 dB.
- `Bright` (`key: Bright`, `id: 10`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts the high end response (2 kHz) of the input signal by 6 dB.
- `EQ` (`key: EQ`, `id: 11`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, enables the 9-band graphic EQ.
- `33 Hz` (`key: 33Hz`, `id: 12`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 12 dB.
- `80 Hz` (`key: 80Hz`, `id: 13`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Boost or cut up to 12 dB.
- `150 Hz` (`key: 150Hz`, `id: 14`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Boost or cut up to 12 dB.
- `300 Hz` (`key: 300Hz`, `id: 15`, `type: f`): display range `-12` to `12` dB; default `0`.

Raw range ``-12` to `12`; raw default `0`. Boost or cut up to 12 dB.`

- ``600 Hz`` (``key: 600Hz``, ``id: 16``, ``type: f``): display range ``-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Boost or cut up to 12 dB.`
- ``900 Hz`` (``key: 900Hz``, ``id: 17``, ``type: f``): display range ``-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 12 dB.`
- ``2 kHz`` (``key: 2kHz``, ``id: 18``, ``type: f``): display range ``-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Boost or cut up to 12 dB.`
- ``5 kHz`` (``key: 5kHz``, ``id: 19``, ``type: f``): display range ``-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Boost or cut up to 12 dB.`
- ``8 kHz`` (``key: 8kHz``, ``id: 20``, ``type: f``): display range ``-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Boost or cut up to 12 dB.`
- ``EQ Level`` (``key: EQLevel``, ``id: 21``, ``type: f``): display range ``-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Controls the output level of the 9-band graphic EQ. If the EQ'd signal is too soft, turn EQ Level up; if it's too loud, turn EQ Level down.`

Brit MegaBass

- Model key: ``Agoura_AmpBritMegaBass``
- Model ID: ``757``
- Type: Amp
- Category: ``amp``
- Class: Bass
- DSP usage estimate: 14.5
- Based on: Marshall Super Bass 1992 (Normal, Bright & Jumped channels)
- Agoura model: Yes

Parameters

- ``Channel`` (``key: Channel``, ``id: 1``, ``type: i``): valid values ``Normal``, ``Bright``, ``Jumped``; default ``Normal``. Raw range ``0` to `2`; raw default `0`. Selects the amp channel or which input is connected. "Jumped" jumps between the Normal and Bright channels.`
- ``Normal Drive`` (``key: NrmDrive``, ``id: 2``, ``type: f``): display range ``0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the amount of Normal channel gain applied to the signal. The inactive channel can sometimes "bleed into" the active channel, resulting in interesting interactions.`
- ``Bright Drive`` (``key: BrtDrive``, ``id: 3``, ``type: f``): display range ``0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the amount of Bright channel gain applied to the signal. The inactive channel can sometimes "bleed into" the active channel, resulting in interesting interactions.`
- ``Bass`` (``key: Bass``, ``id: 4``, ``type: f``): display range ``0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the low frequency EQ of the tonestack.`
- ``Mid`` (``key: Mid``, ``id: 5``, ``type: f``): display range ``0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the midrange frequency EQ of the tonestack.`
- ``Treble`` (``key: Treble``, ``id: 6``, ``type: f``): display range ``0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the high frequency EQ of the tonestack.`
- ``Presence`` (``key: Presence``, ``id: 7``, ``type: f``): display range ``0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.`
- ``Level`` (``key: Level``, ``id: 8``, ``type: f``): display range ``-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.`
- ``Master`` (``key: Master``, ``id: 9``, ``type: f``): display range ``0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.`

- `Sag` (`key: Sag`, `id: 10`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 11`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 13`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Busy One Ch1

- Model key: `HD2\_AmpBusyOneCh1`
- Model ID: `649`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 4.3
- Based on: Pearce BC-1 preamp (Channel 1)
- Agoura model: No

Parameters

- `Drive` (`key: Ch1 Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Ch1 Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Ch1 Mid`, `id: 3`, `type: f`): display range `-15` to `15` dB; default `15`. Raw range `-15` to `15`; raw default `15`. Controls the midrange frequency EQ of the tonestack.
- `Mid Freq` (`key: Ch1 Mid Freq`, `id: 4`, `type: f`): display range `100` to `3000` Hz; default `220`. Raw range `100` to `3000`; raw default `220`. Sets the frequency boosted or cut by the Mid parameter.
- `Treble` (`key: Ch1 Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `1.5`. Raw range `0` to `1`; raw default `0.15`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Ch1 Master`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the Master Volume of the amplifier.
- `Input Pad` (`key: Input Pad`, `id: 7`, `type: i`): valid values `-10dB`, `0dB`, `10dB`; default `0dB`. Raw range `0` to `2`; raw default `1`. Boosts or cuts the input signal into the preamp by 10 dB.

- `Boost` (`key: Ch1 Boost`, `id: 8`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, supplies an additional boost for noticeably more gain and distortion.
- `Limiter` (`key: Limiter`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, enables the built-in limiter.
- `Threshold` (`key: Threshold`, `id: 10`, `type: f`): display range `-22` to `3` dB; default `-6`. Raw range `-22` to `3`; raw default `-6`. Sets the level above which limiting is applied. Lower values limit more of the signal; higher values limit only louder parts of the signal.
- `Level` (`key: Ch Vol`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

Busy One Ch1

- Model key: `HD2\_PreamplifierBusyOneCh1`
- Model ID: `650`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 4.0
- Based on: Pearce BC-1 preamp (Channel 1)
- Agoura model: No

Parameters

- `Drive` (`key: Ch1 Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Ch1 Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Ch1 Mid`, `id: 3`, `type: f`): display range `-15` to `15` dB; default `15`. Raw range `-15` to `15`; raw default `15`. Controls the midrange frequency EQ of the tonestack.
- `Mid Freq` (`key: Ch1 Mid Freq`, `id: 4`, `type: f`): display range `100` to `3000` Hz; default `220`. Raw range `100` to `3000`; raw default `220`. Sets the frequency boosted or cut by the Mid parameter.
- `Treble` (`key: Ch1 Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `1.5`. Raw range `0` to `1`; raw default `0.15`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Ch1 Master`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the Master Volume of the amplifier.
- `Input Pad` (`key: Input Pad`, `id: 7`, `type: i`): valid values `-10dB`, `0dB`, `10dB`; default `0dB`. Raw range `0` to `2`; raw default `1`. Boosts or cuts the input signal into the preamp by 10 dB.
- `Boost` (`key: Ch1 Boost`, `id: 8`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, supplies an additional boost for noticeably more gain and distortion.
- `Limiter` (`key: Limiter`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, enables the built-in limiter.
- `Threshold` (`key: Threshold`, `id: 10`, `type: f`): display range `-22` to `3` dB; default `-6`. Raw range `-22` to `3`; raw default `-6`. Sets the level above which limiting is applied. Lower values limit more of the signal; higher values limit only louder parts of the signal.

- `Level` (`key: Ch Vol`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Preamp block.

Busy One Ch2

- Model key: `HD2\_AmpBusyOneCh2`
- Model ID: `647`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 4.3
- Based on: Pearce BC-1 preamp (Channel 2)
- Agoura model: No

Parameters

- `Drive` (`key: Ch2 Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Ch2 Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.14`. Raw range `0` to `1`; raw default `0.214`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Ch2 Mid`, `id: 3`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Controls the midrange frequency EQ of the tonestack.
- `Mid Freq` (`key: Ch2 Mid Freq`, `id: 4`, `type: f`): display range `90` to `3000` Hz; default `435.98`. Raw range `90` to `3000`; raw default `435.98`. Sets the frequency boosted or cut by the Mid parameter.
- `Treble` (`key: Ch2 Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.16`. Raw range `0` to `1`; raw default `0.416`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Ch2 Master`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.22`. Raw range `0` to `1`; raw default `0.822`. Controls the Master Volume of the amplifier.
- `Input Pad` (`key: Input Pad`, `id: 7`, `type: i`): valid values `-10dB`, `0dB`, `10dB`; default `0dB`. Raw range `0` to `2`; raw default `1`. Boosts or cuts the input signal into the preamp by 10 dB.
- `Boost` (`key: Ch2 Boost`, `id: 8`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, supplies an additional boost for noticeably more gain and distortion.
- `Limiter` (`key: Limiter`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, enables the built-in limiter.
- `Threshold` (`key: Threshold`, `id: 10`, `type: f`): display range `-22` to `3` dB; default `-6`. Raw range `-22` to `3`; raw default `-6`. Sets the level above which limiting is applied. Lower values limit more of the signal; higher values limit only louder parts of the signal.
- `Level` (`key: Ch Vol`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

Busy One Ch2

- Model key: `HD2\_PreamplifierBusyOneCh2`

- Model ID: `648`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 4.0
- Based on: Pearce BC-1 preamp (Channel 2)
- Agoura model: No

Parameters

- `Drive` (`key: Ch2 Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Ch2 Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.14`. Raw range `0` to `1`; raw default `0.214`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Ch2 Mid`, `id: 3`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Controls the midrange frequency EQ of the tonestack.
- `Mid Freq` (`key: Ch2 Mid Freq`, `id: 4`, `type: f`): display range `90` to `3000` Hz; default `435.98`. Raw range `90` to `3000`; raw default `435.98`. Sets the frequency boosted or cut by the Mid parameter.
- `Treble` (`key: Ch2 Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.16`. Raw range `0` to `1`; raw default `0.416`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Ch2 Master`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.22`. Raw range `0` to `1`; raw default `0.822`. Controls the Master Volume of the amplifier.
- `Input Pad` (`key: Input Pad`, `id: 7`, `type: i`): valid values `-10dB`, `0dB`, `10dB`; default `0dB`. Raw range `0` to `2`; raw default `1`. Boosts or cuts the input signal into the preamp by 10 dB.
- `Boost` (`key: Ch2 Boost`, `id: 8`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, supplies an additional boost for noticeably more gain and distortion.
- `Limiter` (`key: Limiter`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, enables the built-in limiter.
- `Threshold` (`key: Threshold`, `id: 10`, `type: f`): display range `-22` to `3` dB; default `-6`. Raw range `-22` to `3`; raw default `-6`. Sets the level above which limiting is applied. Lower values limit more of the signal; higher values limit only louder parts of the signal.
- `Level` (`key: Ch Vol`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Controls the overall level of the Preamp block.

Busy One Jump

- Model key: `HD2\_AmpBusyOneJump`
- Model ID: `645`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 6.5
- Based on: Pearce BC-1 preamp (Jumped channels)
- Agoura model: No

Parameters

- `Ch 1 Drive` (`key: Ch1 Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the amount of Channel 1 gain applied to the signal, which influences the level of distortion.
- `Ch 1 Bass` (`key: Ch1 Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the low frequency EQ of the tonestack on Channel 1.
- `Ch 1 Mid` (`key: Ch1 Mid`, `id: 3`, `type: f`): display range `-15` to `15` dB; default `15`. Raw range `-15` to `15`; raw default `15`. Controls the midrange frequency EQ of the tonestack on Channel 1.
- `Ch 1 Mid Freq` (`key: Ch1 Mid Freq`, `id: 4`, `type: f`): display range `100` to `3000` Hz; default `150`. Raw range `100` to `3000`; raw default `150`. Sets the frequency boosted or cut by the Mid parameter on Channel 1.
- `Ch 1 Treble` (`key: Ch1 Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `1.5`. Raw range `0` to `1`; raw default `0.15`. Controls the high frequency EQ of the tonestack on Channel 1.
- `Ch 1 Master` (`key: Ch1 Master`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the Master Volume of Channel 1.
- `Ch 2 Drive` (`key: Ch2 Drive`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of Channel 2 gain applied to the signal, which influences the level of distortion.
- `Ch 2 Bass` (`key: Ch2 Bass`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the low frequency EQ of the tonestack on Channel 2.
- `Ch 2 Mid` (`key: Ch2 Mid`, `id: 9`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Controls the midrange frequency EQ of the tonestack on Channel 2.
- `Ch 2 Mid Freq` (`key: Ch2 Mid Freq`, `id: 10`, `type: f`): display range `90` to `3000` Hz; default `500`. Raw range `90` to `3000`; raw default `500`. Sets the frequency boosted or cut by the Mid parameter on Channel 2.
- `Ch 2 Treble` (`key: Ch2 Treble`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `4.38`. Raw range `0` to `1`; raw default `0.438`. Controls the high frequency EQ of the tonestack on Channel 2.
- `Ch 2 Master` (`key: Ch2 Master`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the Master Volume of Channel 2.
- `Input Pad` (`key: Input Pad`, `id: 13`, `type: i`): valid values `-10dB`, `0dB`, `10dB`; default `0dB`. Raw range `0` to `2`; raw default `1`. Boosts or cuts the input signal into the preamp by 10 dB.
- `Ch 1 Boost` (`key: Ch1 Boost`, `id: 14`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, supplies an additional boost to Channel 1 for noticeably more gain and distortion.
- `Ch 2 Boost` (`key: Ch2 Boost`, `id: 15`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, supplies an additional boost to Channel 2 for noticeably more gain and distortion.
- `Limiter` (`key: Limiter`, `id: 16`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, enables the built-in limiter.
- `Threshold` (`key: Threshold`, `id: 17`, `type: f`): display range `-22` to `3` dB; default `-6`. Raw range `-22` to `3`; raw default `-6`. Sets the level above which limiting is applied. Lower values limit more of the signal; higher values limit only louder parts of the signal.
- `Level` (`key: Ch Vol`, `id: 18`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

Busy One Jump

- Model key: `HD2\_PreamplifierBusyOneJump`
- Model ID: `646`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 6.6
- Based on: Pearce BC-1 preamp (Jumped channels)
- Agoura model: No

Parameters

- `Ch 1 Drive` (`key: Ch1 Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the amount of Channel 1 gain applied to the signal, which influences the level of distortion.
- `Ch 1 Bass` (`key: Ch1 Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the low frequency EQ of the tonestack on Channel 1.
- `Ch 1 Mid` (`key: Ch1 Mid`, `id: 3`, `type: f`): display range `-15` to `15` dB; default `15`. Raw range `-15` to `15`; raw default `15`. Controls the midrange frequency EQ of the tonestack on Channel 1.
- `Ch 1 Mid Freq` (`key: Ch1 Mid Freq`, `id: 4`, `type: f`): display range `100` to `3000` Hz; default `150`. Raw range `100` to `3000`; raw default `150`. Sets the frequency boosted or cut by the Mid parameter on Channel 1.
- `Ch 1 Treble` (`key: Ch1 Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `1.5`. Raw range `0` to `1`; raw default `0.15`. Controls the high frequency EQ of the tonestack on Channel 1.
- `Ch 1 Master` (`key: Ch1 Master`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the Master Volume of Channel 1.
- `Ch 2 Drive` (`key: Ch2 Drive`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of Channel 2 gain applied to the signal, which influences the level of distortion.
- `Ch 2 Bass` (`key: Ch2 Bass`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the low frequency EQ of the tonestack on Channel 2.
- `Ch 2 Mid` (`key: Ch2 Mid`, `id: 9`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Controls the midrange frequency EQ of the tonestack on Channel 2.
- `Ch 2 Mid Freq` (`key: Ch2 Mid Freq`, `id: 10`, `type: f`): display range `90` to `3000` Hz; default `500`. Raw range `90` to `3000`; raw default `500`. Sets the frequency boosted or cut by the Mid parameter on Channel 2.
- `Ch 2 Treble` (`key: Ch2 Treble`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `4.38`. Raw range `0` to `1`; raw default `0.438`. Controls the high frequency EQ of the tonestack on Channel 2.
- `Ch 2 Master` (`key: Ch2 Master`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the Master Volume of Channel 2.
- `Input Pad` (`key: Input Pad`, `id: 13`, `type: i`): valid values `-10dB`, `0dB`, `10dB`; default `0dB`. Raw range `0` to `2`; raw default `1`. Boosts or cuts the input signal into the preamp by 10 dB.
- `Ch 1 Boost` (`key: Ch1 Boost`, `id: 14`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, supplies an additional boost to Channel 1 for noticeably more gain and distortion.
- `Ch 2 Boost` (`key: Ch2 Boost`, `id: 15`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, supplies an additional boost to Channel 2 for noticeably more gain and distortion.

- `Limiter` (`key: Limiter`, `id: 16`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, enables the built-in limiter.
- `Threshold` (`key: Threshold`, `id: 17`, `type: f`): display range `-22` to `3` dB; default `-6`. Raw range `-22` to `3`; raw default `-6`. Sets the level above which limiting is applied. Lower values limit more of the signal; higher values limit only louder parts of the signal.
- `Level` (`key: Ch Vol`, `id: 18`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Preamp block.

Cali 400 Ch1

- Model key: `HD2\_AmpCali400Ch1`
- Model ID: `590`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 11.1
- Based on: MESA/Boogie Bass 400+ (channel 1)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the midrange frequency EQ of the tonestack.
- `High Mid` (`key: HighMid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.4`. Raw range `0` to `1`; raw default `0.74`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that

the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Cali 400 Ch1

- Model key: `HD2\_PreampCali400Ch1`
- Model ID: `592`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 7.0
- Based on: MESA/Boogie Bass 400+ (channel 1)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the midrange frequency EQ of the tonestack.
- `High Mid` (`key: HighMid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.4`. Raw range `0` to `1`; raw default `0.74`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Cali 400 Ch2

- Model key: `HD2\_AmpCali400Ch2`
- Model ID: `591`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 11.1
- Based on: MESA/Boogie Bass 400+ (channel 2)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.9`. Raw range `0` to `1`; raw default `0.49`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the midrange frequency EQ of the tonestack.
- `High Mid` (`key: HighMid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the high midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8.7`. Raw range `0` to `1`; raw default `0.87`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression.

This parameter is highly reactive with the Drive and Master settings.

Cali 400 Ch2

- Model key: `HD2\_PreampCali400Ch2`
- Model ID: `593`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 7.0
- Based on: MESA/Boogie Bass 400+ (channel 2)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.9`. Raw range `0` to `1`; raw default `0.49`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the midrange frequency EQ of the tonestack.
- `High Mid` (`key: HighMid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the high midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8.7`. Raw range `0` to `1`; raw default `0.87`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Cali Bass

- Model key: `HD2\_AmpCaliBass`
- Model ID: `588`
- Type: Amp
- Category: `amp`

- Class: Bass
- DSP usage estimate: 6.5
- Based on: MESA/Boogie M9 Carbine
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.9`. Raw range `0` to `1`; raw default `0.29`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the midrange frequency EQ of the tonestack.
- `High Mid` (`key: HighMid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the high midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8.6`. Raw range `0` to `1`; raw default `0.86`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Voice` (`key: Voice`, `id: 9`, `type: i`): valid values `Voice 1`, `Voice 2`, `Voice 3`, `Voice 4`, `Voice 5`; default `Voice 4`. Raw range `0` to `4`; raw default `3`. This 5-position parameter changes the overall tonal character of the amp: Voices 1 and 2 are variations of a "scooped" sound, Voices 4 and 5 are variations of a "mid-forward" sound, and Voice 3 is flat.

Cali Bass

- Model key: `HD2\_PreamplifierCaliBass`
- Model ID: `589`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 6.8
- Based on: MESA/Boogie M9 Carbine
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.9`. Raw range `0` to `1`; raw default `0.29`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the low frequency EQ of the

tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the midrange frequency EQ of the tonestack.
- `High Mid` (`key: HighMid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the high midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8.6`. Raw range `0` to `1`; raw default `0.86`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Voice` (`key: Voice`, `id: 9`, `type: i`): valid values `Voice 1`, `Voice 2`, `Voice 3`, `Voice 4`, `Voice 5`; default `Voice 4`. Raw range `0` to `4`; raw default `3`. This 5-position parameter changes the overall tonal character of the preamp: Voices 1 and 2 are variations of a "scooped" sound, Voices 4 and 5 are variations of a "mid-forward" sound, and Voice 3 is flat.

Del Sol 300

- Model key: `HD2\_AmpDelSol300`
- Model ID: `639`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 4.3
- Based on: Sunn Coliseum 300
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `8.2`. Raw range `0` to `1`; raw default `0.82`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bright` (`key: Bright`, `id: 2`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Selects the Input jack configuration--Normal (Off) or Bright (On).
- `Contour` (`key: Contour`, `id: 3`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, acts as a "mid-scoop", reducing the midrange frequencies while boosting the low and high frequencies.
- `Master` (`key: Master`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `62.5 Hz` (`key: 62p5Hz`, `id: 6`, `type: f`): display range `-15` to `15` dB; default `9`. Raw range `-15` to `15`; raw default `9`. Boost or cut up to 15.0 dB.

- `125 Hz` (`key: 125Hz`, `id: 7`, `type: f`): display range `-15` to `15` dB; default `2.5`. Raw range `-15` to `15`; raw default `2.5`. Boost or cut up to 15.0 dB.
- `250 Hz` (`key: 250Hz`, `id: 8`, `type: f`): display range `-15` to `15` dB; default `-3.2`. Raw range `-15` to `15`; raw default `-3.2`. Boost or cut up to 15.0 dB.
- `500 Hz` (`key: 500Hz`, `id: 9`, `type: f`): display range `-15` to `15` dB; default `-2`. Raw range `-15` to `15`; raw default `-2`. Boost or cut up to 15.0 dB.
- `1 kHz` (`key: 1kHz`, `id: 10`, `type: f`): display range `-15` to `15` dB; default `4.5`. Raw range `-15` to `15`; raw default `4.5`. Boost or cut up to 15.0 dB.
- `2 kHz` (`key: 2kHz`, `id: 11`, `type: f`): display range `-15` to `15` dB; default `1.5`. Raw range `-15` to `15`; raw default `1.5`. Boost or cut up to 15.0 dB.
- `4 kHz` (`key: 4kHz`, `id: 12`, `type: f`): display range `-15` to `15` dB; default `5.7`. Raw range `-15` to `15`; raw default `5.7`. Boost or cut up to 15.0 dB.

Del Sol 300

- Model key: `HD2\_PreamplDelSol300`
- Model ID: `640`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 2.8
- Based on: Sunn Coliseum 300
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `8.2`. Raw range `0` to `1`; raw default `0.82`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `62.5 Hz` (`key: 62p5Hz`, `id: 2`, `type: f`): display range `-15` to `15` dB; default `9`. Raw range `-15` to `15`; raw default `9`. Boost or cut up to 15.0 dB.
- `125 Hz` (`key: 125Hz`, `id: 3`, `type: f`): display range `-15` to `15` dB; default `2.5`. Raw range `-15` to `15`; raw default `2.5`. Boost or cut up to 15.0 dB.
- `250 Hz` (`key: 250Hz`, `id: 4`, `type: f`): display range `-15` to `15` dB; default `-3.2`. Raw range `-15` to `15`; raw default `-3.2`. Boost or cut up to 15.0 dB.
- `500 Hz` (`key: 500Hz`, `id: 5`, `type: f`): display range `-15` to `15` dB; default `-2`. Raw range `-15` to `15`; raw default `-2`. Boost or cut up to 15.0 dB.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the Master Volume of the amplifier.
- `1 kHz` (`key: 1kHz`, `id: 8`, `type: f`): display range `-15` to `15` dB; default `4.5`. Raw range `-15` to `15`; raw default `4.5`. Boost or cut up to 15.0 dB.
- `2 kHz` (`key: 2kHz`, `id: 9`, `type: f`): display range `-15` to `15` dB; default `1.5`. Raw range `-15` to `15`; raw default `1.5`. Boost or cut up to 15.0 dB.
- `4 kHz` (`key: 4kHz`, `id: 10`, `type: f`): display range `-15` to `15` dB; default `5.7`. Raw range `-15` to `15`; raw default `5.7`. Boost or cut up to 15.0 dB.
- `Bright` (`key: Brite`, `id: 11`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Selects the Input jack configuration--Normal (Off) or Bright (On).
- `Contour` (`key: Contour`, `id: 12`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, acts as a "mid-scoop", reducing the midrange frequencies while boosting the low and high frequencies.

G Cougar 800

- Model key: `HD2\_AmpGCougar800`
- Model ID: `578`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 8.7
- Based on: Gallien-Krueger GK 800RB
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.6`. Raw range `0` to `1`; raw default `0.26`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the low frequency EQ (60 Hz) of the tonestack.
- `Low Mid` (`key: LowMid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the low midrange frequency EQ (250 Hz) of the tonestack.
- `High Mid` (`key: HighMid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the high midrange frequency EQ (1 kHz) of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the high frequency EQ (4 kHz) of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.8`. Raw range `0` to `1`; raw default `0.88`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Boost` (`key: Boost`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Adds gain to the post-tonestack signal. At higher settings, a bit of overdrive/distortion can be heard.
- `Contour` (`key: Contour`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, adds a notch filter around 500 Hz to provide a smoother, rounder sound.

G Cougar 800

- Model key: `HD2\_PreampgCougar800`
- Model ID: `579`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 6.6
- Based on: Gallien-Krueger GK 800RB
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default

`2.6`. Raw range `0` to `1`; raw default `0.26`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the low frequency EQ (60 Hz) of the tonestack.
- `Low Mid` (`key: LowMid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the low midrange frequency EQ (250 Hz) of the tonestack.
- `High Mid` (`key: HighMid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the high midrange frequency EQ (1 kHz) of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the high frequency EQ (4 kHz) of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.8`. Raw range `0` to `1`; raw default `0.88`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Boost` (`key: Boost`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Adds gain to the post-tonestack signal. At higher settings, a bit of overdrive/distortion can be heard.
- `Contour` (`key: Contour`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, adds a notch filter around 500 Hz to provide a smoother, rounder sound.

Mandarin Bass 200

- Model key: `HD2\_AmpMandarinBass200`
- Model ID: `733`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 10.8
- Based on: Orange AD200 MkIII
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the low frequency EQ of the tonestack.
- `Middle` (`key: Middle`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.58`. Raw range `0` to `1`; raw default `0.758`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Amp block.

Unlike Master Volume, it has no effect on the block's tone.

- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Mandarin Bass 200

- Model key: `HD2\_PreamplifierMandarinBass200`
- Model ID: `734`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 7.4
- Based on: Orange AD200 MkIII
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Middle` (`key: Middle`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`.

Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`.

Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Mandarin Plus 200

- Model key: `Agoura\_AmpMandarinPlus200`
- Model ID: `754`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 16.3
- Based on: Orange AD200 MkIII (Passive & Active inputs)
- Agoura model: Yes

Parameters

- `Jack` (`key: Jack`, `id: 1`, `type: b`): valid values `Passive`, `Active`; default `Passive`. Raw range `Off` to `On`; raw default `Off`. Selects the input jack on the amp--Passive or Active.

- `Drive` (`key: Drive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the high frequency EQ of the tonestack.

- `Master` (`key: Master`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the master volume of the amplifier.

- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `1.5`. Raw range `-40` to `10`; raw default `1.5`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

- `Ripple` (`key: Ripple`, `id: 9`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Z PrePost` (`key: ZPrePost`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Determines the location of speaker

impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).

- `Hype` (`key: Hype`, `id: 11`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

US Drip Bass

- Model key: `Agoura\_AmpUSDripBass`
- Model ID: `812`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 25.1
- Based on: Fender Bassman Silverface (Bass, Normal, & Jumped channels)
- Agoura model: Yes

Parameters

- `Channel` (`key: Channel`, `id: 1`, `type: i`): valid values `Bass`, `Normal`, `Jumped`; default `Normal`. Raw range `0` to `2`; raw default `1`. Selects the amp channel or which input is connected. "Jumped" jumps between the Bass and Normal channels.
- `Bass Drive` (`key: BasDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the amount of Bass channel gain applied to the signal. The inactive channel can sometimes "bleed into" the active channel, resulting in interesting interactions.
- `Bass Bass` (`key: BasBass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Controls the low frequency EQ of the Bass channel's tonestack.
- `Bass Treble` (`key: BasTreb`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.8`. Raw range `0` to `1`; raw default `0.78`. Controls the high frequency EQ of the Bass channel's tonestack.
- `Normal Drive` (`key: NrmDrive`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `2.3`. Raw range `0` to `1`; raw default `0.23`. Controls the amount of Normal channel gain applied to the signal. The inactive channel can sometimes "bleed into" the active channel, resulting in interesting interactions.
- `Normal Bass` (`key: NrmBass`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the Normal channel's tonestack.
- `Normal Treble` (`key: NrmTreb`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the high frequency EQ of the Normal channel's tonestack.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Bass Deep` (`key: BasDeep`, `id: 9`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, applies a low frequency boost.
- `Normal Bright` (`key: NrmBright`, `id: 10`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, applies a high frequency boost to the Normal channel.
- `Master` (`key: Master`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 12`, `type: f`): display range `-10` to `10` Stock; default `0`.

Raw range ``-1`` to ``1``; raw default ``0``. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- ``Ripple`` (``key: Ripple``, ``id: 13``, ``type: f``): display range ``-10`` to ``10`` Stock; default ``0``. Raw range ``-1`` to ``1``; raw default ``0``. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- ``Z PrePost`` (``key: PrePost``, ``id: 14``, ``type: f``): display range ``0`` to ``10`` unitless; default ``10``. Raw range ``0`` to ``1``; raw default ``1``. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).

- ``Hype`` (``key: Hype``, ``id: 15``, ``type: f``): display range ``0`` to ``10`` Off; default ``0``. Raw range ``0`` to ``1``; raw default ``0``. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

US Dripman Norm

- Model key: ``HD2_AmpUSDripmanNorm``
- Model ID: ``729``
- Type: Amp
- Category: ``amp``
- Class: Bass
- DSP usage estimate: 12.3
- Based on: Marshall JCM-800 (2203)
- Agoura model: No

Parameters

- ``Drive`` (``key: Norm Drive``, ``id: 1``, ``type: f``): display range ``0`` to ``10`` unitless; default ``3``. Raw range ``0`` to ``1``; raw default ``0.3``. Controls the amount of gain applied to the signal, which influences the level of distortion.

- ``Bass`` (``key: Bass``, ``id: 2``, ``type: f``): display range ``0`` to ``10`` unitless; default ``5``. Raw range ``0`` to ``1``; raw default ``0.5``. Controls the low frequency EQ of the tonestack.

- ``Mid`` (``key: Mid``, ``id: 3``, ``type: f``): display range ``0`` to ``10`` unitless; default ``6.8``. Raw range ``0`` to ``1``; raw default ``0.68``. Controls the midrange frequency EQ of the tonestack.

- ``Treble`` (``key: Treble``, ``id: 4``, ``type: f``): display range ``0`` to ``10`` unitless; default ``5``. Raw range ``0`` to ``1``; raw default ``0.5``. Controls the high frequency EQ of the tonestack.

- ``Bright`` (``key: Bright``, ``id: 5``, ``type: b``): valid values ``Off``, ``On``; default ``On``. Raw range ``Off`` to ``On``; raw default ``On``. When on, boosts high frequencies. Is more obvious when Drive is set low.

- ``Level`` (``key: ChVol``, ``id: 6``, ``type: f``): display range ``0`` to ``10`` unitless; default ``7``. Raw range ``0`` to ``1``; raw default ``0.7``. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

- ``Master`` (``key: Master``, ``id: 7``, ``type: f``): display range ``0`` to ``10`` unitless; default ``10``. Raw range ``0`` to ``1``; raw default ``1``. Controls the Master Volume of the amplifier.

- ``Sag`` (``key: Sag``, ``id: 8``, ``type: f``): display range ``0`` to ``10`` unitless; default ``5``. Raw range ``0`` to ``1``; raw default ``0.5``. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values

provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`.

Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

US Dripman Norm

- Model key: `HD2\_PreamplifierUSDripmanNorm`

- Model ID: `730`

- Type: Preamp

- Category: `preamp`

- Class: Bass

- DSP usage estimate: 9.2

- Based on: Marshall JCM-800 (2203)

- Agoura model: No

Parameters

- `Drive` (`key: Norm Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.

- `Bright` (`key: Bright`, `id: 5`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, boosts high frequencies. Is more obvious when Drive is set low.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.

- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.

- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power

supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Woody Blue

- Model key: `HD2\_AmpWoodyBlue`
- Model ID: `641`
- Type: Amp
- Category: `amp`
- Class: Bass
- DSP usage estimate: 6.1
- Based on: Acoustic 360
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the low frequency EQ of the tonestack.

- `Variamp` (`key: Variamp`, `id: 3`, `type: i`): valid values `1`, `2`, `3`, `4`, `5`; default `4`. Raw range `0` to `4`; raw default `3`. This 5-position switch acts selects the mid frequency to be boosted or cut with the Effect parameter.

- `Effect` (`key: Effect`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.2`. Raw range `0` to `1`; raw default `0.22`. Controls the mid EQ of the tonestack, the frequency of which is controlled by the Variamp parameter.

- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the high frequency EQ of the tonestack.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Level controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone. Level is a great way to level your presets as you can quickly jump to each Amp block by pressing the Amp button.

- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.

- `Bright` (`key: Bright`, `id: 8`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts high frequencies. Is more obvious when Drive is set low.

- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `2.7`. Raw range `0` to `1`; raw default `0.27`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

- `Tuning Fork` (`key: TuningFork`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the volume of the Tuning Fork's reference tone. Included only in the interest of hyper-accuracy.

- `TF Coarse` (`key: TFCoarse`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Controls the coarse tuning of the Tuning Fork's reference tone.
- `TF Fine` (`key: TFFine`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `3.1`. Raw range `0` to `1`; raw default `0.31`. Controls the fine tuning of the Tuning Fork's reference tone.

Woody Blue

- Model key: `HD2\_PreampWoodyBlue`
- Model ID: `642`
- Type: Preamp
- Category: `preamp`
- Class: Bass
- DSP usage estimate: 5.0
- Based on: Acoustic 360
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the low frequency EQ of the tonestack.
- `Variamp` (`key: Variamp`, `id: 3`, `type: i`): valid values `1`, `2`, `3`, `4`, `5`; default `4`. Raw range `0` to `4`; raw default `3`. This 5-position switch acts selects the mid frequency to be boosted or cut with the Effect parameter.
- `Effect` (`key: Effect`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.2`. Raw range `0` to `1`; raw default `0.22`. Controls the mid EQ of the tonestack, the frequency of which is controlled by the Variamp parameter.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Level controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone. Level is a great way to level your presets as you can quickly jump to each Amp block by pressing the Amp button.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Bright` (`key: Bright`, `id: 8`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts high frequencies. Is more obvious when Drive is set low.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `2.7`. Raw range `0` to `1`; raw default `0.27`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Tuning Fork` (`key: TuningFork`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the volume of the Tuning Fork's reference tone. Included only in the interest of hyper-accuracy.
- `TF Coarse` (`key: TFCoarse`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Controls the coarse tuning of the Tuning Fork's reference tone.

- `TF Fine` (`key: TFFine`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `3.1`. Raw range `0` to `1`; raw default `0.31`. Controls the fine tuning of the Tuning Fork's reference tone.

Source file: effects-delay-and-reverb.md

Effects: delay and reverb

Upload-ready knowledge for delay and reverb blocks.

Generated from the installed Helix Stadium desktop app bundle on
2026-05-07T22:33:14.224003+00:00.

Use display values for normal user-facing answers. Use model keys, IDs, and raw ranges only when the user asks for automation or low-level control details.

Model count: 76

ADT

- Model key: `HD2\_DelayADTMono`
- Model ID: `131`
- Type: Delay
- Category: `delay`
- Class: Tape
- DSP usage estimate: 6.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Delay 1` (`key: DelayDeck1`, `id: 1`, `type: f`): display range `0` to `20` ms; default `3`. Raw range `0` to `0.02`; raw default `0.003`. Adjusts the delay time of Deck 1. Delay 1 can go up to 20 ms and Delay 2 can go up to 200 ms.
- `Delay 2` (`key: DelayDeck2`, `id: 2`, `type: f`): display range `0` to `200` ms; default `50`. Raw range `0` to `0.2`; raw default `0.05`. Adjusts the delay time of Deck 2. Delay 1 can go up to 20 ms and Delay 2 can go up to 200 ms.
- `Wow/Flutter 1` (`key: WowFlutter1`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls how much warbly tape sound is heard from Deck 1.
- `Wow/Flutter 2` (`key: WowFlutter2`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls how much warbly tape sound is heard from Deck 2.
- `Saturate 1` (`key: DistDeck1`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adds analog tape saturation to Deck 1 and at high enough settings, distortion. At lower settings, it's great for simply warming up a tone.
- `Saturate 2` (`key: DistDeck2`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adds analog tape saturation to Deck 2 and at high enough settings, distortion. At lower settings, it's great for simply warming up a tone.
- `Deck 1 Vol` (`key: Deck1Vol`, `id: 7`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of Deck 1. Deck 2 is a bit lower than Deck 1 by default.
- `Deck 2 Vol` (`key: Deck2Vol`, `id: 8`, `type: f`): display range `-60` to `6` dB; default

`-3`. Raw range `-60` to `6`; raw default `-3`. Sets the level of Deck 2. Deck 2 is a bit lower than Deck 1 by default.

- `Deck 2 Pol` (`key: Deck2Pol`, `id: 9`, `type: i`): valid values `Normal`, `Invert`; default `Normal`. Raw range `0` to `1`; raw default `0`. When set to "Invert," inverts the polarity of Deck 2.
- `Mod Rate` (`key: ModRate`, `id: 10`, `type: f`): display range `0.1` to `8` Hz; default `0.5`. Raw range `0.1` to `8`; raw default `0.5`. Controls the rate or speed of modulation applied to Deck 2.
- `Mod Depth` (`key: ModDepth`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the depth or amount of modulation applied to Deck 2.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Tape Speed` (`key: TapeSpeed`, `id: 13`, `type: i`): valid values `7.5 ips`, `15 ips`, `30 ips`; default `15 ips`. Raw range `0` to `2`; raw default `1`. Changes both the rate of the modulation applied by the WowFlutter control and the filtering response of the analog tape emulation.
- `Texture` (`key: Texture`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `6.25`. Raw range `0` to `1`; raw default `0.625`. Adjusts the amount of the NAB tape EQ in the simulated tape path. When Saturation is set to 0.0, the texture is invisible. When Saturation is turned up, the texture will affect the tightness (or looseness) of the distortion.
- `Low Cut` (`key: LowCut`, `id: 15`, `type: f`): display range `19.9` to `1000` Off; default `40`. Raw range `19.9` to `1000`; raw default `40`. Applies a low cut (high pass) filter to the decks, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 16`, `type: f`): display range `500` to `20100` Hz; default `12000`. Raw range `500` to `20100`; raw default `12000`. Applies a high cut (low pass) filter to the decks, letting you remove the effected signal above a certain frequency.
- `Envelope Thresh` (`key: Threshold`, `id: 17`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Sets the level above which engages the envelope. When on, picking harder can impart very slight pitch fluctuations by tweaking Deck 2's delay. Subtle, but fun.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Adriatic Delay

- Model key: `HD2\_DelayAdriaticDelayMono`
- Model ID: `130`
- Type: Delay
- Category: `delay`
- Class: Analog
- DSP usage estimate: 3.8
- Based on: BOSS DM-2 w/ Adrian Mod
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `20` to `1800` ms; default `400`. Raw range `0.02` to `1.8`; raw default `0.4`. Adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the number of delay repeats. When set to 0%, only one repeat is heard. At high values, the Delay may begin to self-oscillate and squeal (perhaps in a good way).
- `Noise` (`key: Noise`, `id: 3`, `type: f`): display range `0` to `10` unitless; default

`3.6`. Raw range `0` to `1`; raw default `0.36`. Adds subtle graininess to the repeats, which is inherent in many bucket brigade delays.

- `BBD Size` (`key: BBD Size`, `id: 4`, `type: i`): valid values `1024`, `2048`, `4096`, `8192`; default `4096`. Raw range `0` to `3`; raw default `2`. Sets the clock frequency of the bucket brigade device. Higher values provide a wider frequency response.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard. If Dry Thru is off, you'll still hear the tape delay's circuitry when Mix is set to 0%.
- `Rate` (`key: Rate`, `id: 7`, `type: f`): display range `0.1` to `8` Hz; default `0.3`. Raw range `0.1` to `8`; raw default `0.3`. Controls the speed or rate of the pitch modulation applied to the repeats.
- `Depth` (`key: Depth`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `2.2`. Raw range `0` to `1`; raw default `0.22`. Controls the depth or intensity of the pitch modulation applied to the repeats.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Headroom` (`key: Headroom`, `id: 9`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Some delay pedals' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative values increase the perceived amount of grit; positive values clean things up a bit.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Adriatic Swell

- Model key: `HD2\_DelaySwellAdriaticMono`
- Model ID: `118`
- Type: Delay
- Category: `delay`
- Class: Analog
- DSP usage estimate: 4.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `20` to `1800` ms; default `400`. Raw range `0.02` to `1.8`; raw default `0.4`. Adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Feedback controls the number of delay repeats. When set to 0%, only one repeat is heard. At high values, the Delay may begin to self-oscillate and squeal (perhaps in a good way).
- `Noise` (`key: Noise`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Adds subtle graininess to the repeats, which is inherent in many bucket brigade delays.
- `BBD Size` (`key: BBD Size`, `id: 4`, `type: i`): valid values `1024`, `2048`, `4096`, `8192`; default `4096`. Raw range `0` to `3`; raw default `2`. Sets the clock frequency of the bucket brigade device. Higher values provide a wider frequency response.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Rate` (`key: Rate`, `id: 7`, `type: f`): display range `0.1` to `8` Hz; default `0.3`. Raw range `0.1` to `8`; raw default `0.3`. Controls the speed or rate of the pitch modulation applied to the repeats.

- `Depth` (`key: Depth`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `2.2`. Raw range `0` to `1`; raw default `0.22`. Controls the depth or intensity of the pitch modulation applied to the repeats.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Headroom` (`key: Headroom`, `id: 9`, `type: f`): display range `-12` to `12` dB; default `0.5`. Raw range `-12` to `12`; raw default `0.5`. Some delay pedals' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative values increase the perceived amount of grit; positive values clean things up a bit.
- `Threshold` (`key: Threshold`, `id: 10`, `type: f`): display range `-96` to `0` dB; default `-60`. Raw range `-96` to `0`; raw default `-60`. Sets the level below which the volume swell resets.
- `Attack` (`key: Attack`, `id: 11`, `type: f`): display range `100` to `5000` ms; default `1000`. Raw range `0.1` to `5`; raw default `1`. Sets the ramp time for the volume swell applied to the dry signal, and therefore, any delay repeats.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Bucket Brigade

- Model key: `HD2\_DelayBucketBrigadeMono`
- Model ID: `128`
- Type: Delay
- Category: `delay`
- Class: Analog
- DSP usage estimate: 3.5
- Based on: BOSS DM-2
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `20` to `300` ms; default `238`. Raw range `0.02` to `0.3`; raw default `0.238`. Adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo. IMPORTANT! The original pedal's delay time was limited to 300 ms, so depending on the tempo, your repeats may appear twice as fast. For longer repeat times, consider using Adriatic Delay.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `43`. Raw range `0` to `1`; raw default `0.43`. Controls the number of delay repeats. When set to 0%, only one repeat is heard. At high values, the Delay may begin to self-oscillate and squeal (perhaps in a good way).
- `Noise` (`key: Noise`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Adds subtle graininess to the repeats, which is inherent in many bucket brigade delays.
- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard. If Dry Thru is off, you'll still hear the tape delay's circuitry when Mix is set to 0%.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Headroom` (`key: Headroom`, `id: 6`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Some delay pedals' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative values increase the perceived amount of grit; positive values clean things up a bit.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Cosmos Echo

- Model key: `HD2\_DelayCosmosEchoMono`
- Model ID: `127`
- Type: Delay
- Category: `delay`
- Class: Tape
- DSP usage estimate: 6.3
- Based on: Roland RE-201 Space Echo
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `150` to `2000` ms; default `600`. Raw range `0.15` to `2`; raw default `0.6`. Adjusts the delay time of tape head 3. Cosmos Echo has a maximum delay length of 2 seconds, with the delay time divided evenly between the 3 tape heads. So if Time is set to 1.500 seconds, tape head 1's time is 500 ms ($1500 / 3 = 500$). When set to note values, Time follows the system tempo.
- `Ramp` (`key: Ramp`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls how fast the tape speed changes when adjusting the Time parameter. Ramp has no affect on the signal except when Time is being adjusted.
- `Feedback` (`key: Feedback`, `id: 3`, `type: f`): display range `0` to `100` %; default `40`. Raw range `0` to `1`; raw default `0.4`. Controls the number of delay repeats for all four tape heads. When set to 0%, only one repeat is heard. At high values, the Delay may begin to self-oscillate and squeal (perhaps in a good way).
- `Wow/Flutter` (`key: WowFlutter`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much warbly tape sound is heard. Lower values result in the sound of a tape echo in pristine condition; higher values result in the sound of a tape echo that may have seen one too many trips in the back of a van.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Headroom` (`key: Headroom`, `id: 7`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Some delay units' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative values increase the perceived amount of grit; positive values clean things up a bit.
- `Mode` (`key: Mode`, `id: 8`, `type: i`): valid values `Head 1`, `Head 2`, `Head 3`, `Head 1 3`, `Head 2 3`, `Head 1 2 3`; default `Head 2 3`. Raw range `0` to `5`; raw default `4`. Determines which combination of up to three tape heads is active. Head 3 reflects the full delay time (set with the Time parameter). Head 1's time is 1/3 that of Head 3, and Head 2's time is 2/3 that of Head 3.
- `Bass` (`key: Bass`, `id: 9`, `type: f`): display range `-18` to `18` dB; default `0`. Raw range `-18` to `18`; raw default `0`. Controls the low frequency EQ applied to the repeats.
- `Treble` (`key: Treble`, `id: 10`, `type: f`): display range `-18` to `18` dB; default `0`. Raw range `-18` to `18`; raw default `0`. Controls the high frequency EQ applied to the repeats.
- `FB Tone` (`key: FBTone`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Determines how the frequency bandwidth of the repeats changes over time, particularly when Feedback is set high. Lower values gradually roll off more of the highs, approximating the behavior of older tape. Higher values maintain more high end for more repeats, like new tape fresh out of the box.
- `Splice` (`key: Splice`, `id: 12`, `type: f`): display range `0` to `10` unitless; default

`0`. Raw range `0` to `1`; raw default `0`. Controls the level of the tape splice. Like the original unit, Cosmos Echo uses virtual tape with ends that are spliced together. When this spliced area of the tape travels over the heads, a slight warble can be heard. Time also affects how frequently the tape splice occurs.

- `Dry Thru` (`key: DryThru`, `id: 13`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When off, the dry signal is routed through the tape delay's circuitry (even with Mix set to 0%), which can add a bit of warmth and grit. When on, the dry signal bypasses the delay's circuitry.

- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Crisscross

- Model key: `HD2\_DelayCrissCrossMono`
- Model ID: `126`
- Type: Delay
- Category: `delay`
- Class: Digital
- DSP usage estimate: 4.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time A` (`key: TimeA`, `id: 1`, `type: f`): display range `0` to `2000` ms; default `557`. Raw range `0` to `2`; raw default `0.557`. Adjusts the length of time before the first repeat of delay line A. When set to note values, Time follows the system tempo.
- `Time B` (`key: TimeB`, `id: 2`, `type: f`): display range `0` to `2000` ms; default `337`. Raw range `0` to `2`; raw default `0.337`. Adjusts the length of time before the first repeat of delay line B. When set to note values, Time follows the system tempo.
- `Feedback A` (`key: FeedbackA`, `id: 3`, `type: f`): display range `0` to `100` %; default `55.0`. Raw range `0` to `1`; raw default `0.55`. Controls the number of repeats for delay line A. When set to 0%, only one repeat is heard.
- `Feedback B` (`key: FeedbackB`, `id: 4`, `type: f`): display range `0` to `100` %; default `70`. Raw range `0` to `1`; raw default `0.7`. Controls the number of repeats for delay line B. When set to 0%, only one repeat is heard.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `40`. Raw range `0` to `1`; raw default `0.4`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Crossfeed` (`key: Crossfeed`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of the A delay line fed back into the B delay line and vice versa.
- `Headroom` (`key: Headroom`, `id: 8`, `type: f`): display range `-12` to `12` dB; default `12`. Raw range `-12` to `12`; raw default `12`. Some delay pedals' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative values increase the perceived amount of grit; positive values clean things up a bit.
- `Mod Rate` (`key: ModRate`, `id: 9`, `type: f`): display range `0.1` to `10` Hz; default `0.75`. Raw range `0.1` to `10`; raw default `0.75`. Controls the rate or speed of modulation.
- `Mod Depth` (`key: ModDepth`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the depth or amount of modulation.
- `Shape` (`key: Shape`, `id: 11`, `type: i`): valid values `Sine`, `Triangle`; default `Triangle`. Raw range `2` to `3`; raw default `3`. Selects the modulation's wave shape (Sine

or Triangle).

- `Phase` (`key: Phase`, `id: 12`, `type: i`): valid values `0`, `90`, `180`; default `90`. Raw range `0` to `2`; raw default `1`. Determines the modulation's phase relationship between the two delay lines. At 0, the delay lines modulate together; at 180, modulation is inverted from one another.
- `Bit Depth` (`key: BitDepth`, `id: 13`, `type: i`): valid values `6`, `8`, `10`, `11`, `12`, `14`, `16`, `24`; default `12`. Raw range `0` to `7`; raw default `4`. Lowers the bit depth of the delay repeats for a grungier sound. For more transparent results, set to 24 bits.
- `Sample Rate` (`key: SampleRate`, `id: 14`, `type: i`): valid values `8 kHz`, `11.025 kHz`, `12 kHz`, `16 kHz`, `22.05 kHz`, `24 kHz`, `44.1 kHz`, `48 kHz`; default `16 kHz`. Raw range `0` to `7`; raw default `3`. Lowers the sample rate of the delay repeats for a grungier, more vintage digital sound. For more transparent results, set to 48kHz.
- `Low Cut` (`key: LowCut`, `id: 15`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter to the repeats, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 16`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter to the repeats, letting you remove the effected signal above a certain frequency.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Double Tank

- Model key: `HD2\_ReverbDoubleTankMono`
- Model ID: `102`
- Type: Reverb
- Category: `reverb`
- Class: Spaces
- DSP usage estimate: 7.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Decay` (`key: Decay`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.3`. Raw range `0` to `1`; raw default `0.43`. Adjusts the decay time of the reverb effect.
- `Predelay` (`key: Predelay`, `id: 2`, `type: f`): display range `0` to `200` ms; default `0`. Raw range `0` to `0.2`; raw default `0`. Controls the amount of delay heard before the audible onset of reverb. Can sometimes result in more definition between the dry and effected signals.
- `Rate` (`key: Rate`, `id: 3`, `type: f`): display range `0` to `100` %; default `25`. Raw range `0` to `1`; raw default `0.25`. Controls the rate or speed of the modulation.
- `Modulation` (`key: Modulation`, `id: 4`, `type: f`): display range `0` to `100` %; default `40`. Raw range `0` to `1`; raw default `0.4`. Controls the amount or depth of the modulation.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `30`. Raw range `0` to `1`; raw default `0.3`. Controls the blend between the reverb and the dry signal. At 0%, no reverb is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Low Cut` (`key: LowCut`, `id: 7`, `type: f`): display range `19.9` to `500` Off; default `169`. Raw range `19.9` to `500`; raw default `169`. Applies a low cut (or high pass) filter to the reverb, letting you remove the effected signal below a certain frequency.

- `High Cut` (`key: HighCut`, `id: 8`, `type: f`): display range `500` to `20100` Hz; default `6000`. Raw range `500` to `20100`; raw default `6000`. Applies a high cut (or low pass) filter to the reverb, letting you remove the effected signal above a certain frequency.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Dual Delay

- Model key: `HD2\_DelayDualDelayStereo`
- Model ID: `89`
- Type: Delay
- Category: `delay`
- Class: Digital
- DSP usage estimate: 3.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Left Time` (`key: Left Time`, `id: 1`, `type: f`): display range `0` to `2000` ms; default `375`. Raw range `0` to `2`; raw default `0.375`. Adjusts the length of time before the left delay's first repeat. When set to note values, Time follows the system tempo.
- `Right Time` (`key: Right Time`, `id: 2`, `type: f`): display range `0` to `2000` ms; default `500`. Raw range `0` to `2`; raw default `0.5`. Adjusts the length of time before the right delay's first repeat. When set to note values, Time follows the system tempo.
- `Left Feedback` (`key: LeftFeedback`, `id: 3`, `type: f`): display range `0` to `100` %; default `30`. Raw range `0` to `1`; raw default `0.3`. Controls the number of repeats for the left delay. When set to 0%, only one repeat is heard; at 100%, the delay repeats forever.
- `Right Feedback` (`key: RightFeedback`, `id: 4`, `type: f`): display range `0` to `100` %; default `40`. Raw range `0` to `1`; raw default `0.4`. Controls the number of repeats for the right delay. When set to 0%, only one repeat is heard; at 100%, the delay repeats forever.
- `Left Mix` (`key: MixL`, `id: 5`, `type: f`): display range `0` to `100` %; default `35`. Raw range `0` to `1`; raw default `0.35`. Controls the blend between the left channel's repeats and the dry signal.
- `Right Mix` (`key: MixR`, `id: 6`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the left channel's repeats and the dry signal.
- `Level` (`key: Level`, `id: 7`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Low Cut` (`key: LowCut`, `id: 8`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (or high pass) filter to the repeats, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 9`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (or low pass) filter to the repeats, letting you remove the effected signal above a certain frequency.
- `Mod Mode` (`key: ModulationMode`, `id: 10`, `type: i`): valid values `Off`, `Chorus`, `Vibrato`; default `Chorus`. Raw range `0` to `2`; raw default `1`. Selects the type of modulation applied to the repeats--None ("Off"), Chorus, or Vibrato.
- `Speed` (`key: Speed`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `0.5`. Raw range `0` to `1`; raw default `0.05`. Controls the speed or rate of the modulation. Does nothing if Mod Mode is set to "Off"
- `Depth` (`key: Depth`, `id: 12`, `type: f`): display range `0` to `100` %; default `35`.

Raw range `0` to `1`; raw default `0.35`. Controls the depth or intensity of the modulation. Does nothing if Mod Mode is set to "Off"

- `Spread` (`key: Spread`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the apparent stereo width of the modulation between the left and right channels. Does nothing if Mod Mode is set to "Off"
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Ducked Delay

- Model key: `HD2\_DelayDuckedDelayMono`
- Model ID: `123`
- Type: Delay
- Category: `delay`
- Class: Digital
- DSP usage estimate: 2.0
- Based on: TC Electronic 2290
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `8000` ms; default `500`. Raw range `0` to `8`; raw default `0.5`. Adjusts the length of time before the delay's first repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `37.5`. Raw range `0` to `1`; raw default `0.375`. Controls the number of delay repeats. When set to 0%, only one repeat is heard; at 100%, the delay repeats forever.
- `Low Cut` (`key: LowCut`, `id: 3`, `type: f`): display range `19.9` to `500` Off; default `60`. Raw range `19.9` to `500`; raw default `60`. Applies a low cut (or high pass) filter to the repeats, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 4`, `type: f`): display range `500` to `20100` Hz; default `10300`. Raw range `500` to `20100`; raw default `10300`. Applies a high cut (or low pass) filter to the repeats, letting you remove the effected signal above a certain frequency.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Threshold` (`key: Threshold`, `id: 8`, `type: f`): display range `0` to `100` %; default `49`. Raw range `0` to `1`; raw default `0.49`. Controls the sensitivity of the ducking circuit. Higher values increase the likelihood of ducking to occur.
- `Ducking` (`key: Ducking`, `id: 9`, `type: f`): display range `0` to `100` %; default `61`. Raw range `0` to `1`; raw default `0.61`. Controls the amount of ducking applied. Or rather, how far the repeats drop in volume while playing.
- `Dyn Attack` (`key: DynAttack`, `id: 10`, `type: f`): display range `10` to `2000` ms; default `560`. Raw range `0.01` to `2`; raw default `0.56`. Sets the length of time it takes for ducking to occur (and therefore, repeats to decrease in volume) once you start playing.
- `Dyn Release` (`key: DynRel`, `id: 11`, `type: f`): display range `10` to `5000` ms; default `510`. Raw range `0.01` to `5`; raw default `0.51`. Sets the length of time it takes for ducking to stop (and therefore, repeats to ramp up in volume) once you stop playing.
- `Dynamic Type` (`key: DynType`, `id: 12`, `type: b`): valid values `Ducking`, `Gating`; default `Ducking`. Raw range `Off` to `On`; raw default `Off`. When set to "Ducking," repeats are only heard after you stop playing, which can help maintain note definition. "Gating," inverts the ducking behavior; that is, repeats are only heard while playing, and they're ducked after you stop playing.

- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Dynamic Ambience

- Model key: `VIC\_ReverbDynAmbienceMono`
- Model ID: `104`
- Type: Reverb
- Category: `reverb`
- Class: Spaces
- DSP usage estimate: 5.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Room Size` (`key: RoomSize`, `id: 1`, `type: i`): valid values `8 m`, `10 m`, `12 m`; default `8 m`. Raw range `0` to `2`; raw default `0`. Selects the size of the hall (8, 10, or 12 meters).
- `Predelay` (`key: PreDelay`, `id: 2`, `type: f`): display range `0` to `50` ms; default `5`. Raw range `0` to `0.05`; raw default `0.005`. Controls the amount of delay heard before the signal enters the hall. Can sometimes result in more definition between the dry and effected signals.
- `Damping` (`key: Damping`, `id: 3`, `type: f`): display range `500` to `20000` Hz; default `5000`. Raw range `500` to `20000`; raw default `5000`. Determines the frequency above which the reverb will be absorbed. For example, if your hall is full of people wearing fake ocelot jumpsuits, more high frequencies would be absorbed than if the room were empty.
- `Diffusion` (`key: Diffusion`, `id: 4`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of smearing between discrete echoes, sometimes resulting in a softer effected signal.
- `Shape` (`key: EarlyLateBlend`, `id: 5`, `type: f`): display range `-100` to `100` Early; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the blend of the Early and Late reflections. Turning the knob clockwise adds more Late reflections; turning the knob counterclockwise adds more Early reflections.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the reverb and the dry signal. At 0%, no reverb is heard; at 100%, no dry signal is heard.
- `Low Cut` (`key: LowCut`, `id: 7`, `type: f`): display range `19.9` to `1000` Off; default `100`. Raw range `19.9` to `1000`; raw default `100`. Applies a low cut (or high pass) filter to the reverb, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 8`, `type: f`): display range `1000` to `20100` Hz; default `10000`. Raw range `1000` to `20100`; raw default `10000`. Applies a high cut (or low pass) filter to the reverb, letting you remove the effected signal above a certain frequency.
- `Level` (`key: Level`, `id: 9`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Dynamic Bloom

- Model key: `VIC\_ReverbDynBloomMono`
- Model ID: `500`
- Type: Reverb

- Category: `reverb`
- Class: Spaces
- DSP usage estimate: 14.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Decay` (`key: Decay`, `id: 1`, `type: f`): display range `0.1` to `45.1` ms; default `2`. Raw range `0.1` to `45.1`; raw default `2`. Adjusts the decay of the reverb (0.1 sec ~ 45.0 sec, or Infinity).
- `Damping` (`key: Damping`, `id: 2`, `type: f`): display range `500` to `20000` Hz; default `3720`. Raw range `500` to `20000`; raw default `3720`. Determines the frequency above which the reverb will be absorbed. For example, if your hall is full of people wearing fake ocelot jumpsuits, more high frequencies would be absorbed than if the room were empty.
- `Motion Rate` (`key: MatrFreq`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Motion Rate, or how fast the echoes' intensity changes.
- `Rise Time` (`key: RiseTime`, `id: 4`, `type: i`): valid values `Short`, `Medium`, `Long`; default `Medium`. Raw range `0` to `2`; raw default `1`. Controls how long it takes for the reverb to bloom. Choose Short, Medium (default), or Long.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `40`. Raw range `0` to `1`; raw default `0.4`. Controls the blend between the reverb and the dry signal. At 0%, no reverb is heard; at 100%, no dry signal is heard.
- `Low Freq` (`key: BassFreq`, `id: 6`, `type: f`): display range `20` to `500` Hz; default `100`. Raw range `20` to `500`; raw default `100`. Sets the frequency below which the Low Gain parameter is applied.
- `Low Gain` (`key: BassBoost`, `id: 7`, `type: f`): display range `-15` to `3` dB; default `0`. Raw range `-15` to `3`; raw default `0`. Controls the reverb time for frequencies below the Low Freq value. Values below 0.0 dB mean the bass frequencies decay faster than the treble frequencies; values above 0.0 dB mean the bass frequencies decay slower than the treble frequencies.
- `Low Cut` (`key: LowCut`, `id: 8`, `type: f`): display range `19.9` to `1000` Off; default `100`. Raw range `19.9` to `1000`; raw default `100`. Applies a low cut (or high pass) filter to the reverb, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 9`, `type: f`): display range `1000` to `20100` Hz; default `10000`. Raw range `1000` to `20100`; raw default `10000`. Applies a high cut (or low pass) filter to the reverb, letting you remove the effected signal above a certain frequency.
- `Ducking` (`key: DuckingAmount`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Ducking is applied to the reverb's feedback only, not the entire reverb. For example, if you set Decay high and strum one chord, you'll hear that chord sustain for a long time. While it's ringing out, hit another chord. Without ducking, both chords now sustain together. With Ducking set high, the first chord quickly fades out, and all you'll hear sustaining is the 2nd chord. This can help your bloom from turning into a sloppy mess.
- `Level` (`key: Level`, `id: 11`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Dynamic Hall

- Model key: `VIC\_ReverbRotatingMono`
- Model ID: `499`
- Type: Reverb

- Category: `reverb`
- Class: Spaces
- DSP usage estimate: 8.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Decay` (`key: Decay`, `id: 1`, `type: f`): display range `0.1` to `45.1` ms; default `4`. Raw range `0.1` to `45.1`; raw default `4`. Sets the decay of the reverb (0.1 sec ~ 45.0 sec, or Infinity). TIP: Assign a second stomp switch to toggle between a lower Decay value and Infinity. Label it "ForEVER ever?"
- `Predelay` (`key: Predelay`, `id: 2`, `type: f`): display range `0` to `200` ms; default `50`. Raw range `0` to `0.2`; raw default `0.05`. Controls the amount of delay heard before the audible onset of reverb. Can sometimes result in more definition between the dry and effected signals.
- `Room Size` (`key: RoomSize`, `id: 3`, `type: i`): valid values `10 m`, `20 m`, `30 m`; default `20 m`. Raw range `0` to `2`; raw default `1`. Sets the size of the hall (10, 20, or 30 meters). NOTE: This parameter actually changes the algorithm so you'll hear a small bump when changing it. Therefore, we don't recommend assigning Room Size to snapshots or other controllers.
- `Diffusion` (`key: Diffusion`, `id: 4`, `type: f`): display range `0` to `100` %; default `70`. Raw range `0` to `1`; raw default `0.7`. Sets the amount of smearing between discrete echoes, sometimes resulting in a softer effected signal.
- `Damping` (`key: Damping`, `id: 5`, `type: f`): display range `500` to `20000` Hz; default `3720`. Raw range `500` to `20000`; raw default `3720`. Determines the frequency above which the reverb will be absorbed. For example, if your hall is full of people wearing inflatable sumo wrestler Halloween costumes, more high frequencies would be absorbed than if the room were empty.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `39`. Raw range `0` to `1`; raw default `0.39`. Controls the blend between the reverb and the dry signal. At 0%, no reverb is heard; at 100%, no dry signal is heard.
- `Motion` (`key: Motion`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `2.9`. Raw range `0` to `1`; raw default `0.29`. Sets the amount of randomization, which can be helpful to minimize any metallic artifacts common in static reverbs. At higher values, can impart a bit of modulation to the effected signal.
- `Low Freq` (`key: BassFreq`, `id: 8`, `type: f`): display range `20` to `500` Hz; default `100`. Raw range `20` to `500`; raw default `100`. Sets the frequency below which the Low Gain parameter is applied.
- `Low Gain` (`key: BassBoost`, `id: 9`, `type: f`): display range `-15` to `3` dB; default `0`. Raw range `-15` to `3`; raw default `0`. Controls the reverb time for frequencies below the Low Freq value. Values below 0.0dB mean the bass frequencies decay faster than the treble frequencies; values above 0.0dB mean the bass frequencies decay slower than the treble frequencies.
- `Low Cut` (`key: LowCut`, `id: 10`, `type: f`): display range `19.9` to `1000` Off; default `117`. Raw range `19.9` to `1000`; raw default `117`. Applies a low cut (or high pass) filter to the reverb, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 11`, `type: f`): display range `500` to `20100` Hz; default `6300`. Raw range `500` to `20100`; raw default `6300`. Applies a high cut (or low pass) filter to the reverb, letting you remove the effected signal above a certain frequency.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Dynamic Plate

- Model key: `VIC\_DynPlateMono`
- Model ID: `501`
- Type: Reverb
- Category: `reverb`
- Class: Plate
- DSP usage estimate: 11.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Decay` (`key: Decay`, `id: 1`, `type: f`): display range `0.1` to `45.1` ms; default `2`. Raw range `0.1` to `45.1`; raw default `2`. Adjusts the decay of the reverb (0.1 sec ~ 45.0 sec, or Infinity).
- `Predelay` (`key: PreDelay`, `id: 2`, `type: f`): display range `0` to `100` ms; default `10`. Raw range `0` to `0.1`; raw default `0.01`. Controls the amount of delay heard before the signal enters the plate. Can sometimes result in more definition between the dry and effected signals.
- `Damping` (`key: Damping`, `id: 3`, `type: f`): display range `500` to `20000` Hz; default `3720`. Raw range `500` to `20000`; raw default `3720`. Determines the frequency above which the reverb will be absorbed. For example, if your hall is full of people wearing fake ocelot jumpsuits, more high frequencies would be absorbed than if the room were empty.
- `Motion Rate` (`key: MatrFreq`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls Motion Rate, or how fast the echoes' intensity changes, due to changes in plate tension or temperature.
- `Motion Range` (`key: VarDelayAmpl`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls Motion Range, or how much the internal delays change. Similar to the modulation control on older tank reverbs.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `25`. Raw range `0` to `1`; raw default `0.25`. Controls the blend between the reverb and the dry signal. At 0%, no reverb is heard; at 100%, no dry signal is heard.
- `Low Freq` (`key: BassFreq`, `id: 7`, `type: f`): display range `20` to `500` Hz; default `100`. Raw range `20` to `500`; raw default `100`. Sets the frequency below which the Low Gain parameter is applied.
- `Low Gain` (`key: BassBoost`, `id: 8`, `type: f`): display range `-15` to `3` dB; default `0`. Raw range `-15` to `3`; raw default `0`. Sets the reverb time for frequencies below the Low Freq value. Values below 0.0dB mean the bass frequencies decay faster than the treble frequencies; values above 0.0dB mean the bass frequencies decay slower than the treble frequencies.
- `Low Cut` (`key: LowCut`, `id: 9`, `type: f`): display range `19.9` to `1000` Off; default `100`. Raw range `19.9` to `1000`; raw default `100`. Applies a low cut (or high pass) filter to the reverb, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 10`, `type: f`): display range `1000` to `20100` Hz; default `10000`. Raw range `1000` to `20100`; raw default `10000`. Applies a high cut (or low pass) filter to the reverb, letting you remove the effected signal above a certain frequency.
- `Level` (`key: Level`, `id: 11`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Dynamic Room

- Model key: `VIC\_ReverbDynRoomMono`
- Model ID: `103`
- Type: Reverb
- Category: `reverb`
- Class: Spaces
- DSP usage estimate: 9.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Decay` (`key: Decay`, `id: 1`, `type: f`): display range `0.1` to `3` ms; default `1.2`. Raw range `0.1` to `3`; raw default `1.2`. Adjusts the decay of the reverb (0.1 sec ~ 3.0 sec)
- `Predelay` (`key: PreDelay`, `id: 2`, `type: f`): display range `0` to `100` ms; default `10`. Raw range `0` to `0.1`; raw default `0.01`. Controls the amount of delay heard before the signal enters the room. Can sometimes result in more definition between the dry and effected signals.
- `Damping` (`key: Damping`, `id: 3`, `type: f`): display range `500` to `20000` Hz; default `3720`. Raw range `500` to `20000`; raw default `3720`. Determines the frequency above which the reverb will be absorbed. For example, if your room is full of people wearing foam high school mascot costumes, more high frequencies would be absorbed than if the room were empty.
- `Diffusion` (`key: Diffusion`, `id: 4`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of smearing between discrete echoes, sometimes resulting in a softer effected signal.
- `Motion Rate` (`key: MatrFreq`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3.33`. Raw range `0` to `1`; raw default `0.333`. Controls the Motion Rate, or how quickly the room's shape may be changing, due to people moving, doors opening or closing, etc.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `30`. Raw range `0` to `1`; raw default `0.3`. Controls the blend between the reverb and the dry signal. At 0%, no reverb is heard; at 100%, no dry signal is heard.
- `Low Freq` (`key: BassFreq`, `id: 7`, `type: f`): display range `20` to `500` Hz; default `100`. Raw range `20` to `500`; raw default `100`. Sets the frequency below which the Low Gain parameter is applied.
- `Low Gain` (`key: BassBoost`, `id: 8`, `type: f`): display range `-15` to `3` dB; default `0`. Raw range `-15` to `3`; raw default `0`. Controls the reverb time for frequencies below the Low Freq value. Values below 0.0 dB mean the bass frequencies decay faster than the treble frequencies; values above 0.0 dB mean the bass frequencies decay slower than the treble frequencies.
- `Low Cut` (`key: LowCut`, `id: 9`, `type: f`): display range `19.9` to `1000` Off; default `100`. Raw range `19.9` to `1000`; raw default `100`. Applies a low cut (or high pass) filter to the reverb, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 10`, `type: f`): display range `1000` to `20100` Hz; default `10000`. Raw range `1000` to `20100`; raw default `10000`. Applies a high cut (or low pass) filter to the reverb, letting you remove the effected signal above a certain frequency.
- `Early Reflections` (`key: ERLevel`, `id: 11`, `type: f`): display range `0` to `2` unitless; default `0.8`. Raw range `0` to `2`; raw default `0.8`. Controls the amount of early reflective room sound.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Elephant Man

- Model key: `HD2\_DelayElephantManMono`
- Model ID: `129`
- Type: Delay
- Category: `delay`
- Class: Analog
- DSP usage estimate: 3.7
- Based on: Electro-Harmonix Deluxe Memory Man
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `20` to `500` ms; default `375`. Raw range `0.02` to `0.5`; raw default `0.375`. Adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo. IMPORTANT! The original pedal's delay time was limited to 500 ms, so depending on the tempo, your repeats may appear twice as fast.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `39`. Raw range `0` to `1`; raw default `0.39`. Controls the number of delay repeats. When set to 0%, only one repeat is heard. At high values, the Delay may begin to self-oscillate and squeal (perhaps in a good way).
- `Mode` (`key: Mode`, `id: 3`, `type: b`): valid values `Chorus`, `Vibrato`; default `Chorus`. Raw range `Off` to `On`; raw default `Off`. Selects the type of modulation applied to the repeats--Chorus or Vibrato.
- `Depth` (`key: Depth`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Controls the depth or intensity of the modulation applied to the repeats.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Noise` (`key: Noise`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `1`. Raw range `0` to `1`; raw default `0.1`. Adds subtle graininess to the repeats, which is inherent in many bucket brigade delays.
- `Headroom` (`key: Headroom`, `id: 8`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Some delay pedals' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative values increase the perceived amount of grit; positive values clean things up a bit.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Euclidean Delay

- Model key: `EuclideanDelayMono\_Victoria`
- Model ID: `105`
- Type: Delay
- Category: `delay`
- Class: Digital
- DSP usage estimate: 3.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Step Time` (`key: Step Time`, `id: 1`, `type: f`): display range `0` to `500` ms; default `136`. Raw range `0` to `0.5`; raw default `0.136`. Sets the time between steps. The total delay time is Time x Steps, so [Time: 1/16 x Steps: 8] is a 1/2-note. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Controls the overall number of repeats heard for the entire sequence. If you want to hear all fills in the sequence only once, set to 0%.
- `Steps` (`key: Steps`, `id: 3`, `type: i`): display range `1` to `16` unitless; default `8`. Raw range `1` to `16`; raw default `8`. Determines the number of steps in the sequence, from 1 to 16.
- `Fill` (`key: Fill`, `id: 4`, `type: i`): display range `1` to `16` unitless; default `3`. Raw range `1` to `16`; raw default `3`. Controls the number of active taps (from 1 to 16), whose spacing is set by Euclidean algorithms. If Fill is higher than Steps, the extra taps are ignored.
- `Rotate` (`key: Rotate`, `id: 5`, `type: i`): display range `0` to `15` unitless; default `0`. Raw range `0` to `15`; raw default `0`. Rotates all fills forward by the same amount (0-15). Used if you like the sound of a repeat pattern but want the fills and gaps shifted forward.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `42.2`. Raw range `0` to `1`; raw default `0.422`. Controls the blend between the delay sequence and the dry signal. At 0%, no delay sequence is heard; at 100%, no dry signal is heard.
- `Low Cut` (`key: LowCut`, `id: 7`, `type: f`): display range `19.9` to `500` Off; default `80`. Raw range `19.9` to `500`; raw default `80`. Applies a low cut (high pass) filter to the fills, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 8`, `type: f`): display range `500` to `20100` Hz; default `20000`. Raw range `500` to `20100`; raw default `20000`. Applies a high cut (low pass) filter to the fills, letting you remove the effected signal above a certain frequency.
- `Level` (`key: Level`, `id: 9`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

EuclideanDelayStereo_Victoria

- Model key: `EuclideanDelayStereo\_Victoria`
- Model ID: `44`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 4.8
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

Ganymede

- Model key: `HD2\_ReverbGanymedeMono`
- Model ID: `101`
- Type: Reverb
- Category: `reverb`

- Class: Spaces
- DSP usage estimate: 3.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Decay` (`key: Decay`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adjusts the decay time of the reverb effect.
- `Predelay` (`key: Predelay`, `id: 2`, `type: f`): display range `0` to `200` ms; default `40`. Raw range `0` to `0.2`; raw default `0.04`. Controls the amount of delay heard before the audible onset of reverb. Can sometimes result in more definition between the dry and effected signals.
- `Tone` (`key: Tone`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the tonal balance of the reverb. Lower values are darker, higher values are brighter.
- `Modulation` (`key: Modulation`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the amount of modulation applied to the reverb.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `35`. Raw range `0` to `1`; raw default `0.35`. Controls the blend between the reverb and the dry signal. At 0%, no reverb is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Glitch Delay

- Model key: `VIC\_DelayGlitchMono`
- Model ID: `108`
- Type: Delay
- Category: `delay`
- Class: Special FX
- DSP usage estimate: 2.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `100` to `4000` ms; default `1000`. Raw range `0.1` to `4`; raw default `1`. Adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo.
- `Delay Div` (`key: Delay Div`, `id: 2`, `type: i`): display range `1` to `16` unitless; default `4`. Raw range `1` to `16`; raw default `4`. Divides the delay time into smaller increments.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `40`. Raw range `0` to `1`; raw default `0.4`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Feedback` (`key: Feedback`, `id: 4`, `type: f`): display range `0` to `100` %; default `30`. Raw range `0` to `1`; raw default `0.3`. Controls the overall number of repeats heard for the entire sequence.
- `Slice Fdbk` (`key: SliceFdbk`, `id: 5`, `type: f`): display range `0` to `100` %; default `10`. Raw range `0` to `1`; raw default `0.1`. Controls the number of repeats heard for individual slices. At higher values, you could call this "Super Chaotic Feedback."

- `Shuffle` (`key: Shuffle`, `id: 6`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Determines the likelihood of repeats shuffling/reordering. At 0%, repeats won't shuffle at all; at 100% all repeats will shuffle.
- `Pitch` (`key: Pitch`, `id: 7`, `type: f`): display range `0` to `100` %; default `10`. Raw range `0` to `1`; raw default `0.1`. Determines the likelihood of repeats playing back an interval higher or lower.
- `Reverse` (`key: Reverse`, `id: 8`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Determines the likelihood of repeats playing backward. At 0%, all repeats play forward. At 100%, all repeats play backward.
- `Seq Drift` (`key: Seq Drift`, `id: 9`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Determines the likelihood of the entire sequence changing every time it loops around. At 0%, the same sequence loops forever.
- `Smoothing` (`key: Smoothing`, `id: 10`, `type: f`): display range `0` to `50` %; default `10`. Raw range `0` to `0.5`; raw default `0.1`. Higher values apply smoothing between slices and can give a synth-pad type quality; lower values maintain transients. Or set it just high enough to avoid pops and clicks.
- `Interval 1` (`key: Interval 1`, `id: 11`, `type: i`): display range `-12` to `12` unitless; default `-12`. Raw range `-12` to `12`; raw default `-12`. Sets the pitch of some repeats, the likelihood of which is determined by the Pitch parameter (from an octave down to an octave up).
- `Interval 2` (`key: Interval 2`, `id: 12`, `type: i`): display range `-12` to `12` unitless; default `12`. Raw range `-12` to `12`; raw default `12`. Sets the pitch of other repeats, the likelihood of which is determined by the Pitch parameter (from an octave down to an octave up).
- `Low Cut` (`key: Low Cut`, `id: 13`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (or high pass) filter to the slices, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: High Cut`, `id: 14`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (or low pass) filter to the slices, letting you remove the effected signal above a certain frequency.
- `Level` (`key: Level`, `id: 15`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Glitz

- Model key: `HD2\_ReverbGlitzMono`
- Model ID: `100`
- Type: Reverb
- Category: `reverb`
- Class: Spaces
- DSP usage estimate: 5.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Decay` (`key: Decay`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Adjusts the decay time of the reverb effect.
- `Predelay` (`key: Predelay`, `id: 2`, `type: f`): display range `0` to `200` ms; default `10`. Raw range `0` to `0.2`; raw default `0.01`. Controls the amount of delay heard before the audible onset of reverb. Can sometimes result in more definition between the dry and

effected signals.

- `Low Cut` (`key: LowCut`, `id: 3`, `type: f`): display range `19.9` to `500` Off; default `118`. Raw range `19.9` to `500`; raw default `118`. Applies a low cut (or high pass) filter to the reverb, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 4`, `type: f`): display range `500` to `20100` Hz; default `8000`. Raw range `500` to `20100`; raw default `8000`. Applies a high cut (or low pass) filter to the reverb, letting you remove the effected signal above a certain frequency.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `19`. Raw range `0` to `1`; raw default `0.19`. Controls the blend between the reverb and the dry signal. At 0%, no reverb is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Delay` (`key: Delay`, `id: 7`, `type: f`): display range `1` to `200` ms; default `44`. Raw range `0.001` to `0.2`; raw default `0.044`. Adjusts the time before the second modulation is applied to the reverb.
- `Rate` (`key: Rate`, `id: 8`, `type: f`): display range `0.1` to `8` Hz; default `1.8`. Raw range `0.1` to `8`; raw default `1.8`. Controls the speed of modulation applied to the reverb.
- `Depth` (`key: Depth`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Controls the depth of modulation applied to the reverb.
- `Xover` (`key: Xover`, `id: 10`, `type: f`): display range `100` to `10000` Hz; default `866`. Raw range `100` to `10000`; raw default `866`. Determines the frequencies above which the second modulation is applied. Frequencies below this value are only affected by the first modulation.
- `Mod Mix` (`key: Mod Mix`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the blend of reverb with and without the second modulation.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

HD2_DelayADTStereo

- Model key: `HD2\_DelayADTStereo`
- Model ID: `95`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 9.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayAdriaticDelayStereo

- Model key: `HD2\_DelayAdriaticDelayStereo`
- Model ID: `93`
- Type: Delay
- Category: `delay`
- Class: Unknown

- DSP usage estimate: 5.9
- Based on: BOSS DM-2 w/Adrian mod
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayBucketBrigadeStereo

- Model key: `HD2\_DelayBucketBrigadeStereo`
- Model ID: `92`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 5.3
- Based on: BOSS DM-2
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayCosmosEchoStereo

- Model key: `HD2\_DelayCosmosEchoStereo`
- Model ID: `91`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 10.8
- Based on: Roland RE-201 Space Echo
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayCrissCrossStereo

- Model key: `HD2\_DelayCrissCrossStereo`
- Model ID: `90`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 5.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayDuckedDelayStereo

- Model key: `HD2\_DelayDuckedDelayStereo`
- Model ID: `86`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 2.8
- Based on: TC Electronic 2290
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayElephantManStereo

- Model key: `HD2\_DelayElephantManStereo`
- Model ID: `94`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 5.7
- Based on: Electro-Harmonix Deluxe Memory Man
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayHeliosphereStereo

- Model key: `HD2\_DelayHeliosphereStereo`
- Model ID: `493`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 8.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayModChorusEchoStereo

- Model key: `HD2\_DelayModChorusEchoStereo`
- Model ID: `88`

- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 3.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayMultiPassStereo

- Model key: `HD2\_DelayMultiPassStereo`
- Model ID: `84`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 3.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayPitchStereo

- Model key: `HD2\_DelayPitchStereo`
- Model ID: `492`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 7.4
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayReverseDelayStereo

- Model key: `HD2\_DelayReverseDelayStereo`
- Model ID: `82`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 4.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelaySimpleDelayStereo

- Model key: `HD2\_DelaySimpleDelayStereo`
- Model ID: `87`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 2.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelaySweepEchoStereo

- Model key: `HD2\_DelaySweepEchoStereo`
- Model ID: `80`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 5.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelaySwellAdriaticStereo

- Model key: `HD2\_DelaySwellAdriaticStereo`
- Model ID: `79`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 6.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelaySwellVintageDigitalStereo

- Model key: `HD2\_DelaySwellVintageDigitalStereo`
- Model ID: `78`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 5.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayTransistorTapeStereo

- Model key: `HD2\_DelayTransistorTapeStereo`
- Model ID: `77`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 5.3
- Based on: Maestro Echoplex EP-3
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayVintageDigitalStereoV2

- Model key: `HD2\_DelayVintageDigitalStereoV2`
- Model ID: `76`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 4.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_ReverbDoubleTankStereo

- Model key: `HD2\_ReverbDoubleTankStereo`
- Model ID: `75`
- Type: Reverb
- Category: `reverb`
- Class: Unknown
- DSP usage estimate: 7.7

- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_ReverbGanymedeStereo

- Model key: `HD2\_ReverbGanymedeStereo`
- Model ID: `74`
- Type: Reverb
- Category: `reverb`
- Class: Unknown
- DSP usage estimate: 5.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_ReverbGlitzStereo

- Model key: `HD2\_ReverbGlitzStereo`
- Model ID: `73`
- Type: Reverb
- Category: `reverb`
- Class: Unknown
- DSP usage estimate: 6.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_ReverbHxSpringStereo

- Model key: `HD2\_ReverbHxSpringStereo`
- Model ID: `490`
- Type: Reverb
- Category: `reverb`
- Class: Unknown
- DSP usage estimate: 7.6
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_ReverbNonLinearStereo

- Model key: `HD2\_ReverbNonLinearStereo`
- Model ID: `489`
- Type: Reverb
- Category: `reverb`
- Class: Unknown
- DSP usage estimate: 9.7
- Based on: Unknown
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_ReverbPlateauxStereo

- Model key: `HD2\_ReverbPlateauxStereo`
- Model ID: `70`
- Type: Reverb
- Category: `reverb`
- Class: Unknown
- DSP usage estimate: 6.6
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_ReverbSearchlightsStereo

- Model key: `HD2\_ReverbSearchlightsStereo`
- Model ID: `61`
- Type: Reverb
- Category: `reverb`
- Class: Unknown
- DSP usage estimate: 7.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

Harmony Delay

- Model key: `HD2\_DelayHarmonyDelayStereo`
- Model ID: `491`
- Type: Delay

- Category: `delay`
- Class: Digital
- DSP usage estimate: 9.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `2000` ms; default `750`. Raw range `0` to `2`; raw default `0.75`. Adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Feedback controls the number of repeated pitch sequences. When set to 0%, the two voice/harmony repeats are heard only once, followed by the root note again. At higher values, the three note sequence (root, voice/harmony 1, and voice/harmony 2) cycle repeatedly.
- `Key` (`key: Key`, `id: 3`, `type: i`): valid values `A`, `A#`, `B`, `C`, `C#`, `D`, `D#`, `E`, `F`, `F#`, `G`, `G#`; default `A`. Raw range `0` to `11`; raw default `0`. Along with Scale, specifies the scale reference for V1 Shift and V2 Shift values. For example, if you choose D Minor and then PLAY IN D MINOR (Harmony Delay can't fix bad notes), V1 Shift and V2 Shift will always shift your repeats to pitches in that scale.
- `Scale` (`key: Scale`, `id: 4`, `type: i`): valid values `Major`, `Minor`, `Major Pent`, `Minor Pent`, `Harm Minor`, `Melodic Minor`, `Whole Tone`, `Whole Dim`; default `Major`. Raw range `0` to `7`; raw default `0`. Along with Key, specifies the scale reference for V1 Shift and V2 Shift values. For example, if you choose D Minor and then PLAY IN D MINOR (Harmony Delay can't fix wrong notes), V1 Shift and V2 Shift will shift your repeats to pitches in that scale.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Voice 1 Shift` (`key: IntervalVoice1`, `id: 7`, `type: i`): display range `-8` to `8` unitless; default `2`. Raw range `-8` to `8`; raw default `2`. Selects voice/harmony 1's note in the specified Key. For example, if Key is set to "D" and Scale is set to "Minor" (which I always find is the saddest of all keys), setting V1 Shift to +3 will repeat an F (or the third note above D in the D minor scale).
- `Voice 1 Level` (`key: LevelVoice1`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of the voice/harmony 1 repeats.
- `Voice 1 Pan` (`key: PanVoice1`, `id: 9`, `type: f`): display range `-100` to `100` Left; default `0.25`. Raw range `0` to `1`; raw default `0.25`. Controls the panning of the voice/harmony 1 repeats between the left and right channels.
- `Voice 2 Shift` (`key: IntervalVoice2`, `id: 10`, `type: i`): display range `-8` to `8` unitless; default `4`. Raw range `-8` to `8`; raw default `4`. Selects voice/harmony 2's note in the specified Key. For example, if Key is set to "D" and Scale is set to "Minor" (which I always find is the saddest of all keys), setting V2 Shift to -2 will repeat a Bb (or the second note below D in the D minor scale).
- `Voice 2 Level` (`key: LevelVoice2`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of the voice/harmony 2 repeats.
- `Voice 2 Pan` (`key: PanVoice2`, `id: 12`, `type: f`): display range `-100` to `100` Left; default `0.75`. Raw range `0` to `1`; raw default `0.75`. Controls the panning of the voice/harmony 2 repeats between the left and right channels.
- `Voice 1 Scale` (`key: DelayVoice1`, `id: 13`, `type: f`): display range `0` to `100` %; default `33`. Raw range `0` to `1`; raw default `0.33`. Voice/harmony 1's delay time is always some percentage of the root note's time (controlled via Time), and is determined by the V1 Scale parameter. For example, if Time is set to 800 ms and V1 Scale is set to 75%,

voice/harmony 1's delay is 600 ms (or 75% of 800 ms). When scale is set to 100%, voice/harmony 1 and root delays are the same.

- `Voice 2 Scale` (`key: DelayVoice2`, `id: 14`, `type: f`): display range `0` to `100` %; default `66`. Raw range `0` to `1`; raw default `0.66`. Voice/harmony 2's delay time is always some percentage of the root note's time (controlled via Time), and is determined by the V2 Scale parameter. For example, if Time is set to 800 ms and V2 Scale is set to 25%, voice/harmony 2's delay is 200 ms (or 25% of 800 ms). When scale is set to 100%, voice/harmony 2 and root delays are the same.
- `Root Level` (`key: LevelRootVoice`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of the root (unpitched) repeats. If you only want to hear the harmony repeats, set Root Level to 0.0.
- `Root Pan` (`key: PanRootVoice`, `id: 16`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of the root (unpitched) repeats between the left and right channels.
- `Low Cut` (`key: LowCut`, `id: 17`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter to the repeats, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 18`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter to the repeats, letting you remove the effected signal above a certain frequency.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Heliosphere

- Model key: `HD2\_DelayHeliosphereMono`
- Model ID: `503`
- Type: Delay
- Category: `delay`
- Class: Special FX
- DSP usage estimate: 4.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `4000` ms; default `800`. Raw range `0` to `4`; raw default `0.8`. Adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `85`. Raw range `0` to `1`; raw default `0.85`. Controls the number of delay repeats. When set to 0%, only one repeat is heard.
- `Rate` (`key: Rate`, `id: 3`, `type: f`): display range `0.1` to `8` Hz; default `0.1`. Raw range `0.1` to `8`; raw default `0.1`. Controls the rate or speed of modulation in the effected signal.
- `Depth` (`key: Depth`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.42`. Raw range `0` to `1`; raw default `0.442`. Controls the depth or amount of modulation.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `45`. Raw range `0` to `1`; raw default `0.45`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Reverb Mix` (`key: VerbMix`, `id: 7`, `type: f`): display range `0` to `100` %; default

`50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the reverb and the dry signal inside the delay's feedback loop. At 0%, no reverb is heard.

- `Reverb Decay` (`key: VerbDecay`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the decay of the reverb inside the delay's feedback loop.
- `Headroom` (`key: Headroom`, `id: 9`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Some delay pedals' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative values increase the perceived amount of grit; positive values clean things up a bit.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Hot Springs

- Model key: `HD2\_ReverbHxSpringMono`
- Model ID: `497`
- Type: Reverb
- Category: `reverb`
- Class: Spring
- DSP usage estimate: 7.6
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Dwell` (`key: Dwell`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the strength of the signal sent into the spring tank. Higher values result in a longer decay.
- `Spring Count` (`key: Spring Count`, `id: 2`, `type: f`): display range `1` to `3` unitless; default `2`. Raw range `1` to `3`; raw default `2`. Selects how many springs are in the tank (1, 2, or 3, and numerous values in between).
- `Drip` (`key: Drip`, `id: 3`, `type: i`): valid values `Low`, `Medium`, `High`; default `Medium`. Raw range `0` to `2`; raw default `1`. Adjusts the intensity of the spring reverb, or how much "ploink" you might hear.
- `Low Cut` (`key: LowCut`, `id: 4`, `type: f`): display range `19.9` to `500` Off; default `200`. Raw range `19.9` to `500`; raw default `200`. Applies a low cut (or high pass) filter to the reverb, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 5`, `type: f`): display range `500` to `20100` Hz; default `5000`. Raw range `500` to `20100`; raw default `5000`. Applies a high cut (or low pass) filter to the reverb, letting you remove the effected signal above a certain frequency.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `37`. Raw range `0` to `1`; raw default `0.37`. Controls the blend between the reverb and the dry signal. At 0%, no reverb is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 7`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Mod/Chorus Echo

- Model key: `HD2\_DelayModChorusEchoMono`
- Model ID: `124`
- Type: Delay

- Category: `delay`
- Class: Analog
- DSP usage estimate: 2.4
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `8000` ms; default `362`. Raw range `0` to `8`; raw default `0.362`. Adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `28.0`. Raw range `0` to `1`; raw default `0.28`. Controls the number of delay repeats. When set to 0%, only one repeat is heard; at 100%, the delay repeats forever.
- `Low Cut` (`key: LowCut`, `id: 3`, `type: f`): display range `19.9` to `500` Off; default `155`. Raw range `19.9` to `500`; raw default `155`. Applies a low cut (or high pass) filter to the repeats, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 4`, `type: f`): display range `500` to `20100` Hz; default `9540`. Raw range `500` to `20100`; raw default `9540`. Applies a high cut (or low pass) filter to the repeats, letting you remove the effected signal above a certain frequency.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `45`. Raw range `0` to `1`; raw default `0.45`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Mod Mode` (`key: ModulationMode`, `id: 9`, `type: i`): valid values `Off`, `Chorus`, `Vibrato`; default `Chorus`. Raw range `0` to `2`; raw default `1`. Selects the type of modulation applied to the repeats--None (Off), Chorus, or Vibrato.
- `Speed` (`key: Speed`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `0.22`. Raw range `0` to `1`; raw default `0.022`. Controls the speed or rate of the modulation applied to the repeats.
- `Depth` (`key: Depth`, `id: 8`, `type: f`): display range `0` to `100` %; default `49`. Raw range `0` to `1`; raw default `0.49`. Controls the depth or intensity of the modulation applied to the repeats.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Multi Pass

- Model key: `HD2\_DelayMultiPassMono`
- Model ID: `122`
- Type: Delay
- Category: `delay`
- Class: Special FX
- DSP usage estimate: 2.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `4000` ms; default `1200`. Raw range `0` to `4`; raw default `1.2`. Adjusts the length of the entire 6-tap delay pattern. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `45`. Raw range `0` to `1`; raw default `0.45`. Controls how many times the 6-tap delay

pattern repeats. When set to 0%, the pattern is heard only once; at 100%, the pattern cycles forever.

- `Pattern` (`key: Pattern`, `id: 3`, `type: i`): valid values `1`, `2`, `3`, `4`, `5`, `6`, `7`, `8`; default `1`. Raw range `0` to `7`; raw default `0`. Selects one of 8 preset patterns, all utilizing different sequences of filters. Experiment to see which pattern sounds the best for your application.
- `Mode` (`key: Mode`, `id: 4`, `type: b`): valid values `Delay`, `Echo`; default `Delay`. Raw range `Off` to `On`; raw default `Off`. Determines the type of repeat mode. "Delay" results in cleaner rhythmic patterns, with the same pattern repeating every sequence. "Echo" applies delays within the pattern itself, creating more of a sea of echoes, especially when Feedback is set high.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Multitap 4

- Model key: `HD2\_DelayMultitap4Stereo`
- Model ID: `85`
- Type: Delay
- Category: `delay`
- Class: Multitap
- DSP usage estimate: 5.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `4000` ms; default `1000`. Raw range `0` to `4`; raw default `1`. Adjusts the length of time for the 4-tap delay sequence to repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls how many times the 4-tap delay sequence repeats. When set to 0%, the sequence is heard only once. At high values, the delay taps may begin to self-oscillate.
- `Diffusion` (`key: Diffusion`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the amount of smearing between discrete echoes, sometimes resulting in a softer, less percussive repeats.
- `Low Cut` (`key: LowCut`, `id: 4`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (or high pass) filter to the repeats, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 5`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (or low pass) filter to the repeats, letting you remove the effected signal above a certain frequency.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `43`. Raw range `0` to `1`; raw default `0.43`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Tap 1 Scale` (`key: Tap1Delay`, `id: 7`, `type: f`): display range `0` to `100` %; default `24`. Raw range `0` to `1`; raw default `0.24`. For multitap delays, each tap's time is some percentage of the master Time parameter. For example, if Time is set to 500 ms, and T1 Scale is set to 25%, tap 1's delay is 125ms (or 25% of 500 ms).

- `Tap 1 Pan` (`key: Tap1Pan`, `id: 8`, `type: f`): display range `-100` to `100` Left; default `0`. Raw range `0` to `1`; raw default `0`. Controls the panning of delay tap 1 between the left and right channels.
- `Tap 1 Level` (`key: Tap1Level`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of delay tap 1. To mute a tap, set its Level to 0.0.
- `Tap 2 Scale` (`key: Tap2Delay`, `id: 10`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. For multitap delays, each tap's time is some percentage of the master Time parameter. For example, if Time is set to 500 ms, and T2 Scale is set to 50%, tap 2's delay is 250ms (or 50% of 500 ms).
- `Tap 2 Pan` (`key: Tap2Pan`, `id: 11`, `type: f`): display range `-100` to `100` Left; default `0.33`. Raw range `0` to `1`; raw default `0.33`. Controls the panning of delay tap 2 between the left and right channels.
- `Tap 2 Level` (`key: Tap2Level`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of delay tap 2. To mute a tap, set its Level to 0.0.
- `Tap 3 Scale` (`key: Tap3Delay`, `id: 13`, `type: f`): display range `0` to `100` %; default `75`. Raw range `0` to `1`; raw default `0.75`. For multitap delays, each tap's time is some percentage of the master Time parameter. For example, if Time is set to 500 ms, and T3 Scale is set to 75%, tap 3's delay is 375ms (or 75% of 500 ms).
- `Tap 3 Pan` (`key: Tap3Pan`, `id: 14`, `type: f`): display range `-100` to `100` Left; default `0.66`. Raw range `0` to `1`; raw default `0.66`. Controls the panning of delay tap 3 between the left and right channels.
- `Tap 3 Level` (`key: Tap3Level`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of delay tap 3. To mute a tap, set its Level to 0.0.
- `Tap 4 Scale` (`key: Tap4Delay`, `id: 16`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. For multitap delays, each tap's time is some percentage of the master Time parameter. For example, if Time is set to 500 ms, and T4 Scale is set to 100%, tap 4's delay is also 500ms (or 100% of 500 ms).
- `Tap 4 Pan` (`key: Tap4Pan`, `id: 17`, `type: f`): display range `-100` to `100` Left; default `1`. Raw range `0` to `1`; raw default `1`. Controls the panning of delay tap 4 between the left and right channels.
- `Tap 4 Level` (`key: Tap4Level`, `id: 18`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of delay tap 4. To mute a tap, set its Level to 0.0.
- `Mod Mode` (`key: ModulationMode`, `id: 19`, `type: i`): valid values `Off`, `Chorus`, `Vibrato`; default `Chorus`. Raw range `0` to `2`; raw default `1`. Selects the type of modulation applied to the repeats--None (Off), Chorus, or Vibrato.
- `Rate` (`key: Speed`, `id: 20`, `type: f`): display range `0` to `10` unitless; default `1`. Raw range `0` to `1`; raw default `0.1`. Controls the speed or rate of the modulation applied to the repeats.
- `Depth` (`key: Depth`, `id: 21`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Controls the depth or intensity of the modulation applied to the repeats.
- `Spread` (`key: Spread`, `id: 22`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Subtly controls the apparent stereo width of the modulation.
- `Level` (`key: Level`, `id: 23`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Multitap 6

- Model key: `HD2\_DelayMultitap6Stereo`

- Model ID: `81`
- Type: Delay
- Category: `delay`
- Class: Multitap
- DSP usage estimate: 3.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `4000` ms; default `1000`. Raw range `0` to `4`; raw default `1`. Adjusts the length of time for the 6-tap delay sequence to repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `43`. Raw range `0` to `1`; raw default `0.43`. Controls how many times the 6-tap delay sequence repeats. When set to 0%, the sequence is heard only once; at 100%, the sequence cycles forever.
- `Low Cut` (`key: LowCut`, `id: 3`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (or high pass) filter to the repeats, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 4`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (or low pass) filter to the repeats, letting you remove the effected signal above a certain frequency.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `40`. Raw range `0` to `1`; raw default `0.4`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Tap 1 Scale` (`key: Tap1Delay`, `id: 7`, `type: f`): display range `0` to `100` %; default `10`. Raw range `0` to `1`; raw default `0.1`. For multitap delays, each tap's time is some percentage of the master Time parameter. For example, if Time is set to 1.000 second, and T1 Scale is set to 10%, tap 1's delay is 100ms (or 10% of 1.000 second).
- `Tap 1 Pan` (`key: Tap1Pan`, `id: 8`, `type: f`): display range `-100` to `100` Left; default `0.333`. Raw range `0` to `1`; raw default `0.333`. Controls the panning of delay tap 1 between the left and right channels.
- `Tap 1 Level` (`key: Tap1Level`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of delay tap 1. To mute a tap, set its Level to 0.0.
- `Tap 2 Scale` (`key: Tap2Delay`, `id: 10`, `type: f`): display range `0` to `100` %; default `30`. Raw range `0` to `1`; raw default `0.3`. For multitap delays, each tap's time is some percentage of the master Time parameter. For example, if Time is set to 1.000 second, and T2 Scale is set to 30%, tap 2's delay is 300ms (or 30% of 1.000 second).
- `Tap 2 Pan` (`key: Tap2Pan`, `id: 11`, `type: f`): display range `-100` to `100` Left; default `0.666`. Raw range `0` to `1`; raw default `0.666`. Controls the panning of delay tap 2 between the left and right channels.
- `Tap 2 Level` (`key: Tap2Level`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of delay tap 2. To mute a tap, set its Level to 0.0.
- `Tap 3 Scale` (`key: Tap3Delay`, `id: 13`, `type: f`): display range `0` to `100` %; default `40`. Raw range `0` to `1`; raw default `0.4`. For multitap delays, each tap's time is some percentage of the master Time parameter. For example, if Time is set to 1.000 second, and T3 Scale is set to 40%, tap 3's delay is 400ms (or 40% of 1.000 second).
- `Tap 3 Pan` (`key: Tap3Pan`, `id: 14`, `type: f`): display range `-100` to `100` Left; default `0.166`. Raw range `0` to `1`; raw default `0.166`. Controls the panning of delay tap 3 between the left and right channels.
- `Tap 3 Level` (`key: Tap3Level`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of delay tap 3. To

mute a tap, set its Level to 0.0.

- `Tap 4 Scale` (`key: Tap4Delay`, `id: 16`, `type: f`): display range `0` to `100` %; default `60`. Raw range `0` to `1`; raw default `0.6`. For multitap delays, each tap's time is some percentage of the master Time parameter. For example, if Time is set to 1.000 second, and T4 Scale is set to 60%, tap 4's delay is 600ms (or 60% of 1.000 second).
- `Tap 4 Pan` (`key: Tap4Pan`, `id: 17`, `type: f`): display range `-100` to `100` Left; default `0.666`. Raw range `0` to `1`; raw default `0.666`. Controls the panning of delay tap 4 between the left and right channels.
- `Tap 4 Level` (`key: Tap4Level`, `id: 18`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of delay tap 4. To mute a tap, set its Level to 0.0.
- `Tap 5 Scale` (`key: Tap5Delay`, `id: 19`, `type: f`): display range `0` to `100` %; default `82.2`. Raw range `0` to `1`; raw default `0.822`. For multitap delays, each tap's time is some percentage of the master Time parameter. For example, if Time is set to 1.000 second, and T5 Scale is set to 82%, tap 5's delay is 820ms (or 82% of 1.000 second).
- `Tap 5 Pan` (`key: Tap5Pan`, `id: 20`, `type: f`): display range `-100` to `100` Left; default `0`. Raw range `0` to `1`; raw default `0`. Controls the panning of delay tap 5 between the left and right channels.
- `Tap 5 Level` (`key: Tap5Level`, `id: 21`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of delay tap 5. To mute a tap, set its Level to 0.0.
- `Tap 6 Scale` (`key: Tap6Delay`, `id: 22`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. For multitap delays, each tap's time is some percentage of the master Time parameter. For example, if Time is set to 1.000 second, and T6 Scale is set to 100%, tap 6's delay is also 1.000 second (or 100% of 1.000 second).
- `Tap 6 Pan` (`key: Tap6Pan`, `id: 23`, `type: f`): display range `-100` to `100` Left; default `1`. Raw range `0` to `1`; raw default `1`. Controls the panning of delay tap 6 between the left and right channels.
- `Tap 6 Level` (`key: Tap6Level`, `id: 24`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of delay tap 6. To mute a tap, set its Level to 0.0.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Nonlinear

- Model key: `HD2\_ReverbNonLinearMono`
- Model ID: `496`
- Type: Reverb
- Category: `reverb`
- Class: Spaces
- DSP usage estimate: 9.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Decay` (`key: Decay`, `id: 1`, `type: f`): display range `50` to `2000` ms; default `1000`. Raw range `0.05` to `2`; raw default `1`. Sets the decay of the reverb (1.0 ms ~ 2.000 sec). TIP: When set to note values, playing a note/chord 4 beats (Decay set to 1/1) or 2 beats (Decay set to 1/2) before a song transition can cause the reverb to stop right on the downbeat.
- `Predelay` (`key: Predelay`, `id: 2`, `type: f`): display range `0` to `500` ms; default `0`. Raw range `0` to `0.5`; raw default `0`. Controls the amount of delay heard before the audible onset of reverb. Can sometimes result in more definition between the dry and

effected signals.

- `Shape` (`key: Shape`, `id: 3`, `type: i`): valid values `Linear`, `Log`, `Inv Log`, `Gauss`, `Inv Gauss`, `Triangle`, `Inv Triangle`, `Full`; default `Log`. Raw range `0` to `7`; raw default `1`. Determines the shape of the reverb's decay. Gauss and Triangle shapes ramp up and then down, Inverse Gauss and Inverse Triangle shapes ramp down and then up, and Full doesn't ramp at all--the reverb is on full blast until the decay length is reached.
- `Late Dry` (`key: Late Dry`, `id: 4`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Adds a bit of the original signal as the very last tap. Most audible when playing simple lines with gaussian and triangle shapes.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the reverb and the dry signal. At 0%, no reverb is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Diffusion` (`key: Diffusion`, `id: 7`, `type: f`): display range `0` to `100` %; default `88`. Raw range `0` to `1`; raw default `0.88`. Controls the amount of smearing between discrete echoes, sometimes resulting in a softer effected signal.
- `Low Cut` (`key: LowCut`, `id: 8`, `type: f`): display range `19.9` to `500` Off; default `80`. Raw range `19.9` to `500`; raw default `80`. Applies a low cut (or high pass) filter to the reverb, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 9`, `type: f`): display range `500` to `20100` Hz; default `8600`. Raw range `500` to `20100`; raw default `8600`. Applies a high cut (or low pass) filter to the reverb, letting you remove the effected signal above a certain frequency.
- `Mod` (`key: Mod`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of modulation applied to the reverb.
- `Rate` (`key: Rate`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `0.66`. Raw range `0` to `1`; raw default `0.066`. Controls the rate or speed of modulation applied to the reverb.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Ping Pong

- Model key: `HD2\_DelayPingPongStereo`
- Model ID: `83`
- Type: Delay
- Category: `delay`
- Class: Digital
- DSP usage estimate: 2.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `8000` ms; default `600`. Raw range `0` to `8`; raw default `0.6`. Adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `40`. Raw range `0` to `1`; raw default `0.4`. Controls the number of delay repeats. When set to 0%, only one repeat is heard; at 100%, the delay repeats forever.
- `Scale` (`key: Scale`, `id: 3`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. For stereo delays, the right side's time is always some percentage of the left side's time, and is determined by the Scale parameter. For example, if Time is set to 500 ms, and Scale is set to 70%, the left delay is 500 ms and the

right delay is 350ms (or 70% of 500 ms). When scale is set to 100%, left and right delays are the same.

- `Spread` (`key: Spread`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the apparent stereo width of the repeats between the left and right channels.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `45`. Raw range `0` to `1`; raw default `0.45`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Low Cut` (`key: LowCut`, `id: 7`, `type: f`): display range `19.9` to `500` Off; default `100`. Raw range `19.9` to `500`; raw default `100`. Applies a low cut (or high pass) filter to the repeats, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 8`, `type: f`): display range `500` to `20100` Hz; default `8900`. Raw range `500` to `20100`; raw default `8900`. Applies a high cut (or low pass) filter to the repeats, letting you remove the effected signal above a certain frequency.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Pitch Echo

- Model key: `HD2\_DelayPitchMono`
- Model ID: `502`
- Type: Delay
- Category: `delay`
- Class: Digital
- DSP usage estimate: 4.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `8000` ms; default `250`. Raw range `0` to `8`; raw default `0.25`. Adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `40`. Raw range `0` to `1`; raw default `0.4`. Feedback controls the number of delay repeats. When set to 0%, only one repeat is heard, which is perfect for a simple harmony appearing slightly after your playing (set by the Time parameter). Higher values cause the pitch change to feed back into itself, generating a cascading army of pitched echoes.
- `Interval` (`key: Interval1`, `id: 3`, `type: i`): display range `-13` to `13` unitless; default `5`. Raw range `-13` to `13`; raw default `5`. Sets the interval of the initial repeat and if Feedback is sufficient, the transposition of each subsequent repeat.
- `Cents` (`key: Cents1`, `id: 4`, `type: f`): display range `-50` to `50` unitless; default `0`. Raw range `-50` to `50`; raw default `0`. Sets the fine pitch shift of the initial repeat and if Feedback is sufficient, the shifting of each subsequent repeat.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `40`. Raw range `0` to `1`; raw default `0.4`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Low Cut` (`key: LowCut`, `id: 7`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (or high pass) filter to the repeats, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 8`, `type: f`): display range `500` to `20100` Hz;

default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (or low pass) filter to the repeats, letting you remove the effected signal above a certain frequency.

- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Plateaux

- Model key: `HD2\_ReverbPlateauxMono`
- Model ID: `99`
- Type: Reverb
- Category: `reverb`
- Class: Spaces
- DSP usage estimate: 5.4
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Decay` (`key: Decay`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Adjusts the decay time of the reverb effect.

- `Predelay` (`key: Predelay`, `id: 2`, `type: f`): display range `0` to `200` ms; default `0`. Raw range `0` to `0.2`; raw default `0`. Controls the amount of delay heard before the audible onset of reverb. Can sometimes result in more definition between the dry and effected signals.

- `Tone` (`key: Tone`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the tonal balance of the reverb. Lower values are darker, higher values are brighter.

- `Modulation` (`key: Modulation`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of modulation applied to the reverb.

- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `33`. Raw range `0` to `1`; raw default `0.33`. Controls the blend between the reverb and the dry signal. At 0%, no reverb is heard; at 100%, no dry signal is heard.

- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

- `Pitch 1` (`key: Pitch1`, `id: 8`, `type: i`): display range `-24` to `24` unitless; default `-12`. Raw range `-24` to `24`; raw default `-12`. Adjusts the first pitch-shifter in semitones, from 2 octaves down to 2 octaves up.

- `Cents 1` (`key: Cents1`, `id: 9`, `type: f`): display range `-50` to `50` unitless; default `-0.8`. Raw range `-50` to `50`; raw default `-0.8`. Adjusts the first pitch-shifter in cents, from -50 to +50

- `Pitch 2` (`key: Pitch2`, `id: 10`, `type: i`): display range `-24` to `24` unitless; default `7`. Raw range `-24` to `24`; raw default `7`. Adjusts the second pitch-shifter in semitones, from 2 octaves down to 2 octaves up.

- `Cents 2` (`key: Cents2`, `id: 11`, `type: f`): display range `-50` to `50` unitless; default `0.4`. Raw range `-50` to `50`; raw default `0.4`. Adjusts the second pitch-shifter in cents, from -50 to +50.

- `Pitch Mix` (`key: PitchMix`, `id: 12`, `type: f`): display range `0` to `100` %; default `24`. Raw range `0` to `1`; raw default `0.24`. Controls the blend between the pitch-shifted signal and dry signal sent to the reverb.

- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Poly Sustain

- Model key: `VIC\_DelayPolySustain`
- Model ID: `481`
- Type: Delay
- Category: `delay`
- Class: Sustain
- DSP usage estimate: 16.4
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Interval` (`key: Interval`, `id: 1`, `type: i`): display range `-36` to `24` unitless; default `0`. Raw range `-36` to `24`; raw default `0`. Sets the pitch of the sustained note or chord. TIP: This parameter is especially cool for creating massive drones to play over.
- `Attack` (`key: Attack`, `id: 2`, `type: f`): display range `100` to `5000` ms; default `500`. Raw range `0.1` to `5`; raw default `0.5`. Controls the speed at which the sustained note or chord fades in.
- `Decay` (`key: Decay`, `id: 3`, `type: f`): display range `100` to `5000` ms; default `500`. Raw range `0.1` to `5`; raw default `0.5`. Controls the speed at which the sustained note or chord fades out after bypassing the effect.
- `Mod Freq` (`key: ModFreq`, `id: 4`, `type: f`): display range `0.1` to `10` Hz; default `5`. Raw range `0.1` to `10`; raw default `5`. Controls the speed of the built-in modulation.
- `Mod Depth` (`key: ModDepth`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the depth of the built-in modulation.
- `FX Level` (`key: FX Level`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the level of the sustained signal.
- `Rand Depth` (`key: RandDepth`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Higher values increase the randomization of the section of audio being sustained, resulting in a more natural, but less predictable drone.
- `Rand Speed` (`key: RandSpeed`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `1`. Raw range `0` to `1`; raw default `0.1`. Controls how fast the randomization wanders.
- `Level` (`key: Level`, `id: 9`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Auto EQ` (`key: AutoEQ`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Determines how much compensation EQ is applied to the sustained signal. If the sustained signal sounds too harsh when pitched up (or dull when pitched down), adjust this setting to taste. The higher the value, the more EQ is applied at the shift end points; when set to 0.0, no compensation EQ is applied.
- `Operation` (`key: Operation`, `id: 11`, `type: i`): valid values `Mute All`, `Dry Kill`, `Normal`; default `Normal`. Raw range `0` to `2`; raw default `2`. Determines what happens to your signal when Poly Sustain is turned on. When set to "Mute All," THE ENTIRE PATH IS MUTED. When set to "Dry Kill," only the sustained signal is heard. When set to "Normal," both the sustained and dry signals are heard. TIP: With Poly Sustain on a parallel path, assign a second stomp switch to toggle between Mute All and Dry Kill.

Ratchet

- Model key: `VIC\_DelayRatchetMono`

- Model ID: `107`
- Type: Delay
- Category: `delay`
- Class: Digital
- DSP usage estimate: 2.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `50` to `1000` ms; default `100`. Raw range `0.05` to `1`; raw default `0.1`. Predetermines the length of the audio to be recorded and looped. To loop an entire 4/4 bar, choose 1/1; to stutter your playing, start with 1/16 or 1/32.
- `FX Level` (`key: FX Level`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Sets the level of the Ratchet effect.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Operation` (`key: Operation`, `id: 4`, `type: i`): valid values `Mute All`, `Dry Kill`, `Normal`; default `Normal`. Raw range `0` to `2`; raw default `2`. Determines what happens to your signal when Ratchet is turned on. When set to "Mute All," THE ENTIRE PATH IS MUTED. When set to "Dry Kill," only the effected signal is heard. When set to "Normal," both the effected and dry signals are heard. TIP: With Ratchet on a parallel path, assign a second stomp switch to toggle between Mute All and Dry Kill.

Reverse Delay

- Model key: `HD2\_DelayReverseDelayMono`
- Model ID: `121`
- Type: Delay
- Category: `delay`
- Class: Digital
- DSP usage estimate: 2.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `4000` ms; default `1000`. Raw range `0` to `4`; raw default `1`. Determines the length of audio captured before playing it backwards. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the number of reverse delay repeats. When set to 0%, only one reverse repeat is heard; at 100%, the reversed audio repeats forever.
- `Low Cut` (`key: LowCut`, `id: 3`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (or high pass) filter to the repeats, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 4`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (or low pass) filter to the repeats, letting you remove the effected signal above a certain frequency.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`.

Raw range ``-60`` to ``6``; raw default ``0``. Sets the overall level of the block.

- ``Mod Mode`` (``key: ModulationMode``, ``id: 7``, ``type: i``): valid values ``Off``, ``Chorus``, ``Vibrato``; default ``Off``. Raw range ``0`` to ``2``; raw default ``0``. Selects the type of modulation applied to the repeats--None (Off), Chorus, or Vibrato.
- ``Speed`` (``key: Speed``, ``id: 8``, ``type: f``): display range ``0`` to ``10`` unitless; default ``0.2``. Raw range ``0`` to ``1``; raw default ``0.02``. Controls the speed or rate of the modulation applied to the repeats.
- ``Depth`` (``key: Depth``, ``id: 9``, ``type: f``): display range ``0`` to ``100`` %; default ``50``. Raw range ``0`` to ``1``; raw default ``0.5``. Controls the depth or intensity of the modulation applied to the repeats.
- ``Trails`` (``key: Trails``, ``id: 1``, ``type: b``): valid values ``Off``, ``On``; default ``Off``. Raw range ``Off`` to ``On``; raw default ``Off``.

Searchlights

- Model key: ``HD2_ReverbSearchlightsMono``
- Model ID: ``98``
- Type: Reverb
- Category: ``reverb``
- Class: Spaces
- DSP usage estimate: 6.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- ``Decay`` (``key: Decay``, ``id: 1``, ``type: f``): display range ``0`` to ``10`` unitless; default ``5``. Raw range ``0`` to ``1``; raw default ``0.5``. Adjusts the decay time of the reverb effect.
- ``Predelay`` (``key: Predelay``, ``id: 2``, ``type: f``): display range ``0`` to ``200`` ms; default ``70``. Raw range ``0`` to ``0.2``; raw default ``0.07``. Controls the amount of delay heard before the audible onset of reverb. Can sometimes result in more definition between the dry and effected signals.
- ``Low Cut`` (``key: LowCut``, ``id: 3``, ``type: f``): display range ``19.9`` to ``500`` Off; default ``196``. Raw range ``19.9`` to ``500``; raw default ``196``. Applies a low cut (or high pass) filter to the reverb, letting you remove the effected signal below a certain frequency.
- ``High Cut`` (``key: HighCut``, ``id: 4``, ``type: f``): display range ``500`` to ``20100`` Hz; default ``6500``. Raw range ``500`` to ``20100``; raw default ``6500``. Applies a high cut (or low pass) filter to the reverb, letting you remove the effected signal above a certain frequency.
- ``Mix`` (``key: Mix``, ``id: 5``, ``type: f``): display range ``0`` to ``100`` %; default ``29.0``. Raw range ``0`` to ``1``; raw default ``0.29``. Controls the blend between the reverb and the dry signal. At 0%, no reverb is heard; at 100%, no dry signal is heard.
- ``Level`` (``key: Level``, ``id: 6``, ``type: f``): display range ``-60`` to ``6`` dB; default ``0``. Raw range ``-60`` to ``6``; raw default ``0``. Sets the overall level of the block.
- ``Modulation`` (``key: Modulation``, ``id: 7``, ``type: f``): display range ``0`` to ``10`` unitless; default ``3``. Raw range ``0`` to ``1``; raw default ``0.3``. Controls the amount of modulation applied to the reverb.
- ``Speed`` (``key: Speed``, ``id: 8``, ``type: f``): display range ``1`` to ``10`` unitless; default ``3.7``. Raw range ``0.1`` to ``1``; raw default ``0.37``. Controls the speed of the modulation applied to the reverb.
- ``Intensity`` (``key: Intensity``, ``id: 9``, ``type: f``): display range ``0`` to ``10`` unitless; default ``6.3``. Raw range ``0`` to ``1``; raw default ``0.63``. Controls the intensity of the modulation. At higher values, you may hear a phaser-like effect within the reverb.
- ``Trails`` (``key: Trails``, ``id: 1``, ``type: b``): valid values ``Off``, ``On``; default ``Off``. Raw range ``Off`` to ``On``; raw default ``Off``.

Shimmer

- Model key: `VIC\_ReverbShimmerMono`
- Model ID: `498`
- Type: Reverb
- Category: `reverb`
- Class: Special FX
- DSP usage estimate: 10.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Type` (`key: Mode`, `id: 1`, `type: b`): valid values `Luster`, `Sheen`; default `Sheen`. Raw range `Off` to `On`; raw default `On`. Selects the type of shimmer effect applied. "Luster" is more of a traditional, reverb pedal-type shimmer effect with tighter definition in the lustery bits. "Sheen" is more of a lush, studio plugin-type shimmer effect with a massive, sheeny bloom.
- `Pitch A` (`key: Shift1`, `id: 2`, `type: f`): display range `-12` to `12` Oct; default `12`. Raw range `-12` to `12`; raw default `12`. Sets the interval of the first pitch shifter. Set to "Oct Up" for more traditional shimmer sounds; set to "Oct Down" for something a bit creepier. Note that Pitch 1 and Pitch 2 have 0.1 semitone resolution between -1 and +1
- `Pitch B` (`key: Shift2`, `id: 3`, `type: f`): display range `-12` to `12` Oct; default `7`. Raw range `-12` to `12`; raw default `7`. Sets the interval of the second pitch shifter. Set to "Oct Up" for more traditional shimmer sounds; set to "Oct Down" for something a bit creepier. Note that Pitch 1 and Pitch 2 have 0.1 semitone resolution between -1 and +1
- `Intensity` (`key: Intensity`, `id: 4`, `type: f`): display range `0` to `100` %; default `90`. Raw range `0` to `1`; raw default `0.9`. Controls the mix between the pitch-shifted and non-pitch-shifted reverb.
- `Feedback` (`key: Feedback`, `id: 5`, `type: f`): display range `0` to `100` %; default `90`. Raw range `0` to `1`; raw default `0.9`. Controls how many times the pitch shifting recirculates through the reverb.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `39`. Raw range `0` to `1`; raw default `0.39`. Controls the blend between the reverb and the dry signal. At 0%, no reverb is heard; at 100%, no dry signal is heard.
- `Pitch Blend` (`key: Balance`, `id: 7`, `type: f`): display range `-100` to `100` A; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls how much of Pitch 1 is heard vs. Pitch 2 (set to "Even" by default).
- `Decay` (`key: Decay`, `id: 8`, `type: f`): display range `0.1` to `45.1` ms; default `4`. Raw range `0.1` to `45.1`; raw default `4`. Adjusts the decay of the reverb (0.1 sec ~ 45.0 sec or Infinity)
- `Predelay` (`key: Predelay`, `id: 9`, `type: f`): display range `0` to `200` ms; default `150`. Raw range `0` to `0.2`; raw default `0.15`. Controls the amount of delay heard before the audible onset of reverb. Can sometimes result in more definition between the dry and effected signals.
- `Room Size` (`key: RoomSize`, `id: 10`, `type: i`): valid values `10 m`, `20 m`, `30 m`; default `30 m`. Raw range `0` to `2`; raw default `2`. Selects the size of the room (10, 20, or 30 meters).
- `Damping` (`key: Damping`, `id: 11`, `type: f`): display range `500` to `20000` Hz; default `5000`. Raw range `500` to `20000`; raw default `5000`. Determines the frequency above which the reverb will be absorbed. For example, if your hall is full of people wearing shimmery astronaut costumes, more high frequencies would be absorbed than if the room were empty.
- `Diffusion` (`key: Diffusion`, `id: 12`, `type: f`): display range `0` to `100` %; default

`70`. Raw range `0` to `1`; raw default `0.7`. Controls the amount of smearing between discrete echoes, sometimes resulting in a softer effected signal.

- `Motion` (`key: Motion`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the amount of randomization, which can be helpful to minimize any metallic artifacts common in static reverbs. At higher values, can impart a bit of modulation to the effected signal.
- `Low Cut` (`key: LowCut`, `id: 14`, `type: f`): display range `19.9` to `1000` Off; default `120`. Raw range `19.9` to `1000`; raw default `120`. Applies a low cut (or high pass) filter to the reverb, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 15`, `type: f`): display range `500` to `20100` Hz; default `6300`. Raw range `500` to `20100`; raw default `6300`. Applies a high cut (or low pass) filter to the reverb, letting you remove the effected signal above a certain frequency
- `Level` (`key: Level`, `id: 16`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Simple Delay

- Model key: `HD2\_DelaySimpleDelayMono`
- Model ID: `125`
- Type: Delay
- Category: `delay`
- Class: Digital
- DSP usage estimate: 1.6
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `8000` ms; default `600`. Raw range `0` to `8`; raw default `0.6`. Adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `35`. Raw range `0` to `1`; raw default `0.35`. Controls the number of delay repeats. When set to 0%, only one repeat is heard; at 100%, the delay repeats forever.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `40`. Raw range `0` to `1`; raw default `0.4`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Sweep Echo

- Model key: `HD2\_DelaySweepEchoMono`
- Model ID: `119`
- Type: Delay
- Category: `delay`
- Class: Special FX
- DSP usage estimate: 3.5
- Based on: Line 6 Original

- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `8000` ms; default `450`. Raw range `0` to `8`; raw default `0.45`. Adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `58.0`. Raw range `0` to `1`; raw default `0.58`. Feedback controls the number of delay repeats. When set to 0%, only one repeat is heard. At high values, the delay taps may begin to self-oscillate and squeal (perhaps in a good way).
- `Low Cut` (`key: LowCut`, `id: 3`, `type: f`): display range `19.9` to `500` Off; default `120`. Raw range `19.9` to `500`; raw default `120`. Applies a low cut (or high pass) filter to the repeats, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 4`, `type: f`): display range `500` to `20100` Hz; default `8000`. Raw range `500` to `20100`; raw default `8000`. Applies a high cut (or low pass) filter to the repeats, letting you remove the effected signal above a certain frequency.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Filter` (`key: FilterType`, `id: 7`, `type: i`): valid values `Low Pass`, `Band Pass`, `High Pass`; default `Band Pass`. Raw range `0` to `2`; raw default `1`. Selects the type of filter applied to the repeats--Low Pass (High Cut), Band Pass, or High Pass (Low Cut).
- `Shape` (`key: SweepShape`, `id: 8`, `type: i`): valid values `Triangle`, `Sine`, `Square`, `Inverse Sine`, `Exponential`, `Random`; default `Triangle`. Raw range `0` to `5`; raw default `0`. Selects the wave shape of the filter modulation applied to the repeats.
- `Rate` (`key: SweepSpeed`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `3.4`. Raw range `0` to `1`; raw default `0.34`. Controls the speed or rate of the modulation applied to the repeats. When set to 0.0, Rate freezes the current filter frequency.
- `Start Freq` (`key: SweepStart`, `id: 10`, `type: f`): display range `40` to `465` Hz; default `205`. Raw range `40` to `465`; raw default `205`. Sets the lowest frequency in the sweep modulation.
- `Range` (`key: SweepDepth`, `id: 11`, `type: f`): display range `0` to `3250` Hz; default `2830`. Raw range `0` to `3250`; raw default `2830`. Determines how high the modulation sweeps.
- `Resonance` (`key: SweepResonance`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the resonance or width of the frequency band affected by the filters.
- `Duty Cycle` (`key: SweepSymmetry`, `id: 13`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Alters the modulation wave shape in differing ways. For example, when Shape is set to "Triangle," 50% is a normal triangle wave and extreme values warp the wave toward a saw down (0%) or saw up (100%) shape. Or with Sine, 50% is a normal sine wave and extreme values warp the wave toward a parabolic down (0%) or parabolic up (100%) shape.
- `Headroom` (`key: Headroom`, `id: 14`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Provides up to 12.0 dB of additional headroom.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Tesselator

- Model key: `VIC\_DelayStutterEditMono`
- Model ID: `106`
- Type: Delay
- Category: `delay`
- Class: Digital
- DSP usage estimate: 2.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `First` (`key: First`, `id: 1`, `type: f`): display range `50` to `1000` ms; default `100`. Raw range `0.05` to `1`; raw default `0.1`. Determines the length of the repeats at the beginning of the sequence, that is, the length of repeated audio when the block is first engaged. When set to note values, First (Time) follows the system tempo.
- `Last` (`key: Last`, `id: 2`, `type: f`): display range `50` to `1000` ms; default `200`. Raw range `0.05` to `1`; raw default `0.2`. Determines the length of the repeats at the end of the sequence. If shorter than the First step's time, the sequence will get shorter; if longer than the First step's time, the sequence will get longer. If First and Last are the same time, the sequence length remains constant. When set to note values, Last (Time) follows the system tempo.
- `Steps` (`key: Steps`, `id: 3`, `type: i`): display range `1` to `50` unitless; default `8`. Raw range `1` to `50`; raw default `8`. Determines how many steps there are in the sequence (1 to 50), with steps in the middle interpolating repeat length, speed/pitch, and/or filter cutoff. For example, if your first step is 100 ms and your last step is 500 ms, each successive step in the sequence will interpolate between 100 ms and 500 ms.
- `Direction` (`key: Direction`, `id: 4`, `type: i`): valid values `Forward`, `Reverse`, `Fwd/Rev`; default `Forward`. Raw range `0` to `2`; raw default `0`. Determines the direction of the repeats. "Forward" makes each repeat play back normally. "Reverse" causes repeats to play back in reverse. "Fwd/Rev" alternates between forward and reverse.
- `Boomerang` (`key: Boomerang`, `id: 5`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, the sequence plays forward, then backward, then forward again, etc. When off, the end of the sequence repeats indefinitely.
- `Operation` (`key: Operation`, `id: 6`, `type: i`): valid values `Mute All`, `Dry Kill`, `Normal`; default `Normal`. Raw range `0` to `2`; raw default `2`. Determines what happens to your signal when Tesselator is turned on. When set to "Mute All," THE ENTIRE PATH IS MUTED. When set to "Dry Kill," only the effected signal is heard. When set to "Normal," both the effected and dry signals are heard. TIP: With Tesselator on a parallel path, assign a second stomp switch to toggle between Mute All and Dry Kill.
- `Ramp` (`key: Ramp`, `id: 7`, `type: i`): valid values `Speed`, `Pitch`; default `Speed`. Raw range `0` to `1`; raw default `0`. Determines whether any speed/pitch changes across the sequence reference a static or semitone value. "Speed" sets the target speed of the last step; use the Speed parameter to set the specific value (0% ~ 200% speed). "Pitch" sets the target pitch of the last step; use the Pitch parameter to set the value (-12 ~ +12 semitones).
- `Speed` (`key: Speed`, `id: 8`, `type: f`): display range `0` to `200` %; default `100`. Raw range `0` to `2`; raw default `1`. Sets the speed for the last step in the sequence. For example, if set to 200%, the last step's speed will be twice as fast as the first step and if set to 0%, the last step will appear to stop completely, almost like a glitchy tape stop effect. Disabled unless Ramp is set to "Speed."
- `Pitch` (`key: Pitch`, `id: 9`, `type: i`): display range `-12` to `12` unitless; default `0`. Raw range `-12` to `12`; raw default `0`. Sets the pitch shift for the last step in semitones. For example, if set to -12, the last step will be an octave lower than the first step. Disabled unless Ramp is set to "Pitch."
- `HP Filter` (`key: HP Filter`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the high-pass (low cut) filter frequency for the last step. For example, if set to a higher value, each successive step will filter out more bass until the last step of the sequence.

- `LP Filter` (`key: LP Filter`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the low-pass (high cut) filter frequency for the last step. For example, if set to a lower value, each successive step will filter out more treble until the last step of the sequence.
- `FX Level` (`key: FX Level`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the level of the effected signal.
- `Level` (`key: Level`, `id: 13`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Transistor Tape

- Model key: `HD2\_DelayTransistorTapeMono`
- Model ID: `116`
- Type: Delay
- Category: `delay`
- Class: Tape
- DSP usage estimate: 3.5
- Based on: Maestro Echoplex EP-3
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `2000` ms; default `507`. Raw range `0` to `2`; raw default `0.507`. Adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `54`. Raw range `0` to `1`; raw default `0.54`. Controls the number of delay repeats. When set to 0%, only one repeat is heard. At high values, the Delay may begin to self-oscillate and squeal (perhaps in a good way).
- `Wow/Flutter` (`key: WowFlutter`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Controls how much warbly tape sound is heard. Lower values result in the sound of a tape echo in pristine condition; higher values result in the sound of a tape echo that may have seen one too many trips in the back of a van.
- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `40`. Raw range `0` to `1`; raw default `0.4`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Headroom` (`key: Headroom`, `id: 9`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Some delay devices' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative values increase the perceived amount of grit; positive values clean things up a bit.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

VIC_DelayGlitchStereo

- Model key: `VIC\_DelayGlitchStereo`
- Model ID: `43`
- Type: Delay
- Category: `delay`
- Class: Unknown

- DSP usage estimate: 3.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

VIC_DelayRatchetStereo

- Model key: `VIC\_DelayRatchetStereo`
- Model ID: `41`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 3.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

VIC_DelayStutterEditStereo

- Model key: `VIC\_DelayStutterEditStereo`
- Model ID: `42`
- Type: Delay
- Category: `delay`
- Class: Unknown
- DSP usage estimate: 2.8
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

VIC_DynPlateStereo

- Model key: `VIC\_DynPlateStereo`
- Model ID: `486`
- Type: Reverb
- Category: `reverb`
- Class: Unknown
- DSP usage estimate: 11.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

VIC_ReverbDynAmbienceStereo

- Model key: `VIC\_ReverbDynAmbienceStereo`
- Model ID: `60`
- Type: Reverb
- Category: `reverb`
- Class: Unknown
- DSP usage estimate: 5.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

VIC_ReverbDynBloomStereo

- Model key: `VIC\_ReverbDynBloomStereo`
- Model ID: `494`
- Type: Reverb
- Category: `reverb`
- Class: Unknown
- DSP usage estimate: 14.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

VIC_ReverbDynRoomStereo

- Model key: `VIC\_ReverbDynRoomStereo`
- Model ID: `59`
- Type: Reverb
- Category: `reverb`
- Class: Unknown
- DSP usage estimate: 9.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

VIC_ReverbRotatingStereo

- Model key: `VIC\_ReverbRotatingStereo`
- Model ID: `485`

- Type: Reverb
- Category: `reverb`
- Class: Unknown
- DSP usage estimate: 8.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

VIC_ReverbShimmerStereo

- Model key: `VIC\_ReverbShimmerStereo`
- Model ID: `484`
- Type: Reverb
- Category: `reverb`
- Class: Unknown
- DSP usage estimate: 10.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

Vintage Digital

- Model key: `HD2\_DelayVintageDigitalMonoV2`
- Model ID: `115`
- Type: Delay
- Category: `delay`
- Class: Digital
- DSP usage estimate: 2.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `8000` ms; default `500`. Raw range `0` to `8`; raw default `0.5`. Time adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo.
- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `45`. Raw range `0` to `1`; raw default `0.45`. Controls the number of delay repeats. When set to 0%, only one repeat is heard; at 100%, the delay repeats forever.
- `Bit Depth` (`key: BitDepth`, `id: 3`, `type: i`): valid values `6`, `8`, `10`, `11`, `12`, `14`, `16`, `24`; default `12`. Raw range `0` to `7`; raw default `4`. Lowers the bit depth of the repeats for a grungier sound. For more transparent results, set to 24 bits.
- `Sample Rate` (`key: SampleRate`, `id: 4`, `type: i`): valid values `8 kHz`, `11.025 kHz`, `12 kHz`, `16 kHz`, `22.05 kHz`, `24 kHz`, `44.1 kHz`, `48 kHz`; default `16 kHz`. Raw range `0` to `7`; raw default `3`. Lowers the sample rate of the repeats for a grungier, more vintage digital sound. For more transparent results, set to 48kHz.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `45`. Raw range `0` to `1`; raw default `0.45`. Controls the blend between the delay repeats and the

dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.

- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

- `Rate` (`key: Rate`, `id: 7`, `type: f`): display range `0.1` to `8` Hz; default `0.2`. Raw range `0.1` to `8`; raw default `0.2`. Controls the speed or rate of the pitch modulation applied to the repeats.

- `Depth` (`key: Depth`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Controls the depth or intensity of the pitch modulation applied to the repeats.

- `Headroom` (`key: Headroom`, `id: 9`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Some older rackmount delays' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative values increase the perceived amount of grit; positive values clean things up a bit.

- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Vintage Swell

- Model key: `HD2\_DelaySwellVintageDigitalMono`

- Model ID: `117`

- Type: Delay

- Category: `delay`

- Class: Digital

- DSP usage estimate: 2.8

- Based on: Line 6 Original

- Agoura model: No

Parameters

- `Time` (`key: Time`, `id: 1`, `type: f`): display range `0` to `8000` ms; default `500`. Raw range `0` to `8`; raw default `0.5`. Time adjusts the length of time before the first repeat. When set to note values, Time follows the system tempo.

- `Feedback` (`key: Feedback`, `id: 2`, `type: f`): display range `0` to `100` %; default `75`. Raw range `0` to `1`; raw default `0.75`. Controls the number of delay repeats. When set to 0%, only one repeat is heard; at 100%, the delay repeats forever.

- `Bit Depth` (`key: BitDepth`, `id: 3`, `type: i`): valid values `6`, `8`, `10`, `11`, `12`, `14`, `16`, `24`; default `24`. Raw range `0` to `7`; raw default `7`. Lowers the bit depth of the repeats for a grungier sound. For more transparent results, set to 24 bits.

- `Sample Rate` (`key: SampleRate`, `id: 4`, `type: i`): valid values `8 kHz`, `11.025 kHz`, `12 kHz`, `16 kHz`, `22.05 kHz`, `24 kHz`, `44.1 kHz`, `48 kHz`; default `48 kHz`. Raw range `0` to `7`; raw default `7`. Lowers the sample rate of the repeats for a grungier, more vintage digital sound. For more transparent results, set to 48kHz.

- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `45`. Raw range `0` to `1`; raw default `0.45`. Controls the blend between the delay repeats and the dry signal. At 0%, no repeats are heard; at 100%, no dry signal is heard.

- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

- `Rate` (`key: Rate`, `id: 7`, `type: f`): display range `0.1` to `8` Hz; default `0.2`. Raw range `0.1` to `8`; raw default `0.2`. Controls the speed or rate of the pitch modulation applied to the repeats.

- `Depth` (`key: Depth`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Controls the depth or intensity of the pitch modulation applied to the repeats.

- `Headroom` (`key: Headroom`, `id: 9`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Some older rackmount delays' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative

values increase the perceived amount of grit; positive values clean things up a bit.

- `Threshold` (`key: Threshold`, `id: 10`, `type: f`): display range `-96` to `0` dB; default `-60`. Raw range `-96` to `0`; raw default `-60`. Sets the level below which the volume swell resets.
- `Attack` (`key: Attack`, `id: 11`, `type: f`): display range `100` to `5000` ms; default `1000`. Raw range `0.1` to `5`; raw default `1`. Sets the ramp time for the volume swell applied to the dry signal, and therefore, any delay repeats.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Source file: effects-drive-dynamics-eq-filter-utility.md

Effects: drive, dynamics, EQ, filter, and utility

Upload-ready knowledge for distortion, dynamics, EQ, filter, FX Loop, looper, and volume/pan blocks.

Generated from the installed Helix Stadium desktop app bundle on
2026-05-07T22:33:14.224003+00:00.

Use display values for normal user-facing answers. Use model keys, IDs, and raw ranges only when the user asks for automation or low-level control details.

Model count: 155

1 Switch Looper

- Model key: `P35\_LooperHelixOneSwitchMono`
- Model ID: `825`
- Type: Looper
- Category: `looper`
- Class: Unknown
- DSP usage estimate: 2.3
- Based on: Unknown
- Agoura model: No

Parameters

- `Playback` (`key: Playback`, `id: 1`, `type: f`): display range `-60` to `0` dB; default `0`. Raw range `-60` to `0`; raw default `0`. Controls the level of looper playback. You may find it useful to turn this down a bit so your live guitar can be slightly louder.
- `Overdub` (`key: Overdub`, `id: 2`, `type: f`): display range `-60` to `0` dB; default `0`. Raw range `-60` to `0`; raw default `0`. Controls the level of your loop *relatively, over time* while overdubbing. For example, if Overdub is set to 90%, each time your loop repeats, its volume will be reduced by 10%, sounding quieter and quieter with each overdub pass.
- `Low Cut` (`key: lowCut`, `id: 3`, `type: f`): display range `20` to `500` Hz; default `20`. Raw range `20` to `500`; raw default `20`. Applies a low cut (high pass) filter to loop playback, letting you remove the effected signal below a certain frequency. Filtering your loop can sometimes improve the mix with your live instrument.
- `High Cut` (`key: highCut`, `id: 4`, `type: f`): display range `500` to `20000` Hz; default `20000`. Raw range `500` to `20000`; raw default `20000`. Applies a high cut (low pass) filter to loop playback, letting you remove the effected signal above a certain frequency. Filtering your loop can sometimes improve the mix with your live instrument.

10 Band Graphic

- Model key: `HD2\_EQGraphic10BandMono`
- Model ID: `265`
- Type: EQ
- Category: `eq`
- Class: Graphic
- DSP usage estimate: 1.7
- Based on: MXR 10-Band Graphic EQ
- Agoura model: No

Parameters

- `31.25 Hz` (`key: 31p25Hz`, `id: 1`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 15.0 dB.
- `62.5 Hz` (`key: 62p5Hz`, `id: 2`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 15.0 dB.
- `125 Hz` (`key: 125Hz`, `id: 3`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 15.0 dB.
- `250 Hz` (`key: 250Hz`, `id: 4`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 15.0 dB.
- `500 Hz` (`key: 500Hz`, `id: 5`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 15.0 dB.
- `1 kHz` (`key: 1kHz`, `id: 6`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 15.0 dB.
- `2 kHz` (`key: 2kHz`, `id: 7`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 15.0 dB.
- `4 kHz` (`key: 4kHz`, `id: 8`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 15.0 dB.
- `8 kHz` (`key: 8kHz`, `id: 9`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 15.0 dB.
- `16 kHz` (`key: 16kHz`, `id: 10`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Boost or cut up to 15.0 dB.
- `Level` (`key: Level`, `id: 11`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Sets the overall level of the block.

3-Band Comp

- Model key: `HX2\_Compressor3BandCompMono`
- Model ID: `38`
- Type: Dynamics
- Category: `dynamics`
- Class: 3-Band
- DSP usage estimate: 3.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`, `USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.
- `Ratio` (`key: Ratio`, `id: 1`, `type: i`): valid values `2:1`, `3:1`, `4:1`, `6:1`, `8:1`, `12:1`, `20:1`; default `4:1`. Raw range `0` to `6`; raw default `2`. Determines how

much compression is applied to the signal once it exceeds the Threshold. Higher values mean more compression.

- `Attack` (`key: Attack`, `id: 2`, `type: f`): display range `0.1` to `200` ms; default `35`. Raw range `0.0001` to `0.2`; raw default `0.035`. Controls how quickly compression is applied once the signal exceeds the Threshold. Higher values mean a slower attack, which lets the instrument's initial transient sneak through and only compresses the sustained portion of the signal.
- `Release` (`key: Release`, `id: 3`, `type: f`): display range `50` to `2500` ms; default `200`. Raw range `0.05` to `2.5`; raw default `0.2`. Controls how quickly the signal returns to unity gain after it returns below the Threshold.
- `Lo X Freq` (`key: Lo X Freq`, `id: 4`, `type: f`): display range `20` to `1000` Hz; default `400`. Raw range `20` to `1000`; raw default `400`. Sets the crossover frequency between the Low and Mid bands.
- `Hi X Freq` (`key: Hi X Freq`, `id: 5`, `type: f`): display range `1000` to `20000` Hz; default `3000`. Raw range `1000` to `20000`; raw default `3000`. Sets the crossover frequency between the Mid and High bands.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-120` to `36` dB; default `2`. Raw range `-120` to `36`; raw default `2`. Sets the overall level of the block.
- `Lo Threshold` (`key: Lo Thresh`, `id: 7`, `type: f`): display range `-80` to `0` dB; default `-40`. Raw range `-80` to `0`; raw default `-40`. Sets the level above which compression is applied to the Low band. Lower values compress more of the signal; higher values compress only louder parts of the signal.
- `Lo Gain` (`key: Lo Gain`, `id: 8`, `type: f`): display range `-60` to `30` dB; default `3.5`. Raw range `-60` to `30`; raw default `3.5`. Adjusts the Low band's level to compensate for the reduced level that results from compression.
- `Mid Threshold` (`key: Mid Thresh`, `id: 9`, `type: f`): display range `-80` to `0` dB; default `-35`. Raw range `-80` to `0`; raw default `-35`. Sets the level above which compression is applied to the Mid band. Lower values compress more of the signal; higher values compress only louder parts of the signal.
- `Mid Gain` (`key: Mid Gain`, `id: 10`, `type: f`): display range `-60` to `30` dB; default `4`. Raw range `-60` to `30`; raw default `4`. Adjusts the Mid band's level to compensate for the reduced level that results from compression.
- `Hi Threshold` (`key: Hi Thresh`, `id: 11`, `type: f`): display range `-80` to `0` dB; default `-50`. Raw range `-80` to `0`; raw default `-50`. Sets the level above which compression is applied to the High band. Lower values compress more of the signal; higher values compress only louder parts of the signal.
- `Hi Gain` (`key: Hi Gain`, `id: 12`, `type: f`): display range `-60` to `30` dB; default `-2`. Raw range `-60` to `30`; raw default `-2`. Adjusts the High band's level to compensate for the reduced level that results from compression.

Acoustic Sim

- Model key: `L6SPB\_AcousGtrSimMono`
- Model ID: `384`
- Type: EQ
- Category: `eq`
- Class: Acoustic Sim
- DSP usage estimate: 2.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Mode` (`key: Mode`, `id: 1`, `type: i`): valid values `Standard`, `Jumbo`, `Enhanced`, `Piezo`; default `Standard`. Raw range `0` to `3`; raw default `0`. Selects one of four acoustic guitar sounds: Standard is a traditional acoustic guitar, Jumbo is larger and

fuller, Enhanced has a more prominent attack for cutting through a mix, and Piezo approximates the sound of a piezo pickup installed on the guitar.

- `Body` (`key: Body`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adds body resonance, which can provide additional fullness or fatness.
- `Top` (`key: Top`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Accentuates higher end string attack and harmonics.
- `Shimmer` (`key: Shimmer`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Imparts some motion to the harmonics, reminiscent of how a string's vibration tends to affect the other strings.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Alpaca Rouge

- Model key: `HD2\_DistAlpacaRougeMono`
- Model ID: `380`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 3.6
- Based on: Carvin VLD1 Legacy Drive (Hi Gain Channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.4`. Raw range `0` to `1`; raw default `0.34`. Controls the amount of distortion applied to the signal.
- `High Cut` (`key: HiCut`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Lower values apply more cut, which makes the sound a bit darker. Higher values apply less cut, which makes the sound a bit brighter.
- `Level` (`key: Volume`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Sets the overall level of the block.

Ampeg Opto Comp

- Model key: `HX2\_CompressorOptoCompMono`
- Model ID: `32`
- Type: Dynamics
- Category: `dynamics`
- Class: Compress
- DSP usage estimate: 4.0
- Based on: Ampeg Opto Comp Compressor
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`, `USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.
- `Compress` (`key: Compression`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much level the compressor detector circuit receives. More level = more compression. (Ampeg Opto Comp has a fixed

threshold and ratio.)

- `Release` (`key: Release`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls how quickly the effect returns to unity gain after the input signal falls below the threshold. At 0.0, the release is 75 ms; at 10.0, the release is around 600 ms.
- `Mix` (`key: Blend`, `id: 3`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the compressed and dry signals. At 0%, no compressed signal is heard; at 100%, no dry signal is heard. Values in between provide parallel compression.
- `Level` (`key: Level`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Sets the overall level of the block.

Ampeg Scrambler

- Model key: `HD2\_DistAmpegScramblerODMono`
- Model ID: `372`
- Type: Distortion
- Category: `distortion`
- Class: Overdrive
- DSP usage estimate: 6.7
- Based on: Ampeg Scrambler Bass Overdrive
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls the amount of overdrive applied to the signal.
- `Blend` (`key: Blend`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Blends the overdriven signal with the dry signal.
- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Controls the high frequency EQ of the overdrive.
- `Level` (`key: Level`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Sets the overall level of the block.

Arbitrator Fuzz

- Model key: `HD2\_DistArbitratorFuzzMono`
- Model ID: `308`
- Type: Distortion
- Category: `distortion`
- Class: Fuzz
- DSP usage estimate: 2.5
- Based on: Arbiter Fuzz Face
- Agoura model: No

Parameters

- `Fuzz` (`key: Fuzz`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the amount of fuzz applied to the signal.
- `Level` (`key: Level`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Sets the overall level of the block.

Asheville Pattn

- Model key: `HD2\_FilterAshevillePattnMono`
- Model ID: `375`
- Type: Filter
- Category: `filter`
- Class: Filter
- DSP usage estimate: 5.7
- Based on: Analogman King of Tone
- Agoura model: No

Parameters

- `Rate` (`key: Rate`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the rate or speed of the filter step sequence. Has no affect if Pattern is set to "Off."
- `Pattern` (`key: Pattern`, `id: 2`, `type: i`): valid values `Off`, `Stair`, `Cascade`, `Cross`, `Brownian`, `Random`, `Band Exp`, `Down/Up`, `Pulsar`, `Grow/Shrink`, `Dbl Cascade`, `Rhythmicon`, `Double X`, `Perpetual`, `Pyramid`, `Double Dip`, `Inverted`, `Prime`, `Folded`, `Breakbeat`, `Big Beat`; default `Brownian`. Raw range `0` to `20`; raw default `4`. Selects one of 20 different filter sequence patterns. When set to "Off," the LFO can be used.
- `Envelope` (`key: Envelope`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the envelope of all 8 filters. Low values result in choppy steps with a fast attack and slower release. High values result in choppy steps with a slower attack and fast release. Values in the middle result in smoother steps with a noticeably slower attack and release, almost like a tremolo. Has no affect if Pattern is set to "Off."
- `Voice` (`key: Voice`, `id: 4`, `type: b`): valid values `Bass`, `Mid`; default `Mid`. Raw range `Off` to `On`; raw default `On`. Determines whether the 8 filters' fixed frequencies are optimized for Bass ("Bass") or Guitar ("Mid").
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the balance between the filtered and dry signals. At 0%, no filtered signal is heard; at 100%, no dry signal is heard.
- `Output` (`key: Output`, `id: 6`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Sets the overall output level of the effect.
- `Drive` (`key: Drive`, `id: 7`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the input level into the filter section. Higher settings can overdrive the filters, resulting in a bit of (perhaps pleasing) distortion.
- `Direction` (`key: Direction`, `id: 8`, `type: b`): valid values `Forward`, `Reverse`; default `Forward`. Raw range `Off` to `On`; raw default `Off`. When on, reverses direction of the filter step sequence pattern. Has no affect if Pattern is set to "Off."
- `LFO` (`key: LFO`, `id: 9`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Controls the speed of the LFO that . Has no affect unless Pattern is set to "Off."
- `Level 1` (`key: Level1`, `id: 11`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the level of the lowpass filter fixed at 110 Hz (Voice set to "Bass") or 200 Hz (Voice set to "Mid").
- `Level 2` (`key: Level2`, `id: 12`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the level of the resonant filter fixed at 160 Hz (Voice set to "Bass") or 300 Hz (Voice set to "Mid").
- `Level 3` (`key: Level3`, `id: 13`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the level of the resonant filter fixed at 240 Hz (Voice set to "Bass") or 450 Hz (Voice set to "Mid").

- `Level 4` (`key: Level4`, `id: 14`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the level of the resonant filter fixed at 350 Hz (Voice set to "Bass") or 675 Hz (Voice set to "Mid").
- `Level 5` (`key: Level5`, `id: 15`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the level of the resonant filter fixed at 525 Hz (Voice set to "Bass") or 1 kHz (Voice set to "Mid").
- `Level 6` (`key: Level6`, `id: 16`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the level of the resonant filter fixed at 775 Hz (Voice set to "Bass") or 1.5 kHz (Voice set to "Mid").
- `Level 7` (`key: Level7`, `id: 17`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the level of the resonant filter fixed at 1.2 kHz (Voice set to "Bass") or 2.2 kHz (Voice set to "Mid").
- `Level 8` (`key: Level8`, `id: 18`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the level of the resonant filter fixed at 1.8 kHz (Voice set to "Bass") or 3.4 kHz (Voice set to "Mid").

Autofilter

- Model key: `HX2\_FilterAutoFilterMono`
- Model ID: `18`
- Type: Filter
- Category: `filter`
- Class: Filter
- DSP usage estimate: 1.6
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`, `USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.
- `Mode` (`key: Mode`, `id: 1`, `type: i`): valid values `Low Pass`, `Band Pass`, `High Pass`; default `Band Pass`. Raw range `0` to `2`; raw default `1`. Selects the type of filter effect (Low Pass, Band Pass, or High Pass).
- `Filter Gain` (`key: FilterGain`, `id: 2`, `type: f`): display range `0` to `36` dB; default `18`. Raw range `0` to `36`; raw default `18`. Controls the amount of boost or cut applied to the filtered frequencies.
- `Filter Q` (`key: FilterQ`, `id: 3`, `type: f`): display range `1` to `10` unitless; default `7.5`. Raw range `1` to `10`; raw default `7.5`. Controls the resonance or width of the frequency band affected by the filter.
- `Sensitivity` (`key: Sens`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Determines how Autofilter responds to your playing dynamics. Lower values are less sensitive to pick attack; higher values are more sensitive.
- `Attack` (`key: Attack`, `id: 5`, `type: f`): display range `5` to `2000` ms; default `20`. Raw range `0.005` to `2`; raw default `0.02`. Controls how long it takes for the filter to reach its high frequency (determined by Sensitivity and your playing dynamics) once the transient is detected. Lower values are better for funky rhythmic playing; higher values are better for slow filter sweeps and special effects.
- `Decay` (`key: Decay`, `id: 6`, `type: f`): display range `5` to `3000` ms; default `350`. Raw range `0.005` to `3`; raw default `0.35`. Controls how long it takes for the filter to return to its original cutoff frequency after the Attack stage.
- `Frequency` (`key: Frequency`, `id: 7`, `type: f`): display range `20` to `1000` Hz; default `50`. Raw range `20` to `1000`; raw default `50`. Sets the initial filter frequency when no input signal is detected.

- `Freq Depth` (`key: FreqDepth`, `id: 8`, `type: f`): display range `0` to `10000` Hz; default `3500`. Raw range `0` to `10000`; raw default `3500`. Sets the amount of frequency change. If FreqDepth's value is lower than Frequency's value, the filter frequency remains static.
- `Direction` (`key: Direction`, `id: 9`, `type: b`): valid values `Down`, `Up`; default `Up`. Raw range `Off` to `On`; raw default `On`. Determines whether playing dynamics push the filter frequency higher or lower.
- `Mix` (`key: Mix`, `id: 10`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the balance between the filtered and dry signals. At 0%, no filtered signal is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 11`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Autoswell

- Model key: `HX2\_CompressorAutoSwellMono`
- Model ID: `37`
- Type: Dynamics
- Category: `dynamics`
- Class: Swell
- DSP usage estimate: 2.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`, `USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.
- `Threshold` (`key: Threshold`, `id: 1`, `type: f`): display range `-100` to `0` dB; default `-70`. Raw range `-100` to `0`; raw default `-70`. Sets the level above which a swell (fade in) is triggered. To trigger another swell, the signal must drop below this level and then exceed it again.
- `Release Offset` (`key: Rel Offset`, `id: 2`, `type: f`): display range `-40` to `40` dB; default `5`. Raw range `-40` to `40`; raw default `5`. Determines the behavior of the swell's Decay (fade out), relative to the Threshold. When set to 0.0, Attack and Decay have the same Threshold. Negative values cause the Decay to happen immediately after the Attack. Positive values let you continue to play after the Attack stage, preventing the Decay.
- `Attack` (`key: Attack`, `id: 3`, `type: f`): display range `100` to `5000` ms; default `400`. Raw range `0.1` to `5`; raw default `0.4`. Controls how long the swell fades in once the signal exceeds the Threshold.
- `Decay` (`key: Decay`, `id: 4`, `type: f`): display range `1` to `5000` ms; default `15`. Raw range `0.001` to `5`; raw default `0.015`. Controls how long the swell fades out.
- `Taper` (`key: Taper`, `id: 5`, `type: b`): valid values `Linear`, `Logarithmic`; default `Logarithmic`. Raw range `Off` to `On`; raw default `On`. Determines the shape of the Attack (fade in) and Decay (fade out) curves-Linear or Logarithmic.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `36` dB; default `0`. Raw range `-60` to `36`; raw default `0`. Sets the overall level of the block.

Ballistic Fuzz

- Model key: `HD2\_DistBallisticFuzzMono`
- Model ID: `387`
- Type: Distortion

- Category: `distortion`
- Class: Fuzz
- DSP usage estimate: 6.2
- Based on: Euthymia ICBM Fuzz
- Agoura model: No

Parameters

- `Sustain` (`key: Sustain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sustain and fuzz applied to the signal.
- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall tonal balance of the fuzz. Lower values are darker and higher values are brighter.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Sets the overall level of the block.

Bighorn Fuzz

- Model key: `HD2\_DistRamsHeadMono`
- Model ID: `383`
- Type: Distortion
- Category: `distortion`
- Class: Fuzz
- DSP usage estimate: 4.0
- Based on: a73 Electro-Harmonix Ramas Head Big Muff Pi
- Agoura model: No

Parameters

- `Sustain` (`key: Sustain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sustain and fuzz applied to the signal.
- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall tonal balance of the fuzz. Lower values are darker and higher values are brighter.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Sets the overall level of the block.

Bitcrusher

- Model key: `HD2\_DistBitcrusherMono`
- Model ID: `321`
- Type: Distortion
- Category: `distortion`
- Class: Bitcrusher
- DSP usage estimate: 2.6
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `48` dB; default `0`. Raw range `0` to `48`; raw default `0`. Controls the amount of distortion applied to the signal.

- `Bit Depth` (`key: BitDepth`, `id: 2`, `type: f`): display range `1` to `24` unitless; default `8`. Raw range `1` to `24`; raw default `8`. Lowers the bit depth of the block for a grungier sound. For more transparent results, set to 24 bits.
- `Sample Rate` (`key: SampleRate`, `id: 3`, `type: f`): display range `100` to `48000` Hz; default `18000`. Raw range `100` to `48000`; raw default `18000`. Lowers the sample rate of the block for a grungier, more vintage digital sound. For more transparent results, set to 48kHz.
- `Low Cut` (`key: LowCut`, `id: 4`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (or high pass) filter to the block, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 5`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (or low pass) filter to the block, letting you remove the effected signal above a certain frequency.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-120` to `6` dB; default `0`. Raw range `-120` to `6`; raw default `0`. Sets the overall level of the block.
- `Mix` (`key: Mix`, `id: 7`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the affected signal and the dry signal. At 0%, no effected signal is heard; at 100%, no dry signal is heard.
- `Open Threshold` (`key: OpenThreshold`, `id: 8`, `type: f`): display range `-96` to `0` dB; default `-70`. Raw range `-96` to `0`; raw default `-70`. Sets the level above which the built-in noise gate "opens," or passes signal through.
- `Close Threshold` (`key: CloseThreshold`, `id: 9`, `type: f`): display range `-96` to `0` dB; default `-70`. Raw range `-96` to `0`; raw default `-70`. Sets the level below which the built-in noise gate "closes," or stops signal from passing through.
- `Hold Time` (`key: HoldTime`, `id: 10`, `type: f`): display range `10` to `800` ms; default `10`. Raw range `0.01` to `0.8`; raw default `0.01`. Adjusts the length of time after the signal drops below the Close threshold before it is gated. Increase Hold Time if your playing is chopped off too soon.
- `Decay` (`key: Decay`, `id: 11`, `type: f`): display range `10` to `4000` ms; default `10`. Raw range `0.01` to `4`; raw default `0.01`. Controls the length of time it takes for the open noise gate to close once the signal drops below the Close level/threshold.

Cali Q Graphic

- Model key: `HD2\_CaliQMono`
- Model ID: `331`
- Type: EQ
- Category: `eq`
- Class: Graphic
- DSP usage estimate: 1.9
- Based on: MESA/Boogie Mark IV Graphic EQ
- Agoura model: No

Parameters

- `80Hz` (`key: 80Hz`, `id: 1`, `type: f`): display range `-13.75` to `13.25` dB; default `0`. Raw range `-13.75` to `13.25`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `240Hz` (`key: 240Hz`, `id: 2`, `type: f`): display range `-13.25` to `13.25` dB; default `0`. Raw range `-13.25` to `13.25`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `750Hz` (`key: 750Hz`, `id: 3`, `type: f`): display range `-13.25` to `13.25` dB; default `0`. Raw range `-13.25` to `13.25`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `2200Hz` (`key: 2200Hz`, `id: 4`, `type: f`): display range `-9.625` to `9.5` dB; default

`0`. Raw range `-9.625` to `9.5`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `6600Hz` (`key: 6600Hz`, `id: 5`, `type: f`): display range `-9.625` to `9.5` dB; default `0`. Raw range `-9.625` to `9.5`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-15` to `15` dB; default `0`. Raw range `-15` to `15`; raw default `0`. Sets the overall level of the block.

Clawthorn Drive

- Model key: `HD2\_DistClawthornDriveMono`
- Model ID: `334`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 5.5
- Based on: Wounded Paw Battering Ram
- Agoura model: No

Parameters

- `OD Gain` (`key: ODGain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the amount of overdrive applied to the signal.
- `OD Tone` (`key: ODTone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall tonal balance of the overdrive.
- `OD Level` (`key: ODLevel`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the level of the overdrive output.
- `Low Boost` (`key: ODLowBoost`, `id: 4`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Turns a low boost for the overdrive on and off.
- `Fuzz` (`key: Fuzz`, `id: 5`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Turns the fuzz portion of the circuit on and off.
- `Fuzz Oct` (`key: FuzzOct`, `id: 6`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, changes the fuzz into an octave up fuzz.
- `Fuzz Gain` (`key: FuzzGain`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of fuzz applied to the signal.
- `Fuzz Tone` (`key: FuzzTone`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the tone of the fuzz from cutting the treble (at 0.0) to flat (5.0) to treble boost (10.0).
- `Fuzz Level` (`key: FuzzLevel`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Controls the level of the fuzz output.

Compulsive Drive

- Model key: `HD2\_DistCompulsiveDriveMono`
- Model ID: `305`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 2.1

- Based on: Fulltone OCD
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls the amount of distortion applied to the signal.
- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall tonal balance of the distortion. Lower values are darker and higher values are brighter.
- `Peak Type` (`key: LPHP`, `id: 3`, `type: b`): valid values `Low`, `High`; default `Low`. Raw range `Off` to `On`; raw default `Off`. Low is more transparent, and better for a clean boost. High has more distortion, volume, and exhibits a slight bump in the midrange.
- `Version` (`key: Version`, `id: 4`, `type: b`): valid values `V2`, `V4`; default `V2`. Raw range `Off` to `On`; raw default `Off`. Selects which version of the original pedal to emulate--V2 or V4. V4 has a slight upper mid boost and a bit more sustain.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the output level of the distortion.

Dark Dove Fuzz

- Model key: `HD2\_DistDarkDoveFuzzMono`
- Model ID: `410`
- Type: Distortion
- Category: `distortion`
- Class: Fuzz
- DSP usage estimate: 4.9
- Based on: Electro-Harmonix Russian Big Muff Pi
- Agoura model: No

Parameters

- `Sustain` (`key: Sustain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of fuzz applied to the signal.
- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall tonal balance of the fuzz. Lower values are darker and higher values are brighter.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Sets the overall output level of the block.

Deez One Mod

- Model key: `HD2\_DistDeezOneModMono`
- Model ID: `370`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 4.0
- Based on: BOSS DS-1 Distortion (Keeley Electronics modded)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the amount of distortion applied to the signal.
- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the overall tonal balance of the distortion. Lower values are darker and higher values are brighter.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Sets the overall level of the block.
- `Clipping` (`key: Clipping`, `id: 4`, `type: b`): valid values `Symmetric`, `Asymmetric`; default `Asymmetric`. Raw range `Off` to `On`; raw default `On`. Selects the type of clipping. Symmetric results in a bit more compression, sustain, and distortion. Asymmetric results in a bit more clarity and less compression.

Deez One Vintage

- Model key: `HD2\_DistDeezOneVintageMono`
- Model ID: `369`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 4.3
- Based on: BOSS DS-1 Distortion (Made-in-Japan)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the amount of distortion applied to the signal.
- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall tonal balance of the distortion. Lower values are darker and higher values are brighter.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Sets the overall level of the block.

Deluxe Comp

- Model key: `HX2\_CompressorDeluxeCompMono`
- Model ID: `33`
- Type: Dynamics
- Category: `dynamics`
- Class: Compress
- DSP usage estimate: 2.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`, `USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.
- `Threshold` (`key: Threshold`, `id: 1`, `type: f`): display range `-60` to `0` dB; default

`-37.1`. Raw range `-60` to `0`; raw default `-37.1`. Sets the level above which compression is applied. Lower values compress more of the signal; higher values compress only louder parts of the signal.

- `Ratio` (`key: Ratio`, `id: 2`, `type: i`): valid values `2:1`, `3:1`, `4:1`, `6:1`, `10:1`, `20:1`; default `6:1`. Raw range `0` to `5`; raw default `3`. Determines how much compression is applied to the signal once it exceeds the Threshold. Higher values mean more compression.
- `Attack` (`key: Attack`, `id: 3`, `type: f`): display range `0.1` to `200` ms; default `38`. Raw range `0.0001` to `0.2`; raw default `0.038`. Controls how quickly compression is applied once the signal exceeds the Threshold. Higher values mean a slower attack, which lets the instrument's initial transient sneak through and only compresses the sustained portion of the signal.
- `Release` (`key: Release`, `id: 4`, `type: f`): display range `50` to `2500` ms; default `200`. Raw range `0.05` to `2.5`; raw default `0.2`. Controls how quickly the signal returns to unity gain after it returns below the Threshold.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the compressed and dry signals. At 0%, no compressed signal is heard; at 100%, no dry signal is heard. Values in between provide parallel compression.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `36` dB; default `7`. Raw range `-60` to `36`; raw default `7`. Sets the overall level of the block.
- `Knee` (`key: Knee`, `id: 7`, `type: f`): display range `0` to `20` dB; default `6`. Raw range `0` to `20`; raw default `6`. Controls how smoothly compression kicks in. Higher values cause more of a gradual increase in Ratio as the signal approaches the Threshold.

Deluxe Looper

- Model key: `P35\_LooperHelixMono`
- Model ID: `824`
- Type: Looper
- Category: `looper`
- Class: Unknown
- DSP usage estimate: 2.7
- Based on: Unknown
- Agoura model: No

Parameters

- `Playback` (`key: Playback`, `id: 1`, `type: f`): display range `-60` to `0` dB; default `0`. Raw range `-60` to `0`; raw default `0`. Controls the level of looper playback. You may find it useful to turn this down a bit so your live guitar can be slightly louder.
- `Overdub` (`key: Overdub`, `id: 2`, `type: f`): display range `-60` to `0` dB; default `0`. Raw range `-60` to `0`; raw default `0`. Controls the level of your loop *relatively, over time* while overdubbing. For example, if Overdub is set to 90%, each time your loop repeats, its volume will be reduced by 10%, sounding quieter and quieter with each overdub pass.
- `Low Cut` (`key: lowCut`, `id: 3`, `type: f`): display range `20` to `500` Hz; default `20`. Raw range `20` to `500`; raw default `20`. Applies a low cut (high pass) filter to loop playback, letting you remove the effected signal below a certain frequency. Filtering your loop can sometimes improve the mix with your live instrument.
- `High Cut` (`key: highCut`, `id: 4`, `type: f`): display range `500` to `20000` Hz; default `20000`. Raw range `500` to `20000`; raw default `20000`. Applies a high cut (low pass) filter to loop playback, letting you remove the effected signal above a certain frequency. Filtering your loop can sometimes improve the mix with your live instrument.

Deranged Master

- Model key: `HD2\_DistDerangedMasterMono`
- Model ID: `368`
- Type: Distortion
- Category: `distortion`
- Class: Overdrive
- DSP usage estimate: 2.7
- Based on: Dallas Rangemaster Treble Booster
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.7`. Raw range `0` to `1`; raw default `0.77`. Controls the amount of distortion applied to the signal.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.22`. Raw range `0` to `1`; raw default `0.522`. Controls the low frequency EQ of the distortion.
- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the high frequency EQ of the distortion.
- `Level` (`key: Level`, `id: 4`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Distortion Clone

- Model key: `VIC\_DistFlexNet`
- Model ID: `839`
- Type: Distortion
- Category: `distortion`
- Class: Clone
- DSP usage estimate: 25.3
- Based on: Unknown
- Agoura model: Yes

Parameters

- `Pre Gain` (`key: PreGain`, `id: 1`, `type: f`): display range `-40` to `10` dB; default `0`. Raw range `-40` to `10`; raw default `0`.
- `Low Cut` (`key: LowCut`, `id: 3`, `type: f`): display range `19.9` to `1000` Off; default `19.9`. Raw range `19.9` to `1000`; raw default `19.9`.
- `Low` (`key: Low`, `id: 4`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`.
- `Mid` (`key: Mid`, `id: 5`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`.
- `High` (`key: High`, `id: 6`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`.
- `High Cut` (`key: HighCut`, `id: 7`, `type: f`): display range `1000` to `20100` Hz; default `20100`. Raw range `1000` to `20100`; raw default `20100`.
- `Post Gain` (`key: PostGain`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `0`. Raw range `-40` to `10`; raw default `0`.

Dyhana Drive

- Model key: `HD2\_DistDhyanaDriveMono`
- Model ID: `371`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 3.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the amount of distortion applied to the signal.
- `Voice` (`key: Voice`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Lower values result in a warmer and softer sound. Higher values provide more punchiness, clarity, treble, and gain.
- `Tone` (`key: Tone`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the overall tonal balance of the distortion. Lower values are darker and higher values are brighter.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Sets the overall level of the block.

FX Loop 1

- Model key: `HD2\_FXLoopMono1`
- Model ID: `277`
- Type: FX Loop
- Category: `fxloop`
- Class: FX Loop
- DSP usage estimate: 1.3
- Based on: N/A
- Agoura model: No

Parameters

- `Send` (`key: Send`, `id: 1`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Send 1 signal. 0.0 dB is unity gain.
- `Return` (`key: Return`, `id: 2`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Return 1 signal. 0.0 dB is unity gain.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the amount of signal sent through the FX Loop. When connecting time-based pedals like delays or reverbs, it's best to leave the pedal's Mix at 100% and control the amount of the pedal's effect from the FX Loop block's Mix knob; this helps minimize phase issues and latency. For pedals like distortion, fuzz, or compression, it's common to keep the FX Loop's Mix knob at 100% so the entire signal is effected, although parallel processing can be accomplished at lower values.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

FX Loop 1/2

- Model key: `HD2\_FXLoopStereo1\_2`
- Model ID: `143`
- Type: FX Loop
- Category: `fxloop`
- Class: FX Loop
- DSP usage estimate: 1.5
- Based on: N/A
- Agoura model: No

Parameters

- `Send` (`key: Send`, `id: 1`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Send 1/2 signal. 0.0 dB is unity gain.
- `Return` (`key: Return`, `id: 2`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Return 1/2 signal. 0.0 dB is unity gain.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the amount of signal sent through the FX Loop. When connecting time-based pedals like delays or reverbs, it's best to leave the pedal's Mix at 100% and control the amount of the pedal's effect from the FX Loop block's Mix knob; this helps minimize phase issues and latency. For pedals like distortion, fuzz, or compression, it's common to keep the FX Loop's Mix knob at 100% so the entire signal is effected, although parallel processing can be accomplished at lower values.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

FX Loop 2

- Model key: `HD2\_FXLoopMono2`
- Model ID: `278`
- Type: FX Loop
- Category: `fxloop`
- Class: FX Loop
- DSP usage estimate: 1.3
- Based on: N/A
- Agoura model: No

Parameters

- `Send` (`key: Send`, `id: 1`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Send 2 signal. 0.0 dB is unity gain.
- `Return` (`key: Return`, `id: 2`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Return 2 signal. 0.0 dB is unity gain.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the amount of signal sent through the FX Loop. When connecting time-based pedals like delays or reverbs, it's best to leave the pedal's Mix at 100% and control the amount of the pedal's effect from the FX Loop block's Mix knob; this helps minimize phase issues and latency. For pedals like distortion, fuzz, or compression, it's common to keep the FX Loop's Mix knob at 100% so the entire signal is effected, although parallel processing can be accomplished at lower values.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw

range `Off` to `On`; raw default `Off`.

FX Loop 3

- Model key: `HD2\_FXLoopMono3`
- Model ID: `279`
- Type: FX Loop
- Category: `fxloop`
- Class: FX Loop
- DSP usage estimate: 1.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Send` (`key: Send`, `id: 1`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Send 3 signal. 0.0 dB is unity gain.
- `Return` (`key: Return`, `id: 2`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Return 3 signal. 0.0 dB is unity gain.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the amount of signal sent through the FX Loop. When connecting time-based pedals like delays or reverbs, it's best to leave the pedal's Mix at 100% and control the amount of the pedal's effect from the FX Loop block's Mix knob; this helps minimize phase issues and latency. For pedals like distortion, fuzz, or compression, it's common to keep the FX Loop's Mix knob at 100% so the entire signal is effected, although parallel processing can be accomplished at lower values.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

FX Loop 3/4

- Model key: `HD2\_FXLoopStereo3\_4`
- Model ID: `144`
- Type: FX Loop
- Category: `fxloop`
- Class: FX Loop
- DSP usage estimate: 1.5
- Based on: N/A
- Agoura model: No

Parameters

- `Send` (`key: Send`, `id: 1`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Send 3/4 signal. 0.0 dB is unity gain.
- `Return` (`key: Return`, `id: 2`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Return 3/4 signal. 0.0 dB is unity gain.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the amount of signal sent through the FX Loop. When connecting time-based pedals like delays or reverbs, it's best to leave the pedal's Mix at 100% and control the amount of the pedal's effect from the FX Loop block's Mix knob;

this helps minimize phase issues and latency. For pedals like distortion, fuzz, or compression, it's common to keep the FX Loop's Mix knob at 100% so the entire signal is effected, although parallel processing can be accomplished at lower values.

- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

FX Loop 4

- Model key: `HD2\_FXLoopMono4`
- Model ID: `280`
- Type: FX Loop
- Category: `fxloop`
- Class: FX Loop
- DSP usage estimate: 1.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Send` (`key: Send`, `id: 1`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Send 4 signal. 0.0 dB is unity gain.
- `Return` (`key: Return`, `id: 2`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Return 4 signal. 0.0 dB is unity gain.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the amount of signal sent through the FX Loop. When connecting time-based pedals like delays or reverbs, it's best to leave the pedal's Mix at 100% and control the amount of the pedal's effect from the FX Loop block's Mix knob; this helps minimize phase issues and latency. For pedals like distortion, fuzz, or compression, it's common to keep the FX Loop's Mix knob at 100% so the entire signal is effected, although parallel processing can be accomplished at lower values.
- `Trails` (`key: Trails`, `id: 1`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.

Feedbacker

- Model key: `VIC\_FeedbackSim`
- Model ID: `482`
- Type: Dynamics
- Category: `dynamics`
- Class: Feedbacker
- DSP usage estimate: 9.9
- Based on: Line 6 Original, Feedback Generator
- Agoura model: No

Parameters

- `Feedback Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the amount of feedback. At higher settings, can easily overwhelm your guitar signal; at lower settings, the feedback can better "sit" between chords. WARNING! Be careful, as this effect can quickly go off the rails, just like real feedback. Consider assigning it to a momentary stomp so feedback only appears while you hold the switch.

- `Feedback Type` (`key: FeedbackType`, `id: 2`, `type: i`): valid values `-Octave`, `Unison`, `+Octave`, `Oct+5th`, `+2 Octaves`, `2 Oct+3rd`, `2 Oct+5th`, `2 Oct+7th`, `Mid to Low`, `High to Low`, `Rndm Trigger`, `Rndm Onset`; default `2 Oct+5th`. Raw range `0` to `11`; raw default `6`. Determines the type of the feedback generated. For Mid to Low (or High to Low), feedback starts on the highest harmonic below 500 Hz (or 1200 Hz) and descends to lower harmonics. Rndm Onset harmonics are selected randomly every time a new note or chord is detected. Rndm Trigger harmonics are selected randomly every time Retrigger is set to "Trigger."
- `Attack` (`key: Attack`, `id: 3`, `type: f`): display range `150` to `6000` ms; default `500`. Raw range `0.15` to `6`; raw default `0.5`. Controls how quickly feedback appears.
- `Release` (`key: ReleaseTime`, `id: 4`, `type: f`): display range `150` to `6000` ms; default `800`. Raw range `0.15` to `6`; raw default `0.8`. Controls how quickly each harmonic dies out or transitions to a different one. At higher values, you may hear more than one harmonic as they transition.
- `Dry Kill` (`key: DryCtrl`, `id: 5`, `type: i`): valid values `Off`, `On`, `Always`; default `Off`. Raw range `0` to `2`; raw default `0`. Determines what happens to the dry signal: Off-The dry signal is controlled by the Dry Level parameter but is unaffected when the block is turned on. On-The dry signal is muted when the block is turned on. Always-The dry signal is muted from the entire path, regardless of whether the block is on or off. Use this setting only when Feedbacker is on a parallel path.
- `Dry Level` (`key: DryLevel`, `id: 6`, `type: f`): display range `-60` to `0` dB; default `0`. Raw range `-60` to `0`; raw default `0`. Adjusts the amount of dry signal through the Feedbacker block.
- `Reference` (`key: Reference`, `id: 7`, `type: i`): valid values `Lowest`, `Loudest`; default `Lowest`. Raw range `0` to `1`; raw default `0`. Determines which note within a chord is referenced by the feedback. "Lowest" prioritizes a chord's lowest-pitched note while "Loudest" prioritizes the loudest note in the chord.
- `Silence Thresh` (`key: SilenceThresh`, `id: 8`, `type: f`): display range `-120` to `-30` dB; default `-100`. Raw range `-120` to `-30`; raw default `-100`. Adjusts the level threshold above which feedback is generated. Below this level, no feedback is generated.
- `Onset Thresh` (`key: OnsetThresh`, `id: 9`, `type: f`): display range `3` to `30` dB; default `10`. Raw range `3` to `30`; raw default `10`. When Feedback Type is set to Rndm Offset, sets the threshold of onsets (plucks) that cause changes to the feedback note. Lower values increase sensitivity to plucking and strumming and higher values reduce sensitivity.
- `Offset Thresh` (`key: OffsetThresh`, `id: 10`, `type: f`): display range `-40` to `-2` dB; default `-6`. Raw range `-40` to `-2`; raw default `-6`. Rapid drops in the signal level by this amount will quickly kill the feedback to prevent warbling.
- `Retrigger` (`key: Retrigger`, `id: 11`, `type: i`): valid values `---`, `Trigger`; default `---`. Raw range `0` to `1`; raw default `0`. Meant to be assigned to a Stomp switch. Every time you press the switch, the feedback changes, depending on the type of mode: Mid to Low or High to Low-Feedback descends to lower harmonics. Rndm Trigger or Rndm Offset-Feedback randomly chooses a different harmonic. All other modes-Feedback regenerates at the mode's selected frequency.
- `Trails` (`key: Trails`, `id: 12`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Determines whether feedback continues to ring out (for the duration of the Release parameter) after the block is bypassed.

Gain

- Model key: `HD2\_VolPanGainMono`
- Model ID: `282`
- Type: Volume
- Category: `volume`
- Class: Gain
- DSP usage estimate: 0.8
- Based on: Vox AC-15 Tremolo

- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `-120` to `12` dB; default `0`. Raw range `-120` to `12`; raw default `0`. Sets the amount of gain. Unity is 0.0 dB. Values above 0.0 dB provide an ultra-transparent boost. A value of -120.0 dB effectively mutes the signal passing through the block.

HD2_CaliQStereo

- Model key: `HD2\_CaliQStereo`
- Model ID: `196`
- Type: EQ
- Category: `eq`
- Class: Unknown
- DSP usage estimate: 2.4
- Based on: MESA/Boogie Mark IV Graphic EQ
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistAlpacaRougeStereo

- Model key: `HD2\_DistAlpacaRougeStereo`
- Model ID: `243`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 5.5
- Based on: Way Huge Red Llama (modded)
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistAmpegScramblerODStereo

- Model key: `HD2\_DistAmpegScramblerODStereo`
- Model ID: `509`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 12.9
- Based on: Earthquaker Devices Life (Dist side)
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistArbitratorFuzzStereo

- Model key: `HD2\_DistArbitratorFuzzStereo`
- Model ID: `173`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 3.9
- Based on: Dallas Arbiter Fuzz Face
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistBallisticFuzzStereo

- Model key: `HD2\_DistBallisticFuzzStereo`
- Model ID: `514`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 11.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistBitcrusherStereo

- Model key: `HD2\_DistBitcrusherStereo`
- Model ID: `185`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 4.4
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistClawthornDriveStereo

- Model key: `HD2\_DistClawthornDriveStereo`

- Model ID: `508`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 10.8
- Based on: Euthymia ICBM Fuzz
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistCompulsiveDriveStereo

- Model key: `HD2\_DistCompulsiveDriveStereo`
- Model ID: `170`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 3.7
- Based on: Fulltone OCD
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistDarkDoveFuzzStereo

- Model key: `HD2\_DistDarkDoveFuzzStereo`
- Model ID: `516`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 9.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistDeezOneModStereo

- Model key: `HD2\_DistDeezOneModStereo`
- Model ID: `236`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 6.4
- Based on: BOSS DS-1 Distortion (Keeley modded)
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistDeezOneVintageStereo

- Model key: `HD2\_DistDeezOneVintageStereo`
- Model ID: `235`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 7.9
- Based on: BOSS DS-1 Distortion (Made-in-Japan)
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistDerangedMasterStereo

- Model key: `HD2\_DistDerangedMasterStereo`
- Model ID: `234`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 4.1
- Based on: Dallas Rangemaster
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistDhyanaDriveStereo

- Model key: `HD2\_DistDhyanaDriveStereo`
- Model ID: `237`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 5.1
- Based on: Hermida Zendrive
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistHedgehogD9Stereo

- Model key: `HD2\_DistHedgehogD9Stereo`
- Model ID: `149`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 4.2
- Based on: MAXON SD9 Distortion
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistHeirApparentStereo

- Model key: `HD2\_DistHeirApparentStereo`
- Model ID: `242`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 5.3
- Based on: Analogman Prince of Tone
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistHorizonDriveStereo

- Model key: `HD2\_DistHorizonDriveStereo`
- Model ID: `513`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 11.2
- Based on: Unknown
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistIndustrialFuzzStereo

- Model key: `HD2\_DistIndustrialFuzzStereo`
- Model ID: `148`
- Type: Distortion
- Category: `distortion`
- Class: Unknown

- DSP usage estimate: 10.8
- Based on: Z.Vex Fuzz Factory
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistKWBStereo

- Model key: `HD2\_DistKWBStereo`
- Model ID: `187`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 5.9
- Based on: Ben Adrian Kowloon Walled Bunny Distortion
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistKinkyBoostStereo

- Model key: `HD2\_DistKinkyBoostStereo`
- Model ID: `202`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 5.3
- Based on: Xotic EP Booster
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistLegendaryDriveStereo

- Model key: `HD2\_DistLegendaryDriveStereo`
- Model ID: `512`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 14.0
- Based on: Noble Preamp Bass DI
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistMegaphoneStereo

- Model key: `HD2\_DistMegaphoneStereo`
- Model ID: `138`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 2.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistMinotaurStereo

- Model key: `HD2\_DistMinotaurStereo`
- Model ID: `507`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 8.6
- Based on: Horizon Precision Drive
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistObsidian7000Stereo

- Model key: `HD2\_DistObsidian7000Stereo`
- Model ID: `198`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 8.1
- Based on: Darkglass Electronics B7K Ultra
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistPillarsStereo

- Model key: `HD2\_DistPillarsStereo`
- Model ID: `255`

- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 6.5
- Based on: Earthquaker Devices Plumes distortion
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistPocketFuzzStereo

- Model key: `HD2\_DistPocketFuzzStereo`
- Model ID: `249`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 4.0
- Based on: Jordan Boss Tone
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistPrizeDriveStereo

- Model key: `HD2\_DistPrizeDriveStereo`
- Model ID: `517`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 13.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistRamsHeadStereo

- Model key: `HD2\_DistRamsHeadStereo`
- Model ID: `245`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 6.8
- Based on: Electro Harmonix Ram's Head Big Muff Pi (1973)
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistRatatouilleDistStereo

- Model key: `HD2\_DistRatatouilleDistStereo`
- Model ID: `251`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 8.0
- Based on: Pro Co RAT
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistRegalBassDIStereo

- Model key: `HD2\_DistRegalBassDIStereo`
- Model ID: `518`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 6.2
- Based on: Unknown
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistScream808Stereo

- Model key: `HD2\_DistScream808Stereo`
- Model ID: `176`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 4.8
- Based on: Ibanez TS808 Tube Screamer
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistStuporODStereo

- Model key: `HD2\_DistStuporODStereo`
- Model ID: `197`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 5.2
- Based on: BOSS SD-1 Overdrive
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistSwedishChainsawStereo

- Model key: `HD2\_DistSwedishChainsawStereo`
- Model ID: `248`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 4.7
- Based on: BOSS HM-2 Distortion
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistTeemahStereo

- Model key: `HD2\_DistTeemahStereo`
- Model ID: `191`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 4.8
- Based on: Paul Cochrane Timmy Overdrive
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistThrifterFuzzStereo

- Model key: `HD2\_DistThrifterFuzzStereo`
- Model ID: `200`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 9.2

- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistToneSovereignStereo

- Model key: `HD2\_DistToneSovereignStereo`
- Model ID: `510`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 9.9
- Based on: Electro Harmonix Russian Big Muff
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistTopSecretODStereo

- Model key: `HD2\_DistTopSecretODStereo`
- Model ID: `171`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 3.7
- Based on: DOD OD-250
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistTriangleFuzzStereo

- Model key: `HD2\_DistTriangleFuzzStereo`
- Model ID: `169`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 5.3
- Based on: Electro Harmonix Big Muff Pi
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistTycoctaviaFuzzStereo

- Model key: `HD2\_DistTycoctaviaFuzzStereo`
- Model ID: `174`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 4.3
- Based on: Tycobrahe Octavia
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistValveDriverStereo

- Model key: `HD2\_DistValveDriverStereo`
- Model ID: `506`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 9.6
- Based on: Carvin VLD1 Legacy Drive (Hi Gain Channel)
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistVerminDistStereo

- Model key: `HD2\_DistVerminDistStereo`
- Model ID: `172`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 3.4
- Based on: Pro Co RAT
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistVitalBoostStereo

- Model key: `HD2\_DistVitalBoostStereo`
- Model ID: `254`
- Type: Distortion

- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 4.6
- Based on: Earthquaker Devices Life (Boost side)
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistVitalDistStereo

- Model key: `HD2\_DistVitalDistStereo`
- Model ID: `515`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 15.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistWringerFuzzStereo

- Model key: `HD2\_DistWringerFuzzStereo`
- Model ID: `195`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 8.3
- Based on: Garbage's modded BOSS FZ-2
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistXenomorphFuzzStereo

- Model key: `HD2\_DistXenomorphFuzzStereo`
- Model ID: `511`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 7.7
- Based on: Nobels ODR-1
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DistZeroAmpBassDIStereo

- Model key: `HD2\_DistZeroAmpBassDIStereo`
- Model ID: `241`
- Type: Distortion
- Category: `distortion`
- Class: Unknown
- DSP usage estimate: 5.4
- Based on: Tech 21 SansAmp Bass Driver DI V1
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_EQGraphic10BandStereo

- Model key: `HD2\_EQGraphic10BandStereo`
- Model ID: `137`
- Type: EQ
- Category: `eq`
- Class: Unknown
- DSP usage estimate: 2.2
- Based on: MXR 10-Band Graphic EQ
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_EQSimpleTiltStereo

- Model key: `HD2\_EQSimpleTiltStereo`
- Model ID: `238`
- Type: EQ
- Category: `eq`
- Class: Unknown
- DSP usage estimate: 1.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_FilterAshevillePattnStereo

- Model key: `HD2\_FilterAshevillePattrnStereo`
- Model ID: `240`
- Type: Filter
- Category: `filter`
- Class: Unknown
- DSP usage estimate: 7.2
- Based on: Moog Moogerfooger MF-105M MuRF Filter
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_VolPanGainStereo

- Model key: `HD2\_VolPanGainStereo`
- Model ID: `146`
- Type: Volume
- Category: `volume`
- Class: Unknown
- DSP usage estimate: 0.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_VolPanVolStereo

- Model key: `HD2\_VolPanVolStereo`
- Model ID: `136`
- Type: Volume
- Category: `volume`
- Class: Unknown
- DSP usage estimate: 0.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_Compressor3BandCompStereo

- Model key: `HX2\_Compressor3BandCompStereo`
- Model ID: `16`
- Type: Dynamics
- Category: `dynamics`
- Class: Unknown
- DSP usage estimate: 5.8
- Based on: Line 6 Original

- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_CompressorAutoSwellStereo

- Model key: `HX2\_CompressorAutoSwellStereo`
- Model ID: `15`
- Type: Dynamics
- Category: `dynamics`
- Class: Unknown
- DSP usage estimate: 1.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_CompressorDeluxeCompStereo

- Model key: `HX2\_CompressorDeluxeCompStereo`
- Model ID: `9`
- Type: Dynamics
- Category: `dynamics`
- Class: Unknown
- DSP usage estimate: 2.6
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_CompressorKinkyCompStereo

- Model key: `HX2\_CompressorKinkyCompStereo`
- Model ID: `12`
- Type: Dynamics
- Category: `dynamics`
- Class: Unknown
- DSP usage estimate: 7.3
- Based on: Xotic SP Compressor
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_CompressorLAsudioCompStereo

- Model key: `HX2\_CompressorLAsudioCompStereo`
- Model ID: `13`
- Type: Dynamics
- Category: `dynamics`
- Class: Unknown
- DSP usage estimate: 6.5
- Based on: Teletronix LA-2A
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_CompressorOptoCompStereo

- Model key: `HX2\_CompressorOptoCompStereo`
- Model ID: `11`
- Type: Dynamics
- Category: `dynamics`
- Class: Unknown
- DSP usage estimate: 6.5
- Based on: Ampeg Octo Comp compressor
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_CompressorRedSqueezeStereo

- Model key: `HX2\_CompressorRedSqueezeStereo`
- Model ID: `14`
- Type: Dynamics
- Category: `dynamics`
- Class: Unknown
- DSP usage estimate: 8.8
- Based on: MXR Dyna Comp
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_CompressorRochesterCompStereo

- Model key: `HX2\_CompressorRochesterCompStereo`
- Model ID: `10`
- Type: Dynamics
- Category: `dynamics`

- Class: Unknown
- DSP usage estimate: 3.5
- Based on: Ashly CLX-52 (in conjunction w/ B. Sheehan)
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_EQParametricStereo

- Model key: `HX2\_EQParametricStereo`
- Model ID: `259`
- Type: EQ
- Category: `eq`
- Class: Unknown
- DSP usage estimate: 2.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_FilterAutoFilterStereo

- Model key: `HX2\_FilterAutoFilterStereo`
- Model ID: `7`
- Type: Filter
- Category: `filter`
- Class: Unknown
- DSP usage estimate: 2.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_FilterMutantFilterStereo

- Model key: `HX2\_FilterMutantFilterStereo`
- Model ID: `8`
- Type: Filter
- Category: `filter`
- Class: Unknown
- DSP usage estimate: 1.9
- Based on: Musitronics Mu-Tron III
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_FilterMysterFilterStereo

- Model key: `HX2\_FilterMysterFilterStereo`
- Model ID: `6`
- Type: Filter
- Category: `filter`
- Class: Unknown
- DSP usage estimate: 1.9
- Based on: Korg A3
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_GateHardGateStereo

- Model key: `HX2\_GateHardGateStereo`
- Model ID: `5`
- Type: Dynamics
- Category: `dynamics`
- Class: Unknown
- DSP usage estimate: 1.8
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_GateHorizonGateStereo

- Model key: `HX2\_GateHorizonGateStereo`
- Model ID: `4`
- Type: Dynamics
- Category: `dynamics`
- Class: Unknown
- DSP usage estimate: 2.4
- Based on: Horizon Precision Drive - Gate Circuit
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HX2_GateNoiseGateStereo

- Model key: `HX2\_GateNoiseGateStereo`

- Model ID: `3`
- Type: Dynamics
- Category: `dynamics`
- Class: Unknown
- DSP usage estimate: 1.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

Hard Gate

- Model key: `HX2\_GateHardGateMono`
- Model ID: `23`
- Type: Dynamics
- Category: `dynamics`
- Class: Gate
- DSP usage estimate: 1.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`, `USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.
- `Open Threshold` (`key: OpenThreshold`, `id: 1`, `type: f`): display range `-96` to `0` dB; default `-50`. Raw range `-96` to `0`; raw default `-50`. Sets the level above which the gate "opens," or passes signal through.
- `Close Threshold` (`key: CloseThreshold`, `id: 2`, `type: f`): display range `-96` to `0` dB; default `-60`. Raw range `-96` to `0`; raw default `-60`. Sets the level below which the gate "closes," or stops signal from passing through.
- `Hold Time` (`key: HoldTime`, `id: 3`, `type: f`): display range `10` to `800` ms; default `10`. Raw range `0.01` to `0.8`; raw default `0.01`. Adjusts the length of time after the signal drops below the Close threshold before it is gated. Increase Hold Time if your playing is chopped off too soon.
- `Decay` (`key: Decay`, `id: 4`, `type: f`): display range `10` to `4000` ms; default `10`. Raw range `0.01` to `4`; raw default `0.01`. Controls the length of time it takes for the open noise gate to close once the signal drops below the Close level/threshold. Increase Decay if you want the gate to gradually lower the signal instead of chopping it off abruptly.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Hedgehog D9

- Model key: `HD2\_DistHedgehogD9Mono`
- Model ID: `287`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 2.6

- Based on: MAXON SD9 Sonic Distortion
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the amount of distortion applied to the signal.
- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.7`. Raw range `0` to `1`; raw default `0.27`. Controls the overall tonal balance of the distortion. Lower values are darker and higher values are brighter.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Sets the overall level of the block.

Heir Apparent

- Model key: `HD2\_DistHeirApparentMono`
- Model ID: `378`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 3.5
- Based on: Analogman Prince of Tone
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal.
- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall tonal balance of the overdrive. Lower values are darker and higher values are brighter.
- `Presence` (`key: Presence`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adds a bit more high end sparkle.
- `Clipping` (`key: Clipping`, `id: 4`, `type: i`): valid values `Overdrive`, `Boost`, `Distortion`; default `Overdrive`. Raw range `0` to `2`; raw default `0`. Selects the clipping mode. "Overdrive" has a touch of drive and compression. "Clean" is less compressed than "Overdrive" and is ideal for boosting your signal into an amp. "Distortion" provides even more drive and compression.
- `Gain Mod` (`key: GainMod`, `id: 5`, `type: i`): valid values `Normal`, `Higher`; default `Higher`. Raw range `0` to `1`; raw default `1`. The original pedal has different variations available, one with more gain ("Higher").
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Sets the overall level of the block.
- `Voltage` (`key: Voltage`, `id: 7`, `type: b`): valid values `9V`, `18V`; default `9V`. Raw range `Off` to `On`; raw default `Off`. The original pedal was designed to be powered by a 9V power supply but could alternatively accommodate 18V, which would provide a bit more headroom. This is especially apparent when Clipping is set to "Boost" and Gain is turned up.

Horizon Drive

- Model key: `HD2\_DistHorizonDriveMono`
- Model ID: `386`
- Type: Distortion

- Category: `distortion`
- Class: Overdrive
- DSP usage estimate: 6.1
- Based on: Horizon Precision Drive
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the amount of distortion, saturation, and sustain.
- `Attack` (`key: Attack`, `id: 2`, `type: i`): valid values `1`, `2`, `3`, `4`, `5`, `6`; default `2`. Raw range `0` to `5`; raw default `1`. Affects the character of the distortion by applying a low cut (high pass) filter to the signal. Higher values increase the low cut filter's frequency.
- `Bright` (`key: Bright`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3.7`. Raw range `0` to `1`; raw default `0.37`. Controls the brightness of the signal, but acts more like a traditional tone knob. Turn up if your amp is muddy or dark; turn down if the high end appears a bit strident or harsh.
- `Gate` (`key: Gate`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the sensitivity of the dynamic high shelf EQ filter. Lower values eliminate most noise without affecting your tone; higher values can tighten up your bass response, at the expense of note articulation.
- `Gate Range` (`key: Gate Range`, `id: 5`, `type: b`): valid values `Authentic`, `Extended`; default `Authentic`. Raw range `Off` to `On`; raw default `Off`. Determines the range of the dynamic high shelf EQ filter, or how far the signal is attenuated while the gate is active. When set to "Extended," drops the gate's threshold down to -90 dB, which is more attenuation than the real pedal.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Sets the overall level of the block.

Horizon Gate

- Model key: `HX2\_GateHorizonGateMono`
- Model ID: `22`
- Type: Dynamics
- Category: `dynamics`
- Class: Gate
- DSP usage estimate: 1.7
- Based on: Horizon Precision Drive - Gate Circuit
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`, `USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.
- `Mode` (`key: Mode`, `id: 1`, `type: i`): valid values `Bass`, `Guitar`; default `Guitar`. Raw range `0` to `1`; raw default `1`. Determines whether the gate's response is optimized for bass or guitar.
- `Sensitivity` (`key: Sensitivity`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `8.46`. Raw range `0` to `1`; raw default `0.846`. Lower values eliminate most noise without affecting your tone; higher values can tighten up your bass response, at the expense of note articulation. Note that Horizon Gate isn't a traditional gate as much as it's a dynamic high shelf EQ filter that squashes high end noise while letting lower end signals continue to decay naturally.

- `Gate Range` (`key: Gate Range`, `id: 3`, `type: b`): valid values `Authentic`, `Extended`; default `Authentic`. Raw range `Off` to `On`; raw default `Off`. Determines the range of the dynamic high shelf EQ filter, or how far the signal's high end is attenuated while the gate is active. When set to "Extended," drops the gate's threshold down to -90 dB, which is more attenuation than the real pedal.
- `Level` (`key: Level`, `id: 4`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Industrial Fuzz

- Model key: `HD2\_DistIndustrialFuzzMono`
- Model ID: `288`
- Type: Distortion
- Category: `distortion`
- Class: Fuzz
- DSP usage estimate: 5.8
- Based on: Z.Vex Fuzz Factory
- Agoura model: No

Parameters

- `Compress` (`key: Compress`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. The Compress knob doesn't actually control a compressor, it controls the pedal's transistor bias. However, higher values can pinch the dynamics of the signal, much like a compressor.
- `Gate` (`key: Gate`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Higher values can squelch your sustain, like a gate, but it's more spitty and nasty than a gate, not that there's anything wrong with that.
- `Drive` (`key: Drive`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Adjusts the amount of fuzz applied to the signal. Becomes less effective as Comp is turned up.
- `Stability` (`key: Stability`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.3`. Raw range `0` to `1`; raw default `0.73`. Controls the amount of voltage the pedal sees. Lower settings can slightly soften or mellow out the fuzz.
- `Oscillator` (`key: Oscillator`, `id: 5`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Turns the oscillator on and off.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.7`. Raw range `0` to `1`; raw default `0.77`. Sets the overall level of the block.

KWB

- Model key: `HD2\_DistKWBMono`
- Model ID: `323`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 3.5
- Based on: Benadrian Kowloon Walled Bunny Distortion
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default

`6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the amount of distortion applied to the signal.

- `Push Diode` (`key: PushDiode`, `id: 2`, `type: i`): valid values `None`, `Germanium`, `Silicon`, `LED`; default `Germanium`. Raw range `0` to `3`; raw default `1`. Selects the type of clipping diode for the first socket. The original pedal's circuit included sockets so the user could swap out diodes to customize their sound.
- `Pull Diode` (`key: PullDiode`, `id: 3`, `type: i`): valid values `None`, `Germanium`, `Silicon`, `LED`; default `LED`. Raw range `0` to `3`; raw default `3`. Selects the type of clipping diode for the second socket. The original pedal's circuit included sockets so the user could swap out diodes to customize their sound.
- `Bass` (`key: Bass`, `id: 4`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Controls the low frequency EQ of the distortion.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Controls the high frequency EQ of the distortion.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.92`. Raw range `0` to `1`; raw default `0.692`. Sets the overall level of the block.
- `Asymmetry` (`key: Asym`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the amount of clipping symmetry. Lower values are more symmetrical; higher values are more asymmetrical, or more "broken." More audible when running into a clean amp.

Kinky Boost

- Model key: `HD2\_DistKinkyBoostMono`
- Model ID: `339`
- Type: Distortion
- Category: `distortion`
- Class: Boost
- DSP usage estimate: 3.2
- Based on: Xotic EP Booster
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of drive applied to the signal.
- `Boost` (`key: Boost`, `id: 2`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Adds a 3dB boost to the signal via a virtual dip switch.
- `Bright` (`key: Bright`, `id: 3`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Adds additional brightness via a virtual dip switch.

Kinky Comp

- Model key: `HX2\_CompressorKinkyCompMono`
- Model ID: `34`
- Type: Dynamics
- Category: `dynamics`
- Class: Compress
- DSP usage estimate: 4.2
- Based on: Xotic SP Compressor
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`, `USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.
- `Sensitivity` (`key: Sensitivity`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the sensitivity of the compressor's input. Higher values apply more compression.
- `Mix` (`key: Mix`, `id: 2`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the compressed and dry signals. At 0%, no compressed signal is heard; at 100%, no dry signal is heard. Values in between provide parallel compression.
- `Attack` (`key: Attack`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls how quickly compression responds to increases in input signal level. Higher values mean a slower attack, which lets the instrument's initial transient sneak through and only compresses the sustained portion of the signal.
- `Release` (`key: Release`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls how quickly the signal returns to unity gain after it falls below the threshold.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Sets the overall level of the block.

L6SPB_AcousGtrSimStereo

- Model key: `L6SPB\_AcousGtrSimStereo`
- Model ID: `246`
- Type: EQ
- Category: `eq`
- Class: Unknown
- DSP usage estimate: 4.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

LA Studio Comp

- Model key: `HX2\_CompressorLAStudioCompMono`
- Model ID: `35`
- Type: Dynamics
- Category: `dynamics`
- Class: Compress
- DSP usage estimate: 3.9
- Based on: Teletronix LA-2A
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`,

`USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.

- `Peak Reduction` (`key: PeakReduction`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.8`. Raw range `0` to `1`; raw default `0.78`. Peak Reduction lowers the threshold, controlling how much compression is applied to the input signal.
- `Gain` (`key: Gain`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Increases the signal's level to compensate for the reduced level that results from compression/peak reduction.
- `Type` (`key: Type`, `id: 3`, `type: b`): valid values `Compress`, `Limit`; default `Compress`. Raw range `Off` to `On`; raw default `Off`. Switches between compression (3:1 ratio) and limiting (Infinity:1 ratio).
- `Emphasis` (`key: Emphasis`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `0.9`. Raw range `0` to `1`; raw default `0.09`. Subtly increases the compression circuit's sensitivity to high frequencies. At 0.0, no emphasis is applied.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the compressed and dry signals. At 0%, no compressed signal is heard; at 100%, no dry signal is heard. Values in between provide parallel compression.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-120` to `12` dB; default `0`. Raw range `-120` to `12`; raw default `0`. Sets the overall level of the block.

Legendary Drive

- Model key: `HD2\_DistLegendaryDriveMono`
- Model ID: `382`
- Type: Distortion
- Category: `distortion`
- Class: Overdrive
- DSP usage estimate: 7.4
- Based on: Carvin VLD1 Legacy Drive (hi gain channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.7`. Raw range `0` to `1`; raw default `0.77`. Controls the amount of distortion applied to the signal.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the low frequency EQ of the distortion.
- `Mid` (`key: Middle`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the distortion.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the distortion.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Adds a bit more high end sparkle to clean sounds and allows for driven signals to cut through a mix. At lower levels, provides thicker and warmer sounds.
- `Level` (`key: Volume`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the block.

Megaphone

- Model key: `HD2\_DistMegaphoneMono`
- Model ID: `266`
- Type: Distortion
- Category: `distortion`
- Class: Megaphone
- DSP usage estimate: 1.6
- Based on: Megaphone
- Agoura model: No

Parameters

- `Grit` (`key: Grit`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Determines how old and distorted the megaphone sounds.
- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall tonal balance of the effect.
- `Focus` (`key: Focus`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adds more resonance to the effected signal.
- `Space` (`key: Space`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Adds a bit of echo to the effected signal.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `79`. Raw range `0` to `1`; raw default `0.79`. Controls the blend between the effected and the dry signal. At 0%, no effect is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Sets the overall level of the block.

Minotaur

- Model key: `HD2\_DistMinotaurMono`
- Model ID: `304`
- Type: Distortion
- Category: `distortion`
- Class: Overdrive
- DSP usage estimate: 4.8
- Based on: Klon Centaur
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Controls the amount of overdrive applied to the signal. At higher settings, you may experience the fabled (1N34A germanium) "magic diodes."
- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the overall tonal balance of the distortion. Lower values are darker and higher values are brighter.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Sets the overall level of the block.

Mutant Filter

- Model key: `HX2\_FilterMutantFilterMono`
- Model ID: `19`
- Type: Filter

- Category: `filter`
- Class: Filter
- DSP usage estimate: 1.5
- Based on: Musitronics Mu-Tron III
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`, `USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.
- `Mode` (`key: Mode`, `id: 1`, `type: i`): valid values `Low Pass`, `Band Pass`, `High Pass`; default `Band Pass`. Raw range `0` to `2`; raw default `1`. Selects the type of filter effect (Low Pass, Band Pass, or High Pass).
- `Peak` (`key: Peak`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the resonance or width of the frequency band affected by the filter.
- `Gain` (`key: Gain`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `1.5`. Raw range `0` to `1`; raw default `0.15`. Adjusts the filter's sensitivity to the incoming signal.
- `Range` (`key: Range`, `id: 4`, `type: b`): valid values `Low`, `High`; default `Low`. Raw range `Off` to `On`; raw default `Off`. Frequency range of the filter
- `Drive` (`key: Drive`, `id: 5`, `type: b`): valid values `Down`, `Up`; default `Up`. Raw range `Off` to `On`; raw default `On`. Selects whether the filter's cutoff frequency shifts Up or Down in response to the input signal.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the balance between the filtered and dry signals. At 0%, no filtered signal is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 7`, `type: f`): display range `-60` to `6` dB; default `1`. Raw range `-60` to `6`; raw default `1`. Sets the overall level of the block.

Mystery Filter

- Model key: `HX2\_FilterMysterFilterMono`
- Model ID: `20`
- Type: Filter
- Category: `filter`
- Class: Filter
- DSP usage estimate: 1.6
- Based on: Korg A3
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`, `USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.
- `Sensitivity` (`key: Sensitivity`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the filter envelope's input sensitivity. Higher values are more sensitive to your playing dynamics.
- `Frequency` (`key: Frequency`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Sets the highest frequency in the filter sweep. Higher values are more extreme.
- `Resonance` (`key: Resonance`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the resonance or width of the frequency band affected by the filters.

- `Attack` (`key: Attack`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `1.3`. Raw range `0` to `1`; raw default `0.13`. Controls how long it takes for the filter to sweep down (the Attack stage) before sweeping back up (the Release stage). Lower values result in a longer downward filter sweep. Is somewhat interactive with the Sensitivity parameter.
- `Release` (`key: Release`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `9.7`. Raw range `0` to `1`; raw default `0.97`. Controls how long it takes for the filter to sweep back up (the Release Stage) after first sweeping down (the Attack stage).
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the balance between the filtered and dry signals. At 0%, no filtered signal is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 7`, `type: f`): display range `-60` to `6` dB; default `-1`. Raw range `-60` to `6`; raw default `-1`. Sets the overall level of the block.

Noise Gate

- Model key: `HX2\_GateNoiseGateMono`
- Model ID: `21`
- Type: Dynamics
- Category: `dynamics`
- Class: Gate
- DSP usage estimate: 1.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`, `USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.
- `Threshold` (`key: Threshold`, `id: 1`, `type: f`): display range `-96` to `0` dB; default `-48`. Raw range `-96` to `0`; raw default `-48`. Sets the noise gate's Threshold. The gate "opens" when the signal's level exceeds the Threshold, to let audio pass through. The gate "closes" when the signal's level drops below the Threshold. Adjust Threshold so only softer, unwanted signals (such as noise or hum) are gated.
- `Decay` (`key: Decay`, `id: 2`, `type: f`): display range `10` to `1000` ms; default `500`. Raw range `0.01` to `1`; raw default `0.5`. Controls the length of time it takes for the open noise gate to close once the signal drops below the Threshold. Increase Decay if you want the gate to gradually lower the signal instead of chopping it off abruptly.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Obsidian 7000

- Model key: `HD2\_DistObsidian7000Mono`
- Model ID: `333`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 4.8
- Based on: Darkglass Electronics Microtubes B7K Ultra
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Controls the amount of distortion and saturation applied to the signal.
- `Level` (`key: Level`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the level of the overdriven signal.
- `Blend` (`key: Blend`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Blends in the overdriven signal with the dry, unprocessed signal. At 0.0, no effect is heard.
- `Grunt` (`key: Grunt`, `id: 4`, `type: i`): valid values `Cut`, `Flat`, `Boost`; default `Boost`. Raw range `0` to `2`; raw default `2`. Boosts or cuts low frequencies of the distorted signal. Does not affect the sound when set to "Flat."
- `Attack` (`key: Attack`, `id: 5`, `type: i`): valid values `Cut`, `Flat`, `Boost`; default `Flat`. Raw range `0` to `2`; raw default `1`. Boosts or cuts high frequencies of the distorted signal. Does not affect the sound when set to "Flat."
- `Master` (`key: Master`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Sets the overall level of the block.
- `Bass` (`key: Bass`, `id: 7`, `type: f`): display range `-20` to `20` dB; default `5.5`. Raw range `-20` to `20`; raw default `5.5`. Controls the level of the bass EQ band sent into the distortion.
- `Lo Mid Freq` (`key: LoMidFreq`, `id: 8`, `type: i`): valid values `250 Hz`, `500 Hz`, `1 kHz`; default `250 Hz`. Raw range `0` to `2`; raw default `0`. Sets the frequency of the low mid EQ band sent into the distortion.
- `Lo Mid` (`key: LoMid`, `id: 9`, `type: f`): display range `-15` to `15` dB; default `-5`. Raw range `-15` to `15`; raw default `-5`. Controls the level of the low mid EQ band sent into the distortion.
- `Hi Mid Freq` (`key: HiMidFreq`, `id: 10`, `type: i`): valid values `750 Hz`, `1.5 kHz`, `3 kHz`; default `750 Hz`. Raw range `0` to `2`; raw default `0`. Sets the frequency of the high mid EQ band sent into the distortion.
- `Hi Mid` (`key: HiMid`, `id: 11`, `type: f`): display range `-15` to `15` dB; default `-4.6`. Raw range `-15` to `15`; raw default `-4.6`. Controls the level of the high mid EQ band sent into the distortion.
- `Treble` (`key: Treble`, `id: 12`, `type: f`): display range `-20` to `20` dB; default `-1.4999`. Raw range `-20` to `20`; raw default `-1.4999`. Controls the level of the treble EQ band sent into the distortion.
- `Distortion` (`key: Distortion`, `id: 13`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Turns the distortion circuit on and off. When off, the EQ parameters remain active.

P35_LooperHelixOneSwitchStereo

- Model key: `P35\_LooperHelixOneSwitchStereo`
- Model ID: `826`
- Type: Looper
- Category: `looper`
- Class: Unknown
- DSP usage estimate: 2.3
- Based on: Unknown
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

P35_LooperHelixStereo

- Model key: `P35\_LooperHelixStereo`
- Model ID: `827`
- Type: Looper
- Category: `looper`
- Class: Unknown
- DSP usage estimate: 2.7
- Based on: Unknown
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

Pan

- Model key: `HD2\_VolPanPanStereo`
- Model ID: `135`
- Type: Volume
- Category: `volume`
- Class: Pan/Image
- DSP usage estimate: 0.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Pan` (`key: Pedal`, `id: 1`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the balance between the signal's left and right channels. When set to L 100, only the left signal is passed through the block; when set to R 100, only the right signal is passed through the block.

Parametric

- Model key: `HX2\_EQParametricMono`
- Model ID: `413`
- Type: EQ
- Category: `eq`
- Class: Parametric
- DSP usage estimate: 1.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Low Cut Enable` (`key: LowCutEnable`, `id: 1`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Turns the Low Cut filter on and off.
- `Low Cut` (`key: LowCut`, `id: 2`, `type: f`): display range `20` to `20000` Off; default `20`. Raw range `20` to `20000`; raw default `20`. Adjusts the frequency of the Low Cut filter. May be useful in removing undesirable low end rumble.
- `Low Cut Slope` (`key: LowCutSlope`, `id: 3`, `type: i`): valid values `6 dB/oct`, `12 dB/oct`, `18 dB/oct`, `24 dB/oct`; default `12 dB/oct`. Raw range `0` to `3`; raw default

`1`. Adjusts the slope of the Low Cut filter. Higher values apply a steeper slope.

- `Low Shelf Enable` (`key: LowShelfEnable`, `id: 11`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Turns the Low Shelf band on and off.
- `Low Shelf Freq` (`key: LowShelfFreq`, `id: 12`, `type: f`): display range `20` to `20000` Hz; default `80`. Raw range `20` to `20000`; raw default `80`. Adjusts the frequency of the Low Shelf band.
- `Low Shelf Gain` (`key: LowShelfGain`, `id: 13`, `type: f`): display range `-24` to `24` dB; default `0`. Raw range `-24` to `24`; raw default `0`. Adjusts the gain of the Low Shelf band.
- `Low Enable` (`key: LowEnable`, `id: 21`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Turns the Low band on and off.
- `Low Freq` (`key: LowFreq`, `id: 22`, `type: f`): display range `20` to `20000` Hz; default `150`. Raw range `20` to `20000`; raw default `150`. Adjusts the frequency of the Low Band
- `Low Q` (`key: LowQ`, `id: 23`, `type: f`): display range `0.1` to `20` unitless; default `0.707`. Raw range `0.1` to `20`; raw default `0.707`. Adjusts the bandwidth of the Low band. Lower values apply a wider boost or cut for shaping overall frequency response; higher values apply a precise, surgical boost or cut for accentuating a specific frequency, removing troublesome resonances, or even controlling feedback.
- `Low Gain` (`key: LowGain`, `id: 24`, `type: f`): display range `-24` to `24` dB; default `0`. Raw range `-24` to `24`; raw default `0`. Adjusts the gain of the Low band.
- `Mid Enable` (`key: MidEnable`, `id: 31`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Turns the Mid band on and off.
- `Mid Freq` (`key: MidFreq`, `id: 32`, `type: f`): display range `20` to `20000` Hz; default `2000`. Raw range `20` to `20000`; raw default `2000`. Adjusts the frequency for the Mid band.
- `Mid Q` (`key: MidQ`, `id: 33`, `type: f`): display range `0.1` to `20` unitless; default `0.707`. Raw range `0.1` to `20`; raw default `0.707`. Adjusts the bandwidth of the Mid band. Lower values apply a wider boost or cut for shaping overall frequency response; higher values apply a precise, surgical boost or cut for accentuating a specific frequency, removing troublesome resonances, or even controlling feedback.
- `Mid Gain` (`key: MidGain`, `id: 34`, `type: f`): display range `-24` to `24` dB; default `0`. Raw range `-24` to `24`; raw default `0`. Adjusts the gain of the Mid band.
- `High Enable` (`key: HighEnable`, `id: 41`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Turns the high band on and off.
- `High Freq` (`key: HighFreq`, `id: 42`, `type: f`): display range `20` to `20000` Hz; default `5000`. Raw range `20` to `20000`; raw default `5000`. Adjusts the frequency for the High band.
- `High Q` (`key: HighQ`, `id: 43`, `type: f`): display range `0.1` to `20` unitless; default `0.707`. Raw range `0.1` to `20`; raw default `0.707`. Adjusts the bandwidth of the High band. Lower values apply a wider boost or cut for shaping overall frequency response; higher values apply a precise, surgical boost or cut for accentuating a specific frequency, removing troublesome resonances, or even controlling feedback.
- `High Gain` (`key: HighGain`, `id: 44`, `type: f`): display range `-24` to `24` dB; default `0`. Raw range `-24` to `24`; raw default `0`. Adjusts the gain of the High band.
- `High Shelf Enable` (`key: HighShelfEnable`, `id: 51`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Turns the High Shelf band on and off.
- `High Shelf Freq` (`key: HighShelfFreq`, `id: 52`, `type: f`): display range `20` to `20000` Hz; default `8000`. Raw range `20` to `20000`; raw default `8000`. Adjusts the frequency of the High Shelf band.
- `High Shelf Gain` (`key: HighShelfGain`, `id: 53`, `type: f`): display range `-24` to `24` dB; default `0`. Raw range `-24` to `24`; raw default `0`. Adjusts the gain of the High Shelf band.
- `High Cut Enable` (`key: HighCutEnable`, `id: 61`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Turns the High Cut filter on and off.

- `High Cut` (`key: HighCut`, `id: 62`, `type: f`): display range `20` to `20000` Hz; default `20000`. Raw range `20` to `20000`; raw default `20000`. Adjusts the frequency of the High Cut filter.
- `High Cut Slope` (`key: HighCutSlope`, `id: 63`, `type: i`): valid values `6 dB/oct`, `12 dB/oct`, `18 dB/oct`, `24 dB/oct`; default `12 dB/oct`. Raw range `0` to `3`; raw default `1`. Controls the slope of the High Cut filter. Higher values apply a steeper slope.
- `Level` (`key: Level`, `id: 71`, `type: f`): display range `-60` to `12` dB; default `0`. Raw range `-60` to `12`; raw default `0`. Sets the overall output level of the EQ block.

Pillars

- Model key: `HD2\_DistPillarsMono`
- Model ID: `406`
- Type: Distortion
- Category: `distortion`
- Class: Overdrive
- DSP usage estimate: 3.8
- Based on: Earthquaker Devices Plumes
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Controls the amount of distortion.
- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the overall tonal balance of the distortion. Lower values are darker and higher values are brighter.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Sets the overall output level of the block.
- `Mode` (`key: Mode`, `id: 4`, `type: i`): valid values `1`, `2`, `3`; default `1`. Raw range `0` to `2`; raw default `0`. Chooses the type of clipping circuit. 1 is LED, 2 is Clean Op-amp, 3 is Asymmetrical.

Plugin 1

- Model key: `HD2\_PluginMono1`
- Model ID: `416`
- Type: FX Loop
- Category: `fxloop`
- Class: FX Loop
- DSP usage estimate: 0.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Send` (`key: Send`, `id: 1`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Send 1 signal. 0.0 dB is unity gain.
- `Return` (`key: Return`, `id: 2`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Return 1 signal. 0.0 dB is unity gain.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the amount of signal sent through the FX Loop.

When connecting time-based pedals like delays or reverbs, it's best to leave the pedal's Mix at 100% and control the amount of the pedal's effect from the FX Loop block's Mix knob; this helps minimize phase issues and latency. For pedals like distortion, fuzz, or compression, it's common to keep the FX Loop's Mix knob at 100% so the entire signal is effected, although parallel processing can be accomplished at lower values.

Plugin 1/2

- Model key: `HD2\_PluginStere01\_2`
- Model ID: `262`
- Type: FX Loop
- Category: `fxloop`
- Class: FX Loop
- DSP usage estimate: 0.0
- Based on: Unknown
- Agoura model: No

Parameters

- `Send` (`key: Send`, `id: 1`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Send 1/2 signal. 0.0 dB is unity gain.
- `Return` (`key: Return`, `id: 2`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Return 1/2 signal. 0.0 dB is unity gain.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the amount of signal sent through the FX Loop. When connecting time-based pedals like delays or reverbs, it's best to leave the pedal's Mix at 100% and control the amount of the pedal's effect from the FX Loop block's Mix knob; this helps minimize phase issues and latency. For pedals like distortion, fuzz, or compression, it's common to keep the FX Loop's Mix knob at 100% so the entire signal is effected, although parallel processing can be accomplished at lower values.

Plugin 2

- Model key: `HD2\_PluginMono2`
- Model ID: `419`
- Type: FX Loop
- Category: `fxloop`
- Class: FX Loop
- DSP usage estimate: 0.0
- Based on: 2x15" MESA/Boogie 2x15 EV
- Agoura model: No

Parameters

- `Send` (`key: Send`, `id: 1`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Send 2 signal. 0.0 dB is unity gain.
- `Return` (`key: Return`, `id: 2`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Return 2 signal. 0.0 dB is unity gain.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the amount of signal sent through the FX Loop.

When connecting time-based pedals like delays or reverbs, it's best to leave the pedal's Mix at 100% and control the amount of the pedal's effect from the FX Loop block's Mix knob; this helps minimize phase issues and latency. For pedals like distortion, fuzz, or compression, it's common to keep the FX Loop's Mix knob at 100% so the entire signal is effected, although parallel processing can be accomplished at lower values.

Plugin 3

- Model key: `HD2\_PluginMono3`
- Model ID: `417`
- Type: FX Loop
- Category: `fxloop`
- Class: FX Loop
- DSP usage estimate: 0.0
- Based on: Unknown
- Agoura model: No

Parameters

- `Send` (`key: Send`, `id: 1`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Send 3 signal. 0.0 dB is unity gain.
- `Return` (`key: Return`, `id: 2`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Return 3 signal. 0.0 dB is unity gain.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the amount of signal sent through the FX Loop. When connecting time-based pedals like delays or reverbs, it's best to leave the pedal's Mix at 100% and control the amount of the pedal's effect from the FX Loop block's Mix knob; this helps minimize phase issues and latency. For pedals like distortion, fuzz, or compression, it's common to keep the FX Loop's Mix knob at 100% so the entire signal is effected, although parallel processing can be accomplished at lower values.

Plugin 3/4

- Model key: `HD2\_PluginStereo3\_4`
- Model ID: `263`
- Type: FX Loop
- Category: `fxloop`
- Class: FX Loop
- DSP usage estimate: 0.0
- Based on: MXR 10-Band Graphic EQ
- Agoura model: No

Parameters

- `Send` (`key: Send`, `id: 1`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Send signal. 0.0 dB is unity gain.
- `Return` (`key: Return`, `id: 2`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Return signal. 0.0 dB is unity gain.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the amount of signal sent through the FX Loop.

When connecting time-based pedals like delays or reverbs, it's best to leave the pedal's Mix at 100% and control the amount of the pedal's effect from the FX Loop block's Mix knob; this helps minimize phase issues and latency. For pedals like distortion, fuzz, or compression, it's common to keep the FX Loop's Mix knob at 100% so the entire signal is effected, although parallel processing can be accomplished at lower values.

Plugin 4

- Model key: `HD2\_PluginMono4`
- Model ID: `418`
- Type: FX Loop
- Category: `fxloop`
- Class: FX Loop
- DSP usage estimate: 0.0
- Based on: Unknown
- Agoura model: No

Parameters

- `Send` (`key: Send`, `id: 1`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Send 4 signal. 0.0 dB is unity gain.
- `Return` (`key: Return`, `id: 2`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the level of the Return 4 signal. 0.0 dB is unity gain.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the amount of signal sent through the FX Loop. When connecting time-based pedals like delays or reverbs, it's best to leave the pedal's Mix at 100% and control the amount of the pedal's effect from the FX Loop block's Mix knob; this helps minimize phase issues and latency. For pedals like distortion, fuzz, or compression, it's common to keep the FX Loop's Mix knob at 100% so the entire signal is effected, although parallel processing can be accomplished at lower values.

Pocket Fuzz

- Model key: `HD2\_DistPocketFuzzMono`
- Model ID: `388`
- Type: Distortion
- Category: `distortion`
- Class: Fuzz
- DSP usage estimate: 2.5
- Based on: Jordan Boss Tone Fuzz
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.94`. Raw range `0` to `1`; raw default `0.494`. Controls the amount of fuzz applied to the signal.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Sets the overall level of the block.

Prize Drive

- Model key: `HD2\_DistPrizeDriveMono`
- Model ID: `411`
- Type: Distortion
- Category: `distortion`
- Class: Overdrive
- DSP usage estimate: 7.2
- Based on: Nobels ODR-1(bc)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Controls the amount of distortion.
- `Spectrum` (`key: Spectrum`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.4`. Raw range `0` to `1`; raw default `0.74`. When turned down, mids are accentuated; when turned up, lows and highs are accentuated. Could almost be considered a "scoop" control.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Sets the overall level of the block.
- `Bass Cut` (`key: Bass Cut`, `id: 4`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When set to "On," slightly attenuates low bass frequencies.
- `Voltage` (`key: Voltage`, `id: 5`, `type: b`): valid values `9V`, `18V`; default `9V`. Raw range `Off` to `On`; raw default `Off`. The original pedal can behave differently depending on how much power it receives. Choose 9V or 18V, the latter of which provides a bit more headroom.

Ratatouille Dist

- Model key: `HD2\_DistRatatouilleDistMono`
- Model ID: `390`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 4.3
- Based on: Maestro Bass Brassmaster
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.42`. Raw range `0` to `1`; raw default `0.742`. Controls the amount of distortion.
- `Filter` (`key: Filter`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Controls the amount of high cut (low pass) filter applied to the distortion, basically letting more treble through (lower values) or filtering it out (higher values).
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.98`. Raw range `0` to `1`; raw default `0.698`. Sets the overall level of the block.

Red Squeeze

- Model key: `HX2\_CompressorRedSqueezeMono`

- Model ID: `36`
- Type: Dynamics
- Category: `dynamics`
- Class: Compress
- DSP usage estimate: 5.0
- Based on: MXR Dyna Comp
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`, `USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.
- `Sensitivity` (`key: Sensitivity`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the sensitivity of the compressor's input. Higher values apply more compression.
- `Mix` (`key: Mix`, `id: 2`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the compressed and dry signals. At 0%, no compressed signal is heard; at 100%, no dry signal is heard. Values in between provide parallel compression.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `-60` to `12` dB; default `5.4`. Raw range `-60` to `12`; raw default `5.4`. Sets the overall level of the block.

Regal Bass DI

- Model key: `HD2\_DistRegalBassDIMono`
- Model ID: `412`
- Type: Distortion
- Category: `distortion`
- Class: Overdrive
- DSP usage estimate: 3.7
- Based on: Nobel Preamp Bass DI
- Agoura model: No

Parameters

- `Bass` (`key: Bass`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Adds a 150Hz bass boost to the signal. 0.0 is flat.
- `Treble` (`key: Treble`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Adds a 3.5kHz treble boost to the signal. 0.0 is flat.
- `Low Cut` (`key: Low Cut`, `id: 3`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Applies a 90Hz low cut (high pass) filter to the signal (6dB/octave).
- `Volume` (`key: Volume`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.3`. Raw range `0` to `1`; raw default `0.23`. Controls the overall output level of the DI.

Rochester Comp

- Model key: `HX2\_CompressorRochesterCompMono`
- Model ID: `31`
- Type: Dynamics

- Category: `dynamics`
- Class: Compress
- DSP usage estimate: 2.5
- Based on: Ashly CLX-52 (in conjunction w/ B. Sheehan)
- Agoura model: No

Parameters

- `Sidechain` (`key: ControlSource`, `id: 1`, `type: i`): valid values `Off`, `Instrument 1`, `Instrument 2`, `Mic`, `Return 1`, `Return 2`, `Return 3`, `Return 4`, `USB 3`, `USB 4`, `USB 5`, `USB 6`, `USB 7`, `USB 8`; default `Off`. Raw range `0` to `13`; raw default `0`.
- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `-15` to `15` dB; default `3`. Raw range `-15` to `15`; raw default `3`. Increases the signal's level to compensate for the reduced level that results from compression.
- `Threshold` (`key: Threshold`, `id: 2`, `type: f`): display range `-40` to `22` dB; default `-24`. Raw range `-40` to `22`; raw default `-24`. Sets the level above which compression is applied. Lower values compress more of the signal; higher values compress only louder parts of the signal.
- `Ratio` (`key: Ratio`, `id: 3`, `type: f`): display range `1` to `40` infinity; default `10`. Raw range `1` to `40`; raw default `10`. Determines how much compression is applied to the signal once it exceeds the Threshold. Higher values mean more compression.
- `Attack` (`key: Attack`, `id: 4`, `type: f`): display range `0.1` to `20` ms; default `10`. Raw range `0.0001` to `0.02`; raw default `0.01`. Controls how quickly compression is applied once the signal exceeds the Threshold. Higher values mean a slower attack, which lets the instrument's initial transient sneak through and only compresses the sustained portion of the signal.
- `Release` (`key: Release`, `id: 5`, `type: f`): display range `100` to `3000` ms; default `100`. Raw range `0.1` to `3`; raw default `0.1`. Controls how quickly the signal returns to unity gain after it returns below the Threshold.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-20` to `20` dB; default `10`. Raw range `-20` to `20`; raw default `10`. Sets the overall level of the block.
- `Knee` (`key: Knee`, `id: 7`, `type: f`): display range `0` to `20` dB; default `0`. Raw range `0` to `20`; raw default `0`. Controls how smoothly compression kicks in. Higher values cause more of a gradual increase in Ratio as the signal approaches the Threshold.
- `Mix` (`key: Mix`, `id: 8`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the compressed and dry signals. At 0%, no compressed signal is heard; at 100%, no dry signal is heard. Values in between provide parallel compression.

Scream 808

- Model key: `HD2\_DistScream808Mono`
- Model ID: `310`
- Type: Distortion
- Category: `distortion`
- Class: Overdrive
- DSP usage estimate: 3.3
- Based on: Ibanez TS808 Tube Screamer
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the amount of distortion applied to the signal. Low Gain and high Level settings are commonly used to tighten up the signal, especially when pushing higher gain amps.

- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the overall tonal balance of the distortion. Lower values are darker and higher values are brighter.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Sets the overall level of the block. Low Gain and high Level settings are commonly used to tighten up the signal, especially when pushing higher gain amps.

Shuffling Looper

- Model key: `VIC\_LooperShufflingMono`
- Model ID: `814`
- Type: Looper
- Category: `looper`
- Class: Unknown
- DSP usage estimate: 2.3
- Based on: Unknown
- Agoura model: No

Parameters

- `Slices` (`key: Slices`, `id: 1`, `type: i`): valid values `2`, `3`, `4`, `6`, `8`, `12`, `16`, `24`, `32`; default `8`. Raw range `0` to `8`; raw default `4`. Changes the number of slices your loop will be chopped into.
- `Seq Length` (`key: SeqLength`, `id: 2`, `type: i`): valid values `2`, `3`, `4`, `6`, `8`, `12`, `16`, `24`, `32`; default `8`. Raw range `0` to `8`; raw default `4`. Determines the number of slices in the sequence. This can be changed even after recording a loop.
- `Shuffle` (`key: Shuffle`, `id: 3`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Determines the likelihood of slices shuffling/reordering. At 0%, the slices never shuffle; at 100%, they're constantly reshuffling.
- `Pitch` (`key: Pitch`, `id: 4`, `type: f`): display range `0` to `100` %; default `20`. Raw range `0` to `1`; raw default `0.2`. Determines the likelihood of slices playing back an interval higher or lower.
- `Reverse` (`key: Reverse`, `id: 5`, `type: f`): display range `0` to `100` %; default `30`. Raw range `0` to `1`; raw default `0.3`. Determines the likelihood of slices playing backward. At 0%, all slices play forward; at 100% all slices play backward.
- `Repeat` (`key: Repeat`, `id: 6`, `type: f`): display range `0` to `100` %; default `20`. Raw range `0` to `1`; raw default `0.2`. Determines the likelihood of slices repeating. At 0%, no slices repeat; at 100%, all slices repeat.
- `Smoothing` (`key: Smoothing`, `id: 7`, `type: f`): display range `0` to `50` %; default `10`. Raw range `0` to `0.5`; raw default `0.1`. Higher values apply smoothing between slices and can give a synth-pad type quality, lower values maintain transients. Or set it just high enough to avoid pops and clicks.
- `Seq Drift` (`key: Seq Drift`, `id: 8`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Determines the likelihood of the entire slice sequence changing every time it loops around. When set to 0%, the same sequence repeats forever; when set to 100%, the sequence changes completely every time it loops.
- `Playback` (`key: Playback`, `id: 9`, `type: f`): display range `-60` to `0` dB; default `0`. Raw range `-60` to `0`; raw default `0`. Sets the overall level of the block.
- `Low Cut` (`key: Low Cut`, `id: 10`, `type: f`): display range `20` to `500` Hz; default `20`. Raw range `20` to `500`; raw default `20`. Applies a low cut (or high pass) filter to the loop, letting you remove the looper signal below a certain frequency.
- `High Cut` (`key: High Cut`, `id: 11`, `type: f`): display range `500` to `20000` Hz; default `20000`. Raw range `500` to `20000`; raw default `20000`. Applies a high cut (or low pass) filter to the loop, letting you remove the looper signal above a certain frequency.

- `Interval 1` (`key: Interval 1`, `id: 12`, `type: i`): display range `-12` to `12` unitless; default `-12`. Raw range `-12` to `12`; raw default `-12`. Sets the pitch of some slices, the likelihood of which is determined by the Pitch parameter (from one octave down to one octave up).
- `Interval 2` (`key: Interval 2`, `id: 13`, `type: i`): display range `-12` to `12` unitless; default `12`. Raw range `-12` to `12`; raw default `12`. Sets the pitch of other slices, the likelihood of which is determined by the Pitch parameter (from -1 octave to +1 octave).

Stereo Imager

- Model key: `HD2\_VolPanStereoImagerStereo`
- Model ID: `247`
- Type: Volume
- Category: `volume`
- Class: Pan/Image
- DSP usage estimate: 1.8
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Mode` (`key: Mode`, `id: 1`, `type: b`): valid values `Mono In`, `Stereo In`; default `Stereo In`. Raw range `Off` to `On`; raw default `On`. Specifies the type of signal sent to the Stereo Imager block. When set to "Mono In", the signal is collapsed to mono before any stereo processing.
- `Width` (`key: Width`, `id: 2`, `type: f`): display range `0` to `200` %; default `150`. Raw range `0` to `2`; raw default `1.5`. Controls the apparent stereo width of the signal. Values greater than 100% increase the signal's apparent stereo width. Values less than 100% narrow the signal's stereo width. At 0%, the signal is collapsed to mono.
- `Pan` (`key: Rotation`, `id: 3`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the balance between the signal's left and right channels. When set to L 100, only the left signal is passed through the block; when set to R 100, only the right signal is passed through the block.
- `Level` (`key: Level`, `id: 4`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Stereo Width

- Model key: `HD2\_VolPanStereoWidthStereo`
- Model ID: `201`
- Type: Volume
- Category: `volume`
- Class: Pan/Image
- DSP usage estimate: 1.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Width` (`key: Width`, `id: 1`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the apparent stereo width of the signal. When set to "Center," the signal is collapsed to mono. When set to "Wide," the signal maintains its stereo width.

- `LR In Swap` (`key: LR In Swap`, `id: 2`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When set to "On," swaps the position of left and right channels, so the left signal appears on the right and the right signal appears on the left.
- `Balance` (`key: Balance`, `id: 3`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the balance between the signal's left and right channels. When set to L 100, only the left signal is passed through the block; when set to R 100, only the right signal is passed through the block.
- `Level` (`key: Level`, `id: 4`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `R Polarity` (`key: R Polarity`, `id: 5`, `type: b`): valid values `Normal`, `Inverted`; default `Normal`. Raw range `Off` to `On`; raw default `Off`. Inverts the polarity of the right signal.

Stupor OD

- Model key: `HD2\_DistStuporODMono`
- Model ID: `332`
- Type: Distortion
- Category: `distortion`
- Class: Overdrive
- DSP usage estimate: 3.1
- Based on: BOSS SD-1 Overdrive
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the amount of overdrive applied to the signal.
- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall tonal balance of the distortion. Lower values are darker and higher values are brighter.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Sets the overall level of the block.

Swedish Chainsaw

- Model key: `HD2\_DistSwedishChainsawMono`
- Model ID: `385`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 2.9
- Based on: BOSS HM-2 Heavy Metal Distortion (MIJ)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the amount of distortion applied to the signal.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the distortion.

- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the high frequency EQ of the distortion.
- `Level` (`key: Level`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Sets the overall level of the block.

Teemah!

- Model key: `HD2\_DistTeemahMono`
- Model ID: `327`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 3.0
- Based on: Paul Cochrane Timmy Overdrive
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the amount of overdrive applied to the signal.
- `Bass Cut` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Cuts low end frequencies from the signal before the overdrive circuit.
- `Treble Cut` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Cuts high end frequencies from the signal after the overdrive circuit.
- `Clipping` (`key: Clipping`, `id: 4`, `type: i`): valid values `Up`, `Center`, `Down`; default `Up`. Raw range `0` to `2`; raw default `0`. Selects the clipping mode. "Up" provides asymmetrical clipping with a bit of compression and saturation. "Center" provides symmetrical clipping with a bit of saturation and high headroom. "Down" is similar to "Center" except with more saturation and lower headroom.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Sets the overall level of the block.

Thrifter Fuzz

- Model key: `HD2\_DistThrifterFuzzMono`
- Model ID: `338`
- Type: Distortion
- Category: `distortion`
- Class: Fuzz
- DSP usage estimate: 5.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the amount of fuzz applied to the signal. Can also affect tone, depending on the Attack knob's setting.
- `Attack` (`key: Attack`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Increases the apparent attack of the

signal, providing transient punch and a bit of additional gain.

- `Notch Freq` (`key: Notch Freq`, `id: 3`, `type: f`): display range `200` to `2500` Hz; default `1600`. Raw range `200` to `2500`; raw default `1600`. Adjusts the frequency at which the Notch Gain boosts or cuts.
- `Notch Gain` (`key: Notch Gain`, `id: 4`, `type: f`): display range `-10` to `10` dB; default `-3.4`. Raw range `-10` to `10`; raw default `-3.4`. Cuts or boosts the signal at the Notch Frequency.
- `Thick` (`key: Thick`, `id: 5`, `type: i`): valid values `Off`, `On`; default `On`. Raw range `0` to `1`; raw default `1`. Adds a bit more thickness and low end to the fuzz, particularly if Drive is set lower.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Sets the overall level of the block.

Tilt

- Model key: `HD2\_EQSimpleTiltMono`
- Model ID: `373`
- Type: EQ
- Category: `eq`
- Class: Tilt
- DSP usage estimate: 1.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Tilt` (`key: Tilt`, `id: 1`, `type: f`): display range `-100` to `100` Dark; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Values above "Flat" boost high frequencies while simultaneously cutting low frequencies; values below "Flat" boost low frequencies while simultaneously cutting high frequencies. Great for quickly making tones a bit brighter or darker with the minimum of fuss.
- `Center Freq` (`key: CenterFreq`, `id: 2`, `type: f`): display range `100` to `5000` Hz; default `1000`. Raw range `100` to `5000`; raw default `1000`. Adjusts the frequency around which the boost and cut pivot.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `-60` to `12` dB; default `0`. Raw range `-60` to `12`; raw default `0`. Sets the overall level of the block.

Tone Sovereign

- Model key: `HD2\_DistToneSovereignMono`
- Model ID: `377`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 5.4
- Based on: Analogman King of Tone
- Agoura model: No

Parameters

- `Gain 1` (`key: Gain 1`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Gain 1 drive applied to the signal.
- `Tone 1` (`key: Tone 1`, `id: 2`, `type: f`): display range `0` to `10` unitless; default

`5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall tonal balance of Gain 1. Lower values are darker and higher values are brighter.

- `Presence 1` (`key: Presence 1`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adds a bit more high end sparkle to Gain 1.
- `Clipping 1` (`key: Clipping 1`, `id: 4`, `type: i`): valid values `Overdrive`, `Boost`, `Distortion`; default `Boost`. Raw range `0` to `2`; raw default `1`. Selects the clipping mode for Gain 1. "Overdrive" has a touch of drive and compression. "Clean" is less compressed than "Overdrive" and is ideal for boosting your signal into an amp; it's the default setting for Gain 1. "Distortion" provides even more drive and compression.
- `Gain Mod 1` (`key: GainMod 1`, `id: 5`, `type: i`): valid values `Normal`, `Higher`; default `Normal`. Raw range `0` to `1`; raw default `0`. The original pedal has different variations available, one with more gain ("Higher").
- `Level 1` (`key: Level 1`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Sets the overall output level of Gain 1.
- `Gain 2` (`key: Gain 2`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Gain 2 drive applied to the signal.
- `Tone 2` (`key: Tone 2`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall tonal balance of Gain 2. Lower values are darker and higher values are brighter.
- `Presence 2` (`key: Presence 2`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adds a bit more high end sparkle to Gain 2.
- `Clipping 2` (`key: Clipping 2`, `id: 10`, `type: i`): valid values `Overdrive`, `Boost`, `Distortion`; default `Overdrive`. Raw range `0` to `2`; raw default `0`. Selects the clipping mode for Gain 2. "Overdrive" has a touch of drive and compression; it's the default setting for Gain 2. "Clean" is less compressed than "Overdrive" and is ideal for boosting your signal into an amp. "Distortion" provides even more drive and compression.
- `Gain Mod 2` (`key: GainMod 2`, `id: 11`, `type: i`): valid values `Normal`, `Higher`; default `Higher`. Raw range `0` to `1`; raw default `1`. The original pedal has different variations available, one with more gain ("Higher").
- `Level 2` (`key: Level 2`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Sets the overall output level of Gain 2.
- `Voltage` (`key: Voltage`, `id: 70`, `type: b`): valid values `9V`, `18V`; default `9V`. Raw range `Off` to `On`; raw default `Off`. The original pedal was designed to be powered by a 9V power supply but could alternatively accommodate 18V, which would provide a bit more headroom. This is especially apparent when Clipping is set to "Boost" and Gain is turned up.

Top Secret OD

- Model key: `HD2\_DistTopSecretODMono`
- Model ID: `306`
- Type: Distortion
- Category: `distortion`
- Class: Overdrive
- DSP usage estimate: 2.4
- Based on: DOD OD-250
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of overdrive applied to

the signal.

- `Level` (`key: Level`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Sets the overall level of the block.

Triangle Fuzz

- Model key: `HD2\_DistTriangleFuzzMono`
- Model ID: `300`
- Type: Distortion
- Category: `distortion`
- Class: Fuzz
- DSP usage estimate: 3.5
- Based on: Electro-Harmonix Big Muff Pi
- Agoura model: No

Parameters

- `Sustain` (`key: Sustain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Controls the amount of sustain and fuzz applied to the signal.
- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the overall tonal balance of the fuzz. Lower values are darker and higher values are brighter.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Sets the overall level of the block.

Tycoctavia Fuzz

- Model key: `HD2\_DistTycoctaviaFuzzMono`
- Model ID: `309`
- Type: Distortion
- Category: `distortion`
- Class: Fuzz
- DSP usage estimate: 2.9
- Based on: Tycobrahe Octavia
- Agoura model: No

Parameters

- `Fuzz` (`key: Fuzz`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the amount of fuzz applied to the signal.
- `Level` (`key: Level`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Sets the overall level of the block.

VIC_LooperShufflingStereo

- Model key: `VIC\_LooperShufflingStereo`
- Model ID: `815`
- Type: Looper
- Category: `looper`
- Class: Unknown

- DSP usage estimate: 2.4
- Based on: Unknown
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

Valve Driver

- Model key: `HD2\_DistValveDriverMono`
- Model ID: `286`
- Type: Distortion
- Category: `distortion`
- Class: Overdrive
- DSP usage estimate: 5.3
- Based on: Chandler Tube Driver
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of overdrive applied to the signal.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the low frequency EQ of the overdrive.
- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the high frequency EQ of the overdrive.
- `Level` (`key: Level`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Sets the overall level of the block.

Vermin Dist

- Model key: `HD2\_DistVerminDistMono`
- Model ID: `307`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 2.5
- Based on: Pro Co RAT
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the amount of distortion applied to the signal.
- `Filter` (`key: Filter`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Applies a filter which gives you brighter tone at lower settings, and darker tone at higher settings.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Sets the overall level of the block.

Vital Boost

- Model key: `HD2\_DistVitalBoostMono`
- Model ID: `405`
- Type: Distortion
- Category: `distortion`
- Class: Boost
- DSP usage estimate: 2.9
- Based on: Earthquaker Devices Life - Boost circuit
- Agoura model: No

Parameters

- `Boost` (`key: Boost`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Sets the output level of the boost circuit.

Vital Dist

- Model key: `HD2\_DistVitalDistMono`
- Model ID: `404`
- Type: Distortion
- Category: `distortion`
- Class: Distortion
- DSP usage estimate: 7.8
- Based on: Earthquaker Devices Life - Octave/Distortion circuit
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the amount of distortion.
- `Filter` (`key: Filter`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Applies a high cut (or low pass) filter to the signal, letting you remove treble frequencies. At 0.0, no filter is applied.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Sets the overall level of the block.
- `Clipping` (`key: Clipping`, `id: 4`, `type: i`): valid values `Opamp`, `Asymmetric`, `Symmetric`; default `Opamp`. Raw range `0` to `2`; raw default `0`. Chooses the type of clipping circuit. Choose Op-amp, Asymmetrical, or Symmetrical.
- `Octave` (`key: Octave`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Blends in a signal one octave up. At 0.0, no octave signal is heard. Works best when playing single notes.

Volume Pedal

- Model key: `HD2\_VolPanVolMono`
- Model ID: `268`
- Type: Volume
- Category: `volume`
- Class: Volume Pedal
- DSP usage estimate: 0.8

- Based on: N/A
- Agoura model: No

Parameters

- `Position` (`key: Pedal`, `id: 1`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Adjusts the position of the Volume Pedal. By default, this is assigned to Expression Pedal 2.
- `Curve` (`key: VolumeTaper`, `id: 2`, `type: b`): valid values `Linear`, `Logarithmic`; default `Linear`. Raw range `Off` to `On`; raw default `Off`. Sets the Volume Pedal's taper to "Linear" (consistent level change across the pedal's travel) or "Logarithmic" (concave curve, with more control toward the heel and faster changes toward the toe)

Wringer Fuzz

- Model key: `HD2\_DistWringerFuzzMono`
- Model ID: `330`
- Type: Distortion
- Category: `distortion`
- Class: Fuzz
- DSP usage estimate: 4.5
- Based on: Garbageas modded BOSS FZ-2
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the amount of fuzz applied to the signal.
- `Treble` (`key: Treble`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the fuzz.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the fuzz.
- `Level` (`key: Level`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Sets the overall level of the block.
- `Fuzz Type` (`key: FuzzType`, `id: 5`, `type: i`): valid values `Fuzz 1`, `Fuzz 2`; default `Fuzz 1`. Raw range `0` to `1`; raw default `0`. Selects the type of fuzz circuit. Type 1 emphasizes the midrange and upper harmonics. Type 2 has more of a scooped frequency response.

Xenomorph Fuzz

- Model key: `HD2\_DistXenomorphFuzzMono`
- Model ID: `379`
- Type: Distortion
- Category: `distortion`
- Class: Fuzz
- DSP usage estimate: 4.6
- Based on: Subdecay Harmonic Antagonizer
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default

`8.75`. Raw range `0` to `1`; raw default `0.875`. Even at 0.0, Gain is buzzy, fuzzy, and nasty. Higher values provide longer sustain.

- `Tone` (`key: Tone`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the tone or timbre of the fuzz.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.78`. Raw range `0` to `1`; raw default `0.578`. Controls the overall output of the fuzz.
- `Clipping` (`key: Clipping`, `id: 4`, `type: i`): valid values `Soft`, `Hard`; default `Hard`. Raw range `0` to `1`; raw default `1`. Selects the clipping type--Soft or Hard.
- `Osc Level` (`key: OscLevel`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.38`. Raw range `0` to `1`; raw default `0.638`. Controls the level of the triggered oscillator.
- `Osc Tone` (`key: OscTone`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the tonal balance of the triggered oscillator. Higher values provide more harmonics.
- `Min Freq` (`key: MinFreq`, `id: 7`, `type: f`): display range `0` to `6000` Hz; default `55`. Raw range `0` to `6000`; raw default `55`. Sets the minimum frequency of the oscillator.
- `Max Freq` (`key: MaxFreq`, `id: 8`, `type: f`): display range `0` to `6000` Hz; default `880`. Raw range `0` to `6000`; raw default `880`. Sets the maximum frequency of the oscillator.
- `Wave Shape` (`key: WaveShape`, `id: 9`, `type: i`): valid values `Triangle`, `Sine`, `Square`; default `Square`. Raw range `0` to `2`; raw default `2`. Selects the wave shape of the triggered oscillator.
- `Sensitivity` (`key: Sensitivity`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the oscillator's filter envelope. Higher values drives the oscillator into higher frequencies.

ZeroAmp Bass DI

- Model key: `HD2\_DistZeroAmpBassDIMono`
- Model ID: `376`
- Type: Distortion
- Category: `distortion`
- Class: Overdrive
- DSP usage estimate: 3.5
- Based on: Tech 21 SansAmp Bass Driver DI V1
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the input sensitivity as well as the amount of gain and overdrive applied to the signal.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.9`. Raw range `0` to `1`; raw default `0.59`. Controls the low frequency EQ of the overdrive.
- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the high frequency EQ of the overdrive.
- `Presence` (`key: Presence`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adds upper harmonic content and increases attack.
- `Blend` (`key: Blend`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the blend between the tube amp emulation circuitry and the dry signal. The Bass and Treble knobs remain active, even when Blend is set to 0.0.

- `Level` (`key: Level`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Sets the overall level of the block.

Source file: effects-modulation-pitch-synth-wah.md

Effects: modulation, pitch, synth, and wah

Upload-ready knowledge for modulation, pitch, synth, and wah blocks.

Generated from the installed Helix Stadium desktop app bundle on
2026-05-07T22:33:14.224003+00:00.

Use display values for normal user-facing answers. Use model keys, IDs, and raw ranges only when the user asks for automation or low-level control details.

Model count: 94

12-String

- Model key: `VIC\_PitchTwelveStringMono`
- Model ID: `520`
- Type: Pitch
- Category: `pitch`
- Class: 12-String
- DSP usage estimate: 17.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Blend` (`key: Blend`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls how much of the 12-String effect is blended in with the dry signal.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the bass response of the effected signal.
- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the treble response of the effected signal.
- `Level` (`key: Level`, `id: 4`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Pluck Type` (`key: OnsetThresh`, `id: 5`, `type: i`): valid values `Normal`, `Finger Pick 1`, `Finger Pick 2`; default `Finger Pick 1`. Raw range `0` to `2`; raw default `1`. Optimizes the 12 String emulation for specific types of playing styles.

122 Rotary

- Model key: `HD2\_Rotary122RotaryStereo`
- Model ID: `157`
- Type: Modulation
- Category: `modulation`
- Class: Rotary
- DSP usage estimate: 5.5
- Based on: Leslie 122

- Agoura model: No

Parameters

- `Speed` (`key: Speed`, `id: 1`, `type: b`): valid values `Slow`, `Fast`; default `Fast`. Raw range `Off` to `On`; raw default `On`. Selects Slow or Fast rotary speed. When changing values, the rotary speaker speed gradually changes, based on the RampTime value.
- `Slow Speed` (`key: SlowSpeed`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.4`. Raw range `0` to `1`; raw default `0.24`. Sets the rotary speed when Speed is set to "Slow." When set to note values, SlowSpeed follows the system tempo.
- `Fast Speed` (`key: FastSpeed`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.3`. Raw range `0` to `1`; raw default `0.73`. Sets the rotary speed when Speed is set to "Fast." When set to note values, FastSpeed follows the system tempo.
- `Ramp Time` (`key: RampTime`, `id: 4`, `type: i`): valid values `Slow`, `Medium`, `Fast`; default `Medium`. Raw range `0` to `2`; raw default `1`. Determines how fast the rotary speed changes when Speed is changed from "Slow" to "Fast" or vice versa.
- `Drive` (`key: Drive`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.1`. Raw range `0` to `1`; raw default `0.71`. Controls how much of the speaker's internal amp is overdriven. At higher values, the speaker imparts more of a gritty sound.
- `Speaker Blend` (`key: Blend`, `id: 6`, `type: f`): display range `-100` to `100` Woofer; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls how much of the woofer speaker is heard vs. the horn speaker. Normally leave this set to "Equal."
- `Mix` (`key: Mix`, `id: 7`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the rotary effect and the dry signal. At 0%, no rotary effect is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-60` to `6` dB; default `-5.7`. Raw range `-60` to `6`; raw default `-5.7`. Sets the overall level of the block.
- `Headroom` (`key: Headroom`, `id: 9`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Provides up to 12.0 dB of additional headroom.

145 Rotary

- Model key: `HD2\_Rotary145RotaryStereo`
- Model ID: `158`
- Type: Modulation
- Category: `modulation`
- Class: Rotary
- DSP usage estimate: 5.5
- Based on: Leslie 145
- Agoura model: No

Parameters

- `Speed` (`key: Speed`, `id: 1`, `type: b`): valid values `Slow`, `Fast`; default `Fast`. Raw range `Off` to `On`; raw default `On`. Selects Slow or Fast rotary speed. When changing values, the rotary speaker speed gradually changes, based on the RampTime value.
- `Slow Speed` (`key: SlowSpeed`, `id: 2`, `type: f`): display range `0.1` to `10` Hz; default `2.72`. Raw range `0.1` to `10`; raw default `2.72`. Sets the rotary speed when Speed is set to "Slow." When set to note values, SlowSpeed follows the system tempo.
- `Fast Speed` (`key: FastSpeed`, `id: 3`, `type: f`): display range `0.1` to `10` Hz; default `5.3`. Raw range `0.1` to `10`; raw default `5.3`. Sets the rotary speed when Speed is set to "Fast." When set to note values, FastSpeed follows the system tempo.
- `Ramp Time` (`key: RampTime`, `id: 4`, `type: i`): valid values `Slow`, `Medium`, `Fast`; default `Medium`. Raw range `0` to `2`; raw default `1`. Determines how fast the rotary speed changes when Speed is changed from "Slow" to "Fast" or vice versa.

- `Drive` (`key: Drive`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Controls how much of the speaker's internal amp is overdriven. At higher values, the speaker imparts more of a gritty sound.
- `Speaker Blend` (`key: Blend`, `id: 6`, `type: f`): display range `-100` to `100` Woofer; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls how much of the woofer speaker is heard vs. the horn speaker. Normally leave this set to "Equal."
- `Mix` (`key: Mix`, `id: 7`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the rotary effect and the dry signal. At 0%, no rotary effect is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-60` to `6` dB; default `-6`. Raw range `-60` to `6`; raw default `-6`. Sets the overall level of the block.
- `Headroom` (`key: Headroom`, `id: 9`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Provides up to 12.0 dB of additional headroom.

3 Note Generator

- Model key: `HD2\_Synth3NoteGeneratorMono`
- Model ID: `336`
- Type: Synth
- Category: `synth`
- Class: Generator
- DSP usage estimate: 3.6
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Osc 1 Shape` (`key: Osc1Shape`, `id: 1`, `type: i`): valid values `Saw Up`, `Saw Down`, `Triangle`, `Sine`, `Square`; default `Sine`. Raw range `0` to `4`; raw default `3`. Selects the shape of Oscillator 1.
- `Osc 1 Octave` (`key: Osc1Octave`, `id: 2`, `type: i`): display range `0` to `8` unitless; default `3`. Raw range `0` to `8`; raw default `3`. Sets the octave of Oscillator 1, with a 9-octave range.
- `Osc 1 Note` (`key: Osc1Note`, `id: 3`, `type: i`): valid values `C`, `C#`, `D`, `D#`, `E`, `F`, `F#`, `G`, `G#`, `A`, `A#`, `B`; default `C`. Raw range `0` to `11`; raw default `0`. Sets the note of Oscillator 1.
- `Osc 1 Level` (`key: Osc1Level`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the level of Oscillator 1.
- `Osc 1 Glide` (`key: Osc1Glide`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the length of time it takes for Osc1 Oct and Osc1 Note to change when adjusting values manually or via snapshots and controllers. 0.0 causes immediate stepped changes whereas higher values cause the octave or note adjustment to glide smoothly.
- `Osc 2 Shape` (`key: Osc2Shape`, `id: 6`, `type: i`): valid values `Saw Up`, `Saw Down`, `Triangle`, `Sine`, `Square`; default `Sine`. Raw range `0` to `4`; raw default `3`. Selects the shape of Oscillator 2.
- `Osc 2 Octave` (`key: Osc2Octave`, `id: 7`, `type: i`): display range `0` to `8` unitless; default `3`. Raw range `0` to `8`; raw default `3`. Sets the octave of Oscillator 2, with a 9-octave range.
- `Osc 2 Note` (`key: Osc2Note`, `id: 8`, `type: i`): valid values `C`, `C#`, `D`, `D#`, `E`, `F`, `F#`, `G`, `G#`, `A`, `A#`, `B`; default `G`. Raw range `0` to `11`; raw default `7`. Sets the note of Oscillator 2.
- `Osc 2 Level` (`key: Osc2Level`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the level of Oscillator 2.
- `Osc 2 Glide` (`key: Osc2Glide`, `id: 10`, `type: f`): display range `0` to `10` unitless;

default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the length of time it takes for Osc2 Oct and Osc2 Note to change when adjusting values manually or via snapshots and controllers. 0.0 causes immediate stepped changes whereas higher values cause the octave or note adjustment to glide smoothly.

- `Osc 3 Shape` (`key: Osc3Shape`, `id: 11`, `type: i`): valid values `Saw Up`, `Saw Down`, `Triangle`, `Sine`, `Square`; default `Sine`. Raw range `0` to `4`; raw default `3`. Selects the shape of Oscillator 3.

- `Osc 3 Octave` (`key: Osc3Octave`, `id: 12`, `type: i`): display range `0` to `8` unitless; default `4`. Raw range `0` to `8`; raw default `4`. Sets the octave of Oscillator 3, with a 9-octave range.

- `Osc 3 Note` (`key: Osc3Note`, `id: 13`, `type: i`): valid values `C`, `C#`, `D`, `D#`, `E`, `F`, `F#`, `G`, `G#`, `A`, `A#`, `B`; default `E`. Raw range `0` to `11`; raw default `4`. Sets the note of Oscillator 3.

- `Osc 3 Level` (`key: Osc3Level`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the level of Oscillator 3.

- `Osc 3 Glide` (`key: Osc3Glide`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the length of time it takes for Osc3 Oct and Osc3 Note to change when adjusting values manually or via snapshots and controllers. 0.0 causes immediate stepped changes whereas higher values cause the octave or note adjustment to glide smoothly.

- `Attack` (`key: Attack`, `id: 16`, `type: f`): display range `10` to `10000` ms; default `500`. Raw range `0.01` to `10`; raw default `0.5`. Controls how fast the 3 Note Generator fades in when engaged, from 10 ms to 10 sec.

- `Decay` (`key: Decay`, `id: 17`, `type: f`): display range `10` to `10000` ms; default `3000`. Raw range `0.01` to `10`; raw default `3`. Controls how fast the 3 Note Generator fades out when bypassed, from 10 ms to 10 sec.

- `Dry Level` (`key: DryLevel`, `id: 18`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of the dry signal.

- `Level` (`key: Level`, `id: 19`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

3 OSC Synth

- Model key: `HD2\_SynthSubtractiveStereo`

- Model ID: `505`

- Type: Synth

- Category: `synth`

- Class: Synth

- DSP usage estimate: 8.5

- Based on: Line 6 Original

- Agoura model: No

Parameters

- `Osc 1 Wave` (`key: ShapeVoice1`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Morphs Oscillator 1 from a sine wave (at 0.0) to a triangle wave (at 5.0) to a modified square wave (at 10.0).

- `Osc 1 Duty Cycle` (`key: DutyVoice1`, `id: 2`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the duty cycle of Oscillator 1. Adjusting Duty Cycle to either extreme increases harmonic content of the waveform.

- `Osc 1 Octave` (`key: OctaveVoice1`, `id: 3`, `type: i`): display range `-3` to `2` unitless; default `0`. Raw range `-3` to `2`; raw default `0`. Sets the octave of Oscillator 1, with a 6-octave range.

- `Osc 1 Freq` (`key: PitchVoice1`, `id: 4`, `type: f`): display range `-12` to `12` unitless; default `0`. Raw range `-12` to `12`; raw default `0`. Sets the interval of Oscillator 1, from 1 octave down to 1 octave up, with 0.1 octave resolution.

- `Osc 1 Pan` (`key: PanVoice1`, `id: 5`, `type: f`): display range `-100` to `100` Left; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls the panning of Oscillator 1 between the left and right channels.
- `Osc 1 Level` (`key: LevelVoice1`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the level of Oscillator 1.
- `Osc 2 Wave` (`key: ShapeVoice2`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Morphs Oscillator 2 from a sine wave (at 0.0) to a triangle wave (at 5.0) to a modified square wave (at 10.0).
- `Osc 2 Duty Cycle` (`key: DutyVoice2`, `id: 8`, `type: f`): display range `0` to `100` %; default `30.2`. Raw range `0` to `1`; raw default `0.302`. Controls the duty cycle of Oscillator 2. Adjusting Duty Cycle to either extreme increases harmonic content of the waveform.
- `Osc 2 Octave` (`key: OctaveVoice2`, `id: 9`, `type: i`): display range `-3` to `2` unitless; default `-1`. Raw range `-3` to `2`; raw default `-1`. Sets the octave of Oscillator 2, with a 6-octave range.
- `Osc 2 Freq` (`key: PitchVoice2`, `id: 10`, `type: f`): display range `-12` to `12` unitless; default `-0.1`. Raw range `-12` to `12`; raw default `-0.1`. Sets the interval of Oscillator 2, from 1 octave down to 1 octave up, with 0.1 octave resolution.
- `Osc 2 Pan` (`key: PanVoice2`, `id: 11`, `type: f`): display range `-100` to `100` Left; default `0.544`. Raw range `0` to `1`; raw default `0.544`. Controls the panning of Oscillator 2 between the left and right channels.
- `Osc 2 Level` (`key: LevelVoice2`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the level of Oscillator 2.
- `Osc 3 Wave` (`key: ShapeVoice3`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Morphs Oscillator 3 from a sine wave (at 0.0) to a triangle wave (at 5.0) to a modified square wave (at 10.0).
- `Osc 3 Duty Cycle` (`key: DutyVoice3`, `id: 14`, `type: f`): display range `0` to `100` %; default `72`. Raw range `0` to `1`; raw default `0.72`. Controls the duty cycle of Oscillator 3. Adjusting Duty Cycle to either extreme increases harmonic content of the waveform.
- `Osc 3 Octave` (`key: OctaveVoice3`, `id: 15`, `type: i`): display range `-3` to `2` unitless; default `-1`. Raw range `-3` to `2`; raw default `-1`. Sets the octave of Oscillator 3, with a 6-octave range.
- `Osc 3 Freq` (`key: PitchVoice3`, `id: 16`, `type: f`): display range `-12` to `12` unitless; default `-0.15`. Raw range `-12` to `12`; raw default `-0.15`. Sets the interval of Oscillator 3, from 1 octave down to 1 octave up, with 0.1 octave resolution.
- `Osc 3 Pan` (`key: PanVoice3`, `id: 17`, `type: f`): display range `-100` to `100` Left; default `0.478`. Raw range `0` to `1`; raw default `0.478`. Controls the panning of Oscillator 3 between the left and right channels.
- `Osc 3 Level` (`key: LevelVoice3`, `id: 18`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the level of Oscillator 3.
- `Filter Preset` (`key: SynthPreset`, `id: 19`, `type: i`): valid values `1`, `2`, `3`, `4`; default `1`. Raw range `0` to `3`; raw default `0`. Choose between 4 filter responses to shape the synth.
- `FM 3 > 1` (`key: FM Voice3to1`, `id: 20`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls how much of Oscillator 3 is used to modulate Oscillator 1's frequency.
- `Low Cut` (`key: LowCut`, `id: 21`, `type: f`): display range `19.9` to `1000` Off; default `19.9`. Raw range `19.9` to `1000`; raw default `19.9`. Applies a low cut (or high pass) filter to the synth, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 22`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (or low pass) filter to the synth, letting you remove the effected signal above a certain frequency.
- `Mix` (`key: Mix`, `id: 23`, `type: f`): display range `0` to `100` %; default `100`. Raw

range `0` to `1`; raw default `1`. Controls the blend between the synth and the dry signal. At 0%, no synth is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 24`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

4 OSC Generator

- Model key: `HD2\_Synth4OSCGeneratorMono`
- Model ID: `337`
- Type: Synth
- Category: `synth`
- Class: Generator
- DSP usage estimate: 3.8
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Osc 1 Shape` (`key: Osc1Shape`, `id: 1`, `type: i`): valid values `Saw Up`, `Saw Down`, `Triangle`, `Sine`, `Square`; default `Sine`. Raw range `0` to `4`; raw default `3`. Selects the shape of Oscillator 1.
- `Osc 1 Freq` (`key: Osc1Freq`, `id: 2`, `type: f`): display range `20` to `10000` Hz; default `110`. Raw range `20` to `10000`; raw default `110`. Controls the frequency of Oscillator 1, from 20 Hz to 10.0 kHz.
- `Osc 1 Level` (`key: Osc1Level`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the level of Oscillator 1.
- `Osc 2 Shape` (`key: Osc2Shape`, `id: 4`, `type: i`): valid values `Saw Up`, `Saw Down`, `Triangle`, `Sine`, `Square`; default `Sine`. Raw range `0` to `4`; raw default `3`. Selects the shape of Oscillator 2.
- `Osc 2 Freq` (`key: Osc2Freq`, `id: 5`, `type: f`): display range `20` to `10000` Hz; default `220`. Raw range `20` to `10000`; raw default `220`. Controls the frequency of Oscillator 2, from 20 Hz to 10.0 kHz.
- `Osc 2 Level` (`key: Osc2Level`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the level of Oscillator 2.
- `Osc 3 Shape` (`key: Osc3Shape`, `id: 7`, `type: i`): valid values `Saw Up`, `Saw Down`, `Triangle`, `Sine`, `Square`; default `Sine`. Raw range `0` to `4`; raw default `3`. Selects the shape of Oscillator 3.
- `Osc 3 Freq` (`key: Osc3Freq`, `id: 8`, `type: f`): display range `20` to `10000` Hz; default `440`. Raw range `20` to `10000`; raw default `440`. Controls the frequency of Oscillator 3, from 20 Hz to 10.0 kHz.
- `Osc 3 Level` (`key: Osc3Level`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the level of Oscillator 3.
- `Osc 4 Shape` (`key: Osc4Shape`, `id: 10`, `type: i`): valid values `Saw Up`, `Saw Down`, `Triangle`, `Sine`, `Square`; default `Sine`. Raw range `0` to `4`; raw default `3`. Selects the shape of Oscillator 4.
- `Osc 4 Freq` (`key: Osc4Freq`, `id: 11`, `type: f`): display range `20` to `10000` Hz; default `660`. Raw range `20` to `10000`; raw default `660`. Controls the frequency of Oscillator 4, from 20 Hz to 10.0 kHz.
- `Osc 4 Level` (`key: Osc4Level`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the level of Oscillator 4.
- `Attack` (`key: Attack`, `id: 13`, `type: f`): display range `10` to `10000` ms; default `500`. Raw range `0.01` to `10`; raw default `0.5`. Controls how fast the 4 OSC Generator fades in when engaged, from 10 ms to 10 sec.
- `Decay` (`key: Decay`, `id: 14`, `type: f`): display range `10` to `10000` ms; default `3000`. Raw range `0.01` to `10`; raw default `3`. Controls how fast the 4 OSC Generator fades out when bypassed, from 10 ms to 10 sec.

- `Dry Level` (`key: DryLevel`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of the dry signal.
- `Level` (`key: Level`, `id: 16`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

4-Voice Chorus

- Model key: `HD2\_Chorus4VoiceMono`
- Model ID: `408`
- Type: Modulation
- Category: `modulation`
- Class: Chorus
- DSP usage estimate: 2.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Rate` (`key: Speed`, `id: 1`, `type: f`): display range `0.1` to `2` Hz; default `0.5`. Raw range `0.1` to `2`; raw default `0.5`. Controls the speed of the chorus' low-frequency oscillator (LFO) from slow to fast.
- `Depth` (`key: Depth`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the amplitude of the modulation, from mild to deep.
- `Voices` (`key: NumVoices`, `id: 3`, `type: i`): display range `2` to `4` unitless; default `4`. Raw range `2` to `4`; raw default `4`. Determines the number of voices in the chorus (2, 3, or 4).
- `Low Cut` (`key: HPFFrq`, `id: 4`, `type: f`): display range `40` to `1000` Hz; default `266`. Raw range `40` to `1000`; raw default `266`. Applies a low cut (high pass) filter to the chorus, letting you remove the effected signal below a certain frequency.
- `High Shelf` (`key: HighShelf`, `id: 5`, `type: f`): display range `-6` to `3` dB; default `0`. Raw range `-6` to `3`; raw default `0`. Applies a high cut (low pass) filter to the fills, letting you remove the effected signal above a certain frequency.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the chorus effect and the dry signal. At 0%, no chorus effect is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 7`, `type: f`): display range `-60` to `6` dB; default `1`. Raw range `-60` to `6`; raw default `1`. Sets the overall level of the block.

60s Bias Trem

- Model key: `HD2\_Tremolo60sBiasTremMono`
- Model ID: `284`
- Type: Modulation
- Category: `modulation`
- Class: Tremolo
- DSP usage estimate: 1.8
- Based on: Vox AC-15 Tremolo
- Agoura model: No

Parameters

- `Speed` (`key: Speed`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the speed or rate of the tremolo.

When set to note values, Speed follows the system tempo.

- `Intensity` (`key: Intensity`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.3`. Raw range `0` to `1`; raw default `0.73`. Controls the depth of the tremolo, or the intensity of the volume fluctuations (or when Mode is set to "Vibrato", pitch fluctuations).
- `Mode` (`key: Mode`, `id: 3`, `type: b`): valid values `Tremolo`, `Vibrato`; default `Tremolo`. Raw range `Off` to `On`; raw default `Off`. Selects between Tremolo (repeating volume fluctuations) and Vibrato (repeating pitch fluctuations).
- `Level` (`key: Level`, `id: 4`, `type: f`): display range `-60` to `6` dB; default `1`. Raw range `-60` to `6`; raw default `1`. Sets the overall level of the block.

70s Chorus

- Model key: `HD2\_Chorus70sChorusMono`
- Model ID: `298`
- Type: Modulation
- Category: `modulation`
- Class: Chorus
- DSP usage estimate: 3.0
- Based on: BOSS CE-1
- Agoura model: No

Parameters

- `Chorus Rate` (`key: ChorusIntensity`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Controls the speed or rate of the chorus. When set to note values, Cho Rate follows the system tempo. Does nothing when Mode is set to "Vibrato."
- `Mode` (`key: Mode`, `id: 2`, `type: b`): valid values `Chorus`, `Vibrato`; default `Chorus`. Raw range `Off` to `On`; raw default `Off`. Selects the type of modulation--Chorus or Vibrato.
- `Vibrato Rate` (`key: VibratoRate`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the speed or rate of the vibrato. When set to note values, Vib Rate follows the system tempo. Does nothing when Mode is set to "Chorus."
- `Vibrato Depth` (`key: VibratoDepth`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the depth or intensity of the vibrato. Does nothing when Mode is set to "Chorus."
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the modulation effect and the dry signal. At 0%, no modulation is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `1`. Raw range `-60` to `6`; raw default `1`. Sets the overall level of the block.
- `Headroom` (`key: Headroom`, `id: 7`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Some chorus pedals' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative values increase the perceived amount of grit; positive values clean things up a bit.

AM Ring Mod

- Model key: `HD2\_RingModulatorAMRingModMono`
- Model ID: `293`
- Type: Modulation
- Category: `modulation`

- Class: Ring Mod
- DSP usage estimate: 2.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Frequency` (`key: Frequency`, `id: 1`, `type: f`): display range `5` to `4000` Hz; default `1280`. Raw range `5` to `4000`; raw default `1280`. Controls the frequency of the FM (Frequency Modulation).
- `AM` (`key: AM`, `id: 2`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, adds AM (Amplitude Modulation).
- `AM Freq` (`key: AMFreq`, `id: 3`, `type: f`): display range `200` to `8000` Hz; default `1650.8`. Raw range `200` to `8000`; raw default `1650.8`. Controls the frequency of the AM (Amplitude Modulation).
- `LFO` (`key: LFO`, `id: 4`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, enables the LFO (Low Frequency Oscillator) to modulate the FM and AM frequencies up and down.
- `LFO Rate` (`key: LFORate`, `id: 5`, `type: f`): display range `0.0001` to `10` Hz; default `5`. Raw range `0.0001` to `10`; raw default `5`. Controls the rate or speed of the LFO. When LFO Rate is set to note values, it follows the system tempo. Does nothing if LFO is off.
- `LFO Shape` (`key: LFOShape`, `id: 6`, `type: i`): valid values `Saw Up`, `Saw Down`, `Triangle`, `Sine`, `Square`, `Inverse Sine`; default `Triangle`. Raw range `0` to `5`; raw default `2`. Controls the wave shape of the LFO. Does nothing if LFO is off.
- `Mix` (`key: Mix`, `id: 7`, `type: f`): display range `0` to `100` %; default `67`. Raw range `0` to `1`; raw default `0.67`. Controls the blend between the ring modulation effect and the dry signal. At 0%, no effect is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-60` to `6` dB; default `4.5`. Raw range `-60` to `6`; raw default `4.5`. Sets the overall level of the block.

Ampeg Liquifier

- Model key: `HD2\_ChorusAmpegLiquifierMono`
- Model ID: `403`
- Type: Modulation
- Category: `modulation`
- Class: Chorus
- DSP usage estimate: 5.1
- Based on: Ampeg Liquifier Chorus
- Agoura model: No

Parameters

- `Rate` (`key: Rate`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the speed of the chorus' low-frequency oscillator (LFO) from slow to fast.
- `Depth` (`key: Depth`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amplitude of the modulation, from mild to deep.
- `Mix` (`key: Mix`, `id: 3`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the chorus effect and the dry signal. At 0%, no chorus is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 4`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Headroom` (`key: Headroom`, `id: 5`, `type: f`): display range `-12` to `12` dB; default

`0`. Raw range `-12` to `12`; raw default `0`. Some mod pedals' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative values increase the perceived amount of grit; positive values clean things up a bit. At 0dB, the model behaves like the original pedal.

- `Type` (`key: Mode`, `id: 6`, `type: b`): valid values `Single`, `Dual`; default `Dual`. Raw range `Off` to `On`; raw default `On`. Liquifier is actually two choruses in one, hence the "Dual" default. If you'd prefer it to behave more like a traditional chorus pedal, choose "Single"

Bleat Chop Trem

- Model key: `HD2\_TremoloPatternMono`
- Model ID: `341`
- Type: Modulation
- Category: `modulation`
- Class: Tremolo
- DSP usage estimate: 1.7
- Based on: Lightfoot Labs Goatkeeper
- Agoura model: No

Parameters

- `Speed` (`key: Speed`, `id: 1`, `type: f`): display range `0` to `15` Hz; default `1`. Raw range `0` to `15`; raw default `1`. Controls the speed or rate of the step sequence. When set to note values, Speed follows the system tempo.
- `Wave Shape` (`key: WaveShape`, `id: 2`, `type: i`): valid values `Saw Up`, `Saw Down`, `Triangle`, `Sine`, `Square`; default `Square`. Raw range `0` to `4`; raw default `4`. Selects the wave shape of the tremolo. "Square" is generally the most audible here.
- `Step 1` (`key: Step1`, `id: 3`, `type: i`): display range `0` to `17` unitless; default `2`. Raw range `0` to `17`; raw default `2`. Determines the number of pulses in the sequence's first step, with higher values resulting in progressively shorter and faster tremolo pulses. "Mute" mutes the signal and "Full" bypasses the tremolo for the entirety of the step.
- `Step 2` (`key: Step2`, `id: 4`, `type: i`): display range `0` to `17` unitless; default `4`. Raw range `0` to `17`; raw default `4`. Determines the number of pulses in the sequence's second step, with higher values resulting in progressively shorter and faster tremolo pulses. "Mute" mutes the signal and "Full" bypasses the tremolo for the entirety of the step.
- `Step 3` (`key: Step3`, `id: 5`, `type: i`): display range `0` to `17` unitless; default `8`. Raw range `0` to `17`; raw default `8`. Determines the number of pulses in the sequence's third step, with higher values resulting in progressively shorter and faster tremolo pulses. "Mute" mutes the signal and "Full" bypasses the tremolo for the entirety of the step.
- `Step 4` (`key: Step4`, `id: 6`, `type: i`): display range `0` to `17` unitless; default `6`. Raw range `0` to `17`; raw default `6`. Determines the number of pulses in the sequence's fourth step, with higher values resulting in progressively shorter and faster tremolo pulses. "Mute" mutes the signal and "Full" bypasses the tremolo for the entirety of the step.
- `Depth` (`key: Depth`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the depth of the tremolo, or the intensity of the volume fluctuations.
- `Level` (`key: Level`, `id: 9`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Boctaver

- Model key: `VIC\_PitchBoctaverMono`
- Model ID: `409`
- Type: Pitch
- Category: `pitch`
- Class: Pitch
- DSP usage estimate: 2.5
- Based on: Boss OC-2 Octaver
- Agoura model: No

Parameters

- `-1 Octave` (`key: Oct1Level`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Sets the level of the signal one octave down.
- `-2 Octave` (`key: Oct2Level`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Sets the level of the signal two octaves down.
- `Dry Level` (`key: DryLevel`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Sets the level of the dry (unaffected) signal.

Bubble Vibrato

- Model key: `HD2\_VibratoBubbleVibratoMono`
- Model ID: `299`
- Type: Modulation
- Category: `modulation`
- Class: Chorus
- DSP usage estimate: 3.0
- Based on: BOSS VB-2 Vibrato
- Agoura model: No

Parameters

- `Speed` (`key: Speed`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.32`. Raw range `0` to `1`; raw default `0.632`. Controls the speed or rate of the phaser. When set to note values, Speed follows the system tempo.
- `Depth` (`key: Depth`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the depth or intensity of the vibrato effect.
- `Rise Time` (`key: RiseTime`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls how long it takes for the vibrato effect to fade in.
- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the vibrato effect and the dry signal.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Headroom` (`key: Headroom`, `id: 6`, `type: f`): display range `-12` to `12` dB; default `3`. Raw range `-12` to `12`; raw default `3`. Provides up to 12.0 dB of additional headroom. Some pedals' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative values increase the perceived amount of grit; positive values clean things up a bit.

Chorus

- Model key: `HD2\_ChorusMono`
- Model ID: `267`
- Type: Modulation
- Category: `modulation`
- Class: Chorus
- DSP usage estimate: 2.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Speed` (`key: Speed`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the speed or rate of the chorus. When set to note values, Speed follows the system tempo.
- `Depth` (`key: Depth`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the depth or intensity of the chorus. Higher values can get into pretty warbly territory, depending on the WavShape value.
- `Predelay` (`key: Predelay`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3.2`. Raw range `0` to `1`; raw default `0.32`. Applies a bit of delay to the affected signal which at higher values, can impart a bit of ADT (Automatic Double Tracking) sound. Most evident when Mix is not maxed out or the Chorus block is on a parallel path.
- `Wave Shape` (`key: WavShape`, `id: 4`, `type: i`): valid values `Saw Up`, `Saw Down`, `Triangle`, `Sine`, `Square`, `Inverse Sine`, `Random`; default `Triangle`. Raw range `0` to `6`; raw default `2`. Selects one of seven wave shapes for the modulation.
- `Tone` (`key: Tone`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall tonal balance of the chorus.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the modulation effect and the dry signal. At 0%, no modulation is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 7`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Chrome

- Model key: `HD2\_WahChromeMono`
- Model ID: `314`
- Type: Wah
- Category: `wah`
- Class: Wah
- DSP usage estimate: 1.3
- Based on: Maestro Boomerang
- Agoura model: No

Parameters

- `Position` (`key: Pedal`, `id: 1`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the position or frequency of the wah effect. By default, this is assigned to Expression Pedal 1.
- `Fc Low` (`key: FcLow`, `id: 2`, `type: f`): display range `20` to `500` Hz; default `470`. Raw range `20` to `500`; raw default `470`. Sets the low frequency cutoff of the wah filter. Along with Fc High, sets the frequency range or sweep of the wah.
- `Fc High` (`key: FcHigh`, `id: 3`, `type: f`): display range `500` to `5000` Hz; default

`2415`. Raw range `500` to `5000`; raw default `2415`. Sets the high frequency cutoff of the wah filter. Along with Fc Low, sets the frequency range or sweep of the wah.

- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the wah effect and the dry signal. At 0%, no wah effect is heard; at 100%, no dry signal is heard. If the wah effect is a bit strong, consider bringing this down a bit.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Wah block.

Chrome Custom

- Model key: `HD2\_WahChromeCustomMono`
- Model ID: `313`
- Type: Wah
- Category: `wah`
- Class: Wah
- DSP usage estimate: 1.3
- Based on: Colorsound Wah-fuzz
- Agoura model: No

Parameters

- `Position` (`key: Pedal`, `id: 1`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the position or frequency of the wah effect. By default, this is assigned to Expression Pedal 1.
- `Fc Low` (`key: FcLow`, `id: 2`, `type: f`): display range `20` to `500` Hz; default `300`. Raw range `20` to `500`; raw default `300`. Sets the low frequency cutoff of the wah filter. Along with Fc High, sets the frequency range or sweep of the wah.
- `Fc High` (`key: FcHigh`, `id: 3`, `type: f`): display range `500` to `5000` Hz; default `1975`. Raw range `500` to `5000`; raw default `1975`. Sets the high frequency cutoff of the wah filter. Along with Fc Low, sets the frequency range or sweep of the wah.
- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the wah effect and the dry signal. At 0%, no wah effect is heard; at 100%, no dry signal is heard. If the wah effect is a bit strong, consider bringing this down a bit.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Wah block.

Colorful

- Model key: `HD2\_WahColorfulMono`
- Model ID: `315`
- Type: Wah
- Category: `wah`
- Class: Wah
- DSP usage estimate: 1.3
- Based on: Dunlop Cry Baby Super
- Agoura model: No

Parameters

- `Position` (`key: Pedal`, `id: 1`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the position or frequency of the wah effect. By default, this is assigned to Expression Pedal 1.

- `Fc Low` (`key: FcLow`, `id: 2`, `type: f`): display range `20` to `500` Hz; default `280`. Raw range `20` to `500`; raw default `280`. Sets the low frequency cutoff of the wah filter. Along with Fc High, sets the frequency range or sweep of the wah.
- `Fc High` (`key: FcHigh`, `id: 3`, `type: f`): display range `500` to `5000` Hz; default `2101`. Raw range `500` to `5000`; raw default `2101`. Sets the high frequency cutoff of the wah filter. Along with Fc Low, sets the frequency range or sweep of the wah.
- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the wah effect and the dry signal. At 0%, no wah effect is heard; at 100%, no dry signal is heard. If the wah effect is a bit strong, consider bringing this down a bit.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Wah block.

Conductor

- Model key: `HD2\_WahConductorMono`
- Model ID: `316`
- Type: Wah
- Category: `wah`
- Class: Wah
- DSP usage estimate: 1.3
- Based on: RMC Real McCoy 1
- Agoura model: No

Parameters

- `Position` (`key: Pedal`, `id: 1`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the position or frequency of the wah effect. By default, this is assigned to Expression Pedal 1.
- `Fc Low` (`key: FcLow`, `id: 2`, `type: f`): display range `20` to `500` Hz; default `392`. Raw range `20` to `500`; raw default `392`. Sets the low frequency cutoff of the wah filter. Along with Fc High, sets the frequency range or sweep of the wah.
- `Fc High` (`key: FcHigh`, `id: 3`, `type: f`): display range `500` to `5000` Hz; default `922`. Raw range `500` to `5000`; raw default `922`. Sets the high frequency cutoff of the wah filter. Along with Fc Low, sets the frequency range or sweep of the wah.
- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the wah effect and the dry signal. At 0%, no wah effect is heard; at 100%, no dry signal is heard. If the wah effect is a bit strong, consider bringing this down a bit.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Wah block.

Courtesan Flange

- Model key: `HD2\_FlangerCourtesanFlangeMono`
- Model ID: `295`
- Type: Modulation
- Category: `modulation`
- Class: Flanger/Tape
- DSP usage estimate: 4.0
- Based on: Electro-Harmonix Deluxe Electric Mistress
- Agoura model: No

Parameters

- `Rate` (`key: Rate`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.3`. Raw range `0` to `1`; raw default `0.43`. Controls the speed or rate of the flanger. When set to note values, Speed follows the system tempo.
- `Range` (`key: Range`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.1`. Raw range `0` to `1`; raw default `0.71`. Sets the lower limit of the flanger sweep. Higher values result in wider, more dramatic sweeps. When FreezeLFO is on, sweeps the frequency of the comb filter.
- `Color` (`key: Color`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the intensity of the flanger sweep by increasing feedback. Higher values result in more of that classic "whoosh."
- `Freeze LFO` (`key: FilterMatrix`, `id: 4`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, disables the automatic flanger sweep (LFO), so Rate no longer affects the sound. Adjusting Range then manually sweeps the frequency of the comb filter.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the modulation effect and the dry signal.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Headroom` (`key: Headroom`, `id: 7`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Provides up to 12.0 dB of additional headroom.

Deluxe Phaser

- Model key: `HD2\_PhaserDeluxePhaserMono`
- Model ID: `326`
- Type: Modulation
- Category: `modulation`
- Class: Phaser
- DSP usage estimate: 2.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Rate` (`key: Rate`, `id: 1`, `type: f`): display range `0` to `10` Hz; default `0.2`. Raw range `0` to `10`; raw default `0.2`. Controls the speed or rate of the phaser. When set to note values, Speed follows the system tempo.
- `Depth` (`key: Depth`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `1`. Raw range `0` to `1`; raw default `0.1`. Along with Offset, controls the depth or intensity of the phaser. For the most obvious results, set both Depth and Offset to lower values (but not all the way to 0.0).
- `Offset` (`key: Offset`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `0.1`. Raw range `0` to `1`; raw default `0.01`. Along with Depth, controls the depth or intensity of the phaser. For the most obvious results, set both Depth and Offset to lower values (but not all the way to 0.0).
- `Feedback` (`key: Feedback`, `id: 4`, `type: f`): display range `-100` to `100` %; default `25`. Raw range `-1` to `1`; raw default `0.25`. Controls how much of the processed signal feeds back into the input.
- `Wave Shape` (`key: WaveShape`, `id: 5`, `type: i`): valid values `Saw Up`, `Saw Down`, `Triangle`, `Sine`, `Square`, `Inverse Sine`, `Random`; default `Triangle`. Raw range `0` to `6`; raw default `2`. Selects one of seven wave shapes for the phaser sweep.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the modulation effect and

the dry signal.

- `Stages` (`key: Stages`, `id: 7`, `type: i`): display range `2` to `16` unitless; default `8`. Raw range `2` to `16`; raw default `8`. Selects the number of phase stages, thus controlling the degree of out-of-phase-ness. The higher number of stages, the richer the effect.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Double Take

- Model key: `HD2\_DelayDoubleDoubleMono`
- Model ID: `340`
- Type: Modulation
- Category: `modulation`
- Class: Flanger/Tape
- DSP usage estimate: 8.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Doubles` (`key: Doubles`, `id: 1`, `type: i`): valid values `1`, `2`, `3`, `4`; default `1`. Raw range `0` to `3`; raw default `0`. Selects the number of additional voices, 1-4.
- `Slop` (`key: Slop`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the apparent tightness or sloppiness of the additional voices. Higher values result in more slop, or more variation between the voices.
- `Sensitivity` (`key: Sensitivity`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Adjusts the Slop parameter's sensitivity to playing dynamics. At higher values, playing harder generates more slop.
- `Dry Level` (`key: Dry Level`, `id: 4`, `type: f`): display range `-60` to `9` dB; default `0`. Raw range `-60` to `9`; raw default `0`. Controls the level of the dry (unaffected) signal.
- `Wet Level` (`key: Wet Level`, `id: 5`, `type: f`): display range `-60` to `9` dB; default `0`. Raw range `-60` to `9`; raw default `0`. Controls the level of the wet (effected) signal.

Dual Pitch

- Model key: `HD2\_PitchDualPitchMono`
- Model ID: `324`
- Type: Pitch
- Category: `pitch`
- Class: Pitch
- DSP usage estimate: 4.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Interval 1` (`key: Interval1`, `id: 1`, `type: i`): display range `-24` to `24` unitless; default `7`. Raw range `-24` to `24`; raw default `7`. Sets the pitch of the first pitch-shifted voice in semitones, from 2 octaves down to 2 octaves up.

- `Cents 1` (`key: Cents1`, `id: 2`, `type: f`): display range `-50` to `50` unitless; default `0`. Raw range `-50` to `50`; raw default `0`. Sets the pitch of the first pitch-shifted voice in cents, from -50.0 to +50.0.
- `Delay 1` (`key: Time1`, `id: 3`, `type: f`): display range `0` to `100` ms; default `0`. Raw range `0` to `0.1`; raw default `0`. Delays the first pitch-shifted voice slightly. At lower values, it can thicken up your tone or at higher values, it can kind of emulate strumming from a single note.
- `Voice 1 Level` (`key: LevelVoice1`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of the first pitch-shifted voice.
- `Interval 2` (`key: Interval2`, `id: 5`, `type: i`): display range `-24` to `24` unitless; default `16`. Raw range `-24` to `24`; raw default `16`. Sets the pitch of the second pitch-shifted voice in semitones, from 2 octaves down to 2 octaves up.
- `Cents 2` (`key: Cents2`, `id: 6`, `type: f`): display range `-50` to `50` unitless; default `-5`. Raw range `-50` to `50`; raw default `-5`. Sets the pitch of the second pitch-shifted voice in cents, from -50.0 to +50.0.
- `Delay 2` (`key: Time2`, `id: 7`, `type: f`): display range `0` to `100` ms; default `0`. Raw range `0` to `0.1`; raw default `0`. Delays the second pitch-shifted voice slightly. At lower values, it can thicken up your tone or at higher values, it can kind of emulate strumming from a single note.
- `Voice 2 Level` (`key: LevelVoice2`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of the second pitch-shifted voice.
- `Mix` (`key: Mix`, `id: 9`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the pitch-shifted signal and the dry signal. At 0%, no pitch-shifted signal is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 10`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Dynamix Flanger

- Model key: `HD2\_FlangerDynamixFlangerMono`
- Model ID: `325`
- Type: Modulation
- Category: `modulation`
- Class: Flanger/Tape
- DSP usage estimate: 2.9
- Based on: MicMix Dyna Flanger
- Agoura model: No

Parameters

- `Speed` (`key: Speed`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `0.44`. Raw range `0` to `1`; raw default `0.044`. Controls the speed or rate of the flanger when Ctl Select is set to "LF0." When Speed is set to note values, it follows the system tempo. Does nothing when Ctl Select is set to "Envelope" or "Manual."
- `Control Select` (`key: Control Select`, `id: 2`, `type: i`): valid values `LF0`, `Envelope`, `Manual`; default `LF0`. Raw range `0` to `2`; raw default `0`. Selects whether the flanger sweep shifts up and down automatically like a traditional flanger ("LF0"), responds to your playing dynamics ("Envelope"), or is adjusted manually from the Manual knob/slider ("Manual").
- `Depth` (`key: Depth`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls how wide and dramatic the flanging sweep appears.
- `Manual` (`key: Manual`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.18`. Raw range `0` to `1`; raw default `0.418`. Manually controls the flanger sweep when

Ctl Select is set to "Manual." Does nothing when Ctl Select is set to "LFO" or "Envelope."

- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the modulation effect and the dry signal.
- `Phasing` (`key: Phasing`, `id: 6`, `type: f`): display range `-10` to `10` unitless; default `-9.999`. Raw range `-1` to `1`; raw default `-0.9999`. Chooses whether the effect produces in-phase flanging (negative values) or out-of-phase flanging (positive values).
- `Recycle` (`key: Recycle`, `id: 7`, `type: b`): valid values `Out`, `In`; default `In`. Raw range `Off` to `On`; raw default `On`. When on, adds feedback.
- `CV Dynamics` (`key: CV Dynamics`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls how wide the sweep range is based on your playing dynamics when Ctl Select is set to "Envelope." Higher values result in a wider range. Does nothing when Ctl Select is set to "LFO" or "Manual."
- `Max Delay` (`key: Max Delay`, `id: 9`, `type: f`): display range `10` to `99.7` ms; default `10`. Raw range `0.01` to `0.0997`; raw default `0.01`. Sets the longest point of the flanger sweep. Higher values can result in spacey slapback delay and chorus-type sounds.
- `CV Tracking` (`key: CV Tracking`, `id: 10`, `type: b`): valid values `Normal`, `Invert`; default `Normal`. Raw range `Off` to `On`; raw default `Off`. Selects whether the flanger sweep moves from high to low ("Normal") or from low to high ("Inverted").
- `Envelope Lag` (`key: Env Lag`, `id: 11`, `type: f`): display range `0` to `100` ms; default `100`. Raw range `0` to `0.1`; raw default `0.1`. Delays the flanger sweep slightly when Ctl Select is set to "Envelope." Does nothing when Ctl Select is set to "LFO" or "Manual."
- `Envelope Input` (`key: Env Input`, `id: 12`, `type: f`): display range `0` to `70` dB; default `70`. Raw range `0` to `70`; raw default `70`. If your playing dynamics aren't generating the desired flanger sweep range (when Ctl Select is set to "Envelope"), adjust this setting so that your hardest picking triggers the highest point of your ideal sweep. Does nothing when Ctl Select is set to "LFO" or "Manual."
- `CV Decay` (`key: CV Decay`, `id: 13`, `type: i`): valid values `x1`, `x2`, `x4`; default `x4`. Raw range `0` to `2`; raw default `2`. Controls the super quick initial sweep down (or sweep up if CVTracking is set to "Inverted"). x1 is about 0.5 seconds long, x2 is about 1 second, and x4 is about 2 seconds. Does nothing when Ctl Select is set to "LFO" or "Manual."

Fassel

- Model key: `HD2\_WahFasselMono`
- Model ID: `317`
- Type: Wah
- Category: `wah`
- Class: Wah
- DSP usage estimate: 1.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Position` (`key: Pedal`, `id: 1`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the position or frequency of the wah effect. By default, this is assigned to Expression Pedal 1.
- `Fc Low` (`key: FcLow`, `id: 2`, `type: f`): display range `20` to `500` Hz; default `455`. Raw range `20` to `500`; raw default `455`. Sets the low frequency cutoff of the wah filter. Along with Fc High, sets the frequency range or sweep of the wah.
- `Fc High` (`key: FcHigh`, `id: 3`, `type: f`): display range `500` to `5000` Hz; default `2155`. Raw range `500` to `5000`; raw default `2155`. Sets the high frequency cutoff of the wah filter. Along with Fc Low, sets the frequency range or sweep of the wah.
- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `100`. Raw

range `0` to `1`; raw default `1`. Controls the blend between the wah effect and the dry signal. At 0%, no wah effect is heard; at 100%, no dry signal is heard. If the wah effect is a bit strong, consider bringing this down a bit.

- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Wah block.

FlexoVibe

- Model key: `VIC\_FlexoVibeMono`
- Model ID: `407`
- Type: Modulation
- Category: `modulation`
- Class: Phaser
- DSP usage estimate: 1.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Rate` (`key: Speed`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the speed of the chorus' low-frequency oscillator (LFO) from slow to fast.

- `Intensity` (`key: Intensity`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the amplitude of the modulation, from mild to deep.

- `Warp` (`key: Warp`, `id: 3`, `type: f`): display range `-1` to `1` unitless; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the shape of the LFO. At 0.0, the LFO waveform is a triangle; at +1.0 and -1.0, the waveforms exhibit more chaos, or "warping."

- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the effected signal and the dry signal. At 0%, no effect is heard; at 100%, no dry signal is heard.

- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Gray Flanger

- Model key: `HD2\_FlangerGrayFlangerMono`
- Model ID: `296`
- Type: Modulation
- Category: `modulation`
- Class: Flanger/Tape
- DSP usage estimate: 4.0
- Based on: MXR 117 Flanger
- Agoura model: No

Parameters

- `Rate` (`key: Rate`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `1.6`. Raw range `0` to `1`; raw default `0.16`. Controls the speed or rate of the flanger. When set to note values, Speed follows the system tempo.

- `Width` (`key: Width`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.8`. Raw range `0` to `1`; raw default `0.78`. Controls how wide and dramatic the flanging sweep appears.

- `Manual` (`key: Manual`, `id: 3`, `type: f`): display range `0` to `10` unitless; default

`7.7`. Raw range `0` to `1`; raw default `0.77`. Controls the degree of phase shifting. Has no affect when Width is set to 100%.

- `Regeneration` (`key: Regen`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the amount of feedback in the effected signal.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the modulation effect and the dry signal.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Headroom` (`key: Headroom`, `id: 7`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Provides up to 12.0 dB of additional headroom.

HD2_Chorus4VoiceStereo

- Model key: `HD2\_Chorus4VoiceStereo`
- Model ID: `257`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 2.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_Chorus70sChorusStereo

- Model key: `HD2\_Chorus70sChorusStereo`
- Model ID: `167`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 4.9
- Based on: B0Line 6 Original CE-1
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_ChorusAmpegLiquifierStereo

- Model key: `HD2\_ChorusAmpegLiquifierStereo`
- Model ID: `252`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 9.2

- Based on: Ampeg Liquifier Chorus
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_ChorusPlastiChorusStereo

- Model key: `HD2\_ChorusPlastiChorusStereo`
- Model ID: `199`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 5.7
- Based on: Modded Arion SCH-Z chorus
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_ChorusStereo

- Model key: `HD2\_ChorusStereo`
- Model ID: `134`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 3.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_DelayDoubleDoubleStereo

- Model key: `HD2\_DelayDoubleDoubleStereo`
- Model ID: `203`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 8.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_FlangerCourtesanFlangeStereo

- Model key: `HD2\_FlangerCourtesanFlangeStereo`
- Model ID: `163`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 6.5
- Based on: Electro-Harmonix Deluxe EM
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_FlangerDynamixFlangerStereo

- Model key: `HD2\_FlangerDynamixFlangerStereo`
- Model ID: `188`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 3.5
- Based on: MicMix Dynaflanger
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_FlangerGrayFlangerStereo

- Model key: `HD2\_FlangerGrayFlangerStereo`
- Model ID: `164`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 7.5
- Based on: MXR 117 Flanger
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_FlangerHarmonicFlangerStereo

- Model key: `HD2\_FlangerHarmonicFlangerStereo`
- Model ID: `165`
- Type: Modulation

- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 6.5
- Based on: A/DA Flanger
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_PhaserDeluxePhaserStereo

- Model key: `HD2\_PhaserDeluxePhaserStereo`
- Model ID: `189`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 2.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_PhaserPebblePhaserStereo

- Model key: `HD2\_PhaserPebblePhaserStereo`
- Model ID: `244`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 5.0
- Based on: Electro-Harmonix Small Stone
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_PhaserScriptModPhaseStereo

- Model key: `HD2\_PhaserScriptModPhaseStereo`
- Model ID: `162`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 2.6
- Based on: MXR Phase 90
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_PhaserUbiquitousVibeStereo

- Model key: `HD2\_PhaserUbiquitousVibeStereo`
- Model ID: `152`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 3.9
- Based on: Shin-ei Uni-Vibe
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_PitchDualPitchStereo

- Model key: `HD2\_PitchDualPitchStereo`
- Model ID: `192`
- Type: Pitch
- Category: `pitch`
- Class: Unknown
- DSP usage estimate: 7.8
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_PitchPitchWhamStereo

- Model key: `HD2\_PitchPitchWhamStereo`
- Model ID: `156`
- Type: Pitch
- Category: `pitch`
- Class: Unknown
- DSP usage estimate: 4.2
- Based on: Digitech Whammy
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_PitchSimplePitchStereo

- Model key: `HD2\_PitchSimplePitchStereo`
- Model ID: `193`
- Type: Pitch
- Category: `pitch`
- Class: Unknown
- DSP usage estimate: 5.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_PitchTwinHarmonyStereo

- Model key: `HD2\_PitchTwinHarmonyStereo`
- Model ID: `155`
- Type: Pitch
- Category: `pitch`
- Class: Unknown
- DSP usage estimate: 7.7
- Based on: Eventide H3000
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_RetroReelStereo

- Model key: `HD2\_RetroReelStereo`
- Model ID: `250`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 5.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_RingModulatorAMRingModStereo

- Model key: `HD2\_RingModulatorAMRingModStereo`
- Model ID: `161`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 2.4
- Based on: Line 6 Original

- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_Synth3NoteGeneratorStereo

- Model key: `HD2\_Synth3NoteGeneratorStereo`
- Model ID: `422`
- Type: Synth
- Category: `synth`
- Class: Unknown
- DSP usage estimate: 3.6
- Based on: 1x12" Fender Blackface Deluxe
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_Synth40SCGeneratorStereo

- Model key: `HD2\_Synth40SCGeneratorStereo`
- Model ID: `421`
- Type: Synth
- Category: `synth`
- Class: Unknown
- DSP usage estimate: 3.8
- Based on: 4x12" ENGL XXL V30
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_Tremolo60sBiasTremStereo

- Model key: `HD2\_Tremolo60sBiasTremStereo`
- Model ID: `150`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 2.3
- Based on: Vox AC-15 Tremolo
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_TremoloHarmonicStereo

- Model key: `HD2\_TremoloHarmonicStereo`
- Model ID: `194`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 2.4
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_TremoloOpticalTremStereo

- Model key: `HD2\_TremoloOpticalTremStereo`
- Model ID: `151`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 2.0
- Based on: Fender optical tremolo circuit
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_TremoloPatternStereo

- Model key: `HD2\_TremoloPatternStereo`
- Model ID: `204`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 2.1
- Based on: Lightfoot Labs Goatkeeper
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_VibratoBubbleVibratoStereo

- Model key: `HD2\_VibratoBubbleVibratoStereo`
- Model ID: `168`
- Type: Modulation
- Category: `modulation`

- Class: Unknown
- DSP usage estimate: 5.0
- Based on: BOSS VB-2 Vibrato
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_WahChromeCustomStereo

- Model key: `HD2\_WahChromeCustomStereo`
- Model ID: `177`
- Type: Wah
- Category: `wah`
- Class: Unknown
- DSP usage estimate: 1.9
- Based on: Modded Vox V847
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_WahChromeStereo

- Model key: `HD2\_WahChromeStereo`
- Model ID: `178`
- Type: Wah
- Category: `wah`
- Class: Unknown
- DSP usage estimate: 1.9
- Based on: Vox V847
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_WahColorfulStereo

- Model key: `HD2\_WahColorfulStereo`
- Model ID: `179`
- Type: Wah
- Category: `wah`
- Class: Unknown
- DSP usage estimate: 1.9
- Based on: Colorsound Wah-fuzz
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_WahConductorStereo

- Model key: `HD2\_WahConductorStereo`
- Model ID: `180`
- Type: Wah
- Category: `wah`
- Class: Unknown
- DSP usage estimate: 1.9
- Based on: Maestro Boomerang
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_WahFasselStereo

- Model key: `HD2\_WahFasselStereo`
- Model ID: `181`
- Type: Wah
- Category: `wah`
- Class: Unknown
- DSP usage estimate: 1.9
- Based on: Dunlop Cry Baby Super
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_WahTeardrop310Stereo

- Model key: `HD2\_WahTeardrop310Stereo`
- Model ID: `153`
- Type: Wah
- Category: `wah`
- Class: Unknown
- DSP usage estimate: 3.1
- Based on: Dunlop Cry Baby Fasel model 310
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_WahTeardropBassQStereo

- Model key: `HD2\_WahTeardropBassQStereo`

- Model ID: `261`
- Type: Wah
- Category: `wah`
- Class: Unknown
- DSP usage estimate: 2.0
- Based on: Dunlop Bass Cry Baby Model 105Q
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_WahThroatyStereo

- Model key: `HD2\_WahThroatyStereo`
- Model ID: `182`
- Type: Wah
- Category: `wah`
- Class: Unknown
- DSP usage estimate: 1.9
- Based on: RMC Real McCoy 1
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_WahUKWah846Stereo

- Model key: `HD2\_WahUKWah846Stereo`
- Model ID: `154`
- Type: Wah
- Category: `wah`
- Class: Unknown
- DSP usage estimate: 3.1
- Based on: Vox V846
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_WahVettaWahStereo

- Model key: `HD2\_WahVettaWahStereo`
- Model ID: `183`
- Type: Wah
- Category: `wah`
- Class: Unknown
- DSP usage estimate: 1.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

HD2_WahWeeperStereo

- Model key: `HD2\_WahWeeperStereo`
- Model ID: `184`
- Type: Wah
- Category: `wah`
- Class: Unknown
- DSP usage estimate: 1.9
- Based on: Arbiter Cry Baby
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

Harmonic Flanger

- Model key: `HD2\_FlangerHarmonicFlangerMono`
- Model ID: `297`
- Type: Modulation
- Category: `modulation`
- Class: Flanger/Tape
- DSP usage estimate: 3.9
- Based on: A/DA Flanger
- Agoura model: No

Parameters

- `Rate` (`key: Rate`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the speed or rate of the flanger. When set to note values, Speed follows the system tempo.
- `Width` (`key: Width`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls how wide and dramatic the flanging sweep appears.
- `Manual` (`key: Manual`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `8.4`. Raw range `0` to `1`; raw default `0.84`. Controls the degree of phase shifting. Has no effect when Width is set to 100%.
- `Enhance` (`key: Enhance`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Controls the amount of feedback in the effected signal. WARNING! When set to higher values, Harmonic Flanger can begin to self-oscillate and get really loud.
- `Harmonic` (`key: Harmonic`, `id: 5`, `type: b`): valid values `Odd`, `Even`; default `Even`. Raw range `Off` to `On`; raw default `On`. Selects an Even or Odd harmonic relationship between the passband peaks.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the modulation effect and the dry signal.
- `Level` (`key: Level`, `id: 7`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

- `Headroom` (`key: Headroom`, `id: 8`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Provides up to 12.0 dB of additional headroom.

Harmonic Tremolo

- Model key: `HD2\_TremoloHarmonicMono`
- Model ID: `329`
- Type: Modulation
- Category: `modulation`
- Class: Tremolo
- DSP usage estimate: 2.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Speed` (`key: Speed`, `id: 1`, `type: f`): display range `0` to `15` Hz; default `4`. Raw range `0` to `15`; raw default `4`. Controls the speed or rate of the tremolo. When set to note values, Speed follows the system tempo.
- `Intensity` (`key: Intensity`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the depth of the tremolo, or the intensity of the frequency band fluctuations.
- `Wave Shape` (`key: WaveShape`, `id: 3`, `type: i`): valid values `Saw Up`, `Saw Down`, `Triangle`, `Sine`, `Square`, `Inverse Sine`, `Random`; default `Sine`. Raw range `0` to `6`; raw default `3`. Selects the wave shape of the tremolo. Classic tremolo is commonly a sine or triangle wave, but cool choppy sounds can be discovered with square or saw down waves.
- `Duty Cycle` (`key: DutyCycle`, `id: 4`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Alters the wave shape in differing ways. With Triangle, 50% is a normal triangle wave and extreme values warp the wave toward a saw down (0%) or saw up (100%) shape. With Sine, 50% is a normal sine wave and extreme values warp the wave toward a parabolic down (0%) or parabolic up (100%) shape. With Square, 50% is an even square wave, higher values lengthen the signal's on time, and lower values shorten the signal's on time. DutyCycle does not apply to Saw Up or Saw down.
- `Bass Freq` (`key: BassFreq`, `id: 5`, `type: f`): display range `40` to `2000` Hz; default `500`. Raw range `40` to `2000`; raw default `500`. Sets the upper range of the low frequency band. Harmonic Tremolo modulates between the low and high frequency bands.
- `Treble Freq` (`key: TrebFreq`, `id: 6`, `type: f`): display range `100` to `10000` Hz; default `700`. Raw range `100` to `10000`; raw default `700`. Sets the lower range of the high frequency band. Harmonic Tremolo modulates between the low and high frequency bands.
- `Level` (`key: Level`, `id: 7`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Mix` (`key: Mix`, `id: 8`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the modulation effect and the dry signal. At 0%, no modulation is heard; at 100%, no dry signal is heard.

Optical Trem

- Model key: `HD2\_TremoloOpticalTremMono`
- Model ID: `311`
- Type: Modulation
- Category: `modulation`
- Class: Tremolo

- DSP usage estimate: 1.5
- Based on: Fender optical tremolo circuit
- Agoura model: No

Parameters

- `Speed` (`key: Speed`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls the speed or rate of the tremolo. When set to note values, Speed follows the system tempo.
- `Intensity` (`key: Intensity`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the depth of the tremolo, or the intensity of the volume fluctuations.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Pebble Phaser

- Model key: `HD2\_PhaserPebblePhaserMono`
- Model ID: `381`
- Type: Modulation
- Category: `modulation`
- Class: Phaser
- DSP usage estimate: 3.1
- Based on: Electro-Harmonix Small Stone
- Agoura model: No

Parameters

- `Rate` (`key: Rate`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the speed or rate of the phaser. When set to note values, Speed follows the system tempo.
- `Color` (`key: Color`, `id: 2`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When turned on, results in a more pronounced phase shifting effect.
- `Level` (`key: Level`, `id: 4`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Pitch Ring Mod

- Model key: `HD2\_RingModulatorPitchRingModStereo`
- Model ID: `160`
- Type: Modulation
- Category: `modulation`
- Class: Ring Mod
- DSP usage estimate: 3.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Shape` (`key: Shape`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the shape of the main oscillator used for the AM (Amplitude Modulation) carrier. The oscillator is a sine wave at 0.0, a triangle wave at 5.0, and a square wave at 10.0.

- `Duty Cycle` (`key: DutyCycle`, `id: 2`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Alters the oscillator wave shape in differing ways. For example, when Shape is a triangle wave (5.0), 50% is a normal triangle wave and extreme values warp the wave toward a saw down (0%) or saw up (100%) shape. Or when Shape is a square wave (10.0), 50% is symmetrical and extreme values result in a wave shape that's mostly low (0%) or mostly high (100%).
- `Octave` (`key: Octave`, `id: 3`, `type: i`): display range `-3` to `3` unitless; default `-1`. Raw range `-3` to `3`; raw default `-1`. The frequency of the AM (Amplitude Modulation) carrier follows the pitch of the input signal. Octave shifts the AM carrier in relation to the input signal by up to 3 octaves up or down.
- `Pitch` (`key: Pitch`, `id: 4`, `type: f`): display range `-12` to `12` unitless; default `-2.3999`. Raw range `-12` to `12`; raw default `-2.3999`. The frequency of the AM (Amplitude Modulation) carrier follows the pitch of the input signal. Pitch shifts the AM (Amplitude Modulation) carrier in relation to the input signal by up to 12.0 semitones up or down.
- `Low Cut` (`key: LowCut`, `id: 5`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (or high pass) filter to the ring modulation, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 6`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (or low pass) filter to the ring modulation, letting you remove the effected signal above a certain frequency.
- `FM Amount` (`key: FMAmount`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the amount of the FM (Frequency Modulation) modulator applied to the AM carrier. At 0.0, only the AM carrier is applied; at 10.0 the AM carrier is fully modulated by the FM modulator.
- `FM Shape` (`key: FMShape`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `7.7`. Raw range `0` to `1`; raw default `0.77`. Controls the shape of the oscillator used for FM of the AM carrier. The oscillator is a sine wave at 0.0, a triangle wave at 5.0, and a square wave at 10.0.
- `FM Duty` (`key: FMDuty`, `id: 9`, `type: f`): display range `0` to `100` %; default `70`. Raw range `0` to `1`; raw default `0.7`. Alters the FM oscillator wave shape. 50% is symmetrical and extreme values result in a wave shape that's mostly low (0%) or mostly high (100%).
- `FM Octave` (`key: FMOctave`, `id: 10`, `type: i`): display range `-3` to `3` unitless; default `1`. Raw range `-3` to `3`; raw default `1`. The frequency of the FM carrier follows the pitch of the input signal. FM Octave shifts the FM carrier in relation to the input signal by up to 3 octaves up or down.
- `FM Pitch` (`key: FMPitch`, `id: 11`, `type: f`): display range `-12` to `12` unitless; default `1.4`. Raw range `-12` to `12`; raw default `1.4`. The frequency of the FM carrier follows the pitch of the input signal. FM Pitch shifts the FM carrier in relation to the input signal by up to 12.0 semitones up or down.
- `Mix` (`key: Mix`, `id: 12`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the ring modulation effect and the dry signal. At 0%, no effect is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 13`, `type: f`): display range `-60` to `6` dB; default `5.5`. Raw range `-60` to `6`; raw default `5.5`. Sets the overall level of the block.

Pitch Wham

- Model key: `HD2\_PitchPitchWhamMono`
- Model ID: `292`
- Type: Pitch
- Category: `pitch`
- Class: Wham

- DSP usage estimate: 3.5
- Based on: Digitech Whammy
- Agoura model: No

Parameters

- ``Position`` (``key: Pedal``, ``id: 1``, ``type: f``): display range ``0`` to ``100`` %; default ``50``. Raw range ``0`` to ``1``; raw default ``0.5``. Adjusts the position of the controller. By default, this is assigned to Expression Pedal 1.
- ``Heel Pitch`` (``key: Heel``, ``id: 2``, ``type: i``): display range ``-24`` to ``24`` unitless; default ``-12``. Raw range ``-24`` to ``24``; raw default ``-12``. Sets the pitch when the pedal/controller is in its lowest position.
- ``Toe Pitch`` (``key: Toe``, ``id: 3``, ``type: i``): display range ``-24`` to ``24`` unitless; default ``12``. Raw range ``-24`` to ``24``; raw default ``12``. Sets the pitch when the pedal/controller is in its highest position.
- ``Mix`` (``key: Mix``, ``id: 4``, ``type: f``): display range ``0`` to ``100`` %; default ``100``. Raw range ``0`` to ``1``; raw default ``1``. Controls the blend between the pitch-shifted signal and the dry signal. At 0%, no pitch-shifted signal is heard; at 100%, no dry signal is heard.
- ``Level`` (``key: Level``, ``id: 5``, ``type: f``): display range ``-60`` to ``6`` dB; default ``0``. Raw range ``-60`` to ``6``; raw default ``0``. Sets the overall level of the block.

PlastiChorus

- Model key: ``HD2_ChorusPlastiChorusMono``
- Model ID: ``335``
- Type: Modulation
- Category: ``modulation``
- Class: Chorus
- DSP usage estimate: 3.7
- Based on: Modded Arion SCH-Z chorus
- Agoura model: No

Parameters

- ``Rate`` (``key: Rate``, ``id: 1``, ``type: f``): display range ``0`` to ``10`` unitless; default ``3.5``. Raw range ``0`` to ``1``; raw default ``0.35``. Controls the speed or rate of the chorus/vibrato. When set to note values, Rate follows the system tempo.
- ``Depth`` (``key: Depth``, ``id: 2``, ``type: f``): display range ``0`` to ``10`` unitless; default ``4.7``. Raw range ``0`` to ``1``; raw default ``0.47``. Controls the depth or intensity of the modulation.
- ``Mode`` (``key: Mode``, ``id: 3``, ``type: b``): valid values ``Chorus``, ``Vibrato``; default ``Chorus``. Raw range ``Off`` to ``On``; raw default ``Off``. Selects the type of modulation--Chorus or Vibrato.
- ``Tone`` (``key: Tone``, ``id: 4``, ``type: f``): display range ``0`` to ``10`` unitless; default ``7.5``. Raw range ``0`` to ``1``; raw default ``0.75``. Controls the overall tonal balance of the modulation.
- ``Mix`` (``key: Mix``, ``id: 5``, ``type: f``): display range ``0`` to ``100`` %; default ``50``. Raw range ``0`` to ``1``; raw default ``0.5``. Controls the blend between the modulation effect and the dry signal. At 0%, no modulation is heard; at 100%, no dry signal is heard.
- ``Level`` (``key: Level``, ``id: 6``, ``type: f``): display range ``-60`` to ``6`` dB; default ``0``. Raw range ``-60`` to ``6``; raw default ``0``. Sets the overall level of the block.
- ``Headroom`` (``key: Headroom``, ``id: 7``, ``type: f``): display range ``-12`` to ``12`` dB; default ``0``. Raw range ``-12`` to ``12``; raw default ``0``. Some chorus pedals' internal signal paths exhibit a bit of grit, especially when placed after a high-gain amp block. Negative values increase the perceived amount of grit; positive values clean things up a bit.

Poly Capo

- Model key: `L6SPB\_PolyDowntune`
- Model ID: `523`
- Type: Pitch
- Category: `pitch`
- Class: Pitch
- DSP usage estimate: 16.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Interval` (`key: Interval`, `id: 1`, `type: i`): display range `-12` to `12` unitless; default `-2`. Raw range `-12` to `12`; raw default `-2`. Sets the pitch of the effect in semitones, from an octave down to an octave up.
- `Tracking` (`key: Tracking`, `id: 2`, `type: i`): valid values `X Fast`, `Fast`, `Stable`, `X Stable`; default `X Stable`. Raw range `0` to `3`; raw default `3`. Determines how the poly pitch engine reacts to your playing. Leave this set to "X Stable" (fewest artifacts when pitch shifting complex chords) and only select a different setting if you experience too much latency when playing fast lead lines.
- `Auto EQ` (`key: AutoEQ`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Determines how much compensation EQ is applied to the shifted signal. If the effected signal sounds too harsh when pitched up (or dull when pitched down), adjust this setting to taste. The higher the value, the more EQ is applied at the shift end points; when set to 0.0, no compensation EQ is applied.
- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the pitch-shifted signal and the dry signal. At 0%, no pitch-shifted signal is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Poly Detune

- Model key: `L6SPB\_PolyChorus`
- Model ID: `521`
- Type: Modulation
- Category: `modulation`
- Class: Chorus
- DSP usage estimate: 16.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Blend` (`key: Blend`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the blend between the detuned signal and the dry signal. At 0%, no detuning is heard; at 100%, no dry signal is heard.
- `Detune` (`key: Detune`, `id: 2`, `type: f`): display range `-50` to `50` unitless; default `10`. Raw range `-50` to `50`; raw default `10`. Controls the amount of detuning, from -50 cents to +50 cents. Extreme values add more depth or intensity to the chorus-like sound.
- `Low Cut` (`key: LowCut`, `id: 3`, `type: i`): valid values `Off`, `20 Hz`, `50 Hz`, `100 Hz`, `200 Hz`, `500 Hz`, `1 kHz`, `2 kHz`, `5 kHz`; default `Off`. Raw range `0` to `8`; raw

default `0`. Applies a low cut (or high pass) filter to the detuning, letting you remove the effected signal below a certain frequency.

- `High Cut` (`key: HighCut`, `id: 4`, `type: i`): valid values `1 kHz`, `2 kHz`, `5 kHz`, `10 kHz`, `Off`; default `Off`. Raw range `0` to `4`; raw default `4`. Applies a high cut (or low pass) filter to the detuning, letting you remove the effected signal above a certain frequency.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Poly Pitch

- Model key: `L6SPB\_PolyPitch`
- Model ID: `480`
- Type: Pitch
- Category: `pitch`
- Class: Pitch
- DSP usage estimate: 17.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Interval` (`key: Interval`, `id: 1`, `type: i`): display range `-24` to `24` unitless; default `7`. Raw range `-24` to `24`; raw default `7`. Sets the pitch of the effect in semitones, from 2 octaves down to 2 octaves up.
- `Cents` (`key: Cents`, `id: 2`, `type: f`): display range `-50` to `50` unitless; default `0`. Raw range `-50` to `50`; raw default `0`. Sets the pitch of the effect in cents, from -50.0 to +50.0.
- `Shift Time` (`key: ShiftTime`, `id: 3`, `type: f`): display range `0` to `8000` ms; default `176`. Raw range `0` to `8`; raw default `0.176`. Determines how long it takes for the signal to ramp up or down to the set pitch when the block is enabled.
- `Shift Curve` (`key: ShiftCurve`, `id: 4`, `type: i`): valid values `Start Slow 5`, `Start Slow 4`, `Start Slow 3`, `Start Slow 2`, `Start Slow 1`, `Linear`, `Start Fast 1`, `Start Fast 2`, `Start Fast 3`, `Start Fast 4`, `Start Fast 5`; default `Linear`. Raw range `-5` to `5`; raw default `0`. Determines the trajectory curve of the pitch shift over time. Start Slow values are concave (slower changes to start, speeding up toward the end); Start Fast values are convex (the opposite). At the knob's extremes (Start Slow 5 and Start Fast 5), the pitch will actually overshoot a little before settling on the target pitch.
- `Return Time` (`key: ReturnTime`, `id: 5`, `type: f`): display range `0` to `8000` ms; default `0`. Raw range `0` to `8`; raw default `0`. Determines how long it takes for the signal to return to normal pitch when the block is bypassed.
- `Return Curve` (`key: ReturnCurve`, `id: 6`, `type: i`): valid values `Start Slow 5`, `Start Slow 4`, `Start Slow 3`, `Start Slow 2`, `Start Slow 1`, `Linear`, `Start Fast 1`, `Start Fast 2`, `Start Fast 3`, `Start Fast 4`, `Start Fast 5`; default `Linear`. Raw range `-5` to `5`; raw default `0`. Determines the trajectory curve when returning to the original pitch. Start Slow values are concave (slower changes to start, speeding up toward the end); Start Fast values are convex (the opposite). At the knob's extremes (Start Slow 5 and Start Fast 5), the pitch will actually overshoot a little before settling on the original pitch.
- `Tracking` (`key: Tracking`, `id: 7`, `type: i`): valid values `X Fast`, `Fast`, `Stable`, `X Stable`; default `X Stable`. Raw range `0` to `3`; raw default `3`. Determines how the poly pitch engine reacts to your playing. Leave this set to "X Stable" (fewest artifacts when pitch shifting complex chords) and only select a different setting if you experience too much latency when playing fast lead lines.
- `Auto EQ` (`key: AutoEQ`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Determines how much compensation EQ is applied to the shifted signal. If the effected signal sounds too harsh when pitched up (or

dull when pitched down), adjust this setting to taste. The higher the value, the more EQ is applied at the shift end points; when set to 0.0, no compensation EQ is applied.

- `Mix` (`key: Mix`, `id: 9`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the pitch-shifted signal and the dry signal. At 0%, no pitch-shifted signal is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 10`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Poly Wham

- Model key: `L6SPB\_PolyWham`
- Model ID: `522`
- Type: Pitch
- Category: `pitch`
- Class: Wham
- DSP usage estimate: 17.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Position` (`key: Position`, `id: 1`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Adjusts the position of the controller. By default, this is assigned to Expression Pedal 1.
- `Heel Shift` (`key: HeelShift`, `id: 2`, `type: i`): display range `-36` to `24` unitless; default `0`. Raw range `-36` to `24`; raw default `0`. Sets the pitch when the pedal/controller is in its lowest position.
- `Toe Shift` (`key: ToeShift`, `id: 3`, `type: i`): display range `-36` to `24` unitless; default `12`. Raw range `-36` to `24`; raw default `12`. Sets the pitch when the pedal/controller is in its highest position.
- `Tracking` (`key: Tracking`, `id: 4`, `type: i`): valid values `X Fast`, `Fast`, `Stable`, `X Stable`; default `X Stable`. Raw range `0` to `3`; raw default `3`. Determines how the poly pitch engine reacts to your playing. Leave this set to "X Stable" (fewest artifacts when pitch shifting complex chords) and only select a different setting if you experience too much latency when playing fast lead lines.
- `Auto EQ` (`key: AutoEQ`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Determines how much compensation EQ is applied to the shifted signal. If the effected signal sounds too harsh when pitched up (or dull when pitched down), adjust this setting to taste. The higher the value, the more EQ is applied at the shift end points; when set to 0.0, no compensation EQ is applied.
- `Mix` (`key: Mix`, `id: 6`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the pitch-shifted signal and the dry signal. At 0%, no pitch-shifted signal is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 7`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Retro Reel

- Model key: `HD2\_RetroReelMono`
- Model ID: `389`
- Type: Modulation
- Category: `modulation`
- Class: Flanger/Tape
- DSP usage estimate: 3.7

- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Wow/Flutter` (`key: WowFlutter`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls how much warbly tape sound is heard.
- `Saturation` (`key: Saturation`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adds analog tape saturation and at high enough settings, distortion. At lower settings, it's great for simply warming up a tone.
- `Low Cut` (`key: LowCut`, `id: 3`, `type: f`): display range `19.9` to `1000` Off; default `19.9`. Raw range `19.9` to `1000`; raw default `19.9`. Determines the frequency of the Low Cut (High Pass) filter. At higher settings, can provide a lo-fi effect.
- `High Cut` (`key: HighCut`, `id: 4`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Determines the frequency of the High Cut (Low Pass) filter. At lower settings, can provide the natural high-end roll-off of old tape.
- `Tape Speed` (`key: TapeSpeed`, `id: 5`, `type: i`): valid values `7.5 ips`, `15 ips`, `30 ips`; default `15 ips`. Raw range `0` to `2`; raw default `1`. Changes both the rate of the modulation applied by the WowFlutter control and the filtering response of the analog tape emulation.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Texture` (`key: Texture`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6.25`. Raw range `0` to `1`; raw default `0.625`. Controls the amount of the NAB tape EQ in the simulated tape path. When Saturation is set to 0.0, the texture is invisible. When Saturation is turned up, the texture will affect the tightness (or looseness) of the distortion.

Script Mod Phase

- Model key: `HD2\_PhaserScriptModPhaseMono`
- Model ID: `294`
- Type: Modulation
- Category: `modulation`
- Class: Phaser
- DSP usage estimate: 2.0
- Based on: MXR Phase 90
- Agoura model: No

Parameters

- `Rate` (`key: Rate`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `1.9`. Raw range `0` to `1`; raw default `0.19`. Controls the speed or rate of the phaser. When set to note values, Speed follows the system tempo.
- `Mix` (`key: Mix`, `id: 2`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the modulation effect and the dry signal. The most intense phasing happens around 50%.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `-60` to `6` dB; default `1`. Raw range `-60` to `6`; raw default `1`. Sets the overall level of the block.

Simple Pitch

- Model key: `HD2\_PitchSimplePitchMono`
- Model ID: `328`
- Type: Pitch
- Category: `pitch`
- Class: Pitch
- DSP usage estimate: 3.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Interval` (`key: Interval1`, `id: 1`, `type: i`): display range `-24` to `24` unitless; default `7`. Raw range `-24` to `24`; raw default `7`. Sets the pitch of the effected signal in semitones, from 2 octaves down to 2 octaves up.
- `Cents` (`key: Cents1`, `id: 2`, `type: f`): display range `-50` to `50` unitless; default `0`. Raw range `-50` to `50`; raw default `0`. Sets the pitch of the effected signal in cents, from -50.0 to +50.0.
- `Delay` (`key: Time1`, `id: 3`, `type: f`): display range `0` to `100` ms; default `0`. Raw range `0` to `0.1`; raw default `0`. Delays the pitch-shifted signal slightly. At lower values, it can thicken up your tone or at higher values, it can kind of emulate strumming from a single note.
- `Shift Level` (`key: LevelVoice1`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of the pitch-shifted signal.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the pitch-shifted signal and the dry signal. At 0%, no pitch-shifted signal is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Controls the overall level of the block.

Teardrop 310

- Model key: `HD2\_WahTeardrop310Mono`
- Model ID: `289`
- Type: Wah
- Category: `wah`
- Class: Wah
- DSP usage estimate: 2.3
- Based on: Eventide H3000
- Agoura model: No

Parameters

- `Position` (`key: Pedal`, `id: 1`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the position or frequency of the wah effect. By default, this is assigned to Expression Pedal 1. Set Min and Max below to restrict the wah's frequency sweep range.
- `Mix` (`key: Mix`, `id: 2`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the wah effect and the dry signal. At 0%, no wah effect is heard; at 100%, no dry signal is heard. If the wah effect is a bit strong, consider bringing this down a bit.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Wah block.

Teardrop Bass Q

- Model key: `HD2\_WahTeardropBassQMono`
- Model ID: `415`
- Type: Wah
- Category: `wah`
- Class: Wah
- DSP usage estimate: 1.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Position` (`key: Pedal`, `id: 1`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the position or frequency of the wah effect. By default, this is assigned to Expression Pedal 1. Set Min and Max below to restrict the wah's frequency sweep range.
- `Q Trim` (`key: Q Trim`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Q or bandwidth of the effect. Lower values boost a wider frequency band and higher values boost a narrower frequency band.
- `Volume Trim` (`key: Volume Trim`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Emulates the actual pedal's side volume trim knob.
- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the wah effect and the dry signal. At 0%, no wah effect is heard; at 100%, no dry signal is heard. If the wah effect is a bit strong, consider bringing this down a bit.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Wah block.

Throaty

- Model key: `HD2\_WahThroatyMono`
- Model ID: `318`
- Type: Wah
- Category: `wah`
- Class: Wah
- DSP usage estimate: 1.3
- Based on: Arbiter Cry Baby
- Agoura model: No

Parameters

- `Position` (`key: Pedal`, `id: 1`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the position or frequency of the wah effect. By default, this is assigned to Expression Pedal 1.
- `Fc Low` (`key: FcLow`, `id: 2`, `type: f`): display range `20` to `500` Hz; default `310`. Raw range `20` to `500`; raw default `310`. Sets the low frequency cutoff of the wah filter. Along with Fc High, sets the frequency range or sweep of the wah.
- `Fc High` (`key: FcHigh`, `id: 3`, `type: f`): display range `500` to `5000` Hz; default `1735`. Raw range `500` to `5000`; raw default `1735`. Sets the high frequency cutoff of the wah filter. Along with Fc Low, sets the frequency range or sweep of the wah.
- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the wah effect and the dry signal. At 0%, no wah effect is heard; at 100%, no dry signal is heard. If the wah effect is a bit strong, consider bringing this down a bit.

- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Wah block.

Tremolo

- Model key: `HD2\_TremoloTremoloMono`
- Model ID: `322`
- Type: Modulation
- Category: `modulation`
- Class: Tremolo
- DSP usage estimate: 1.5
- Based on: BOSS PN-2
- Agoura model: No

Parameters

- `Speed` (`key: Speed`, `id: 1`, `type: f`): display range `0` to `15` Hz; default `3`. Raw range `0` to `15`; raw default `3`. Controls the speed or rate of the tremolo. When set to note values, Speed follows the system tempo.
- `Intensity` (`key: Intensity`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the depth of the tremolo, or the intensity of the volume fluctuations.
- `Wave Shape` (`key: WaveShape`, `id: 3`, `type: i`): valid values `Saw Up`, `Saw Down`, `Triangle`, `Sine`, `Square`, `Inverse Sine`, `Random`; default `Sine`. Raw range `0` to `6`; raw default `3`. Selects the wave shape of the tremolo. Classic tremolo is commonly a sine or triangle wave, but cool choppy sounds can be discovered with square or saw down waves.
- `Duty Cycle` (`key: DutyCycle`, `id: 4`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Alters the wave shape in differing ways. With Triangle, 50% is a normal triangle wave and extreme values warp the wave toward a saw down (0%) or saw up (100%) shape. With Sine, 50% is a normal sine wave and extreme values warp the wave toward a parabolic down (0%) or parabolic up (100%) shape. With Square, 50% is an even square wave, higher values lengthen the signal's on time, and lower values shorten the signal's on time. DutyCycle does not apply to Saw Up or Saw down.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Tremolo/Autopan

- Model key: `HD2\_TremoloTremoloStereo`
- Model ID: `186`
- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 1.8
- Based on: BOSS PN-2
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

Trinity Chorus

- Model key: `HD2\_ChorusTrinityChorusStereo`
- Model ID: `166`
- Type: Modulation
- Category: `modulation`
- Class: Chorus
- DSP usage estimate: 4.7
- Based on: Dytronics Tri-Stereo Chorus
- Agoura model: No

Parameters

- `Rate` (`key: Rate`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the speed or rate of the chorus. Only active when LFO Man is turned on. When set to note values, Rate follows the system tempo.
- `Left Depth` (`key: Left`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.9`. Raw range `0` to `1`; raw default `0.79`. Controls the depth or intensity of the Left delay channel/chorus circuit 1.
- `Center Depth` (`key: Center`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the depth or intensity of the Center delay channel/chorus circuit 2.
- `Right Depth` (`key: Right`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the depth or intensity of the Right delay channel/chorus circuit 3.
- `LFO Preset` (`key: Preset`, `id: 5`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, engages an "ensemble-style" chorus preset with fixed Rate, L Depth, C Depth, and R Depth.
- `LFO Manual` (`key: Manual`, `id: 6`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, enables control of Rate, L Depth, C Depth, and R Depth. Can be used in conjunction with LFO Prst.
- `Left Boost` (`key: LeftBoost`, `id: 7`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Adds an enhanced frequency response to the Left delay channel, making it a bit more pronounced.
- `Center Boost` (`key: CenterBoost`, `id: 8`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Adds an enhanced frequency response to the Center delay channel, making it a bit more pronounced.
- `Right Boost` (`key: RightBoost`, `id: 9`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Adds an enhanced frequency response to the Right delay channel, making it a bit more pronounced.
- `Mode` (`key: Mode`, `id: 10`, `type: b`): valid values `Mono`, `Stereo`; default `Stereo`. Raw range `Off` to `On`; raw default `On`. Selects whether Trinity Chorus operates in mono or stereo.
- `Mix` (`key: Mix`, `id: 11`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the modulation effect and the dry signal. At 0%, no modulation is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 12`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.

Triple Rotary

- Model key: `HD2\_Rotary3RotorStereo`
- Model ID: `260`
- Type: Modulation
- Category: `modulation`

- Class: Rotary
- DSP usage estimate: 7.2
- Based on: Yamaha RA-200
- Agoura model: No

Parameters

- `Speed` (`key: Speed`, `id: 1`, `type: b`): valid values `Slow`, `Fast`; default `Slow`. Raw range `Off` to `On`; raw default `Off`. Selects Slow or Fast rotary speed. When changing values, the rotary speaker speed gradually changes, based on the RampTime value.
- `Slow Speed` (`key: SlowSpeed`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Sets the rotary speed when Speed is set to "Slow." When set to note values, SlowSpeed follows the system tempo.
- `Fast Speed` (`key: FastSpeed`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Sets the rotary speed when Speed is set to "Fast." When set to note values, FastSpeed follows the system tempo.
- `Ramp Time` (`key: RampTime`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Determines how fast the rotary speed changes when Speed is changed from "Slow" to "Fast" or vice versa.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the rotary effect and the dry signal. At 0%, no rotary effect is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Drive` (`key: Drive`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `2.2`. Raw range `0` to `1`; raw default `0.22`. Controls the amount of drive into the speaker's power amp.
- `Headroom` (`key: Headroom`, `id: 8`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Provides up to 12.0dB of additional headroom.
- `Low Cut` (`key: LowCut`, `id: 9`, `type: f`): display range `19.9` to `500` Off; default `19.9`. Raw range `19.9` to `500`; raw default `19.9`. Applies a low cut (high pass) filter to the speakers, letting you remove the effected signal below a certain frequency.
- `High Cut` (`key: HighCut`, `id: 10`, `type: f`): display range `500` to `20100` Hz; default `20100`. Raw range `500` to `20100`; raw default `20100`. Applies a high cut (low pass) filter to the speakers, letting you remove the effected signal above a certain frequency.
- `Wobble` (`key: Wobble`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Models how evenly the rotating speaker and its ballast weight are balanced about the axis. At zero, the speaker and ballast are perfectly balanced; as the wobble control is increased, the rotation of the speakers becomes more eccentric.
- `Separation` (`key: Separation`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the separation of the stereo field. Practically, this simulates moving the two listening points further apart as the separation knob is increased.
- `Rotor Drift` (`key: RotorFcDrift`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts how close the three rotor motors are in sync with each other in speed. As each of the rotors were belt driven, there are often some differences in belt or motor wear, and it creates some subtle modulation effects between the three rotors.
- `Rotor 2 Level` (`key: Rotor2Level`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the individual volume of the second rotor.
- `Rotor 3 Level` (`key: Rotor3Level`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the individual volume of the third rotor.

Twin Harmony

- Model key: `HD2\_PitchTwinHarmonyMono`
- Model ID: `291`
- Type: Pitch
- Category: `pitch`
- Class: Pitch
- DSP usage estimate: 4.0
- Based on: Eventide H3000
- Agoura model: No

Parameters

- `Voice 1 Key` (`key: KeyVoice1`, `id: 1`, `type: i`): valid values `A`, `A#`, `B`, `C`, `C#`, `D`, `D#`, `E`, `F`, `F#`, `G`, `G#`; default `A`. Raw range `0` to `11`; raw default `0`. Selects the key of the Voice 1 harmony.
- `Voice 1 Scale` (`key: ScaleVoice1`, `id: 2`, `type: i`): valid values `Major`, `Minor`, `Major Pent`, `Minor Pent`, `Harm Minor`, `Melodic Minor`, `Whole Tone`, `Whole Dim`; default `Major`. Raw range `0` to `7`; raw default `0`. Selects the scale of the Voice 1 harmony.
- `Voice 1 Shift` (`key: IntervalVoice1`, `id: 3`, `type: i`): valid values `-9th`, `-8th`, `-7th`, `-6th`, `-5th`, `-4th`, `-3rd`, `-2nd`, `0`, `2nd`, `3rd`, `4th`, `5th`, `6th`, `7th`, `8th`, `9th`; default `-4th`. Raw range `-8` to `8`; raw default `-3`. Sets the interval of the Voice 1 harmony, from a 9th below to a 9th above. When set to 0, the incoming signal is doubled.
- `Voice 1 Level` (`key: LevelVoice1`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of the Voice 1 harmony.
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the effected signal and the dry signal. At 0%, no effected signal is heard; at 100%, no dry signal is heard.
- `Voice 2 Key` (`key: KeyVoice2`, `id: 7`, `type: i`): valid values `A`, `A#`, `B`, `C`, `C#`, `D`, `D#`, `E`, `F`, `F#`, `G`, `G#`; default `A`. Raw range `0` to `11`; raw default `0`. Selects the key of the Voice 2 harmony.
- `Voice 2 Scale` (`key: ScaleVoice2`, `id: 8`, `type: i`): valid values `Major`, `Minor`, `Major Pent`, `Minor Pent`, `Harm Minor`, `Melodic Minor`, `Whole Tone`, `Whole Dim`; default `Major`. Raw range `0` to `7`; raw default `0`. Selects the scale of the Voice 2 harmony.
- `Voice 2 Shift` (`key: IntervalVoice2`, `id: 9`, `type: i`): valid values `-9th`, `-8th`, `-7th`, `-6th`, `-5th`, `-4th`, `-3rd`, `-2nd`, `0`, `2nd`, `3rd`, `4th`, `5th`, `6th`, `7th`, `8th`, `9th`; default `3rd`. Raw range `-8` to `8`; raw default `2`. Sets the interval of the Voice 2 harmony, from a 9th below to a 9th above. When set to 0, the incoming signal is doubled.
- `Voice 2 Level` (`key: LevelVoice2`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the level of the Voice 2 harmony.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Controls the overall level of the block.

UK Wah 846

- Model key: `HD2\_WahUKWah846Mono`
- Model ID: `290`
- Type: Wah
- Category: `wah`

- Class: Wah
- DSP usage estimate: 2.3
- Based on: Digitech Whammy
- Agoura model: No

Parameters

- `Position` (`key: Pedal`, `id: 1`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the position or frequency of the wah effect. By default, this is assigned to Expression Pedal 1. Set Min and Max below to restrict the wah's frequency sweep range.
- `Mix` (`key: Mix`, `id: 2`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the wah effect and the dry signal. At 0%, no wah effect is heard; at 100%, no dry signal is heard. If the wah effect is a bit strong, consider bringing this down a bit.
- `Level` (`key: Level`, `id: 3`, `type: f`): display range `-60` to `6` dB; default `4`. Raw range `-60` to `6`; raw default `4`. Sets the overall level of the Wah block.

Ubiquitous Vibe

- Model key: `HD2\_PhaserUbiquitousVibeMono`
- Model ID: `285`
- Type: Modulation
- Category: `modulation`
- Class: Phaser
- DSP usage estimate: 2.4
- Based on: Shin-ei Uni-Vibe
- Agoura model: No

Parameters

- `Rate` (`key: Rate`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.9`. Raw range `0` to `1`; raw default `0.29`. Controls the speed or rate of the effect. When set to note values, Speed follows the system tempo.
- `Intensity` (`key: Intensity`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the depth or intensity of the effect.
- `Mode` (`key: Mode`, `id: 3`, `type: b`): valid values `Chorus`, `Vibrato`; default `Chorus`. Raw range `Off` to `On`; raw default `Off`. Selects Chorus or Vibrato mode.
- `Lamp Bias` (`key: LampBias`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the amount of current going to the original pedal's filament bulb. Lower values result in a smoother LFO sweep (closer to a sine wave); higher values result in a more dramatic LFO sweep (closer to a square wave).
- `Mix` (`key: Mix`, `id: 5`, `type: f`): display range `0` to `100` %; default `50`. Raw range `0` to `1`; raw default `0.5`. Controls the blend between the modulation effect and the dry signal.
- `Level` (`key: Level`, `id: 6`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Adjusts the overall output level of the modulation effect

VIC_FlexoVibeStereo

- Model key: `VIC\_FlexoVibeStereo`
- Model ID: `256`

- Type: Modulation
- Category: `modulation`
- Class: Unknown
- DSP usage estimate: 2.8
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

VIC_PitchBoctaverStereo

- Model key: `VIC\_PitchBoctaverStereo`
- Model ID: `258`
- Type: Pitch
- Category: `pitch`
- Class: Unknown
- DSP usage estimate: 2.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- No editable parameters were extracted for this model.

Vetta Wah

- Model key: `HD2\_WahVettaWahMono`
- Model ID: `319`
- Type: Wah
- Category: `wah`
- Class: Wah
- DSP usage estimate: 1.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Position` (`key: Pedal`, `id: 1`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the position or frequency of the wah effect. By default, this is assigned to Expression Pedal 1.
- `Fc Low` (`key: FcLow`, `id: 2`, `type: f`): display range `20` to `500` Hz; default `300`. Raw range `20` to `500`; raw default `300`. Sets the low frequency cutoff of the wah filter. Along with Fc High, sets the frequency range or sweep of the wah.
- `Fc High` (`key: FcHigh`, `id: 3`, `type: f`): display range `500` to `5000` Hz; default `2300`. Raw range `500` to `5000`; raw default `2300`. Sets the high frequency cutoff of the wah filter. Along with Fc Low, sets the frequency range or sweep of the wah.
- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the wah effect and the dry signal. At 0%, no wah effect is heard; at 100%, no dry signal is heard. If the wah effect is a bit strong, consider bringing this down a bit.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Wah block.

Vibe Rotary

- Model key: `HD2\_RotaryVibeRotaryStereo`
- Model ID: `159`
- Type: Modulation
- Category: `modulation`
- Class: Rotary
- DSP usage estimate: 5.5
- Based on: Fender Vibratone
- Agoura model: No

Parameters

- `Speed` (`key: Speed`, `id: 1`, `type: b`): valid values `Slow`, `Fast`; default `Fast`. Raw range `Off` to `On`; raw default `On`. Selects Slow or Fast rotary speed. When changing values, the rotary speaker speed gradually changes, based on the RampTime value.
- `Slow Speed` (`key: SlowSpeed`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Sets the rotary speed when Speed is set to "Slow." When set to note values, SlowSpeed follows the system tempo.
- `Fast Speed` (`key: FastSpeed`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Sets the rotary speed when Speed is set to "Fast." When set to note values, FastSpeed follows the system tempo.
- `Ramp Time` (`key: RampTime`, `id: 4`, `type: i`): valid values `Slow`, `Medium`, `Fast`; default `Medium`. Raw range `0` to `2`; raw default `1`. Determines how fast the rotary speed changes when Speed is changed from "Slow" to "Fast" or vice versa.
- `Drive` (`key: Drive`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls how much of the speaker's internal amp is overdriven. At higher values, the speaker imparts more of a gritty sound. Note that the original speaker Vibe Rotary is based on did not have an amplifier, so for the most authentic sound, leave this set to 0.0.
- `Speaker Blend` (`key: Blend`, `id: 6`, `type: f`): display range `-100` to `100` Woofer; default `0.5`. Raw range `0` to `1`; raw default `0.5`. Controls how much of the woofer speaker is heard vs. the horn speaker. Normally leave this set to "Equal."
- `Mix` (`key: Mix`, `id: 7`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the rotary effect and the dry signal. At 0%, no rotary effect is heard; at 100%, no dry signal is heard.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the block.
- `Headroom` (`key: Headroom`, `id: 9`, `type: f`): display range `-12` to `12` dB; default `0`. Raw range `-12` to `12`; raw default `0`. Provides up to 12.0 dB of additional headroom.

Weeper

- Model key: `HD2\_WahWeeperMono`
- Model ID: `320`
- Type: Wah
- Category: `wah`
- Class: Wah
- DSP usage estimate: 1.3
- Based on: BOSS PN-2
- Agoura model: No

Parameters

- `Position` (`key: Pedal`, `id: 1`, `type: f`): display range `0` to `100` %; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the position or frequency of the wah effect. By default, this is assigned to Expression Pedal 1.
- `Fc Low` (`key: FcLow`, `id: 2`, `type: f`): display range `20` to `500` Hz; default `435`. Raw range `20` to `500`; raw default `435`. Sets the low frequency cutoff of the wah filter. Along with Fc High, sets the frequency range or sweep of the wah.
- `Fc High` (`key: FcHigh`, `id: 3`, `type: f`): display range `500` to `5000` Hz; default `1901`. Raw range `500` to `5000`; raw default `1901`. Sets the high frequency cutoff of the wah filter. Along with Fc Low, sets the frequency range or sweep of the wah.
- `Mix` (`key: Mix`, `id: 4`, `type: f`): display range `0` to `100` %; default `100`. Raw range `0` to `1`; raw default `1`. Controls the blend between the wah effect and the dry signal. At 0%, no wah effect is heard; at 100%, no dry signal is heard. If the wah effect is a bit strong, consider bringing this down a bit.
- `Level` (`key: Level`, `id: 5`, `type: f`): display range `-60` to `6` dB; default `0`. Raw range `-60` to `6`; raw default `0`. Sets the overall level of the Wah block.

Source file: guitar-amps-and-preamps-0-9-to-d.md

Guitar amps and preamps (0-9 to D)

Upload-ready knowledge for guitar amp and preamp blocks.

Generated from the installed Helix Stadium desktop app bundle on
2026-05-07T22:33:14.224003+00:00.

Use display values for normal user-facing answers. Use model keys, IDs, and raw ranges only when the user asks for automation or low-level control details.

Model count: 70

2204 Mod

- Model key: `HD2\_AmpLine62204Mod`
- Model ID: `628`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the amount of gain applied to the signal, which influences the level of distortion. This model is based on a hot-rodded 2204, which has more gain than the stock version.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.7`. Raw range `0` to `1`; raw default `0.77`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.7`. Raw range `0` to `1`; raw default `0.77`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Pre Mid` (`key: PreMid`, `id: 9`, `type: f`): display range `-12` to `12` dB; default `4`. Raw range `-12` to `12`; raw default `4`. Controls the level of the modded midrange EQ inserted before the preamp.
- `Pre Mid Fc` (`key: PreMidFc`, `id: 10`, `type: f`): display range `500` to `1000` Hz; default `1000`. Raw range `500` to `1000`; raw default `1000`. Controls the frequency of the modded midrange EQ inserted before the preamp.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

2204 Mod

- Model key: `HD2\_Preampline62204ModV2`
- Model ID: `632`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 10.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the amount of gain applied to the signal, which influences the level of distortion. This model is based on a hot-rodded 2204, which has more gain than the stock version.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.7`. Raw range `0` to `1`; raw default `0.77`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the high frequency EQ of the

tonestack.

- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.7`. Raw range `0` to `1`; raw default `0.77`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Pre Mid` (`key: PreMid`, `id: 8`, `type: f`): display range `-12` to `12` dB; default `4`. Raw range `-12` to `12`; raw default `4`. Controls the level of the modded midrange EQ inserted before the preamp.
- `Pre Mid Fc` (`key: PreMidFc`, `id: 9`, `type: f`): display range `500` to `1000` Hz; default `1000`. Raw range `500` to `1000`; raw default `1000`. Controls the frequency of the modded midrange EQ inserted before the preamp.

A30 Fawn Brt

- Model key: `HD2\_AmpA30FawnBrt`
- Model ID: `612`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 10.1
- Based on: Vox AC-30 Fawn (Bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.8`. Raw range `0` to `1`; raw default `0.78`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Cut` (`key: Cut`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Increasing this parameter cuts high frequencies in the negative feedback loop, which can mellow out the overall treble response.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

A30 Fawn Brt

- Model key: `HD2\_PreampA30FawnBrt`
- Model ID: `614`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 5.7
- Based on: Vox AC-30 Fawn (Bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.8`. Raw range `0` to `1`; raw default `0.78`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Preamp block.
- `Hum` (`key: Hum`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic

distortion adds a bit of realism to the amp model.

A30 Fawn Nrm

- Model key: `HD2\_AmpA30FawnNrm`
- Model ID: `613`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 10.1
- Based on: Vox AC-30 Fawn (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Cut` (`key: Cut`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Increasing this parameter cuts high frequencies in the negative feedback loop, which can mellow out the overall treble response.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing

reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

A30 Fawn Nrm

- Model key: `HD2\_PreampA30FawnNrm`
- Model ID: `615`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 6.0
- Based on: Vox AC-30 Fawn (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Hum` (`key: Hum`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

ANGL Meteor

- Model key: `HD2\_AmpANGLMeteor`
- Model ID: `610`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.5
- Based on: ENGL Fireball 100
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.
- `Mid Boost` (`key: MidBoost`, `id: 13`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, boosts midrange frequencies. Typically used when soloing.

ANGL Meteor

- Model key: `HD2\_PreampANGLMeteor`
- Model ID: `611`
- Type: Preamp
- Category: `preamp`
- Class: Guitar

- DSP usage estimate: 9.6
- Based on: ENGL Fireball 100
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls the high frequency EQ of the tonestack.
- `Mid Boost` (`key: MidBoost`, `id: 5`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, boosts midrange frequencies. Typically used when soloing.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Archetype Clean

- Model key: `HD2\_AmpArchetypeClean`
- Model ID: `637`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.5
- Based on: Paul Reed Smith Archon (Clean channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of preamp gain applied to the signal. At high settings, a bit of saturation can be heard.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default

`6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tubeamps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.
- `Depth` (`key: Depth`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Boosts low frequencies in the power amp.
- `Bright` (`key: BrightSW`, `id: 14`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, increases the brightness of the amp.

Archetype Clean

- Model key: `HD2\_PreamplifierClean`
- Model ID: `638`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 7.9
- Based on: Paul Reed Smith Archon (Clean channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of preamp gain applied to the signal. At high settings, a bit of saturation can be heard.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Bright` (`key: BrightSW`, `id: 9`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, increases the brightness of the amp.

Archetype Lead

- Model key: `HD2\_AmpArchetypeLead`
- Model ID: `635`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.7
- Based on: Paul Reed Smith Archon (Lead channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the amount of preamp gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default

`6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the high frequency EQ of the tonestack.

- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.
- `Depth` (`key: Depth`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Boosts low frequencies in the power amp.

Archetype Lead

- Model key: `HD2\_PreampArchetypeLead`
- Model ID: `636`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.1
- Based on: Paul Reed Smith Archon (Lead channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the amount of preamp gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Aristocrat

- Model key: `HD2\_AmpLine6Aristocrat`
- Model ID: `713`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Boost` (`key: Boost`, `id: 7`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of Drive from the built in

Distortion > Kinky Boost.

- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: HumSwitch`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Aristocrat

- Model key: `HD2\_PreamplifierAristocrat`
- Model ID: `717`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 12.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the overall level of the Preamp block.
- `Boost` (`key: Boost`, `id: 7`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of Drive from the built in Distortion > Kinky Boost.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: HumSwitch`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Badonk

- Model key: `HD2\_AmpLine6Badonk`
- Model ID: `643`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 8.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.3`. Raw range `0` to `1`; raw default `0.43`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the Master Volume of the amplifier.
- `Depth` (`key: Depth`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `3.7`. Raw range `0` to `1`; raw default `0.37`. Boosts low frequencies in the power amp, resulting in extra weight and thump.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Badonk

- Model key: `HD2\_PreamplLine6Badonk`
- Model ID: `644`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.3`. Raw range `0` to `1`; raw default `0.43`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

Brit 2203

- Model key: `HD2\_AmpBrit2203`
- Model ID: `735`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.9
- Based on: Marshall JCM-800, 2203, 100W
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.66`. Raw range `0` to `1`; raw default `0.566`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.98`. Raw range `0` to `1`; raw default `0.698`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.36`. Raw range `0` to `1`; raw default `0.236`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.
- `Input` (`key: InputType`, `id: 13`, `type: b`): valid values `Low`, `High`; default `High`. Raw range `Off` to `On`; raw default `On`. Selects the input of the amp--Low or High. Like the real amp, the level and gain difference here is significant.

Brit 2203

- Model key: `HD2\_PreampBrit2203`
- Model ID: `736`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 14.5
- Based on: Marshall JCM-800, 2203, 100W
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.66`. Raw range `0` to `1`; raw default `0.566`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.98`. Raw range `0` to `1`; raw default `0.698`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.36`. Raw range `0` to `1`; raw default `0.236`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Input` (`key: InputType`, `id: 9`, `type: b`): valid values `Low`, `High`; default `High`. Raw range `Off` to `On`; raw default `On`. Selects the input of the amp--Low or High. Like the real amp, the level and gain difference here is significant.

Brit 2203MV

- Model key: `Agoura\_AmpBrit2203MV`
- Model ID: `758`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 21.0
- Based on: Marshall JCM-800, 100W, 2203 (Low and High inputs)
- Agoura model: Yes

Parameters

- `Jack` (`key: Jack`, `id: 1`, `type: i`): valid values `Low`, `High`; default `High`. Raw range `0` to `1`; raw default `1`. Selects the input jack on the amp--Low or High.
- `Drive` (`key: Drive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.1`. Raw range `0` to `1`; raw default `0.71`. Controls the low frequency EQ of the

tonestack.

- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `3.7`. Raw range `0` to `1`; raw default `0.37`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the Master Volume of the amplifier.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 12`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Brit 2204

- Model key: `HD2\_AmpBrit2204`
- Model ID: `608`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.2
- Based on: Marshall JCM-800, 2204, 50W
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the low frequency EQ of the

tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the high frequency EQ of the tonestack.

- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.1`. Raw range `0` to `1`; raw default `0.71`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the Master Volume of the amplifier.

- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Brit 2204

- Model key: `HD2\_PreampBrit2204`
- Model ID: `609`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 10.1
- Based on: Marshall JCM-800, 2204, 50W
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Brit J45 Brt

- Model key: `HD2\_AmpBritJ45Brt`
- Model ID: `604`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.6
- Based on: Marshall JTM-45 (Bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default

`10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.

- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Brit J45 Brt

- Model key: `HD2\_PreampBritJ45Brt`
- Model ID: `606`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 7.6
- Based on: Marshall JTM-45 (Bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power

supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Brit J45 Nrm

- Model key: `HD2\_AmpBritJ45Nrm`
- Model ID: `605`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.6
- Based on: Marshall JTM-45 (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.4`. Raw range `0` to `1`; raw default `0.74`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8.6`. Raw range `0` to `1`; raw default `0.86`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that

the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Brit J45 Nrm

- Model key: `HD2\_PreampBritJ45Nrm`
- Model ID: `607`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 7.6
- Based on: Marshall JTM-45 (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.4`. Raw range `0` to `1`; raw default `0.74`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8.6`. Raw range `0` to `1`; raw default `0.86`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Brit Jujube

- Model key: `Agoura\_AmpBritJujube`
- Model ID: `834`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 24.0
- Based on: Marshall Silver Jubilee (Rhythm, Rhythm Clip, & Lead channels)
- Agoura model: Yes

Parameters

- `Channel` (`key: Chan`, `id: 1`, `type: i`): valid values `Rhythm`, `Rhythm Clip`, `Lead`, `Lead No Rhy Clp`; default `Lead`. Raw range `0` to `3`; raw default `2`. Selects the amp channel-Rhythm, Rhythm Clip, Lead, or Lead No Rhythm Clip.
- `Drive` (`key: Drive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.375`. Raw range `0` to `1`; raw default `0.4375`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3.68`. Raw range `0` to `1`; raw default `0.368`. Controls the low frequency EQ of the tonestack.
- `Middle` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.66`. Raw range `0` to `1`; raw default `0.566`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `2.74`. Raw range `0` to `1`; raw default `0.274`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Lead Master` (`key: LeadMaster`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.12`. Raw range `0` to `1`; raw default `0.412`.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-6`. Raw range `-40` to `10`; raw default `-6`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 10`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 11`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 13`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Brit P75 Brt

- Model key: `HD2\_AmpBritP75Brt`
- Model ID: `600`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.7
- Based on: Park 75 (Bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing

reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Brit P75 Brt

- Model key: `HD2\_PreampBritP75Brt`
- Model ID: `602`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 7.4
- Based on: Park 75 (Bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Brit P75 Nrm

- Model key: `HD2\_AmpBritP75Nrm`
- Model ID: `601`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.7
- Based on: Park 75 (Normal channel)

- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Brit P75 Nrm

- Model key: `HD2\_PreampBritP75Nrm`
- Model ID: `603`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 7.4

- Based on: Park 75 (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Brit Plexi

- Model key: `Agoura\_AmpBritPlexi`
- Model ID: `756`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 23.0
- Based on: Marshall Super Lead 100 (Normal, Bright & Jumped channels)
- Agoura model: Yes

Parameters

- `Channel` (`key: Channel`, `id: 1`, `type: i`): valid values `Normal`, `Bright`, `Jumped`; default `Jumped`. Raw range `0` to `2`; raw default `2`. Selects the amp channel or which input is connected. "Jumped" jumps between the Normal and Bright channels.
- `Normal Drive` (`key: NormDrv`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.2`. Raw range `0` to `1`; raw default `0.22`. Controls the amount of Normal channel gain applied to the signal. The inactive channel can sometimes "bleed into" the active channel, resulting in interesting interactions.
- `Bright Drive` (`key: BrightDrv`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of Bright channel gain applied to the signal. The inactive channel can sometimes "bleed into" the active

channel, resulting in interesting interactions.

- `Bass` (`key: Bass`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.94`. Raw range `0` to `1`; raw default `0.594`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Presence` (`key: Presence`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Sag` (`key: Sag`, `id: 10`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 11`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 13`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Brit Plexi Brt

- Model key: `HD2\_AmpBritPlexiBrt`
- Model ID: `594`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.5
- Based on: Marshall Super Lead 100 (Bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default

`7.4`. Raw range `0` to `1`; raw default `0.74`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tubeamps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Brit Plexi Brt

- Model key: `HD2\_PreampBritPlexiBrt`
- Model ID: `597`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.7
- Based on: Marshall Super Lead 100 (Bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the amount of gain applied to the

signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.4`. Raw range `0` to `1`; raw default `0.74`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.1`. Raw range `0` to `1`; raw default `0.71`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Brit Plexi Jump

- Model key: `HD2\_AmpBritPlexiJump`
- Model ID: `595`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 16.3
- Based on: Marshall Super Lead 100 (Normal channel)
- Agoura model: No

Parameters

- `Brt Drive` (`key: BrtDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls the amount of Bright channel drive applied to the signal.
- `Nrm Drive` (`key: NrmDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the amount of Normal channel drive applied to the signal.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.3`. Raw range `0` to `1`; raw default `0.73`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall level of the Amp block.

Unlike Master Volume, it has no effect on the block's tone.

- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Master` (`key: Master`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Brit Plexi Jump

- Model key: `HD2\_PreamplifierBritPlexiJump`
- Model ID: `598`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 11.2
- Based on: Marshall Super Lead 100 (Normal channel)
- Agoura model: No

Parameters

- `Brt Drive` (`key: BrtDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls the amount of Bright channel drive applied to the signal.
- `Nrm Drive` (`key: NrmDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the amount of Normal channel drive applied to the signal.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default

`7.3`. Raw range `0` to `1`; raw default `0.73`. Controls the high frequency EQ of the tonestack.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Brit Plexi Nrm

- Model key: `HD2\_AmpBritPlexiNrm`
- Model ID: `596`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.3
- Based on: Marshall Super Lead 100 (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps;

lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Brit Plexi Nrm

- Model key: `HD2\_PreampBritPlexiNrm`
- Model ID: `599`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.5
- Based on: Marshall Super Lead 100 (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Controls the high frequency EQ of the tonestack.

- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.

- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Brit Trem Brt

- Model key: `HD2\_AmpBritTremBrt`
- Model ID: `657`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.9
- Based on: Marshall JTM-50 (Bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: BrtDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `9.2`. Raw range `0` to `1`; raw default `0.92`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the high frequency EQ of the tonestack.

- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.

- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Brit Trem Brt

- Model key: `HD2\_PreampBritTremBrt`
- Model ID: `660`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.9
- Based on: Marshall JTM-50 (Bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: BrtDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `9.2`. Raw range `0` to `1`; raw default `0.92`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Brit Trem Jump

- Model key: `HD2\_AmpBritTremJump`
- Model ID: `658`
- Type: Amp

- Category: `amp`
- Class: Guitar
- DSP usage estimate: 15.2
- Based on: Marshall JTM-50 (Jumped channels)
- Agoura model: No

Parameters

- `Brt Drive` (`key: BrtDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Controls the amount of Bright channel drive applied to the signal, which influences the level of distortion.
- `Nrm Drive` (`key: NrmDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the amount of Normal channel drive applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Master` (`key: Master`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Brit Trem Jump

- Model key: `HD2\_PreamBritTremJump`
- Model ID: `661`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 10.6
- Based on: Marshall JTM-50 (Jumped channels)
- Agoura model: No

Parameters

- `Brt Drive` (`key: BrtDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Controls the amount of Bright channel drive applied to the signal, which influences the level of distortion.
- `Nrm Drive` (`key: NrmDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the amount of Normal channel drive applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Brit Trem Nrm

- Model key: `HD2\_AmpBritTremNrm`
- Model ID: `659`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.9
- Based on: Marshall JTM-50 (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: NrmDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8.6`. Raw range `0` to `1`; raw default `0.86`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Brit Trem Nrm

- Model key: `HD2\_PreampBritTremNrm`
- Model ID: `662`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.9
- Based on: Marshall JTM-50 (Normal channel)

- Agoura model: No

Parameters

- `Drive` (`key: NrmDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8.6`. Raw range `0` to `1`; raw default `0.86`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Cali 2C+

- Model key: `Agoura\_AmpCali2CPlus`
- Model ID: `832`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 24.7
- Based on: Mesa/Boogie Mark IIC (Normal & Lead channels, all switches)
- Agoura model: Yes

Parameters

- `Channel` (`key: Channel`, `id: 1`, `type: b`): valid values `Normal`, `Lead`; default `Lead`. Raw range `Off` to `On`; raw default `On`. Selects the amp channel--Normal or Lead.
- `Drive` (`key: Volume1`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.54`. Raw range `0` to `1`; raw default `0.654`. Controls the amount of gain applied to the signal, which influences the level of distortion. This parameter affects both Normal and Lead channels.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3.23`. Raw range `0` to `1`; raw default `0.323`. Controls the low frequency EQ of the tonestack.
- `Middle` (`key: Middle`, `id: 4`, `type: f`): display range `0` to `10` unitless; default

`3.24`. Raw range `0` to `1`; raw default `0.324`.

- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.42`. Raw range `0` to `1`; raw default `0.742`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Deep` (`key: Deep`, `id: 7`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, boosts the bass frequencies before the graphic EQ.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Bass Shift` (`key: ShiftBass`, `id: 9`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts the bass frequencies at the first gain stage.
- `Treble Shift` (`key: ShiftTreble`, `id: 10`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`.
- `Bright` (`key: Bright`, `id: 11`, `type: i`): valid values `Off`, `On`; default `Off`. Raw range `0` to `1`; raw default `0`. When on, applies a high frequency boost. This parameter interacts with the Drive parameter and affects both Normal and Lead channels.
- `Lead Drive` (`key: LeadDrive`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the amount of gain applied to the signal, which influences the level of distortion in the Lead channel.
- `Lead Brite` (`key: LeadBright`, `id: 13`, `type: i`): valid values `Off`, `On`; default `Off`. Raw range `0` to `1`; raw default `0`. When on, applies a high frequency boost. This parameter interacts with the LeadDrive parameter and affects only the Lead channel.
- `Lead Master` (`key: LeadMaster`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `3.68`. Raw range `0` to `1`; raw default `0.368`.
- `Master` (`key: MasterVol`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier. This parameter affects both Normal and Lead channels.
- `Power` (`key: Class`, `id: 16`, `type: b`): valid values `Class A`, `Simulclass`; default `Class A`. Raw range `Off` to `On`; raw default `Off`. Selects the topology of the power amp.
- `80 Hz` (`key: 80 Hz`, `id: 17`, `type: f`): display range `-14` to `14` dB; default `0`. Raw range `-14` to `14`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `240 Hz` (`key: 240 Hz`, `id: 18`, `type: f`): display range `-14` to `14` dB; default `0`. Raw range `-14` to `14`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `750 Hz` (`key: 750 Hz`, `id: 19`, `type: f`): display range `-14` to `14` dB; default `0`. Raw range `-14` to `14`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `2200 Hz` (`key: 2.2 KHz`, `id: 20`, `type: f`): display range `-10` to `10` dB; default `2`. Raw range `-10` to `10`; raw default `2`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `6600 Hz` (`key: 6.6 KHz`, `id: 21`, `type: f`): display range `-11` to `11` dB; default `0`. Raw range `-11` to `11`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `Sag` (`key: Sag`, `id: 22`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 23`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the

power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Z PrePost` (`key: PrePost`, `id: 24`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 25`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Cali IV Lead

- Model key: `HD2\_AmpCaliIVLead`
- Model ID: `626`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.5
- Based on: MESA/Boogie Mark IV (Lead channel)
- Agoura model: No

Parameters

- `Lead Gain` (`key: LeadGain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the amount of gain applied to the signal, which influences the level of distortion. Lead Gain is before the tonestack.
- `Lead Drive` (`key: LeadDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the amount of additional gain applied to the signal after the tonestack.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `1.4`. Raw range `0` to `1`; raw default `0.14`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.8`. Raw range `0` to `1`; raw default `0.88`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `3.4`. Raw range `0` to `1`; raw default `0.34`. Boosts upper mid and high frequencies in the preamp.
- `Master` (`key: Master`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `1.5`. Raw range `0` to `1`; raw default `0.15`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default

`5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.
- `80 Hz` (`key: 80Hz`, `id: 13`, `type: f`): display range `-13.75` to `13.25` dB; default `0`. Raw range `-13.75` to `13.25`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `240 Hz` (`key: 240Hz`, `id: 14`, `type: f`): display range `-13.25` to `13.25` dB; default `-0.9`. Raw range `-13.25` to `13.25`; raw default `-0.9`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `750 Hz` (`key: 750Hz`, `id: 15`, `type: f`): display range `-13.25` to `13.25` dB; default `-2.9`. Raw range `-13.25` to `13.25`; raw default `-2.9`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `2200 Hz` (`key: 2200Hz`, `id: 16`, `type: f`): display range `-9.625` to `9.5` dB; default `-1.3`. Raw range `-9.625` to `9.5`; raw default `-1.3`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `6600 Hz` (`key: 6600Hz`, `id: 17`, `type: f`): display range `-9.625` to `9.5` dB; default `0`. Raw range `-9.625` to `9.5`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.

Cali IV Lead

- Model key: `HD2\_PreampCaliIVLead`
- Model ID: `627`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.5
- Based on: MESA/Boogie Mark IV (Lead channel)
- Agoura model: No

Parameters

- `Lead Gain` (`key: LeadGain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the amount of gain applied to the signal, which influences the level of distortion. Lead Gain is before the tonestack.
- `Lead Drive` (`key: LeadDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the amount of additional gain applied to the signal after the tonestack.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `1.4`. Raw range `0` to `1`; raw default `0.14`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the high frequency EQ of the tonestack.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.8`. Raw range `0` to `1`; raw default `0.88`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `3.4`. Raw range `0` to `1`; raw default `0.34`. Boosts upper mid and high frequencies in the preamp.
- `Master` (`key: Master`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `1.5`. Raw range `0` to `1`; raw default `0.15`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `80 Hz` (`key: 80Hz`, `id: 13`, `type: f`): display range `-13.75` to `13.25` dB; default `0`. Raw range `-13.75` to `13.25`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `240 Hz` (`key: 240Hz`, `id: 14`, `type: f`): display range `-13.25` to `13.25` dB; default `-0.9`. Raw range `-13.25` to `13.25`; raw default `-0.9`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `750 Hz` (`key: 750Hz`, `id: 15`, `type: f`): display range `-13.25` to `13.25` dB; default `-2.9`. Raw range `-13.25` to `13.25`; raw default `-2.9`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `2200 Hz` (`key: 2200Hz`, `id: 16`, `type: f`): display range `-9.625` to `9.5` dB; default `-1.3`. Raw range `-9.625` to `9.5`; raw default `-1.3`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `6600 Hz` (`key: 6600Hz`, `id: 17`, `type: f`): display range `-9.625` to `9.5` dB; default `0`. Raw range `-9.625` to `9.5`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.

Cali IV Rhythm 1

- Model key: `HD2\_AmpCaliIVR1`
- Model ID: `622`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.1
- Based on: MESA/Boogie Mark IV (Channel I)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.1`. Raw range `0` to `1`; raw default `0.41`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Boosts upper mid and high

frequencies in the preamp.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.
- `80 Hz` (`key: 80Hz`, `id: 12`, `type: f`): display range `-13.75` to `13.25` dB; default `1.6`. Raw range `-13.75` to `13.25`; raw default `1.6`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `240 Hz` (`key: 240Hz`, `id: 13`, `type: f`): display range `-13.25` to `13.25` dB; default `0.1`. Raw range `-13.25` to `13.25`; raw default `0.1`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `750 Hz` (`key: 750Hz`, `id: 14`, `type: f`): display range `-13.25` to `13.25` dB; default `0`. Raw range `-13.25` to `13.25`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `2200 Hz` (`key: 2200Hz`, `id: 15`, `type: f`): display range `-9.625` to `9.5` dB; default `-0.5`. Raw range `-9.625` to `9.5`; raw default `-0.5`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `6600 Hz` (`key: 6600Hz`, `id: 16`, `type: f`): display range `-9.625` to `9.5` dB; default `0.4`. Raw range `-9.625` to `9.5`; raw default `0.4`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.

Cali IV Rhythm 1

- Model key: `HD2\_PreampCaliIVR1`
- Model ID: `624`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.2
- Based on: MESA/Boogie Mark IV (Channel I)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.1`. Raw range `0` to `1`; raw default `0.41`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Boosts upper mid and high frequencies in the preamp.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `80 Hz` (`key: 80Hz`, `id: 9`, `type: f`): display range `-13.75` to `13.25` dB; default `1.6`. Raw range `-13.75` to `13.25`; raw default `1.6`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `240 Hz` (`key: 240Hz`, `id: 13`, `type: f`): display range `-13.25` to `13.25` dB; default `0.1`. Raw range `-13.25` to `13.25`; raw default `0.1`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `750 Hz` (`key: 750Hz`, `id: 14`, `type: f`): display range `-13.25` to `13.25` dB; default `0`. Raw range `-13.25` to `13.25`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `2200 Hz` (`key: 2200Hz`, `id: 15`, `type: f`): display range `-9.625` to `9.5` dB; default `-0.5`. Raw range `-9.625` to `9.5`; raw default `-0.5`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `6600 Hz` (`key: 6600Hz`, `id: 16`, `type: f`): display range `-9.625` to `9.5` dB; default `0.4`. Raw range `-9.625` to `9.5`; raw default `0.4`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.

Cali IV Rhythm 2

- Model key: `HD2\_AmpCaliIVR2`
- Model ID: `623`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.1
- Based on: MESA/Boogie Mark IV (Channel II)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `1`. Raw range `0` to `1`; raw default `0.1`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.9`. Raw range `0` to `1`; raw default `0.49`. Boosts upper mid and high frequencies in the preamp.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.4`. Raw range `0` to `1`; raw default `0.74`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.
- `80 Hz` (`key: 80Hz`, `id: 13`, `type: f`): display range `-13.75` to `13.25` dB; default `1.4`. Raw range `-13.75` to `13.25`; raw default `1.4`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `240 Hz` (`key: 240Hz`, `id: 14`, `type: f`): display range `-13.25` to `13.25` dB; default `-2`. Raw range `-13.25` to `13.25`; raw default `-2`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `750 Hz` (`key: 750Hz`, `id: 15`, `type: f`): display range `-13.25` to `13.25` dB; default `-5.4`. Raw range `-13.25` to `13.25`; raw default `-5.4`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `2200 Hz` (`key: 2200Hz`, `id: 16`, `type: f`): display range `-9.625` to `9.5` dB; default `-1.7`. Raw range `-9.625` to `9.5`; raw default `-1.7`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `6600 Hz` (`key: 6600Hz`, `id: 17`, `type: f`): display range `-9.625` to `9.5` dB; default `0`. Raw range `-9.625` to `9.5`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.

Cali IV Rhythm 2

- Model key: `HD2\_PreampCaliIVR2`
- Model ID: `625`
- Type: Preamp
- Category: `preamp`
- Class: Guitar

- DSP usage estimate: 8.2
- Based on: MESA/Boogie Mark IV (Channel II)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `1`. Raw range `0` to `1`; raw default `0.1`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.9`. Raw range `0` to `1`; raw default `0.49`. Boosts upper mid and high frequencies in the preamp.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.4`. Raw range `0` to `1`; raw default `0.74`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `80 Hz` (`key: 80Hz`, `id: 13`, `type: f`): display range `-13.75` to `13.25` dB; default `1.4`. Raw range `-13.75` to `13.25`; raw default `1.4`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `240 Hz` (`key: 240Hz`, `id: 14`, `type: f`): display range `-13.25` to `13.25` dB; default `-2`. Raw range `-13.25` to `13.25`; raw default `-2`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `750 Hz` (`key: 750Hz`, `id: 15`, `type: f`): display range `-13.25` to `13.25` dB; default `-5.4`. Raw range `-13.25` to `13.25`; raw default `-5.4`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `2200 Hz` (`key: 2200Hz`, `id: 16`, `type: f`): display range `-9.625` to `9.5` dB; default `-1.7`. Raw range `-9.625` to `9.5`; raw default `-1.7`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.
- `6600 Hz` (`key: 6600Hz`, `id: 17`, `type: f`): display range `-9.625` to `9.5` dB; default `0`. Raw range `-9.625` to `9.5`; raw default `0`. The amount of boost and cut is not equal for all bands. This is consistent with the real amp.

Cali Rectifire

- Model key: `HD2\_AmpCaliRectifire`
- Model ID: `586`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.3
- Based on: MESA/Boogie Dual Rectifier

- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.6`. Raw range `0` to `1`; raw default `0.26`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.9`. Raw range `0` to `1`; raw default `0.59`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Boosts upper mid and high frequencies in the preamp.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `2.7`. Raw range `0` to `1`; raw default `0.27`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Cali Rectifire

- Model key: `HD2\_PreampCaliRectifire`
- Model ID: `587`
- Type: Preamp
- Category: `preamp`

- Class: Guitar
- DSP usage estimate: 9.8
- Based on: MESA/Boogie Dual Rectifier
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.6`. Raw range `0` to `1`; raw default `0.26`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.9`. Raw range `0` to `1`; raw default `0.59`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Boosts upper mid and high frequencies in the preamp.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `2.7`. Raw range `0` to `1`; raw default `0.27`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Cali Texas Ch1

- Model key: `HD2\_AmpCaliTexasCh1`
- Model ID: `671`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.5
- Based on: MESA/Boogie Lone Star (Clean channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Boosts upper mid and high frequencies in the preamp.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Cali Texas Ch1

- Model key: `HD2\_PreamplifierCaliTexasCh1`
- Model ID: `672`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 7.9
- Based on: MESA/Boogie Lone Star (Clean channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Boosts upper mid and high frequencies in the preamp.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.

Cali Texas Ch2

- Model key: `HD2\_AmpCaliTexasCh2`
- Model ID: `667`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.9
- Based on: MESA/Boogie Lone Star (Drive channel)
- Agoura model: No

Parameters

- `Drive 1` (`key: Drive 1`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `8.8`. Raw range `0` to `1`; raw default `0.88`. Controls the amount of Channel 1 gain applied to the signal.
- `Drive 2` (`key: Drive 2`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Channel 2 gain applied to the signal.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.3`. Raw range `0` to `1`; raw default `0.73`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Shape` (`key: TS Shape`, `id: 7`, `type: i`): valid values `Normal`, `Thick`, `Thicker`; default `Normal`. Raw range `0` to `2`; raw default `0`. Selects which frequencies the Treble parameter controls. "Normal" maintains Treble as a traditional high frequency EQ. "Thick" lowers the Treble frequency for a more robust, throatier sound. "Thicker" lowers the treble frequency even further and saturates that region, for singing sustain.
- `Presence` (`key: Presence`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Boosts upper mid and high frequencies in the preamp.
- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values

provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Ripple` (`key: Ripple`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Cali Texas Ch2

- Model key: `HD2\_PreampCaliTexasCh2`
- Model ID: `668`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.3
- Based on: MESA/Boogie Lone Star (Drive channel)
- Agoura model: No

Parameters

- `Drive 1` (`key: Drive 1`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `8.8`. Raw range `0` to `1`; raw default `0.88`. Controls the amount of Channel 1 gain applied to the signal.

- `Drive 2` (`key: Drive 2`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Channel 2 gain applied to the signal.

- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.3`. Raw range `0` to `1`; raw default `0.73`. Controls the high frequency EQ of the tonestack.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.3`. Raw range `0` to `1`; raw default `0.43`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.

- `Shape` (`key: TS Shape`, `id: 7`, `type: i`): valid values `Normal`, `Thick`, `Thicker`; default `Normal`. Raw range `0` to `2`; raw default `0`. Selects which frequencies the Treble parameter controls. "Normal" maintains Treble as a traditional high frequency EQ. "Thick" lowers the Treble frequency for a more robust, throatier sound. "Thicker" lowers the treble frequency even further and saturates that region, for singing sustain.

- `Presence` (`key: Presence`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Boosts upper mid and high frequencies in the preamp.

- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the Master Volume of the

amplifier.

Carillon

- Model key: `HD2\_AmpLine6Carillon`
- Model ID: `712`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.1
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Amp block.
- `Boost` (`key: Boost`, `id: 7`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Controls the level of the built-in germanium transistor treble booster.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: HumSwitch`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Carillon

- Model key: `HD2\_PreamplLine6Carillon`
- Model ID: `718`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 11.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Preamp block.
- `Boost` (`key: Boost`, `id: 7`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Controls the level of the built-in germanium transistor treble booster.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: HumSwitch`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Cartographer

- Model key: `HD2\_AmpCartographer`
- Model ID: `655`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.4
- Based on: Ben Adrian Cartographer
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain between the first and second tube gain stages. The character of the amp changes drastically depending on where Drive 1 and Drive 2 are set in relation to one another.
- `Drive2` (`key: Drive2`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the amount of gain between the second and third tube gain stages. The character of the amp changes drastically depending on where Drive 1 and Drive 2 are set in relation to one another.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the Master Volume of the amplifier.
- `Presence` (`key: Presence`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Controls the level of high frequencies in the power amp.
- `Depth` (`key: Depth`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the level of low frequencies in the power amp.
- `Bright 1` (`key: Bright1`, `id: 10`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, adds a high boost after the first tube preamp stage, affecting the character and harmonics of the preamp gain. Can be subtle, especially at higher Drive settings.
- `Bright 2` (`key: Bright2`, `id: 11`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, adds a high boost after the second tube preamp stage, affecting the character and harmonics of the preamp gain. Can be subtle, especially at higher Drive settings.
- `Sag` (`key: Sag`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 16`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing

reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Cartographer

- Model key: `HD2\_PreampCartographer`
- Model ID: `656`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.3
- Based on: Ben Adrian Cartographer
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain between the first and second tube gain stages. The character of the amp changes drastically depending on where Drive 1 and Drive 2 are set in relation to one another.
- `Drive2` (`key: Drive2`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the amount of gain between the second and third tube gain stages. The character of the amp changes drastically depending on where Drive 1 and Drive 2 are set in relation to one another.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the Master Volume of the amplifier.
- `Bright 1` (`key: Bright1`, `id: 8`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, adds a high boost after the first tube preamp stage, affecting the character and harmonics of the preamp gain. Can be subtle, especially at higher Drive settings.
- `Bright 2` (`key: Bright2`, `id: 9`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, adds a high boost after the second tube preamp stage, affecting the character and harmonics of the preamp gain. Can be subtle, especially at higher Drive settings.
- `Sag` (`key: Sag`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level,

non-harmonic distortion adds a bit of realism to the amp model.

Clarity

- Model key: `HD2\_AmpLine6Clarity`
- Model ID: `710`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 8.6
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `1`. Raw range `0` to `1`; raw default `0.1`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the overall level of the Amp block.
- `Boost` (`key: Boost`, `id: 7`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Adds a tube stage with gentle clipping at lower values and increased distortion at higher values.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: HumSwitch`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Clarity

- Model key: `HD2\_PreamplLine6Clarity`
- Model ID: `719`
- Type: Preamp
- Category: `preamp`

- Class: Guitar
- DSP usage estimate: 8.8
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the overall level of the Preamp block.
- `Boost` (`key: Boost`, `id: 7`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Adds a tube stage with gentle clipping at lower values and increased distortion at higher values.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: HumSwitch`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Das Benzin Lead

- Model key: `HD2\_AmpDasBenzinLead`
- Model ID: `693`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.8
- Based on: Diezel VH4 (Lead channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.2`. Raw range `0` to `1`; raw default `0.82`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the Master Volume of the amplifier.
- `Deep` (`key: Deep`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Adds low punch (centered around 80 Hz) to the the power amp.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Das Benzin Lead

- Model key: `HD2\_PreamplifierDasBenzinLead`
- Model ID: `694`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.8
- Based on: Diezel VH4 (Lead channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.2`. Raw range `0` to `1`; raw default `0.82`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

Das Benzin Mega

- Model key: `HD2\_AmpDasBenzinMega`
- Model ID: `695`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.6
- Based on: Diezel VH4 (Mega channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Deep` (`key: Deep`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Adds low punch (centered around 80 Hz) to

the the power amp.

- `Sag` (`key: Sag`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Das Benzin Mega

- Model key: `HD2\_PreamplifierDasBenzinMega`
- Model ID: `696`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.5
- Based on: Diezel VH4 (Mega channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

Derailed Ingrid

- Model key: `HD2\_AmpDerailedIngrid`
- Model ID: `651`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.0
- Based on: Trainwreck Circuits Express
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.3`. Raw range `0` to `1`; raw default `0.43`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.8`. Raw range `0` to `1`; raw default `0.88`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing

reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

- `Bright` (`key: Bright`, `id: 13`, `type: i`): display range `0` to `2` unitless; default `0`. Raw range `0` to `2`; raw default `0`. Selects the amount of brightness--Off (0), softer brightness (1), or harder, edgy brightness (2). This parameter is more dramatic at lower Drive settings.

Derailed Ingrid

- Model key: `HD2\_PreamplifierDerailedIngrid`
- Model ID: `652`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 7.9
- Based on: Trainwreck Circuits Express
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.3`. Raw range `0` to `1`; raw default `0.43`. Controls the high frequency EQ of the tonestack.

- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the Master Volume of the amplifier.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.8`. Raw range `0` to `1`; raw default `0.88`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.

- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

- `Bright` (`key: Bright`, `id: 9`, `type: i`): display range `0` to `2` unitless; default `0`. Raw range `0` to `2`; raw default `0`. Selects the amount of brightness--Off (0), softer brightness (1), or harder, edgy brightness (2). This parameter is more dramatic at lower Drive settings.

Divided Duo

- Model key: `HD2\_AmpDividedDuo`
- Model ID: `584`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.7
- Based on: A13 JRT 9/15
- Agoura model: No

Parameters

- `Drive 1` (`key: Drive 1`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.1`. Raw range `0` to `1`; raw default `0.41`. Controls the amount of Channel 1 gain applied to the signal, which has a bright and clean sound with plenty of headroom. Some breakup can be heard at higher settings.
- `Drive 2` (`key: Drive 2`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the amount of Channel 2 gain applied to the signal, which has a thicker low mid response, more overdrive, and lower headroom.
- `Tone` (`key: Tone`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.3`. Raw range `0` to `1`; raw default `0.43`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies. Lower settings decreases upper mid and high frequencies and higher settings add mid and high frequencies, with a slight shift in the mids.
- `Cut` (`key: Cut`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Increasing this parameter cuts high frequencies, which can be used to soften or lessen any undesirable harshness.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0.6`. Raw range `0` to `1`; raw default `0.06`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default

`5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Divided Duo

- Model key: `HD2\_PreamplifierDividedDuo`
- Model ID: `585`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 6.6
- Based on: A13 JRT 9/15
- Agoura model: No

Parameters

- `Drive 1` (`key: Drive1`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.1`. Raw range `0` to `1`; raw default `0.41`. Controls the amount of Channel 1 gain applied to the signal, which has a bright and clean sound with plenty of headroom. Some breakup can be heard at higher settings.
- `Drive 2` (`key: Drive2`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the amount of Channel 2 gain applied to the signal, which has a thicker low mid response, more overdrive, and lower headroom.
- `Tone` (`key: Tone`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.3`. Raw range `0` to `1`; raw default `0.43`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies. Lower settings decreases upper mid and high frequencies and higher settings add mid and high frequencies, with a slight shift in the mids.
- `Master` (`key: Master`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Source file: guitar-amps-and-preamps-d-to-m.md

Guitar amps and preamps (D to M)

Upload-ready knowledge for guitar amp and preamp blocks.

Generated from the installed Helix Stadium desktop app bundle on
2026-05-07T22:33:14.224003+00:00.

Use display values for normal user-facing answers. Use model keys, IDs, and raw ranges only when the user asks for automation or low-level control details.

Model count: 69

Doom

- Model key: `HD2\_AmpLine6Doom`
- Model ID: `568`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.9`. Raw range `0` to `1`; raw default `0.69`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion

to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Doom

- Model key: `HD2\_Preampline6Doom`
- Model ID: `569`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

EV Panama Blue

- Model key: `Agoura\_AmpEVPanamaBlue`

- Model ID: `811`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 26.8
- Based on: EVH 5150III 100, 6L6 (Blue channel)
- Agoura model: Yes

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.4`. Raw range `0` to `1`; raw default `0.74`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Master` (`key: Master`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Ripple` (`key: Ripple`, `id: 9`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 11`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

EV Panama Blue

- Model key: `HD2\_AmpEVPanamaBlue`
- Model ID: `746`

- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 15.0
- Based on: EVH 5150III 100, 6L6 (Blue channel)
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Low` (`key: Low`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the midrange frequency EQ of the tonestack.
- `High` (`key: High`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.1`. Raw range `0` to `1`; raw default `0.71`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Gain and Master settings.

EV Panama Blue

- Model key: `HD2\_PreampEVPanamaBlue`
- Model ID: `747`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 11.9
- Based on: EVH 5150III 100, 6L6 (Blue channel)
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Low` (`key: Low`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the midrange frequency EQ of the tonestack.
- `High` (`key: High`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

EV Panama Red

- Model key: `Agoura\_AmpEVPanamaRed`
- Model ID: `823`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 27.0
- Based on: EVH 5150III 100, 6L6 (Red channel)
- Agoura model: Yes

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.75`. Raw range `0` to `1`; raw default `0.375`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.3`. Raw range `0` to `1`; raw default `0.73`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.1`. Raw range `0` to `1`; raw default `0.71`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Master` (`key: Master`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Ripple` (`key: Ripple`, `id: 9`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 11`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

EV Panama Red

- Model key: `HD2\_AmpEVPanamaRed`
- Model ID: `745`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 18.4
- Based on: EVH 5150III 100, 6L6 (Red channel)
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Low` (`key: Low`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.8`.

Raw range `0` to `1`; raw default `0.38`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls the midrange frequency EQ of the tonestack.
- `High` (`key: High`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Gain and Master settings.

EV Panama Red

- Model key: `HD2\_PreampEVPanamaRed`
- Model ID: `748`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 15.1
- Based on: EVH 5150III 100, 6L6 (Red channel)
- Agoura model: No

Parameters

- `Gain` (`key: Gain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Controls the amount of gain applied to the

signal, which influences the level of distortion.

- `Low` (`key: Low`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls the midrange frequency EQ of the tonestack.
- `High` (`key: High`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Elektrik

- Model key: `HD2\_AmpLine6Elektrik`
- Model ID: `566`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 9.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.4`. Raw range `0` to `1`; raw default `0.34`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.6`. Raw range `0` to `1`; raw default `0.26`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default

`7`. Raw range `0` to `1`; raw default `0.7`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `4.3`. Raw range `0` to `1`; raw default `0.43`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Elektrik

- Model key: `HD2\_PreamplifierElektrik`
- Model ID: `567`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.4`. Raw range `0` to `1`; raw default `0.34`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.6`. Raw range `0` to `1`; raw default `0.26`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.3`.

Raw range `0` to `1`; raw default `0.43`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

Elmsley

- Model key: `HD2\_AmpLine6Elmsley`
- Model ID: `725`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 15.6
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Amp block.
- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency response in the power amp.
- `Depth` (`key: Depth`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency response in the power amp.
- `NFB` (`key: NFB`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of NFB (Negative Feedback) within the power section, allowing for a response anywhere from wild and unhinged, tight and punchy, and anything in between. Higher settings increase the influence of Presence and Depth; when NFB is at 0.0, Presence and Depth are effectively deactivated.
- `Sag` (`key: Sag`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 12`, `type: f`): display range `0` to `10` unitless; default

`5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Elmsley

- Model key: `HD2\_Preamplifier6Elmsley`
- Model ID: `724`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.6
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.

- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.

- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Epic

- Model key: `HD2\_AmpLine6Epic`
- Model ID: `564`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.2
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3.2`. Raw range `0` to `1`; raw default `0.32`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Epic

- Model key: `HD2\_PreamplLine6Epic`
- Model ID: `565`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.7
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Essex A15

- Model key: `HD2\_AmpEssexA15`
- Model ID: `582`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.2
- Based on: Vox AC-15
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Cut` (`key: Cut`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Increasing this parameter attenuates high frequencies, effectively reducing the amp's brightness.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `7.1`. Raw range `0` to `1`; raw default `0.71`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Essex A15

- Model key: `HD2\_PreampEssexA15`
- Model ID: `583`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 6.5
- Based on: Vox AC-15

- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Essex A30

- Model key: `HD2\_AmpEssexA30`
- Model ID: `580`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.2
- Based on: Vox AC-30 with Top Boost
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Cut` (`key: Cut`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.8`. Raw range `0` to `1`; raw default `0.78`. Increasing this parameter attenuates high frequencies, effectively reducing the amp's brightness.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.

- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.4`. Raw range `0` to `1`; raw default `0.74`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Essex A30

- Model key: `HD2\_PreampEssexA30`
- Model ID: `581`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 7.4
- Based on: Vox AC-30 with Top Boost
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.

- `Sag` (`key: Sag`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.4`. Raw range `0` to `1`; raw default `0.74`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Hum` (`key: Hum`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Essex TB30CC

- Model key: `Agoura\_AmpEssexTB30CC`
- Model ID: `810`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 22.5
- Based on: Vox AC-30CC (Normal and Top Boost channels)
- Agoura model: Yes

Parameters

- `Channel` (`key: Channel`, `id: 1`, `type: i`): valid values `Normal`, `Top Boost`; default `Top Boost`. Raw range `0` to `1`; raw default `1`. Selects the amp channel or which input is connected.
- `Normal Drive` (`key: NrmDrv`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of Normal channel gain applied to the signal. The inactive channel can sometimes "bleed into" the active channel, resulting in interesting interactions.
- `Bright Drive` (`key: BrtDrv`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Bright channel gain applied to the signal. The inactive channel can sometimes "bleed into" the active channel, resulting in interesting interactions.
- `Bass` (`key: Bass`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls the high frequency EQ of the tonestack.
- `High Cut` (`key: HighCut`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `0.5`. Raw range `0` to `1`; raw default `0.05`. Increasing this parameter attenuates high frequencies, effectively reducing the amp's brightness.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-30` to `10` dB; default `-10`. Raw range `-30` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps;

lower values offer a "tighter" responsiveness for a more modern feel.

- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 12`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Fatality

- Model key: `HD2\_AmpLine6Fatality`
- Model ID: `630`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Boosts upper mid and high frequencies, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Fatality

- Model key: `HD2\_PreamplifierFatality`
- Model ID: `631`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.8
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3.2`. Raw range `0` to `1`; raw default `0.32`. Boosts upper mid and high frequencies, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `2`. Raw range `0` to `1`; raw default `0.2`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60

cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Fullerton Brt

- Model key: `HD2\_AmpFullertonBrt`
- Model ID: `682`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.0
- Based on: Fender Tweed Deluxe 5C3 (Bright channel)
- Agoura model: No

Parameters

- `Drive Norm` (`key: DriveNorm`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `0.3`. Raw range `0` to `1`; raw default `0.03`. Controls the amount of Normal channel bleed, even while the Bright channel is active. Around halfway up, the sound is a bit mid-forward and at higher settings, the sound appears slightly "scooped."
- `Drive Bright` (`key: DriveBright`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.9`. Raw range `0` to `1`; raw default `0.29`. Controls the amount of Bright channel gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Tone` (`key: Tone`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power

amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Fullerton Brt

- Model key: `HD2\_PreamplifierFullertonBrt`
- Model ID: `685`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 6.2
- Based on: Fender Tweed Deluxe 5C3 (Bright channel)
- Agoura model: No

Parameters

- `Drive Norm` (`key: DriveNorm`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `0.3`. Raw range `0` to `1`; raw default `0.03`. Controls the amount of Normal channel bleed, even while the Bright channel is active. Around halfway up, the sound is a bit mid-forward and at higher settings, the sound appears slightly "scooped."
- `Drive Bright` (`key: DriveBright`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.9`. Raw range `0` to `1`; raw default `0.29`. Controls the amount of Bright channel gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Tone` (`key: Tone`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Fullerton Jump

- Model key: `HD2\_AmplifierFullertonJump`

- Model ID: `683`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.0
- Based on: Fender Tweed Deluxe 5C3 (Jumped channels)
- Agoura model: No

Parameters

- `Drive Norm` (`key: DriveNorm`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the amount of Normal channel gain applied to the signal.
- `Drive Bright` (`key: DriveBright`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `1`. Raw range `0` to `1`; raw default `0.1`. Controls the amount of Bright channel gain applied to the signal.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Tone` (`key: Tone`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Fullerton Jump

- Model key: `HD2\_PreamplifierFullertonJump`
- Model ID: `686`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.3
- Based on: Fender Tweed Deluxe 5C3 (Jumped channels)
- Agoura model: No

Parameters

- `Drive Norm` (`key: DriveNorm`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the amount of Normal channel gain applied to the signal.
- `Drive Bright` (`key: DriveBright`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.1`. Raw range `0` to `1`; raw default `0.41`. Controls the amount of Bright channel gain applied to the signal.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Tone` (`key: Tone`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Fullerton Nrm

- Model key: `HD2\_AmpFullertonNrm`
- Model ID: `684`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.0
- Based on: Fender Tweed Deluxe 5C3 (Normal channel)
- Agoura model: No

Parameters

- `Drive Norm` (`key: DriveNorm`, `id: 1`, `type: f`): display range `0` to `10` unitless;

default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of Normal channel gain applied to the signal, which influences the level of distortion.

- `Drive Bright` (`key: DriveBright`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.4`. Raw range `0` to `1`; raw default `0.34`. Controls the amount of subtle Bright channel bleed, even while the Normal channel is active.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Tone` (`key: Tone`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Fullerton Nrm

- Model key: `HD2\_PreamFullertonNrm`
- Model ID: `687`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 6.2
- Based on: Fender Tweed Deluxe 5C3 (Normal channel)
- Agoura model: No

Parameters

- `Drive Norm` (`key: DriveNorm`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of Normal channel gain applied to the signal, which influences the level of distortion.
- `Drive Bright` (`key: DriveBright`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.4`. Raw range `0` to `1`; raw default `0.34`. Controls the amount of subtle Bright channel bleed, even while the Normal channel is active.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Tone` (`key: Tone`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

German Mahadeva

- Model key: `HD2\_AmpGermanMahadeva`
- Model ID: `576`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.8
- Based on: Bogner Shiva
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.1`. Raw range `0` to `1`; raw default `0.31`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls the high frequency EQ of the tonestack.

- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

German Mahadeva

- Model key: `HD2\_PreamperGermanMahadeva`
- Model ID: `577`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.8
- Based on: Bogner Shiva
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.1`. Raw range `0` to `1`; raw default `0.31`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

German Ubersonic

- Model key: `HD2\_AmpGermanUbersonic`
- Model ID: `574`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.0
- Based on: Bogner Aerschall
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.3`. Raw range `0` to `1`; raw default `0.23`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power

supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Ripple` (`key: Ripple`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

German Ubersonic

- Model key: `HD2\_PreamperGermanUbersonic`
- Model ID: `575`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.1
- Based on: Bogner Aerschall
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.3`. Raw range `0` to `1`; raw default `0.23`. Controls the high frequency EQ of the tonestack.

- `Level` (`key: Ch Vol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.

- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the Master Volume of the amplifier.

- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

German Xtra Blue

- Model key: `Agoura\_AmpGermanXtraBlue`
- Model ID: `818`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 22.2
- Based on: Bogner Ecstasy 101B, EL34 (Blue channel)
- Agoura model: Yes

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.98`. Raw range `0` to `1`; raw default `0.698`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.12`. Raw range `0` to `1`; raw default `0.412`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.88`. Raw range `0` to `1`; raw default `0.588`. Controls the high frequency EQ of the tonestack.
- `Bright` (`key: PreEQ\_Brt`, `id: 5`, `type: i`): valid values `Off`, `B1`, `B2`; default `B1`. Raw range `0` to `2`; raw default `1`. Adds two levels of brightness before the tonestack--B1 and B2.
- `Boost` (`key: Boost`, `id: 6`, `type: i`): valid values `Off`, `On`; default `Off`. Raw range `0` to `1`; raw default `0`. When on, boosts the preamp's gain.
- `Structure` (`key: Structure`, `id: 7`, `type: i`): valid values `Low`, `High`; default `Low`. Raw range `0` to `1`; raw default `0`. Adjusts the amount and texture of distortion, providing a subtle EQ shift.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `0`. Raw range `-40` to `10`; raw default `0`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the master volume of the amplifier.
- `Presence` (`key: Presence`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `6.48`. Raw range `0` to `1`; raw default `0.648`. Adjusts the presence or brightness of the amplifier.
- `Depth` (`key: Excursion\_Depth`, `id: 11`, `type: i`): valid values `Tight`, `Medium`, `Loose`; default `Medium`. Raw range `0` to `2`; raw default `1`. This 3-position switch sets the amount of damping. "Tight" maintains balance between the low and high strings, "Loose" provides a notable bass boost, and "Medium" is somewhere in the middle.
- `Style` (`key: Old\_New`, `id: 12`, `type: b`): valid values `Triode`, `Pentode`; default `Pentode`. Raw range `Off` to `On`; raw default `On`. When set to "Triode," 3 out of 5 elements in the tubes are active, which can sound a bit smoother. When set to "Pentode," all tube elements are active, which provides more bite and punch.
- `Sag` (`key: Sag`, `id: 13`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 14`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion

to the power amp at distorted settings.

- `ZPrePost` (`key: ZPrePost`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 16`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

German Xtra Blue

- Model key: `HD2\_AmpGermanXtraBlue`
- Model ID: `741`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.3
- Based on: Bogner Ecstasy 101B, EL34 (Blue channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.12`. Raw range `0` to `1`; raw default `0.412`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.56`. Raw range `0` to `1`; raw default `0.456`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.54`. Raw range `0` to `1`; raw default `0.654`. Controls the high frequency EQ of the tonestack.
- `Bright` (`key: PreEQ\_Brt`, `id: 5`, `type: i`): valid values `Off`, `B1`, `B2`; default `B1`. Raw range `0` to `2`; raw default `1`. Adds two levels of brightness before the tonestack--B1 and B2.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Boost` (`key: Boost`, `id: 7`, `type: b`): valid values `Low`, `High`; default `High`. Raw range `Off` to `On`; raw default `On`. When set to "High," boosts the preamp's gain.
- `Structure` (`key: Structure`, `id: 8`, `type: b`): valid values `Low`, `High`; default `Low`. Raw range `Off` to `On`; raw default `Off`. Adjusts the amount and texture of distortion, providing a subtle EQ shift.
- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `4.12`. Raw range `0` to `1`; raw default `0.412`. Controls the master volume of the amplifier.
- `Presence` (`key: Presence`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Depth` (`key: Excursion\_Depth`, `id: 11`, `type: i`): valid values `Tight`, `Medium`, `Loose`; default `Loose`. Raw range `0` to `2`; raw default `2`. This 3-position switch sets

the amount of damping. "Tight" maintains balance between the low and high strings, "Loose" provides a notable bass boost, and "Medium" is somewhere in the middle.

- `Style` (`key: Old\_New`, `id: 12`, `type: b`): valid values `Triode`, `Pentode`; default `Pentode`. Raw range `Off` to `On`; raw default `On`. When set to "Triode," 3 out of 5 elements in the tubes are active, which can sound a bit smoother. When set to "Pentode," all tube elements are active, which provides more bite and punch.
- `Class` (`key: Class\_AB\_A`, `id: 13`, `type: b`): valid values `A`, `AB`; default `AB`. Raw range `Off` to `On`; raw default `On`. Selects the power amp class--A or A/B. Class A generally sounds a bit richer and more compressed while Class A/B exhibits greater punch with better note separation and additional headroom.
- `Sag` (`key: Sag`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 16`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 17`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

German Xtra Blue

- Model key: `HD2\_PreamperGermanXtraBlue`
- Model ID: `744`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.1
- Based on: Bogner Ecstasy 101B, EL34 (Blue channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Bright` (`key: PreEQ\_Brt`, `id: 5`, `type: i`): valid values `Off`, `B1`, `B2`; default `Off`. Raw range `0` to `2`; raw default `0`. Adds two levels of brightness before the tonestack--B1 and B2.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Boost` (`key: Boost`, `id: 7`, `type: b`): valid values `Low`, `High`; default `Low`. Raw range `Off` to `On`; raw default `Off`. When set to "High," boosts the preamp's gain.
- `Structure` (`key: Structure`, `id: 8`, `type: b`): valid values `Low`, `High`; default `Low`. Raw range `Off` to `On`; raw default `Off`. Adjusts the amount and texture of distortion, providing a subtle EQ shift.
- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the master volume of the amplifier.

German Xtra Red

- Model key: `Agoura\_AmpGermanXtraRed`
- Model ID: `819`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 23.7
- Based on: Bogner Ecstasy 101B, EL34 (Red channel)
- Agoura model: Yes

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.62`. Raw range `0` to `1`; raw default `0.362`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.88`. Raw range `0` to `1`; raw default `0.588`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Controls the high frequency EQ of the tonestack.
- `Bright` (`key: PreEQ\_Brt`, `id: 5`, `type: i`): valid values `Off`, `B1`, `B2`; default `B1`. Raw range `0` to `2`; raw default `1`. Adds two levels of brightness before the tonestack--B1 and B2.
- `Boost` (`key: Boost`, `id: 6`, `type: i`): valid values `Off`, `On`; default `Off`. Raw range `0` to `1`; raw default `0`. When on, boosts the preamp's gain.
- `Structure` (`key: Structure`, `id: 7`, `type: i`): valid values `Low`, `High`; default `High`. Raw range `0` to `1`; raw default `1`. Adjusts the amount and texture of distortion, providing a subtle EQ shift.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the master volume of the amplifier.
- `Presence` (`key: Presence`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `3.68`. Raw range `0` to `1`; raw default `0.368`. Adjusts the presence or brightness of the amplifier.
- `Depth` (`key: Excursion\_Depth`, `id: 11`, `type: i`): valid values `Tight`, `Medium`, `Loose`; default `Tight`. Raw range `0` to `2`; raw default `0`. This 3-position switch sets the amount of damping. "Tight" maintains balance between the low and high strings, "Loose" provides a notable bass boost, and "Medium" is somewhere in the middle.

- `Style` (`key: Old\_New`, `id: 12`, `type: b`): valid values `Triode`, `Pentode`; default `Pentode`. Raw range `Off` to `On`; raw default `On`. When set to "Triode," 3 out of 5 elements in the tubes are active, which can sound a bit smoother. When set to "Pentode," all tube elements are active, which provides more bite and punch.
- `Sag` (`key: Sag`, `id: 13`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 14`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `3.52`. Raw range `0` to `1`; raw default `0.352`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 16`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

German Xtra Red

- Model key: `HD2\_AmpGermanXtraRed`
- Model ID: `742`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.7
- Based on: Bogner Ecstasy 101B, EL34 (Red channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the high frequency EQ of the tonestack.
- `Bright` (`key: PreEQ\_Brt`, `id: 5`, `type: i`): valid values `Off`, `B1`, `B2`; default `Off`. Raw range `0` to `2`; raw default `0`. Adds two levels of brightness before the tonestack--B1 and B2.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the overall level of the Amp

block. Unlike Master Volume, it has no effect on the block's tone.

- `Boost` (`key: Boost`, `id: 7`, `type: b`): valid values `Low`, `High`; default `High`. Raw range `Off` to `On`; raw default `On`. When set to "High," boosts the preamp's gain.
- `Structure` (`key: Structure`, `id: 8`, `type: b`): valid values `Low`, `High`; default `High`. Raw range `Off` to `On`; raw default `On`. Adjusts the amount and texture of distortion, providing a subtle EQ shift.
- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the master volume of the amplifier.
- `Presence` (`key: Presence`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Depth` (`key: Excursion\_Depth`, `id: 11`, `type: i`): valid values `Tight`, `Medium`, `Loose`; default `Tight`. Raw range `0` to `2`; raw default `0`. This 3-position switch sets the amount of damping. "Tight" maintains balance between the low and high strings, "Loose" provides a notable bass boost, and "Medium" is somewhere in the middle.
- `Style` (`key: Old\_New`, `id: 12`, `type: b`): valid values `Triode`, `Pentode`; default `Pentode`. Raw range `Off` to `On`; raw default `On`. When set to "Triode," 3 out of 5 elements in the tubes are active, which can sound a bit smoother. When set to "Pentode," all tube elements are active, which provides more bite and punch.
- `Class` (`key: Class\_AB\_A`, `id: 13`, `type: b`): valid values `A`, `AB`; default `AB`. Raw range `Off` to `On`; raw default `On`. Selects the power amp class--A or A/B. Class A generally sounds a bit richer and more compressed while Class A/B exhibits greater punch with better note separation and additional headroom.
- `Sag` (`key: Sag`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 16`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 17`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

German Xtra Red

- Model key: `HD2\_PreamperGermanXtraRed`
- Model ID: `743`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 10.8
- Based on: Bogner Ecstasy 101B, EL34 (Red channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default

`5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Bright` (`key: PreEQ\_Brt`, `id: 5`, `type: i`): valid values `Off`, `B1`, `B2`; default `Off`. Raw range `0` to `2`; raw default `0`. Adds two levels of brightness before the tonestack--B1 and B2.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Boost` (`key: Boost`, `id: 7`, `type: b`): valid values `Low`, `High`; default `High`. Raw range `Off` to `On`; raw default `On`. When set to "High," boosts the preamp's gain.
- `Structure` (`key: Structure`, `id: 8`, `type: b`): valid values `Low`, `High`; default `High`. Raw range `Off` to `On`; raw default `On`. Adjusts the amount and texture of distortion, providing a subtle EQ shift.
- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the master volume of the amplifier.

Grammatico GSG

- Model key: `HD2\_AmpGSG100`
- Model ID: `731`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 15.8
- Based on: Grammatico GSG100
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the tonestack. NOTE: Voicing changes with the Jazz Rock switch.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack. NOTE: Voicing changes with the Jazz Rock switch.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack. NOTE: Voicing changes with the Jazz Rock switch.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Boosts high frequencies in the power amp by modifying the EQ filtering in the power amp's negative feedback loop.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the master volume of the amplifier. It is located between the preamp and power amp and can be used to get more or less power amp distortion. This amp is VERY loud, and if the Master is cranked, the power amp distortion can be pushed into unpleasant territory.
- `Mid Switch` (`key: MidSwitch`, `id: 8`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Changes the value of the treble capacitor in the tone stack. When off, the amp has more of a scooped sound; when on, there is a noticeable upper-mid boost.
- `Jazz Rock` (`key: JazzRock`, `id: 9`, `type: b`): valid values `Jazz`, `Rock`; default `Rock`. Raw range `Off` to `On`; raw default `On`. Changes the tonestack's wiring, allowing for two totally separate tonal voices. Jazz is quieter with a lower center frequency for the mids. Rock is louder with a more traditional mid frequency center. Tone controls rarely translate well between the Jazz and Rock settings. If a good sound is achieved in one mode, it is not guaranteed that the same settings in the opposite mode will still sound pleasing.
- `OD Switch` (`key: ODSwitch`, `id: 10`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Turns the two-gain-stage tube overdrive circuit on and off. This circuit is located AFTER the tone controls and Drive knob. When the overdrive is turned on it's as if third and fourth gain stages are added to the preamp.
- `OD Drive` (`key: ODDrive`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `2.4`. Raw range `0` to `1`; raw default `0.24`. Controls the amount of drive or saturation in the overdrive circuit. Since the whole overdrive circuit is after the amp's regular Drive and Tone controls, the range of OD Drive will change based on those earlier knob settings.
- `OD Level` (`key: ODLevel`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the output level of the overdrive circuit.
- `Bright` (`key: Bright`, `id: 13`, `type: i`): valid values `Off`, `1`, `2`; default `Off`. Raw range `0` to `2`; raw default `0`. Engages one of two different values of bright capacitor, and is more pronounced at lower Drive settings. When Drive is at 10.0, Bright is effectively removed from the amp circuit.
- `FET Boost` (`key: FETBoost`, `id: 14`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Provides a 7-9 dB FET (Field Effect Transistor) boost and tweaks the EQ a bit. The result is similar to placing a FET boost pedal before the amp.
- `PAB` (`key: PAB`, `id: 15`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Adds a preamp boost between tube stages 1 and 2, but at the expense of removing the tonestack controls from the circuit.
- `Sag` (`key: Sag`, `id: 16`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Controls the amount of sag, or how much the power supply compresses or "drips" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 17`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 18`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 19`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 20`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Grammatico GSG

- Model key: `HD2\_PreampGSG100`
- Model ID: `732`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 11.5
- Based on: Grammatico GSG100
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the tonestack. NOTE: Voicing changes with the Jazz Rock switch.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack. NOTE: Voicing changes with the Jazz Rock switch.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack. NOTE: Voicing changes with the Jazz Rock switch.

- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the master volume of the amplifier. It is located between the preamp and power amp and can be used to get more or less power amp distortion. This amp is VERY loud, and if the Master is cranked, the power amp distortion can be pushed into unpleasant territory.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.

- `Mid Switch` (`key: MidSwitch`, `id: 7`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Changes the value of the treble capacitor in the tone stack. When off, the amp has more of a scooped sound; when on, there is a noticeable upper-mid boost.

- `Jazz Rock` (`key: JazzRock`, `id: 8`, `type: b`): valid values `Jazz`, `Rock`; default `Rock`. Raw range `Off` to `On`; raw default `On`. Changes the tonestack's wiring, allowing for two totally separate tonal voices. Jazz is quieter with a lower center frequency for the mids. Rock is louder with a more traditional mid frequency center. Tone controls rarely translate well between the Jazz and Rock settings. If a good sound is achieved in one mode, it is not guaranteed that the same settings in the opposite mode will still sound pleasing.

- `OD Switch` (`key: ODSwitch`, `id: 9`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Turns the two-gain-stage tube overdrive circuit on and off. This circuit is located AFTER the tone controls and Drive knob. When the overdrive is turned on it's as if third and fourth gain stages are added to the preamp.

- `OD Drive` (`key: ODDrive`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `2.4`. Raw range `0` to `1`; raw default `0.24`. Controls the amount of drive or saturation in the overdrive circuit. Since the whole overdrive circuit is after the amp's regular Drive and Tone controls, the range of OD Drive will change based on those earlier

knob settings.

- `OD Level` (`key: ODLevel`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the output level of the overdrive circuit.
- `Bright` (`key: Bright`, `id: 12`, `type: i`): valid values `Off`, `1`, `2`; default `Off`. Raw range `0` to `2`; raw default `0`. Engages one of two different values of bright capacitor, and is more pronounced at lower Drive settings. When Drive is at 10.0, Bright is effectively removed from the amp circuit.
- `FET Boost` (`key: FETBoost`, `id: 13`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Provides a 7-9 dB FET (Field Effect Transistor) boost and tweaks the EQ a bit. The result is similar to placing a FET boost pedal before the amp.
- `PAB` (`key: PAB`, `id: 14`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. Adds a preamp boost between tube stages 1 and 2, but at the expense of removing the tonestack controls from the circuit.
- `Sag` (`key: Sag`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Controls the amount of sag, or how much the power supply compresses or "drips" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 16`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

GrammaticoLG Brt

- Model key: `HD2\_AmpGrammaticoBrt`
- Model ID: `676`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.5
- Based on: Grammatico LaGrange (Bright channel)
- Agoura model: No

Parameters

- `Drive Norm` (`key: DriveNorm`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of Normal channel bleed, even while the Bright channel is active.
- `Drive Bright` (`key: DriveBright`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Bright channel gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Tone` (`key: Tone`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Amp

block. Unlike Master Volume, it has no effect on the block's tone.

- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `4.1`. Raw range `0` to `1`; raw default `0.41`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

GrammaticoLG Brt

- Model key: `HD2\_PreamplifierGrammaticoBrt`
- Model ID: `679`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 7.4
- Based on: Grammatico LaGrange (Bright channel)
- Agoura model: No

Parameters

- `Drive Norm` (`key: DriveNorm`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of Normal channel bleed, even while the Bright channel is active.
- `Drive Bright` (`key: DriveBright`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Bright channel gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Tone` (`key: Tone`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

GrammaticoLG Jmp

- Model key: `HD2\_AmpGrammaticoJump`
- Model ID: `677`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.7
- Based on: Grammatico LaGrange (Jumped channels)
- Agoura model: No

Parameters

- `Drive Norm` (`key: DriveNorm`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Normal channel gain applied to the signal.
- `Drive Bright` (`key: DriveBright`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Bright channel gain applied to the signal.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Controls the low frequency EQ of the tonestack.
- `Tone` (`key: Tone`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.1`. Raw range `0` to `1`; raw default `0.71`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps;

lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `4.1`. Raw range `0` to `1`; raw default `0.41`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

GrammaticoLG Jmp

- Model key: `HD2\_PreamplifierGrammaticoJump`
- Model ID: `680`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.4
- Based on: Grammatico LaGrange (Jumped channels)
- Agoura model: No

Parameters

- `Drive Norm` (`key: DriveNorm`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Normal channel gain applied to the signal.
- `Drive Bright` (`key: DriveBright`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Bright channel gain applied to the signal.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Controls the low frequency EQ of the tonestack.
- `Tone` (`key: Tone`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.1`. Raw range `0` to `1`; raw default `0.71`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5.1`.

Raw range `0` to `1`; raw default `0.51`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `6.5`.

Raw range `0` to `1`; raw default `0.65`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

GrammaticoLG Nrm

- Model key: `HD2\_AmpGrammaticoNrm`
- Model ID: `678`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.5
- Based on: Grammatico LaGrange (Normal channel)
- Agoura model: No

Parameters

- `Drive Norm` (`key: DriveNorm`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of Normal channel gain applied to the signal, which influences the level of distortion.

- `Drive Bright` (`key: DriveBright`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of Bright channel bleed, even while the Normal channel is active.

- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.

- `Tone` (`key: Tone`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.

- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7.9`. Raw range `0` to `1`; raw default `0.79`. Controls the Master Volume of the amplifier.

- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default

`7.6`. Raw range `0` to `1`; raw default `0.76`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `8.3`. Raw range `0` to `1`; raw default `0.83`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

GrammaticoLG Nrm

- Model key: `HD2\_PreampGrammaticoNrm`
- Model ID: `681`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 7.4
- Based on: Grammatico LaGrange (Normal channel)
- Agoura model: No

Parameters

- `Drive Norm` (`key: DriveNorm`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of Normal channel gain applied to the signal, which influences the level of distortion.
- `Drive Bright` (`key: DriveBright`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of Bright channel bleed, even while the Normal channel is active.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Tone` (`key: Tone`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7.9`. Raw range `0` to `1`; raw default `0.79`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level,

non-harmonic distortion adds a bit of realism to the amp model.

Interstate Zed

- Model key: `HD2\_AmpInterstateZed`
- Model ID: `572`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 10.3
- Based on: Dr Z Route 66
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.9`. Raw range `0` to `1`; raw default `0.69`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.9`. Raw range `0` to `1`; raw default `0.49`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0.8`. Raw range `0` to `1`; raw default `0.08`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default

`5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Interstate Zed

- Model key: `HD2\_PreampInterstateZed`
- Model ID: `573`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 5.9
- Based on: Dr Z Route 66
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.9`. Raw range `0` to `1`; raw default `0.69`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.9`. Raw range `0` to `1`; raw default `0.49`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Jazz Rivet 120

- Model key: `HD2\_AmpJazzRivet120`
- Model ID: `570`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 6.9

- Based on: Roland JC-120 Jazz Chorus
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `2.7`. Raw range `0` to `1`; raw default `0.27`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Bright` (`key: Bright`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adds additional treble and brightness to the tone. On the original amp, the Bright switch toggles off (0.0) and on (10.0); here you have continuous control (0.0-10.0).

Jazz Rivet 120

- Model key: `HD2\_PreamplifierJazzRivet120`
- Model ID: `571`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 4.5
- Based on: Roland JC-120 Jazz Chorus
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `2.7`. Raw range `0` to `1`; raw default `0.27`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Controls the high frequency EQ of the tonestack.
- `Bright` (`key: Bright`, `id: 5`, `type: f`): display range `0` to `10` unitless; default

```

`0`. Raw range `0` to `1`; raw default `0`. Adds additional treble and brightness to the
tone. On the original amp, the Bright switch toggles off (0.0) and on (10.0); here you have
continuous control (0.0-10.0).
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default
`7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Preamp
block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default
`10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.

---

## Kinetic

- Model key: `HD2_AmpLine6Kinetic`
- Model ID: `711`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.2
- Based on: Line 6 Original
- Agoura model: No

### Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default
`5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the
signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default
`4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the
tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`.
Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the
tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default
`5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the
tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless;
default `1`. Raw range `0` to `1`; raw default `0.1`. Boosts upper mid and high frequencies
in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default
`4.7`. Raw range `0` to `1`; raw default `0.47`. Controls the overall level of the Amp
block.
- `Boost` (`key: Boost`, `id: 7`, `type: f`): display range `0` to `10` Off; default `0`.
Raw range `0` to `1`; raw default `0`. Adds gain and EQ modifications to simulate classic
amp mods.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`.
Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power
supply compresses or "droops" in response to striking the strings hard. Higher values
provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps;
lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: HumSwitch`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw
range `Off` to `On`; raw default `On`. Adjusts the level of power supply hum that interacts
with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum
into the audio signal. When this hum mixes with the distorted audio signal, a non-musical
distortion is created at low levels. To some players, this low-level, non-harmonic
distortion adds a bit of realism to the amp model.
- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default
`5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power

```


amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Kinetic

- Model key: `HD2\_PreamplLine6Kinetic`
- Model ID: `716`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 11.4
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.7`. Raw range `0` to `1`; raw default `0.47`. Controls the overall level of the Preamp block.
- `Boost` (`key: Boost`, `id: 7`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Adds gain and EQ modifications to simulate classic amp mods.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: HumSwitch`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Litigator

- Model key: `HD2\_AmplLine6Litigator`
- Model ID: `633`
- Type: Amp

- Category: `amp`
- Class: Guitar
- DSP usage estimate: 9.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Litigator

- Model key: `HD2\_PreamplifierLine6Litigator`

- Model ID: `634`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.3
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Mail Order Twin

- Model key: `HD2\_AmpMailOrderTwin`
- Model ID: `562`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.3
- Based on: Silvertone 1484
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`.

Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Mail Order Twin

- Model key: `HD2\_PreamplifierMailOrderTwin`
- Model ID: `563`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.3
- Based on: Silvertone 1484
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Mandarin 80

- Model key: `HD2\_AmpMandarin80`
- Model ID: `560`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.9
- Based on: Orange OR80
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.
- `FAC` (`key: FAC`, `id: 13`, `type: i`): valid values `1`, `2`, `3`, `4`, `5`, `6`; default `3`. Raw range `0` to `5`; raw default `2`. This 6-position switch selects different capacitors that change the preamp's low frequency cutoff. Higher values cut more of the bass.

Mandarin 80

- Model key: `HD2\_PreamplifierMandarin80`
- Model ID: `561`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 7.6
- Based on: Orange OR80
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the high frequency EQ of the tonestack.

- `FAC` (`key: FAC`, `id: 5`, `type: i`): valid values `1`, `2`, `3`, `4`, `5`, `6`; default `3`. Raw range `0` to `5`; raw default `2`. This 6-position switch selects different capacitors that change the preamp's low frequency cutoff. Higher values cut more of the bass.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Mandarin Rock 3

- Model key: `Agoura\_AmpMandarinRockerMk3`
- Model ID: `844`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 27.0
- Based on: Orange Rockerverb 100MKIII
- Agoura model: Yes

Parameters

- `Channel` (`key: Channel`, `id: 1`, `type: b`): valid values `Normal`, `Overdrive`; default `Overdrive`. Raw range `Off` to `On`; raw default `On`. Selects the amp channel--Normal or Overdrive.
- `Drive` (`key: Drive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `OD Master` (`key: ODMaster`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the Overdrive channel of the amplifier.
- `Attenuator` (`key: Attenuator`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Attenuates the signal between the amp's phase-inverter and power tubes
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block.

Unlike Master Volume, it has no effect on the block's tone.

- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 12`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Mandarin Rocker

- Model key: `HD2\_AmpMandarinRocker`
- Model ID: `697`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.0
- Based on: Orange Rockerverb 100 MkIII (dirty channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values

provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Mandarin Rocker

- Model key: `HD2\_PreamMandarinRocker`
- Model ID: `698`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.9
- Based on: Orange Rockerverb 100 MkIII (dirty channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps;

lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Matchstick 30

- Model key: `Agoura\_AmpMatchstick30`
- Model ID: `835`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 25.5
- Based on: Matchless DC30
- Agoura model: Yes

Parameters

- `Channel` (`key: Channel`, `id: 1`, `type: i`): valid values `Ch 1`, `Ch 2`, `Jumped`; default `Ch 1`. Raw range `0` to `2`; raw default `0`. Selects the amp channel or which input is connected. "Jumped" jumps between Channel 1 and Channel 2.
- `Ch1 Drive` (`key: Ch1Drv`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Channel 1 gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of Channel 1.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of Channel 1.
- `Ch2 Drive` (`key: Ch2Drv`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Channel 2 gain applied to the signal, which influences the level of distortion and overall tone.
- `Ch2 Tone` (`key: Ch2Tone`, `id: 6`, `type: i`): valid values `0`, `1`, `2`, `3`, `4`, `5`; default `0`. Raw range `0` to `5`; raw default `0`. Selects one of 6 settings for varying the width of the tone envelope on Channel 2. Lower values result in thinner sounds; higher values result in thicker sounds.
- `High Cut` (`key: HighCut`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Increasing the parameter attenuates high frequencies, effectively reducing the amp's brightness
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-30` to `10` dB; default `-7`. Raw range `-30` to `10`; raw default `-7`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 10`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 11`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion

to the power amp at distorted settings.

- `ZPrePost` (`key: ZPrePost`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 13`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Matchstick Ch1

- Model key: `HD2\_AmpMatchstickCh1`
- Model ID: `616`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.3
- Based on: Matchless DC30 (Channel 1)
- Agoura model: No

Parameters

- `Drive` (`key: Ch1Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Cut` (`key: Cut`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Increasing this parameter cuts high frequencies, which can be used to soften or lessen any undesirable harshness.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.8`. Raw range `0` to `1`; raw default `0.78`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default

`5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Matchstick Ch1

- Model key: `HD2\_PreamplifierMatchstickCh1`
- Model ID: `619`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 6.8
- Based on: Matchless DC30 (Channel 1)
- Agoura model: No

Parameters

- `Drive` (`key: Ch1Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the high frequency EQ of the tonestack.

- `Master` (`key: Master`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.

- `Sag` (`key: Sag`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.8`. Raw range `0` to `1`; raw default `0.78`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.

- `Hum` (`key: Hum`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Matchstick Ch2

- Model key: `HD2\_AmplifierMatchstickCh2`

- Model ID: `617`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.3
- Based on: Matchless DC30 (Channel 2)
- Agoura model: No

Parameters

- `Drive` (`key: Ch2Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Tone` (`key: Tone`, `id: 2`, `type: i`): valid values `1`, `2`, `3`, `4`, `5`, `6`; default `3`. Raw range `0` to `5`; raw default `2`. Selects one of 6 settings for varying the width of the tone envelope. Lower values result in thinner sounds; higher values result in thicker sounds.
- `Cut` (`key: Cut`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Increasing this parameter cuts high frequencies, which can be used to soften or lessen any undesirable harshness.
- `Presence` (`key: Presence`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Matchstick Ch2

- Model key: `HD2\_PreamplifierMatchstickCh2`

- Model ID: `620`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 6.6
- Based on: Matchless DC30 (Channel 2)
- Agoura model: No

Parameters

- `Drive` (`key: Ch2Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Tone` (`key: Tone`, `id: 2`, `type: i`): valid values `1`, `2`, `3`, `4`, `5`, `6`; default `3`. Raw range `0` to `5`; raw default `2`. Selects one of 6 settings for varying the width of the tone envelope. Lower values result in thinner sounds; higher values result in thicker sounds.
- `Master` (`key: Master`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.

Matchstick Jump

- Model key: `HD2\_AmpMatchstickJump`
- Model ID: `618`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.4
- Based on: Matchless DC30 (Jumped channels)
- Agoura model: No

Parameters

- `Ch1 Drive` (`key: Ch1Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the amount of Channel 1 gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.7`. Raw range `0` to `1`; raw default `0.37`. Controls the low frequency EQ of Channel 1.
- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of Channel 1.
- `Ch2 Drive` (`key: Ch2Drive`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the amount of Channel 2

gain applied to the signal, which influences the level of distortion and overall tone.

- `Tone` (`key: Tone`, `id: 5`, `type: i`): valid values `1`, `2`, `3`, `4`, `5`, `6`; default `4`. Raw range `0` to `5`; raw default `3`. Selects one of 6 settings for varying the width of the tone envelope on Channel 2. Lower values result in thinner sounds; higher values result in thicker sounds.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Cut` (`key: Cut`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `7.4`. Raw range `0` to `1`; raw default `0.74`. Increasing this parameter cuts high frequencies, which can be used to soften or lessen any undesirable harshness.
- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tubeamps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Matchstick Jump

- Model key: `HD2\_PreamplifierMatchstickJump`
- Model ID: `621`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.7
- Based on: Matchless DC30 (Jumped channels)
- Agoura model: No

Parameters

- `Ch1 Drive` (`key: Ch1Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the amount of Channel 1

gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.7`. Raw range `0` to `1`; raw default `0.37`. Controls the low frequency EQ of Channel 1.
- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of Channel 1.
- `Ch2 Drive` (`key: Ch2Drive`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the amount of Channel 2 gain applied to the signal, which influences the level of distortion and overall tone.
- `Tone` (`key: Tone`, `id: 5`, `type: i`): valid values `1`, `2`, `3`, `4`, `5`, `6`; default `4`. Raw range `0` to `5`; raw default `3`. Selects one of 6 settings for varying the width of the tone envelope on Channel 2. Lower values result in thinner sounds; higher values result in thicker sounds.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Moo)))n Brt

- Model key: `HD2\_AmpMoonBrt`
- Model ID: `703`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.0
- Based on: Sunn Model T (Bright channel)
- Agoura model: No

Parameters

- `Brt Drive` (`key: BrtDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.4`. Raw range `0` to `1`; raw default `0.24`. Controls the amount of Bright channel gain applied to the signal, which influences the level of distortion.
- `Nrm Drive` (`key: NrmDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of Normal channel bleed into the Bright channel.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Master` (`key: Master`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Moo)))n Brt

- Model key: `HD2\_PreamMoonBrt`
- Model ID: `706`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.5
- Based on: Sunn Model T (Bright channel)
- Agoura model: No

Parameters

- `Brt Drive` (`key: BrtDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.4`. Raw range `0` to `1`; raw default `0.24`. Controls the amount of Bright channel gain applied to the signal, which influences the level of distortion.
- `Nrm Drive` (`key: NrmDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of Normal channel bleed into the Bright channel.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the midrange frequency EQ of the

tonestack.

- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Master` (`key: Master`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Source file: guitar-amps-and-preamps-m-to-w.md

Guitar amps and preamps (M to W)

Upload-ready knowledge for guitar amp and preamp blocks.

Generated from the installed Helix Stadium desktop app bundle on
2026-05-07T22:33:14.224003+00:00.

Use display values for normal user-facing answers. Use model keys, IDs, and raw ranges only when the user asks for automation or low-level control details.

Model count: 70

Moo)))n Jump

- Model key: `HD2\_AmpMoonJump`
- Model ID: `702`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.3
- Based on: Sunn Model T (Jumped channels)
- Agoura model: No

Parameters

- `Brt Drive` (`key: BrtDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of Bright channel gain applied to the signal.
- `Nrm Drive` (`key: NrmDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless;

default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the amount of Normal channel gain applied to the signal.

- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Master` (`key: Master`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Moo)))n Jump

- Model key: `HD2\_PreamplifierMoonJump`
- Model ID: `705`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.8
- Based on: Sunn Model T (Jumped channels)
- Agoura model: No

Parameters

- `Brt Drive` (`key: BrtDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of Bright channel gain applied to the signal.
- `Nrm Drive` (`key: NrmDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the amount of Normal channel gain applied to the signal.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Master` (`key: Master`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Moo)))n Nrm

- Model key: `HD2\_AmpMoonNrm`
- Model ID: `701`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.0
- Based on: Sunn Model T (Normal channel)
- Agoura model: No

Parameters

- `Brt Drive` (`key: BrtDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of Bright channel gain, which can still add a bit of girth to the signal when the Normal channel is active.
- `Nrm Drive` (`key: NrmDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of Normal channel gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.5`.

Raw range `0` to `1`; raw default `0.45`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Master` (`key: Master`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Moo)))n Nrm

- Model key: `HD2\_PreamMoonNrm`
- Model ID: `704`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.6
- Based on: Sunn Model T (Normal channel)
- Agoura model: No

Parameters

- `Brt Drive` (`key: BrtDrive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of Bright channel gain, which can still add a bit of girth to the signal when the Normal channel is active.
- `Nrm Drive` (`key: NrmDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of Normal

channel gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Master` (`key: Master`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Oblivion

- Model key: `HD2\_AmpLine60blivion`
- Model ID: `714`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.8
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3.1`. Raw range `0` to `1`; raw default `0.31`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the overall level of the Amp block.
- `Boost` (`key: Boost`, `id: 7`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of Drive from the built in Distortion > Stupor OD.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: HumSwitch`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Oblivion

- Model key: `HD2\_PreamplLine60blivion`
- Model ID: `715`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 13.8
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the overall level of the Preamp block.
- `Boost` (`key: Boost`, `id: 7`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of Drive from the built in Distortion > Stupor OD.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`.

Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: HumSwitch`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

PV Panama

- Model key: `HD2\_AmpPVPanama`
- Model ID: `558`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.6
- Based on: Peavey 5150
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `1`. Raw range `0` to `1`; raw default `0.1`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `2.4`. Raw range `0` to `1`; raw default `0.24`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.
- `Resonance` (`key: Resonance`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `4.9`. Raw range `0` to `1`; raw default `0.49`. Controls the level of low frequencies in the power amp.

PV Panama

- Model key: `HD2\_PreamPVPanama`
- Model ID: `559`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.5
- Based on: Peavey 5150
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `1`. Raw range `0` to `1`; raw default `0.1`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.1`. Raw range `0` to `1`; raw default `0.81`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60

cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

PV Vitriol Clean

- Model key: `HD2\_AmpPVVitriolClean`
- Model ID: `723`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.6
- Based on: Peavey Invector (Clean channel)
- Agoura model: No

Parameters

- `Pre Gain` (`key: PreGain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal. Higher settings add a bit of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the high frequency EQ of the tonestack.
- `Post Gain` (`key: PostGain`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the Clean channel's level going into the power amp.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the entire Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power

amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.
- `Presence` (`key: Presence`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the high frequency response in the power amp.
- `Depth` (`key: Depth`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Controls the low frequency response in the power amp.

PV Vitriol Clean

- Model key: `HD2\_PreamplifierPVVitriolClean`
- Model ID: `728`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 10.6
- Based on: Peavey Invector (Clean channel)
- Agoura model: No

Parameters

- `Pre Gain` (`key: PreGain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal. Higher settings add a bit of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the high frequency EQ of the tonestack.
- `Post Gain` (`key: PostGain`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the Clean channel's level going into the power amp.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the entire Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "drips" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

PV Vitriol Crunch

- Model key: `HD2\_AmpPVVitriolCrunch`
- Model ID: `708`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 18.4
- Based on: Peavey Invector (Crunch channel)
- Agoura model: No

Parameters

- `Pre Gain` (`key: PreGain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.9`. Raw range `0` to `1`; raw default `0.59`. Controls the high frequency EQ of the tonestack.
- `Post Gain` (`key: PostGain`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.3`. Raw range `0` to `1`; raw default `0.73`. Controls the Crunch channel's level going into the power amp.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.2`. Raw range `0` to `1`; raw default `0.82`. Controls the overall level of the entire Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default

`5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

- `Presence` (`key: Presence`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `3.7`. Raw range `0` to `1`; raw default `0.37`. Controls the high frequency response in the power amp.
- `Depth` (`key: Depth`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency response in the power amp.

PV Vitriol Crunch

- Model key: `HD2\_PreamplifierPVVitriolCrunch`
- Model ID: `722`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 13.8
- Based on: Peavey Invector (Crunch channel)
- Agoura model: No

Parameters

- `Pre Gain` (`key: PreGain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.9`. Raw range `0` to `1`; raw default `0.59`. Controls the high frequency EQ of the tonestack.
- `Post Gain` (`key: PostGain`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7.3`. Raw range `0` to `1`; raw default `0.73`. Controls the Crunch channel's level going into the power amp.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.2`. Raw range `0` to `1`; raw default `0.82`. Controls the overall level of the entire Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

PV Vitriol Lead

- Model key: `HD2\_AmpPVVitriolLead`
- Model ID: `707`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 18.4
- Based on: Peavey Invector (Lead channel)
- Agoura model: No

Parameters

- `Pre Gain` (`key: PreGain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack.
- `Post Gain` (`key: PostGain`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the Lead channel's level going into the power amp.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the overall level of the entire Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression.

This parameter is highly reactive with the Drive and Master settings.

- `Presence` (`key: Presence`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `4.3`. Raw range `0` to `1`; raw default `0.43`. Controls the high frequency response in the power amp.
- `Depth` (`key: Depth`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the low frequency response in the power amp.

PV Vitriol Lead

- Model key: `HD2\_PreamPVVitriolLead`
- Model ID: `721`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 14.0
- Based on: Peavey Invector (Lead channel)
- Agoura model: No

Parameters

- `Pre Gain` (`key: PreGain`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack.
- `Post Gain` (`key: PostGain`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the Lead channel's level going into the power amp.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.7`. Raw range `0` to `1`; raw default `0.67`. Controls the overall level of the entire Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Placater Clean

- Model key: `HD2\_AmpPlacaterClean`
- Model ID: `669`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 10.5
- Based on: Friedman BE-100 (clean channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the amount of gain applied to the signal. Higher settings add a bit of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.4`. Raw range `0` to `1`; raw default `0.34`. Controls the low frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.2`. Raw range `0` to `1`; raw default `0.82`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Bright` (`key: Bright`, `id: 7`, `type: i`): valid values `Off`, `1`, `2`; default `2`. Raw range `0` to `2`; raw default `2`. Selects the amount of overall brightness of the clean channel, enhancing snap and detail.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Placater Clean

- Model key: `HD2\_PreamplacaterClean`
- Model ID: `670`
- Type: Preamp

- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 6.7
- Based on: Friedman BE-100 (clean channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the amount of gain applied to the signal. Higher settings add a bit of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.4`. Raw range `0` to `1`; raw default `0.34`. Controls the low frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the high frequency EQ of the tonestack.
- `Bright` (`key: Bright`, `id: 4`, `type: i`): valid values `Off`, `1`, `2`; default `2`. Raw range `0` to `2`; raw default `2`. Selects the amount of overall brightness of the clean channel, enhancing snap and detail.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.2`. Raw range `0` to `1`; raw default `0.82`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

Placater Dirty

- Model key: `HD2\_AmpPlacaterDirty`
- Model ID: `665`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.6
- Based on: Friedman BE-100 (BE/HBE channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the high frequency EQ of the tonestack.

- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `HBE` (`key: HBE`, `id: 9`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When off, the amp operates in BE mode, which provides more of a British-style gain. When on, the amp operates in HBE mode, which provides higher gain and heavier distortion.
- `Fat` (`key: Fat`, `id: 10`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, thickens up your tone. Especially helpful for guitars with single coil pickups.
- `C45` (`key: C45`, `id: 11`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, revoices the amp for more of a scooped sound.
- `Saturation` (`key: Saturation`, `id: 12`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, adds saturation and a bit of compression to your tone.
- `Ripple` (`key: Ripple`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 15`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Placater Dirty

- Model key: `HD2\_PreamplacaterDirty`
- Model ID: `666`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 10.7
- Based on: Friedman BE-100 (BE/HBE channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `HBE` (`key: HBE`, `id: 8`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When off, the amp operates in BE mode, which provides more of a British-style gain. When on, the amp operates in HBE mode, which provides higher gain and heavier distortion.
- `Fat` (`key: Fat`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, thickens up your tone. Especially helpful for guitars with single coil pickups.
- `C45` (`key: C45`, `id: 10`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. When on, revoices the amp for more of a scooped sound.
- `Saturation` (`key: Saturation`, `id: 11`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, adds saturation and a bit of compression to your tone.

Revv 120 Purple

- Model key: `Agoura\_AmpRevvCh3Purple`
- Model ID: `817`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 25.0
- Based on: Revv Generator 120 (Purple/Gain Channel 3)
- Agoura model: Yes

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.1`. Raw range `0` to `1`; raw default `0.71`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default

`7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the high frequency EQ of the tonestack.

- `Contour` (`key: Contour`, `id: 5`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, applies a midrange frequency boost.
- `Bright` (`key: Bright`, `id: 6`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, applies a high frequency boost.
- `Ch Level` (`key: Ch Level`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the output level of the Purple channel into the power amp.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the entire Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the Master Volume of the amplifier.
- `Aggression` (`key: Aggression`, `id: 10`, `type: i`): display range `0` to `2` unitless; default `1`. Raw range `0` to `2`; raw default `1`. Selects one of three levels of saturation--Low (0), Mid/Tight (1), and High/Fat (2).
- `Fat` (`key: Fat`, `id: 11`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, applies a low frequency boost.
- `Depth` (`key: Depth`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the low frequency response in the power amp. Be careful here, as higher settings can cause the low end to feel a bit loose.
- `Presence` (`key: Presence`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Sag` (`key: Sag`, `id: 14`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 15`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 16`, `type: f`): display range `0` to `10` unitless; default `3.1`. Raw range `0` to `1`; raw default `0.31`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 17`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Revv 120 Red

- Model key: `Agoura\_AmpRevvCh4Red`
- Model ID: `806`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 27.0
- Based on: Revv Generator 120 (Red/High Gain Channel 4)

- Agoura model: Yes

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7.1`. Raw range `0` to `1`; raw default `0.71`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.2`. Raw range `0` to `1`; raw default `0.72`. Controls the high frequency EQ of the tonestack.
- `Contour` (`key: Contour`, `id: 5`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, applies a midrange frequency boost.
- `Bright` (`key: Bright`, `id: 6`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, applies a high frequency boost.
- `Ch Level` (`key: Ch Level`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the output level of the Red channel into the power amp.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the entire Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the Master Volume of the amplifier.
- `Aggression` (`key: Aggression`, `id: 10`, `type: i`): display range `0` to `2` unitless; default `1`. Raw range `0` to `2`; raw default `1`. Selects one of three levels of saturation--Low (0), Mid/Tight (1), and High/Fat (2).
- `Fat` (`key: Fat`, `id: 11`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, applies a low frequency boost.
- `Depth` (`key: Depth`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the low frequency response in the power amp. Be careful here, as higher settings can cause the low end to feel a bit loose.
- `Presence` (`key: Presence`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Sag` (`key: Sag`, `id: 14`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 15`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: XPrePost`, `id: 16`, `type: f`): display range `0` to `10` unitless; default `3.1`. Raw range `0` to `1`; raw default `0.31`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 17`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp

sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Revv Gen Purple

- Model key: `HD2\_AmpRevvGenPurple`
- Model ID: `689`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.0
- Based on: Revv Generator 120 (Purple/Gain Ch. 3)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.2`. Raw range `0` to `1`; raw default `0.32`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.6`. Raw range `0` to `1`; raw default `0.86`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Resonance` (`key: Resonance`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the low frequency response in the power amp. Be careful here, as higher settings can cause the low end to feel a bit loose.
- `Aggression` (`key: Aggression`, `id: 9`, `type: i`): display range `0` to `2` unitless; default `1`. Raw range `0` to `2`; raw default `1`. Selects one of three levels of saturation--Low (0), Mid/Tight (1), and High/Fat (2).
- `Sag` (`key: Sag`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with

your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Revv Gen Purple

- Model key: `HD2\_PreampRevvGenPurple`
- Model ID: `690`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 10.2
- Based on: Revv Generator 120 (Purple/Gain Ch. 3)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.2`. Raw range `0` to `1`; raw default `0.32`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.6`. Raw range `0` to `1`; raw default `0.86`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Aggression` (`key: Aggression`, `id: 7`, `type: i`): display range `0` to `2` unitless; default `1`. Raw range `0` to `2`; raw default `1`. Selects one of three levels of saturation--Low (0), Mid/Tight (1), and High/Fat (2).
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "drips" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Revv Gen Red

- Model key: `HD2\_AmpRevvGenRed`
- Model ID: `675`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.0
- Based on: Revv Generator 120 (Red/High Gain Ch. 4)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.1`. Raw range `0` to `1`; raw default `0.41`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.4`. Raw range `0` to `1`; raw default `0.84`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Resonance` (`key: Resonance`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the low frequency response in the power amp. Be careful here, as higher settings can cause the low end to feel a bit loose.
- `Aggression` (`key: Aggression`, `id: 9`, `type: i`): display range `0` to `2` unitless; default `2`. Raw range `0` to `2`; raw default `2`. Selects one of three levels of saturation--Low (0), Mid/Tight (1), and High/Fat (2).
- `Sag` (`key: Sag`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power

supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 14`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Revv Gen Red

- Model key: `HD2\_PreampRevvGenRed`
- Model ID: `688`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 10.4
- Based on: Revv Generator 120 (Red/High Gain Ch. 4)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.1`. Raw range `0` to `1`; raw default `0.41`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.4`. Raw range `0` to `1`; raw default `0.84`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Aggression` (`key: Aggression`, `id: 7`, `type: i`): display range `0` to `2` unitless; default `2`. Raw range `0` to `2`; raw default `2`. Selects one of three levels of saturation--Low (0), Mid/Tight (1), and High/Fat (2).
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Solid 100

- Model key: `Agoura\_AmpSolid100`
- Model ID: `753`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 22.5
- Based on: Soldano SLO-100 (Normal & Overdrive channels)
- Agoura model: Yes

Parameters

- `Channel` (`key: Channel`, `id: 1`, `type: b`): valid values `Normal`, `Overdrive`; default `Overdrive`. Raw range `Off` to `On`; raw default `On`. Selects the amp channel--Normal or Overdrive.
- `Normal Mode` (`key: NrmMode`, `id: 2`, `type: b`): valid values `Clean`, `Crunch`; default `Crunch`. Raw range `Off` to `On`; raw default `On`. Selects the mode of the Normal channel--Clean or Crunch. Has no effect when Channel is set to "Overdrive."
- `Drive` (`key: Drive`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Controls the Master Volume of the amplifier.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Presence` (`key: Presence`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Normal Bright` (`key: NrmBright`, `id: 10`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, applies a high frequency boost to the Normal channel. Has no affect when Channel is set to "Overdrive."
- `Sag` (`key: Sag`, `id: 11`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 12`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 13`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and

lower values mean more of the effect is fed back to the input of the power amp (Pre).

- `Hype` (`key: Hype`, `id: 14`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Solo Lead Clean

- Model key: `HD2\_AmpSoloLeadClean`
- Model ID: `550`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.1
- Based on: Soldano SLO-100 (Clean channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the amount of gain applied to the signal. At high settings, a bit of saturation can be heard.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the high frequency EQ of the tonestack.

- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the Master Volume of the amplifier.

- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion

to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Solo Lead Clean

- Model key: `HD2\_PreamSoloLeadClean`
- Model ID: `552`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.9
- Based on: Soldano SLO-100 (Clean channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the amount of gain applied to the signal. At high settings, a bit of saturation can be heard.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.8`. Raw range `0` to `1`; raw default `0.48`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Solo Lead Crunch

- Model key: `HD2\_AmpSoloLeadCrunch`

- Model ID: `551`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.2
- Based on: Soldano SLO-100 (Crunch channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.3`. Raw range `0` to `1`; raw default `0.43`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Solo Lead Crunch

- Model key: `HD2\_PreamplifierSoloLeadCrunch`
- Model ID: `553`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.6
- Based on: Soldano SL0-100 (Crunch channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4.3`. Raw range `0` to `1`; raw default `0.43`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Level` (`key: Ch Vol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Solo Lead OD

- Model key: `HD2\_AmpSoloLeadOD`
- Model ID: `548`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 14.8
- Based on: Soldano SL0-100 (Overdrive channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the amount of gain applied to the

signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.1`. Raw range `0` to `1`; raw default `0.41`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `2.6`. Raw range `0` to `1`; raw default `0.26`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Solo Lead OD

- Model key: `HD2\_PreamSoloLeadOD`
- Model ID: `549`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 10.5
- Based on: Soldano SLO-100 (Overdrive channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.6`. Raw range `0` to `1`; raw default `0.56`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `4.1`. Raw range `0` to `1`; raw default `0.41`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.3`. Raw range `0` to `1`; raw default `0.63`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Soup Pro

- Model key: `HD2\_AmpSoupPro`
- Model ID: `546`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 8.0
- Based on: Supro S6616
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack. The original amp didn't have a Bass knob; set to 5.0 for accurate response.
- `Tone` (`key: Tone`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `9.2`. Raw range `0` to `1`; raw default `0.92`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack. The original amp didn't have a Treble knob; set to 5.0 for accurate response.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Boosts upper mid and high frequencies

in the power amp, resulting in additional punch and bite.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Soup Pro

- Model key: `HD2\_PreamplifierSoupPro`
- Model ID: `547`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 7.7
- Based on: Supro S6616
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack. The original amp didn't have a Bass knob; set to 5.0 for accurate response.
- `Tone` (`key: Tone`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `9.2`. Raw range `0` to `1`; raw default `0.92`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack. The original amp didn't have a Treble knob; set to 5.0 for accurate response.

- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Stone Age 185

- Model key: `HD2\_AmpStoneAge185`
- Model ID: `544`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.2
- Based on: Gibson EH-185
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion. At higher settings, things get gnarly.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the midrange frequency EQ of the tonestack. The original amp didn't have a Mid knob; set to 5.0 for accurate response.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that

interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Stone Age 185

- Model key: `HD2\_PreampStoneAge185`
- Model ID: `545`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.1
- Based on: Gibson EH-185
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion. At higher settings, things get gnarly.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the midrange frequency EQ of the tonestack. The original amp didn't have a Mid knob; set to 5.0 for accurate response.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a

non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Tweed Blues Brt

- Model key: `HD2\_AmpTweedBluesBrt`
- Model ID: `538`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.1
- Based on: Fender Bassman (Bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.9`. Raw range `0` to `1`; raw default `0.59`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3.4`. Raw range `0` to `1`; raw default `0.34`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `7.3`. Raw range `0` to `1`; raw default `0.73`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Tweed Blues Brt

- Model key: `HD2\_PreampTweedBluesBrt`
- Model ID: `540`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 6.7
- Based on: Fender Bassman (Bright channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.9`. Raw range `0` to `1`; raw default `0.59`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.1`. Raw range `0` to `1`; raw default `0.51`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.6`. Raw range `0` to `1`; raw default `0.66`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Tweed Blues Nrm

- Model key: `HD2\_AmpTweedBluesNrm`
- Model ID: `539`
- Type: Amp
- Category: `amp`
- Class: Guitar

- DSP usage estimate: 12.1
- Based on: Fender Bassman (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `2.7`. Raw range `0` to `1`; raw default `0.27`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Tweed Blues Nrm

- Model key: `HD2\_PreamptweedBluesNrm`
- Model ID: `541`
- Type: Preamp

- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 6.7
- Based on: Fender Bassman (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.2`. Raw range `0` to `1`; raw default `0.42`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

US 5W Tweed

- Model key: `Agoura\_AmpUS5WTweed`
- Model ID: `752`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 20.5
- Based on: Fender Champ 5F1 (Low & High inputs)
- Agoura model: Yes

Parameters

- `Jack` (`key: Jack`, `id: 1`, `type: i`): valid values `Low`, `High`; default `High`. Raw range `0` to `1`; raw default `1`. Selects the input jack on the amp--Low or High.
- `Drive` (`key: Drive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5.82`. Raw range `0` to `1`; raw default `0.582`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Master` (`key: Master`, `id: 3`, `type: f`): display range `0` to `10` unitless; default

`10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.

- `Sag` (`key: Sag`, `id: 4`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 5`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Boost` (`key: Boost`, `id: 6`, `type: i`): valid values `Off`, `On`; default `Off`. Raw range `0` to `1`; raw default `0`. When on, applies a boost to the signal.
- `Z PrePost` (`key: ZPrePost`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-30` to `10` dB; default `-10`. Raw range `-30` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Hype` (`key: Hype`, `id: 9`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

US Deluxe Nrm

- Model key: `HD2\_AmpUSDeluxeNrm`
- Model ID: `536`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 11.7
- Based on: Fender Deluxe Reverb (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default

`9`. Raw range `0` to `1`; raw default `0.9`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

US Deluxe Nrm

- Model key: `HD2\_PreamplifierUSDeluxeNrm`
- Model ID: `537`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 6.6
- Based on: Fender Deluxe Reverb (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default

`8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.

- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

US Deluxe Vib

- Model key: `HD2\_AmpUSDeluxeVib`
- Model ID: `534`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.0
- Based on: Fender Deluxe Reverb (Vibrato channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level,

non-harmonic distortion adds a bit of realism to the amp model.

- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5.3`. Raw range `0` to `1`; raw default `0.53`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

US Deluxe Vib

- Model key: `HD2\_PreamplifierUSDeluxeVib`
- Model ID: `535`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.1
- Based on: Fender Deluxe Reverb (Vibrato channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.9`. Raw range `0` to `1`; raw default `0.39`. Controls the high frequency EQ of the tonestack.

- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.

- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

US Double Black

- Model key: `Agoura\_AmpUSDoubleBlack`
- Model ID: `807`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 19.5
- Based on: Fender Twin Reverb AB763 (Normal & Vibrato channels)
- Agoura model: Yes

Parameters

- `Channel` (`key: Channel`, `id: 1`, `type: i`): valid values `Normal`, `Vibrato`; default `Vibrato`. Raw range `0` to `1`; raw default `1`. Selects the amp channel or which input is connected.
- `Drive` (`key: Drive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.7`. Raw range `0` to `1`; raw default `0.37`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bright` (`key: Bright`, `id: 3`, `type: i`): valid values `Off`, `On`; default `Off`. Raw range `0` to `1`; raw default `0`. When on, applies a high frequency boost.
- `Bass` (`key: Bass`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the low frequency EQ of the tonestack.
- `Middle` (`key: Mid`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.5`. Raw range `0` to `1`; raw default `0.45`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: MasterVol`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 12`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the

expense of accuracy.

US Double Nrm

- Model key: `HD2\_AmpUSDoubleNrm`
- Model ID: `532`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.1
- Based on: Fender Twin Reverb (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `1`. Raw range `0` to `1`; raw default `0.1`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default

`5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

US Double Nrm

- Model key: `HD2\_PreamplifierUSDoubleNrm`
- Model ID: `533`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 6.7
- Based on: Fender Twin Reverb (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.4`. Raw range `0` to `1`; raw default `0.44`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.7`. Raw range `0` to `1`; raw default `0.57`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

US Double Vib

- Model key: `HD2\_AmplifierUSDoubleVib`
- Model ID: `530`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.0

- Based on: Fender Twin Reverb (Vibrato channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

US Double Vib

- Model key: `HD2\_PreamplifierUSDoubleVib`
- Model ID: `531`
- Type: Preamp
- Category: `preamp`

- Class: Guitar
- DSP usage estimate: 7.9
- Based on: Fender Twin Reverb (Vibrato channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.6`. Raw range `0` to `1`; raw default `0.76`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

US Luxe Black

- Model key: `Agoura\_AmpUSLuxeBlack`
- Model ID: `751`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 21.0
- Based on: Fender Deluxe Reverb AB763 (Normal & Vibrato channels)
- Agoura model: Yes

Parameters

- `Channel` (`key: Channel`, `id: 1`, `type: i`): valid values `Normal`, `Vibrato`; default `Vibrato`. Raw range `0` to `1`; raw default `1`. Selects the amp channel or which input is connected.
- `Drive` (`key: Drive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 3`, `type: f`): display range `0` to `10` unitless; default

`7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the low frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 6`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 7`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Z PrePost` (`key: ZPrePost`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 10`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

US Princess

- Model key: `HD2\_AmpUSPrincess`
- Model ID: `691`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.7
- Based on: Fender Princeton Reverb
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the high frequency EQ of the

tonestack.

- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5.2`. Raw range `0` to `1`; raw default `0.52`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

US Princess

- Model key: `HD2\_PreamplifierUSPrincess`
- Model ID: `692`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.3
- Based on: Fender Princeton Reverb
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

US Princess 76

- Model key: `Agoura\_AmpUSPrincess76`
- Model ID: `750`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 15.5
- Based on: Fender Princeton Reverb AA1164
- Agoura model: Yes

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `3.8`. Raw range `0` to `1`; raw default `0.38`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the low frequency EQ of the tonestack.
- `Treble` (`key: Treb`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 5`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 6`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Determines the location of speaker

impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).

- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Hype` (`key: Hype`, `id: 9`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

US Small Tweed

- Model key: `HD2\_AmpUSSmallTweed`
- Model ID: `528`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 6.6
- Based on: Fender Champ
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

US Small Tweed

- Model key: `HD2\_PreamplifierUSSmallTweed`
- Model ID: `529`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 7.1
- Based on: Fender Champ
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8`. Raw range `0` to `1`; raw default `0.8`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "drips" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

US Super Black

- Model key: `Agoura\_AmpUSSuperBlack`
- Model ID: `833`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 20.4
- Based on: Fender Super Reverb (Normal & Vibrato channels)
- Agoura model: Yes

Parameters

- `Channel` (`key: Channel`, `id: 1`, `type: i`): valid values `Normal`, `Vibrato`; default `Vibrato`. Raw range `0` to `1`; raw default `1`. Selects the amp channel or which input is connected.
- `Drive` (`key: Drive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.5`. Raw range `0` to `1`; raw default `0.35`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bright` (`key: Bright`, `id: 3`, `type: i`): valid values `Off`, `On`; default `Off`. Raw range `0` to `1`; raw default `0`. When on, applies a high frequency boost.
- `Bass` (`key: Bass`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the low frequency EQ of the tonestack.
- `Middle` (`key: Mid`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.8`. Raw range `0` to `1`; raw default `0.68`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `6.1`. Raw range `0` to `1`; raw default `0.61`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: MasterVol`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 9`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `3.3`. Raw range `0` to `1`; raw default `0.33`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 12`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the

expense of accuracy.

US Super Norm

- Model key: `HD2\_AmpUSSuperNorm`
- Model ID: `737`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 10.8
- Based on: Fender Super Reverb (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `0`. Raw range `0` to `1`; raw default `0`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.7`. Raw range `0` to `1`; raw default `0.77`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default

`5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.
- `Bright` (`key: Bright`, `id: 13`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts high frequencies. Is more obvious when Drive is set low.

US Super Norm

- Model key: `HD2\_PreampUSSuperNorm`
- Model ID: `738`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 6.8
- Based on: Fender Super Reverb (Normal channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5.8`. Raw range `0` to `1`; raw default `0.58`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5.4`. Raw range `0` to `1`; raw default `0.54`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7.7`. Raw range `0` to `1`; raw default `0.77`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Bright` (`key: Bright`, `id: 9`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts high frequencies. Is more obvious when Drive is set low.

US Super Vib

- Model key: `HD2\_AmpUSSuperVib`
- Model ID: `739`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.5
- Based on: Fender Super Reverb (Vibrato channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `1`. Raw range `0` to `1`; raw default `0.1`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.
- `Bright` (`key: Bright`, `id: 13`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts high frequencies. Is more obvious when Drive is set low.

US Super Vib

- Model key: `HD2\_PreampUSSuperVib`
- Model ID: `740`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.1
- Based on: Fender Super Reverb (Vibrato channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `3.6`. Raw range `0` to `1`; raw default `0.36`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the high frequency EQ of the tonestack.
- `Master` (`key: Master`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Sag` (`key: Sag`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Bright` (`key: Bright`, `id: 9`, `type: b`): valid values `Off`, `On`; default `Off`. Raw range `Off` to `On`; raw default `Off`. When on, boosts high frequencies. Is more obvious when Drive is set low.

US Tweedman

- Model key: `Agoura\_AmpUSTweedman`
- Model ID: `749`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 23.5

- Based on: Fender Bassman 5F6A (Normal, Bright, & Jumped channels)
- Agoura model: Yes

Parameters

- `Channel` (`key: Channel`, `id: 1`, `type: i`): valid values `Normal`, `Bright`, `Jumped`; default `Jumped`. Raw range `0` to `2`; raw default `2`. Selects the amp channel or which input is connected. "Jumped" jumps between the Normal and Bright channels.
- `Normal Drive` (`key: NormalDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of Normal channel gain applied to the signal. The inactive channel can sometimes "bleed into" the active channel, resulting in interesting interactions.
- `Bright Drive` (`key: BrightDrive`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the amount of Bright channel gain applied to the signal. The inactive channel can sometimes "bleed into" the active channel, resulting in interesting interactions.
- `Bass` (`key: Bass`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `6.4`. Raw range `0` to `1`; raw default `0.64`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `2.7`. Raw range `0` to `1`; raw default `0.27`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: Level`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `10`. Raw range `0` to `1`; raw default `1`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 10`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Ripple` (`key: Ripple`, `id: 11`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Z PrePost` (`key: ZPrePost`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).
- `Hype` (`key: Hype`, `id: 13`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.

Ventoux

- Model key: `HD2\_AmpLine6Ventoux`
- Model ID: `700`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 8.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `HP Filter` (`key: HPF`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Higher values result in tighter distortions and thinner cleans; lower values result in looser distortions and warmer cleans.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the level of high frequencies in the power amp. These actually occur in the circuit just before phase inverter, but they really need the whole power amp to function. They also affect the character of the power amp distortion.
- `Depth` (`key: Depth`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the level of low frequencies in the power amp. These actually occur in the circuit just before phase inverter, but they really need the whole power amp to function. They also affect the character of the power amp distortion.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Ventoux's Master volume exists in an "impossible" place for a physical amp. Generally, you'll want to leave this at 10.0, like a vintage amp with no master volume. However, a variety of textures can be had by reducing the level.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power

amp, causing a change in tonality and the distortion characteristic.

- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Ventoux

- Model key: `HD2\_Preampline6Ventoux`
- Model ID: `699`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.0
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the amount of gain applied to the signal, which influences the level of distortion.

- `HP Filter` (`key: HPF`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Higher values result in tighter distortions and thinner cleans; lower values result in looser distortions and warmer cleans.

- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.

- `Presence` (`key: Presence`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the level of high frequencies in the power amp. These actually occur in the circuit just before phase inverter, but they really need the whole power amp to function. They also affect the character of the power amp distortion.

- `Depth` (`key: Depth`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Controls the level of low frequencies in the power amp. These actually occur in the circuit just before phase inverter, but they really need the whole power amp to function. They also affect the character of the power amp distortion.

- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.

- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Ventoux's Master volume exists in an "impossible" place for a physical amp. Generally, you'll want to leave this at 10.0, like a vintage amp with no master volume. However, a variety of textures can be had by reducing the level.

- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level,

non-harmonic distortion adds a bit of realism to the amp model.

Voltage

- Model key: `HD2\_AmpLine6Voltage`
- Model ID: `709`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 12.5
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Boosts upper mid and high frequencies in the power amp, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Amp block.
- `Boost` (`key: Boost`, `id: 7`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of gain in the extra preamp tube gain stage.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: HumSwitch`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Bias` (`key: Bias`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Voltage

- Model key: `HD2\_PreamplLine6Voltage`
- Model ID: `720`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 12.9
- Based on: Line 6 Original
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `6.5`. Raw range `0` to `1`; raw default `0.65`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the overall level of the Preamp block.
- `Boost` (`key: Boost`, `id: 7`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Controls the amount of gain in the extra preamp tube gain stage.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: HumSwitch`, `id: 9`, `type: b`): valid values `Off`, `On`; default `On`. Raw range `Off` to `On`; raw default `On`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

Voltage Queen

- Model key: `HD2\_AmpVoltageQueen`
- Model ID: `653`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.2
- Based on: Victoria Electro King
- Agoura model: No

Parameters

- `Drive 1` (`key: Drive 1`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Controls the amount of Normal

channel gain applied to the signal, which influences the level of distortion.

- `Drive 2` (`key: Drive Trem`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the amount of Tremolo channel gain applied to the signal, which influences the level of distortion.
- `Tone` (`key: Tone`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies. Turning the control clockwise boosts the treble for a brighter sound, while turning it counterclockwise boosts the bass for a warmer tone.
- `Bass` (`key: Bass`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.2`. Raw range `0` to `1`; raw default `0.82`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

Voltage Queen

- Model key: `HD2\_PreamplifierVoltageQueen`
- Model ID: `654`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 9.2
- Based on: Victoria Electro King
- Agoura model: No

Parameters

- `Drive 1` (`key: Drive 1`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `2.8`. Raw range `0` to `1`; raw default `0.28`. Controls the amount of Normal channel gain applied to the signal, which influences the level of distortion.
- `Drive 2` (`key: Drive 2`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the amount of Tremolo channel gain applied to the signal, which influences the level of distortion.
- `Tone` (`key: Tone`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `6.2`. Raw range `0` to `1`; raw default `0.62`. Adjusts the overall tonal character of the amplifier, allowing you to emphasize either the bass or treble frequencies. Turning the control clockwise boosts the treble for a brighter sound, while turning it counterclockwise boosts the bass for a warmer tone.
- `Bass` (`key: Bass`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the low frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `5.5`. Raw range `0` to `1`; raw default `0.55`. Controls the high frequency EQ of the tonestack.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `8.2`. Raw range `0` to `1`; raw default `0.82`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `8.5`. Raw range `0` to `1`; raw default `0.85`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

WhoWatt 100

- Model key: `HD2\_AmpWhoWatt100`
- Model ID: `526`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 13.5
- Based on: Hiwatt DR-103 (Brilliant channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the

tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.7`. Raw range `0` to `1`; raw default `0.37`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `2.7`. Raw range `0` to `1`; raw default `0.27`. Boosts upper mid and high frequencies, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.
- `Ripple` (`key: Ripple`, `id: 10`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.
- `Bias` (`key: Bias`, `id: 11`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Adjusts the bias of the tubes in the power amp, causing a change in tonality and the distortion characteristic.
- `Bias X` (`key: BiasX`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Determines how the power amp tubes' voicing reacts when pushed hard. Set low for a tighter feel. Set high for more tube compression. This parameter is highly reactive with the Drive and Master settings.

WhoWatt 100

- Model key: `HD2\_PreamplifierWhoWatt100`
- Model ID: `527`
- Type: Preamp
- Category: `preamp`
- Class: Guitar
- DSP usage estimate: 8.5
- Based on: Hiwatt DR-103 (Brilliant channel)
- Agoura model: No

Parameters

- `Drive` (`key: Drive`, `id: 1`, `type: f`): display range `0` to `10` unitless; default `4`. Raw range `0` to `1`; raw default `0.4`. Controls the amount of gain applied to the signal, which influences the level of distortion.
- `Bass` (`key: Bass`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `9`. Raw range `0` to `1`; raw default `0.9`. Controls the low frequency EQ of the tonestack.
- `Mid` (`key: Mid`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `5`.

Raw range `0` to `1`; raw default `0.5`. Controls the midrange frequency EQ of the tonestack.

- `Treble` (`key: Treble`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `3.7`. Raw range `0` to `1`; raw default `0.37`. Controls the high frequency EQ of the tonestack.
- `Presence` (`key: Presence`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `2.7`. Raw range `0` to `1`; raw default `0.27`. Boosts upper mid and high frequencies, resulting in additional punch and bite.
- `Level` (`key: ChVol`, `id: 6`, `type: f`): display range `0` to `10` unitless; default `7.5`. Raw range `0` to `1`; raw default `0.75`. Controls the overall level of the Preamp block. Unlike Master Volume, it has no effect on the block's tone.
- `Master` (`key: Master`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the Master Volume of the amplifier.
- `Sag` (`key: Sag`, `id: 8`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.
- `Hum` (`key: Hum`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Adjusts the level of power supply hum that interacts with the signal. Preamp tube heaters in tube amps will leak a little bit of 60 cycle hum into the audio signal. When this hum mixes with the distorted audio signal, a non-musical distortion is created at low levels. To some players, this low-level, non-harmonic distortion adds a bit of realism to the amp model.

WhoWatt 103

- Model key: `Agoura\_AmpWhoWatt103`
- Model ID: `808`
- Type: Amp
- Category: `amp`
- Class: Guitar
- DSP usage estimate: 26.5
- Based on: Hiwatt DR-103 (Normal, Bright, & Jumped channels)
- Agoura model: Yes

Parameters

- `Channel` (`key: Channel`, `id: 1`, `type: i`): valid values `Normal`, `Bright`, `Jumped`; default `Jumped`. Raw range `0` to `2`; raw default `2`. Selects the amp channel or which input is connected. "Jumped" jumps between the Normal and Bright channels.
- `Normal Drive` (`key: NormDrive`, `id: 2`, `type: f`): display range `0` to `10` unitless; default `5`. Raw range `0` to `1`; raw default `0.5`. Controls the amount of Normal channel gain applied to the signal. The inactive channel can sometimes "bleed into" the active channel, resulting in interesting interactions.
- `Bright Drive` (`key: BrtDrive`, `id: 3`, `type: f`): display range `0` to `10` unitless; default `2.5`. Raw range `0` to `1`; raw default `0.25`. Controls the amount of Bright channel gain applied to the signal. The inactive channel can sometimes "bleed into" the active channel, resulting in interesting interactions.
- `Bass` (`key: Bass`, `id: 4`, `type: f`): display range `0` to `10` unitless; default `7`. Raw range `0` to `1`; raw default `0.7`. Controls the low frequency EQ of the preamp's tonestack.
- `Mid` (`key: Mid`, `id: 5`, `type: f`): display range `0` to `10` unitless; default `4.6`. Raw range `0` to `1`; raw default `0.46`. Controls the midrange frequency EQ of the tonestack.
- `Treble` (`key: Treble`, `id: 6`, `type: f`): display range `0` to `10` unitless; default

`6.2`. Raw range `0` to `1`; raw default `0.62`. Controls the high frequency EQ of the tonestack.

- `Presence` (`key: Presence`, `id: 7`, `type: f`): display range `0` to `10` unitless; default `4.22`. Raw range `0` to `1`; raw default `0.422`. Boosts upper mids and treble frequencies in the power amp, resulting in additional punch and bite.

- `Level` (`key: Output Volume`, `id: 8`, `type: f`): display range `-40` to `10` dB; default `-10`. Raw range `-40` to `10`; raw default `-10`. Controls the overall level of the Amp block. Unlike Master Volume, it has no effect on the block's tone.

- `Master` (`key: Master`, `id: 9`, `type: f`): display range `0` to `10` unitless; default `6`. Raw range `0` to `1`; raw default `0.6`. Controls the Master Volume of the amplifier.

- `Sag` (`key: Sag`, `id: 10`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls the amount of sag, or how much the power supply compresses or "droops" in response to striking the strings hard. Higher values provide more touch dynamics, sustain, and organic feel that's inherent in vintage tube amps; lower values offer a "tighter" responsiveness for a more modern feel.

- `Ripple` (`key: Ripple`, `id: 11`, `type: f`): display range `-10` to `10` Stock; default `0`. Raw range `-1` to `1`; raw default `0`. Controls how much AC ripple interacts with your tone. Power amp circuits will sometimes let a little bit of rectified 120Hz hum (that the power supply filter caps can't quite fully remove) into the audio signal when the power supply is being pushed hard. Much like Hum, Ripple provides a bit of non-musical distortion to the power amp at distorted settings.

- `Z PrePost` (`key: ZPrePost`, `id: 12`, `type: f`): display range `0` to `10` unitless; default `3`. Raw range `0` to `1`; raw default `0.3`. Determines the location of speaker impedance characteristics in the power amp, primarily due to negative feedback. Higher values mean the effects of the interaction appear at the output of the power amp (Post) and lower values mean more of the effect is fed back to the input of the power amp (Pre).

- `Hype` (`key: Hype`, `id: 13`, `type: f`): display range `0` to `10` Off; default `0`. Raw range `0` to `1`; raw default `0`. Depending on the amp and/or amp settings, increasing Hype may subtly or dramatically adjust various behind-the-scenes parameters to make the amp sound and feel smoother, fuller, punchier, tighter, and/or more forgiving, but at the expense of accuracy.