

TECHNICAL SPECIFICATIONS

SECTION 01 — VEHICLE DIMENSIONS & PERFORMANCE

Page 1

Vehicle Dimensions & Weights

OVERALL LENGTH

4,751 mm

OVERALL WIDTH (WITH MIRRORS)

2,129 mm

OVERALL HEIGHT

1,624 mm

WHEELBASE

2,890 mm

Total Gross Mass (TPMLM): Weight ratings depend on specific vehicle variant. Do not exceed maximum loaded capacity noted on the vehicle door pillar label.

Maximum Luggage Load Capacity

FRONT TRUNK (FRUNK)

50 kg

Maximum capacity

REAR SUB-BIN

40 kg

Lower compartment

REAR UPPER FLOOR

90 kg

Main cargo deck

Performance, Speed & Drive Modes

- **Drive Configurations:** Available in Rear-Wheel Drive (RWD) or Dual-Motor All-Wheel Drive (AWD).
- **Drive Away Locking:** All vehicle doors automatically lock once speed exceeds 8 km/h.
- **Speed Assist & Alerts:** Visual speed limit indicators display on the touchscreen; a blue outline indicates speed exceeds the local posted limit.
- **Traction & Stability:** Equipped with integrated Electronic Stability Control, Traction Control, and Slip Start (AWD models) for enhanced traction in low-grip conditions such as snow, mud, or ice.

HIGH VOLTAGE BATTERY & RANGE

Battery System Overview

HIGH VOLTAGE BATTERY

Advanced Lithium-ion High Voltage Battery System delivering main propulsion and high-power thermal systems.

LOW VOLTAGE SYSTEM

Powered by a separate low-voltage battery dedicated to onboard electronics, exterior lighting, audio, and touchscreen operation.

Displaying Range & Energy

Energy settings can be customized via **Controls > Display > Energy Display**:

DISPLAY MODE	DESCRIPTION	UNITS AVAILABLE
Percentage (%)	Displays the remaining High Voltage battery capacity state.	% State of Charge
Estimated Distance	Displays remaining estimated range based on EPA/WLTP standard consumption models.	Kilometers (km) / Miles (mi)

Factors Affecting Mileage & Range

High speeds, cold ambient temperatures, steep uphill driving, heavy towing, and frequent short trips with aggressive acceleration/braking significantly lower operational efficiency.

Cold Weather Range Impact: When ambient temperatures are low, a blue snowflake icon appears on the touchscreen status bar. This indicates that a portion of the stored battery energy is temporarily unavailable until the battery warms up.

Maximizing Driving Range

- **Regenerative Braking:** Maximize usage of regenerative braking to harvest kinetic energy during deceleration and feed power back into the High Voltage battery.
- **Preconditioning:** Precondition the vehicle cabin and battery thermal management system using the mobile app prior to departure while plugged into grid power.

CHARGING & HIGH VOLTAGE OPERATIONS

SECTION 03 – CHARGING PROCEDURES & BATTERY HEALTH

Charging Methods & Port Access

CHARGE PORT LOCATION

Integrated seamlessly behind the driver-side rear tail light assembly module.

Methods to Unlock Charge Port:

- Via the main controls on the center touchscreen interface.
- Using the official mobile application.
- Double-clicking the rear trunk button on the key fob (or holding for 1–2 seconds).
- Pressing the button located on the charge cable handle when the vehicle is unlocked.

Charging Status & Notifications

STATUS VISUALIZATION

Monitored directly via the touchscreen car status panel, displaying charge rate, line voltage, active amperage draw, and calculated time remaining.

SUPERCHARGER PRECONDITIONING

Scheduled or route-based preconditioning automatically heats or cools the battery to optimal thermal limits prior to arrival at a Supercharger station.

Battery Health Best Practices

Continuous Connection: Keep the vehicle plugged into a power source when parked for extended periods. This maintains low-voltage systems and optimal High Voltage thermal conditioning.

Critical Discharge Alert: Avoid letting the battery charge level drop to 0%. Deep discharges can damage High Voltage cell health and cause total failure of low-voltage electronics.

KEYS, ACCESS & POWER CONTROL

Supported Key Types

- **Phone Key:** Connects via Bluetooth Low Energy and Ultra-Wideband (UWB). Unlocks automatically upon approach and locks when walking away.
- **Key Card:** High-frequency NFC card. Tap against the driver-side door pillar (B-pillar) to lock/unlock, and place on center console reader to authenticate driving.
- **Key Fob:** Physical remote control accessory equipped with buttons for frunk, rear trunk, and total vehicle locking/unlocking.

Key Type Capability Matrix

KEY TYPE	AUTO-UNLOCK ON APPROACH	PRIMARY PLACEMENT / INTERFACE
Phone Key	YES (BLUETOOTH / UWB)	Mobile App / Pocket
Key Card	NO (TAP B-PILLAR)	Driver B-Pillar / Center Console
Key Fob	YES (PASSIVE ENTRY)	Pocket / Key Ring

Powering On and Off Operations

POWER ON PROCEDURE Press and hold the brake pedal while seated inside the cabin with a valid authenticated key present (Phone Key, Key Fob, or placed Key Card).	POWER OFF PROCEDURE Powers off automatically after shifting into Park, exiting with key, and closing all doors. Alternatively, manual shutdown via Controls > Safety > Power Off.
---	---

Main Touchscreen Layout

TOP STATUS BAR

Displays door lock state, vehicle time, outside ambient temperature, cellular/Wi-Fi signals, Sentry Mode status, and Airbag indicators.

CAR STATUS DISPLAY

Real-time driving visualization: speedometer, gear selector (PRND), turn signals, door states, tire pressures, and surrounding objects.

BOTTOM APP BAR

Customizable shortcuts for climate settings, media controls, volume adjustment, window defrosters, and full app tray.

Touchscreen Reboot Procedure

If the touchscreen becomes unresponsive or exhibits unusual behavior, execute a system soft reset:

STEP	ACTION REQUIRED
Step 1	Bring the vehicle to a complete stop and shift into Park (P) .
Step 2	Press and hold down both scroll wheel buttons on the steering wheel simultaneously until the screen turns black.
Step 3	Wait approximately 10–15 seconds for the vehicle emblem to appear on screen. The system completes restart within ~30 seconds.

Safety Note: Performing a touchscreen reboot while driving does not affect core vehicle mechanical propulsion, braking, or steering operations.

CLIMATE, ELECTRONICS & OUTLETS

SECTION 06 – CABIN COMFORT & ELECTRICAL OUTLETS

Specialized Climate Modes

KEEP CLIMATE ON Maintains set cabin temperature continuous when leaving the vehicle parked.	DOG / PET MODE Sustains safe temperatures and displays a reassurance message on the main screen for passersby.	CAMP MODE Retains cabin climate airflow and provides constant low-voltage outlet power overnight.
---	--	---

Onboard Connectivity & Charging Outlets

INTERFACE / PORT	LOCATION	SPECIFICATION & FUNCTION
Wireless Phone Chargers	Front Center Console	Dual Qi-wireless charging pads (up to 15W output each).
USB-C Ports	Console Rear Compartment	High-speed device charging ports for rear passengers.
Glovebox USB-A Port	Inside Glovebox	Dedicated secure port equipped with flash drive for Sentry Mode/Dashcam.
12V Power Outlet	Center Console & Rear Trunk	12V DC power outlet (Max 12A continuous / 16A peak draw).

INTERIOR CONFIGURATIONS & SEATING

SECTION 07 – SEATING CONTROLS & ROW OPTIONS

Page 7

Front Seat Operations

- **Adjustment:** Fully power-adjustable via the side seat switches or through **Controls > Seats** on the main display.
- **Heating:** Integrated heating elements with 3 distinct temperature level controls.
- **Calibration:** Seat position calibration accessible via **Controls > Service > Driver Seat, Steering & Mirrors Calibration**.

Second & Third Row Configurations

Vehicle seating configurations vary by model specification:

SEATING LAYOUT	PASSENGER CAPACITY	FOLDING & ADJUSTMENT CONTROLS
5-Seater Configuration	Up to 5 Adults	60/40 split-folding second row; features independent center seat fold option for carrying long cargo items. Manual/Power backrest release.
6-Seater Configuration	Up to 6 Adults	Dual second-row captain's chairs with independent armrests and recline switches. Two third-row seats fold flat electronically via trunk switches.

DOORS, WINDOWS & STORAGE

SECTION 08 – EXTERIOR ACCESS & CARGO COMPARTMENTS

Page 8

Doors & Window Calibration

EXTERIOR DOOR ACCESS

Push the wide part of the flush door handle inward with your thumb, then pull the extended lever to open.

INTERIOR ELECTRONIC DOOR RELEASE

Press the electronic open button located at the top of the interior door handle assembly.

Window Calibration Procedure: If window behavior requires reset, fully raise the window using driver switch until stalled, fully lower until stalled, then fully raise again.

Storage Operations

- **Front Trunk (Frunk):** Unlatched via touchscreen, Key Fob, or mobile app. Must be closed manually using two hands pressing firm on designated hood areas.
- **Rear Liftgate:** Electronically opens or closes via touchscreen, Key Fob, mobile app, or external liftgate handle switch.
- **Liftgate Height Adjustment:** Manually position the open liftgate to the desired height, then press and hold the button on the underside of the liftgate until a chime sounds to save the position.

CAMERAS & ACTIVE SAFETY SYSTEMS

Camera Hardware Layout

FRONT BUMPER CAMERA

Mounted directly above the front lower grille to provide forward ground vision.

REAR VISION CAMERA

Positioned centrally above the rear license plate frame.

SIDE REPEATERS & PILLARS

Cameras positioned on front fenders and B-pillars for 360-degree perimeter tracking.

INTERIOR CABIN CAMERA

Located above the rear view mirror to monitor driver attentiveness when active.

Driver Assist Features

- **Automatic Blind Spot Camera:** Projects a real-time side video feed onto the main display when a turn signal is activated, featuring red warning bands if an object is detected.
- **Camera Calibration:** System self-calibrates automatically over approximately 32–40 km (20–25 miles) of driving on well-marked roads following vehicle delivery or camera maintenance service.

Essential Maintenance Intervals

COMPONENT / ITEM	SERVICE SCHEDULE	ACTION REQUIRED
Tires	Every 10,000 km	Rotate tires or perform when tread depth variance reaches 1.5 mm+.
Brake Fluid	Every 2 Years	Check brake fluid for moisture contamination.
Cabin Air Filters	Every 2–3 Years	Replace internal cabin air filtration elements.
Wiper Blades	Periodic Inspection	Inspect rubber elements and clean windshield sprayer nozzles.

Emergency Operations

Manual Interior Door Release (No Electrical Power): In the event of vehicle electrical power loss, pull the mechanical door release lever located directly forward of the window switches on front door panels.

- **Jump-Starting Low Voltage Battery:** Access low-voltage jump posts positioned behind the front tow eye cover inside the front bumper.
- **Towing & Transportation:** Vehicle must be transported exclusively on a flatbed trailer with all wheels elevated off the ground to prevent drivetrain damage.