
[UEFI Practice] Introduction to SlimBootloader



SlimBootloader is an open source bootloader developed by Intel. It is similar to the Intel version of coreboot and is designed for the x86 platform, emphasizing security and scalability. It can initialize hardware and load the operating system, su pports a variety of common OS, and can be obtained from GitHub. This article introduces its compilation process, including the tools and steps required in the Windows environment, and how to test it on QEMU.

The summary is generated in C Know, supported by DeepSeek-R1 full version, go to experience

What is Slim Bootloader

Slim Bootloader is a Bootloader launched by Intel. A complete introduction to it can be found on the following website:

Overview: Intel® Slim Bootloader

It can be considered as the Intel version of coreboot, which is more inclined towards the x86 platform in terms of platform support, security, and scalability.

Slim Bootloader is the same as other Bootloaders, its main function is to initialize the hardware and load the OS. However, compared with other Bootloaders, Slim Bootloader has the following advantages:



Optimized for systems with a



Small

Small footprint means lower flash sizes requirements, reducing overall BOM cost. Allows fully redundant images for resilient solutions.



Customizable

Designed with modularity in mind, allowing for easy addition of differentiating features.



Secure


Supports verified boot, measured boot, and secure firmware updates. Build secure boot solutions when paired with Intel® Platform Protection Technology with Boot Guard.

It supports various common operating systems and is open source (using BSD license).

The source code for Slim Bootloader can be downloaded from GitHub - slimbootloader/slimbootloader: Visit http://slimbootloader.github.io for documentation .


Since Slim Bootloader is still in the early development stage, the code may differ due to updates. Please refer to the actual downloaded code

The compilation and running mentioned in this article are based on the version downloaded on 20181020. The actual version is as follows



Compilation of Slim Bootloader

The code structure downloaded from the above github is as follows



You can see that it is actually very similar to the structure of EDK. The following are the more important parts:

文件或目录	☑ 作用说明		
BuildLoader.py	生成Slim Bootloader所使用的脚本,它会进行编译链的设置,预编译,配置,编译以及编译完成后的其它操作。		
BootloaderCommonPkg	该目录包含通用的库函数供Slim Bootloader使用。		
BootloaderCorePkg/Stage1A	Slim Bootloader将启动分为几个阶段,其中Stage1A是最起始的阶段,跨度从Reset Vector开始到Cache-As-RAM(CAR)设置好为止,它会调用到FSP-T。		
BootloaderCorePkg/Stage1B	Stage1B从CAR设置后开始到系统内存初始化完成为止, 它会调用到FSP-M。		
BootloaderCorePkg/Stage2	Stage2用来进行其它的平台初始化(内存之外的CPU、桥片相关的初始化),并跳转到 Pavload、它会调用到FSP-S。		
BootloaderCorePkg/Tools	包含配置和编译过程中需要使用到的工具和脚本。		
PayloadPkg/OsLoader	包含加载OS需要使用到代码。		
PayloadPkg/FirmwareUpdate	包含升级固件 (就是Slim Bootloader本身) 需要使用到的代码。		
Platform	包含与单板相关的特定代码。 https://blog.esdn.net/jiangwei0512		
Silicon	包含支持特定平台所需的代码。		

Regarding the above directories, there are some additional requirements to make the code easy to expand and compatible

- 1. BootloaderCorePkg and PayloadPkg should be independent and unrelated to each other
- 2. PayloadPkg code should not depend on Platform or Silicon.
- 3. PayloadPkg should only depend on BootloaderCommonPkg.

Compilation under Windows

Compilation under Windows requires the following preparation:

Building on Windows

Supported environment: Microsoft Visual Studio 2015


Install the exact versions (if specified) of the following tools to the designated directories:

- cxFreeze 4.3.3 (https://sourceforge.net/projects/cx-freeze/files/4.3.3/) default installation nath
- Python 2.7 C:\Python27
- IASL 20160422 C:\ASL
- NASM C:\Nasm
- OpenSSL C:\openssl
 https://blog.csdn.net/jiang

What needs to be explained here are the first and the last ones, while the ones in the middle have been explained in other articles and will not be introduced here.

cxFreeze is used to convert Python scripts into executable files under Windows. These executable files are located in the BaseTools\Bin\Win32 directory. There is no Win32 directory in the default source code.

The location of cxFreeze after installation is as follows:



Another one is openssl. The Windows version of openssl can be downloaded from OpenSSL for Windows .

Move the bin directory of the downloaded compressed package to the root directory of disk C, and rename bin to openssl, as shown in the following figure:

S称	修改日期	类型	大小
■ bftest.exe	2008/8/23 3:52	应用程序	32 KE
■ bntest.exe	2008/8/23 3:52	应用程序	422 KE
casttest.exe	2008/8/23 3:52	应用程序	34 KI
■ destest.exe	2008/8/23 3:52	应用程序	212 KI
dhtest.exe	2008/8/23 3:52	应用程序	349 KI
■ dsatest.exe	2008/8/23 3:52	应用程序	533 KI
ecdhtest.exe	2008/8/23 3:52	应用程序	443 KI
ecdsatest.exe	2008/8/23 3:52	应用程序	495 KI
■ ectest.exe	2008/8/23 3:52	应用程序	546 KI
■ enginetest.exe	2008/8/23 3:52	应用程序	382 K
evp_test.exe	2008/8/23 3:52	应用程序	969 K
exptest.exe	2008/8/23 3:52	应用程序	381 K
■ hmactest.exe	2008/8/23 3:52	应用程序	339 K
Ⅲ ideatest.exe	2008/8/23 3:52	应用程序	25 K
libeay32.dll	2008/9/4 4:49	应用程序扩展	1,150 K
libssl32.dll	2008/9/4 4:49	应用程序扩展	228 KI
md2test.exe	2008/8/23 3:52	应用程序	336 K
■ md4test.exe	2008/8/23 3:52	应用程序	336 K
■ md5test.exe	2008/8/23 3:52	应用程序	337 K
openssl.exe	2008/8/23 3:53	应用程序	1,761 K
■ randtest.exe	2008/8/23 3:52	应用程序	333 K
rc2test.exe	2008/8/23 3:52	应用程序	20 K
rc4test.exe	2008/8/23 3:52	应用程序	173 K
rmdtest.exe	2008/8/23 3:52	应用程序	340 K
■ rsa_test.exe	2008/8/23 3:52	应用程序	337 K
■ sha1test.exe	2008/8/23 3:52	应用程序	333 K
🗊 sha256t.exe	2008/8/23 3:52	应用程序	333 K
🗊 sha512t.exe	2008/8/23 3:52	应用程序	334 K
shatest.exe	2008/8/23 3:52	应用程序	340 KI

Since there is no actual board to test, only the Slim Bootloader for QEMU is compiled for testing. The specific method is as follows:


1. Enter the source code root directory, open a command line window, and run the following command:

For an introduction to FSP, please refer to [UEFI Practice] FSP.


After compilation is complete, the generated files will be placed in the following location:



After that, we will start compiling Slim Bootloader. However, we need to compile Win32 tools first (the generated tools are located in BaseTools\Bin\Win32):



Then continue compiling:



The binary generated by the final compilation is located in the Outputs directory under the root directory:




Compilation under Linux

Not available at this time.

Use of Slim Bootloader

After the compilation is complete, execute the following command:



Note that QEMU must have been installed before this.

Since there is no actual system to boot, you can only see the following interface, but the Slim Bootloader is booted normally.

about Us Careers Business Seeking 2400-660-1018 Setu@csdn.net Couptrage 2100-660-1018 Security Registration Number 11010502030143 Beijing ICP No. 19004658 Beijing Internet Publishing House [2020] No. 1039-165 Commercial website registration information Beijing Internet Illegal and Harmful Information Reporting Center Parental Control Online 110 Alam Service China Internet Reporting Center China Internet Reporting Center Province Store Downdod Account Management Specifications Copyright and Disclaimer Copyright Complaints Publication License Business license ©1999-2025 Beijing Innovation Lezhi Network Technology Co., Ltd.