

7.9 Parameter List

7.9.1 “Active Setup Menu” Menu

Level 1	Level 2	Level 3	Level 4	Codes
Active setup menu	Balance	Installation site/ambient conditions	Very stable conditions	1.1.1.1
			☐ Stable conditions	1.1.1.2
			Unstable conditions	1.1.1.3
			☐ Very unstable conditions	1.1.1.4
		Application filter	☐ Final readout	1.1.2.1
			☐ Dosing	1.1.2.2
			Reduced filter	1.1.2.3
			☐ Filter off	1.1.2.4
		Stability range/stability	☐ 1/4 scale interval/maximum accuracy	1.1.3.1
			☐ 1/2 scale interval/very accurate	1.1.3.2
			☐ 1 scale interval/accurate	1.1.3.3
			☐ 2 scale interval/quick	1.1.3.4
			☐ 4 scale interval/very quick	1.1.3.5
			☐ 8 scale interval/very low	1.1.3.6
		Stability delay	Very short	1.1.4.1
			☐ Short	1.1.4.2
			☐ Moderate	1.1.4.3
			☐ Long	1.1.4.4
		Taring	Without stability	1.1.5.1
			☐ After stability	1.1.5.2
		Autozero	☐ ON	1.1.6.1
			☐ OFF	1.1.6.2.

○ = Factory setting

Level 1	Level 2	Level 3	Level 4	Codes
Active setup menu	Balance	Weight unit	Available unit	1.1.7.1
			☐ g, grams	1.1.7.2
			Units: Kilogram to Newton	1.1.7.3
				up to
				1.1.7.23
		Accuracy	☐ All digits on	1.1.8.1
			Last digit on/off during load change	1.1.8.2
			Scale interval index +1	1.1.8.3
			Scale interval index +2	1.1.8.4
			Scale interval index +3	1.1.8.5
			Last digit scale interval 1	1.1.8.6
			Last digit off	1.1.8.7
			10x resolution	1.1.8.14
		Cal./adjust. function	☐ Ext. adjustment with default weight	1.1.9.1.
			Ext. adjustment with user-defined weight	1.1.9.3.
			Internal adjustment*	1.1.9.4.
			Ext. linearization with default weights	1.1.9.6.
			Ext. linearization with user-defined weights	1.1.9.7.
			Set the preload	1.1.9.8.
			Delete the preload	1.1.9.9.
			Cal. key/command blocked	1.1.9.10.
			Selection list	2.1.9.12
			Define internal weight (is blocked)	3.1.9.18
		Adjustment process	☐ Adjust immediately	1.1.10.1.
			Calibration before adjustment	1.1.10.2.
		Zero range	☐ 2% of max load	1.1.11.2.
			10% of max load	1.1.11.4.
		Zero at power on	☐ 10% of max load	1.1.12.4.
			100% of max load	1.1.12.7.

* Only for NC models

○ = Factory setting

Level 1	Level 2	Level 3	Level 4	Codes
Active setup menu	Balance	Tare/zero at power on	☐ On	1.1.13.1.
			☐ Off	1.1.13.2.
		Output rate	☐ Normal	1.1.14.1.
			☐ Fast	1.1.14.2.
			☐ Slow, typ. 10 Hz	1.1.14.3.
			☐ Moderate, typ. 20 Hz	1.1.14.4.
			☐ Quick, typ. 25 Hz	1.1.14.5.
			☐ Very quick, typ. 50 Hz	1.1.14.6.
			☐ Maximum, typ. 100 Hz	1.1.14.7.
		Auto. calibration/ ISOCAL	☐ Off	1.1.15.1.
			☐ Note	1.1.15.2.
	General settings	Menu reset	☐ Yes, load factory setting	1.9.1.1
			☐ No, stand-by	1.9.1.2

☐ = Factory setting