

TechMart Electronics — User Manual and Quick Start Guide

Document Version: 2025.1

Applies To: All TechMart Devices

Last Updated: January 2025

=====

GETTING STARTED

=====

1. UNBOX YOUR DEVICE

Your package includes:

- TechMart device
- USB-C charging cable
- Quick start guide
- Warranty card
- SIM ejector tool (phones/tablets with cellular)

2. CHARGE FULLY BEFORE FIRST USE

- Connect the included cable to a USB-C power adapter (not included)
- Recommended adapter: 20W or higher
- Charge for 2 hours before first power-on
- Charge indicator: LED glows amber while charging, green when full

3. POWER ON

- Press and hold the power button for 3 seconds
- The TechMart logo appears
- First boot may take 2–3 minutes

4. INITIAL SETUP WIZARD

Follow the on-screen prompts:

Step 1: Select your language (24 languages available)

Step 2: Connect to Wi-Fi

Step 3: Sign in with your TechMart account OR create a new one

Step 4: Set up biometric security (fingerprint OR face recognition)

Step 5: Choose whether to restore from a backup

Step 6: Accept terms of service

Step 7: Set up TechMart Premium (optional)

5. TRANSFERRING FROM OLD DEVICE

- Android: use the TechMart Switch app
- iOS: use Move to TechMart (built into setup wizard)
- Both devices must be on the same Wi-Fi network

=====

DAILY USE

=====

GESTURES (Phones and Tablets)

- Swipe up from bottom → Home
- Swipe up and hold → Recent apps
- Swipe from left edge → Back
- Swipe down from top-right → Control Center
- Swipe down from top-left → Notifications

KEYBOARD SHORTCUTS (Laptops)

- Cmd/Ctrl + Space → Spotlight search
- Cmd/Ctrl + Tab → Switch apps
- Cmd/Ctrl + Q → Quit app
- Cmd/Ctrl + W → Close window
- Cmd/Ctrl + Shift + 4 → Screenshot

BATTERY OPTIMIZATION

- Enable Low Power Mode: Settings → Battery → Low Power Mode
- Reduce screen brightness
- Turn off background app refresh for unused apps
- Disable Bluetooth and Wi-Fi when not in use

=====

TROUBLESHOOTING

=====

ISSUE: Device won't power on

Solution:

1. Charge for at least 30 minutes with the original cable
2. Try a different USB-C cable
3. Try a different power adapter
4. Force restart: press and hold Power + Volume Down for 10 seconds
5. If still not powering on, contact support

ISSUE: Wi-Fi won't connect

Solution:

1. Confirm the Wi-Fi password is correct
2. Restart your router (unplug 30 seconds, plug back in)
3. On device: Settings → Wi-Fi → tap network → "Forget" → rejoin
4. Try connecting to a different Wi-Fi network to isolate the issue
5. Restart the device

ISSUE: Slow performance

Solution:

1. Close unused apps (swipe up from bottom, hold, then swipe apps away)

2. Restart the device
3. Check for software updates: Settings → About → Software Update
4. Free up storage: Settings → Storage (aim to keep 15% free)
5. Reset: Settings → General → Reset → Reset All Settings (doesn't erase data)

ISSUE: App keeps crashing

Solution:

1. Update the app to the latest version
2. Clear app cache: Settings → Apps → [App Name] → Clear Cache
3. Uninstall and reinstall the app
4. Restart device
5. Check if the app is compatible with your OS version

ISSUE: Overheating

Solution:

1. Remove the case if using one
2. Close demanding apps (games, video editing)
3. Avoid charging while using heavy apps
4. Move to a cooler environment
5. If persistent, contact support — potential battery issue

ISSUE: Battery drains quickly

Solution:

1. Check battery usage: Settings → Battery → Battery Usage
2. Limit background app refresh
3. Reduce screen brightness or enable auto-brightness
4. Turn off location services for apps that don't need it
5. Enable Low Power Mode
6. If battery health is below 80%, consider a replacement (free under warranty)

=====

ACCOUNT AND LOGIN

=====

FORGOT PASSWORD

- Step 1: Go to techmart.example/login
- Step 2: Click "Forgot Password"
- Step 3: Enter your registered email address
- Step 4: Check your inbox for a reset link (valid for 1 hour)
- Step 5: Click the link and set a new password
- Step 6: New password must be at least 8 characters with 1 number and 1 symbol

If you don't receive the email:

- Check spam/junk folder
- Confirm you used the correct email
- Wait 5 minutes and try again
- Contact support if still not received

PREMIUM SUBSCRIPTION LOCKED AFTER PAYMENT

If you paid but Premium is still locked:

- Step 1: Allow up to 15 minutes for activation
- Step 2: Force-close and reopen the app
- Step 3: Check Account → Subscriptions to confirm status
- Step 4: If still locked after 30 minutes, contact support with your order number

Common reasons for delay:

- Payment processing (banks can take up to 10 min)
- Subscription activated on a different account
- Browser cache issue (try a different browser)
- Payment method was declined (check with your bank)

SOFTWARE UPDATES

Updates are delivered automatically when your device is:

- Connected to Wi-Fi
- Charging or above 50% battery
- Idle (not in active use)

To check manually:

Settings → About → Software Update → Check for Updates

Update recommendations:

- Install security updates within 7 days
- Feature updates can be deferred up to 30 days
- Major OS updates: back up your device before installing

SAFETY AND CARE

- Operating temperature: 0°C to 35°C (32°F to 95°F)
- Storage temperature: -20°C to 45°C
- Do not expose to liquids (unless IP-rated)
- Use only TechMart-approved chargers and cables
- Clean screen with a soft, lint-free cloth
- Do not attempt to open or repair the device yourself — voids warranty
- Recycle properly at end of life (techmart.example/recycle)

RESETTING YOUR DEVICE

SOFT RESET (keeps your data)

Settings → General → Reset → Reset All Settings

FACTORY RESET (erases everything)

Settings → General → Reset → Erase All Content and Settings

- You will be prompted for your password
- Device will restart and return to setup wizard
- Required before selling or returning the device

=====

SUPPORT

=====

- Email: support@techmart.example
- Phone: 1-800-TECHMART (1-800-832-4627)
- Live chat: 24/7 at techmart.example/support
- WhatsApp: +1-800-832-4627
- Community forum: community.techmart.example

=====

END OF DOCUMENT

=====

For the latest version of this manual, visit techmart.example/manuals.