User Preset 1 GM Instrument

Faders

Ctrl	Msg Type	CC	Data 1	Data 2	Chan	Param
F1	MIDI	CC	73	127	0	Global Attack
F2	MIDI	CC	75	127	0	Global Decay
F3	MIDI	CC	72	127	0	Global Release
F4	MIDI	CC	91	127	0	Global Effect depth 1 (Reverb Send level)
F5	MIDI	CC	92	127	0	Global Effect depth 2
F6	MIDI	CC	93	127	0	Global Effect depth 3 (Chorus send level)
F7	MIDI	CC	94	127	0	Global Effect depth 4
F8	MIDI	CC	95	127	0	Global Effect depth 5
F9	MIDI	CC	7	127	0	Global Volume

Buttons

Ctrl	Msg Type	CC	Data 1	Data 2	Chan	Param
B1	MIDI	CC (Toggle)	0	127	0	Global Bank MSB
B2	MIDI	CC (Toggle)	2	127	0	Global Breath
B3	MIDI	CC (Toggle)	3	127	0	Global Control Change (Unde-fined)
B4	MIDI	CC (Toggle)	4	127	0	Global Foot Controller
B5	MIDI	CC (Toggle)	6	127	0	Global Data Entry MSB
B6	MIDI	CC (Toggle)	8	127	0	Global Balance
B7	MIDI	CC (Toggle)	9	127	0	Global Control Change (Unde-fined)
B8	MIDI	CC (Toggle)	11	127	0	Global Expression Controller
B9	MIDI	CC (Toggle)	65	127	0	Global Portamento On/Off

Fader

Ctrl	Msg Type	CC	Data 1	Data 2	Chan	Param
K1	MIDI	CC	74	127	0	Global Brightness
K2	MIDI	CC	71	127	0	Global Harmonic Content
K3	MIDI	CC	5	127	0	Global Portamento Rate
K4	MIDI	CC	84	127	0	Global Portamento Depth
K5	MIDI	CC	78	127	0	Global Control Change (Vibrato Delay)
K6	MIDI	CC	76	127	0	Global Control Change (Vibrato Rate)
K7	MIDI	CC	77	127	0	Global Control Change (Vibrato Depth)
K8	MIDI	CC	10	127	0	Global Pan

Note: B9 is assigned to MIDI cc 65 on all presets intended to be available for a global function