Cluster Progress

September 16, 2019

NAS-1 Emergency Mode

- NAS-1 is continuing to boot into emergency mode.
- The indicator light on drive 0:21 lit up, indicating that the drive was failing.
- The command to replace the drive (storcli) could not be run due to controller 0 being in "crit error".
- The faulty drive was replaced and began rebuilding, but soon afterwards controller 0 entered "crit error" state again.

APC Battery issues

- The indicator lights on the APC power supply have all turned off.
- The voltages on a few of the batteries are very low.