

Contacts
Edit VC 110's contact list.

Note: You can't turn it back on using the app. The only way to turn the GizmoPal 2 on is to press the Play button on the gizmo for 4 seconds.













About VC 110's Gizmo



Gizmo Software Version

VC11010B

Gizmo Software Update

Check if a software update is available for VC 110's gizmo.

Gizmo Model Number

LG VC110

Factory Reset This Gizmo

Delete all settings, contacts and stored information from VC 110's gizmo.

Send Logs

Disable Logs

Clear Logs














Gizmo Software Version VC11010B

Factory Reset VC 110's Gizmo?

Factory resetting VC 110's gizmo will delete all settings. All caregivers and approved contacts will be removed and won't be able to call or locate VC 110's gizmo. VC 110's gizmo will need to be reactivated before a new caregiver can register and link to it.

Factory reset this gizmo now?

Note: The gizmo must be turned on to reset it.

FACTORY RESET GIZMO

Clear Logs
















Gizmo Software Version VC11010B

Gizmo Software Update

Check if a software update is available for VC 110's gizmo.

Gizmo Model Number

Resetting gizmo

Delete all settings, contacts and stored information from VC 110's gizmo.

Send Logs

Disable Logs

Clear Logs