

# PARTS LIST OPERATING AND SERVICE MANUAL



45 SERIES  
BLOWERS

Models:  
GGD\_\_D\_

D-9-611  
Version 03  
November, 2005

**MAINTAIN BLOWER RELIABILITY AND PERFORMANCE  
WITH GENUINE DUROFLOW PARTS AND SUPPORT SERVICES  
FROM GARDNER DENVER**

Factory genuine parts, manufactured to design tolerances, are developed for optimum dependability --- specifically for your blower. Design and material innovations are born from years of experience with hundreds of different blower applications. When you specify factory genuine parts you are assured of receiving parts that incorporate the most current design advancements . . . manufactured in our state-of-the-art blower factory under exacting quality standards.

Your **AUTHORIZED DISTRIBUTOR** offers all the backup you require. A worldwide network of authorized distributors provides the finest product support in the blower industry.

Your **AUTHORIZED DISTRIBUTOR** can support your

blower investment with these services:

1. Trained parts technical representatives to assist you in selecting the correct replacement parts.
2. Complete inventory of new machines and new, genuine factory parts.
3. A full line of factory tested AEON™ PD Synthetic Blower Lubricants specifically formulated for optimum performance in all blowers.
4. Authorized Distributor service technicians are factory-trained and skilled in blower maintenance and repair. They are ready to respond and assist you by providing fast, expert maintenance and repair services.

**REMANUFACTURED BLOWERS**

Whenever a DuroFlow blower requires replacement or repair, Gardner Denver offers an industry unique, factory remanufactured blower exchange program. From its modern Remanufacturing Center in Indianapolis, IN, Gardner Denver is committed to supplying you with the highest quality, factory remanufactured DuroFlow blowers that are guaranteed to save you time, aggravation and money.

**Immediately Available**

Repair downtime costs you money, which is why Gardner Denver maintains a large inventory of remanufactured blowers at all times, ready for immediate delivery.

**Skilled Craftsmen**

Our Remanufacturing assembly technicians average over 20 years experience with air compression products.

**Precision Remanufacturing**

All potentially usable parts are thoroughly cleaned, inspected and analyzed. Only those parts that can be brought back to original factory specifications are

remanufactured. Every remanufactured DuroFlow blower receives a new overhaul kit: bearings, seals, sleeves and gaskets.

**Extensive Testing**

Gardner Denver performs testing that repair houses just don't do. Magnaflux and ultrasonic inspection spot cracked or stressed castings, monochromatic light analysis exposes oil leaks, coordinate measurement machine inspects to +/- .0001", and slip and hot run testing insure that all remanufactured DuroFlow blowers meet factory performance specifications.

**Latest Technology**

Factory remanufactured DuroFlow blowers incorporate all of the latest new blower design improvements.

**Warranty**

Gardner Denver backs up every remanufactured blower with a new warranty . . . 18 months from purchase, 12 months from service.

Gardner Denver remanufactured air ends deliver *quality without question . . . year in and year out.*

## **GARDNER DENVER LUBRICANT ORDER INFORMATION**

Re-order Part Numbers for Factory-Recommended Lubricants.

### **AEON PD Synthetic Lubricant or AEON PD-Food Grade Synthetic Lubricant**

#### **AEON PD Synthetic Lubricant**

Description	Part Number
1 Quart	28G23
Case/12Quarts	28G24
5 Gallon Pail	28G25
55 Gallon Drum	28G28

#### **AEON PD-Food Grade Synthetic Lubricant**

Description	Part Number
1 Quart	28H97
Case/12Quarts	28H98
5 Gallon Pail	28H99
55 Gallon Drum	28H100

**Call your local Duroflow Distributor to place your order for Gardner Denver lubricants. Your Authorized Gardner Denver Distributor is:**

---

---

---

## **FOREWORD**

Duroflow® blowers are the result of advanced engineering and skilled manufacturing. To be assured of receiving maximum service from this machine, the owner must exercise care in its operation and maintenance. This book is written to give the operator and maintenance department essential information for day-to-day operation, maintenance and adjustment. Careful adherence to these instructions will result in economical operation and minimum downtime.

### **DANGER**

**Danger is used to indicate the presence of a hazard which will cause severe personal injury, death, or substantial property damage if the warning is ignored.**

### **WARNING**

**Warning is used to indicate the presence of a hazard which can cause severe personal injury, death, or substantial property damage if the warning is ignored.**

### **CAUTION**

**Caution is used to indicate the presence of a hazard which will or can cause minor personal injury or property damage if the warning is ignored.**

### **NOTICE**

**Notice is used to notify people of installation, operation or maintenance information which is important but not hazard-related.**

## SAFETY PRECAUTIONS

Safety is everybody's business and is based on your use of good common sense. All situations or circumstances cannot always be predicted and covered by established rules. Therefore, use your past experience, watch out for safety hazards and be cautious. Some general safety precautions are given below:

### DANGER

**Failure to observe these notices could result in injury to or death of personnel.**

- **Keep fingers and clothing away from blower inlet and discharge ports, revolving belts, sheaves, drive coupling, etc.**
- **Do not use the air discharge from this unit for breathing - not suitable for human consumption.**
- **Do not loosen or remove the oil filler plug, drain plugs, covers, or break any connections, etc., in the blower air or oil system until the unit is shut down and the air pressure has been relieved.**
- **Electrical shock can and may be fatal.**
- **Blower unit must be grounded in accordance with the National Electrical Code. A ground jumper equal to the size of the equipment ground conductor must be used to connect the blower motor base to the unit base.**
- **Open main disconnect switch, tag and lockout before working on the control.**
- **Disconnect the blower unit from its power source, tag and lockout before working on the unit - the machine may be automatically controlled and may start at any time.**

### WARNING

**Failure to observe these notices could result in damage to equipment.**

- **Stop the unit if any repairs or adjustments on or around the blower are required.**
- **Disconnect the blower unit from its power source, tag and lockout before working on the unit - the machine may be automatically controlled and may start at any time.**
- **Do not exceed the rated maximum speed shown on the nameplate.**
- **Do not operate unit if safety devices are not operating properly. Check periodically. Never bypass safety devices.**

## TABLE OF CONTENTS

	<b>Page</b>
Maintain Blower Reliability and Performance with Genuine DuroFlow Parts and Support Services .....	i
Remanufactured Blower Program (see page 17 for complete details) .....	i
Gardner Denver Lubricant Order Information .....	ii
Foreword .....	iii
Safety Precautions .....	iv
Index .....	vi
List of Illustrations .....	vii
Matrix/Menu .....	1
<b>Introduction</b>	
Your Key To Trouble Free Service .....	2
Important Duroflow Telephone Numbers .....	2
<b>Section 1, General Information</b>	
Inspection .....	3
Removing Protective Materials At Start-up .....	3
Storage .....	3
Blower Mounting Configurations .....	4
Outline .....	5
Blower Outline Dimension Chart .....	6
<b>Section 2, Installation</b>	
Location .....	7
Foundation and Base .....	7
Mounting Configurations .....	7
Drive Installation .....	7
Piping .....	9
Duroflow Inlet and Discharge Connectors .....	9
<b>Section 3, Lubrication</b>	
Recommended Lubricant .....	10
Lubrication Instructions .....	10
<b>Section 4, Operation</b>	
Limitations .....	13
Safety Precautions .....	13
Blower Startup Checklist .....	15
<b>Section 5, Maintenance And Troubleshooting</b>	
Key Points for Long Blower Life .....	16
Trouble Shooting .....	16
<b>Section 6, Service Options</b>	
Factory Remanufactured Blower Program .....	18
Parts Ordering Instructions .....	19
Overhaul Kits .....	19
<b>Section 7, Parts Lists And Exploded Views</b>	
45 Series Duroflow Blower .....	20
45 Series Duroflow Blower – Model 4518 Blower .....	22
Warranty .....	24
Warranty Registration .....	Last Page

## INDEX

AEON PD Food Grade Lubricant Part Numbers . . . . .	10	MAINTENANCE AND TROUBLESHOOTING, SECTION 5 . . . . .	16
AEON PD Lubricant Part Numbers . . . . .	10	Matrix/Menu . . . . .	1
Air Seal Vent Systems . . . . .	11	Mounting Configurations . . . . .	7
Alignment, Belt Drive . . . . .	9		
Base and Foundation . . . . .	7	Oil Sump Breathing System . . . . .	11
Belt Drive Alignment . . . . .	9	OPERATION, SECTION 4 . . . . .	13
Blower Startup Checklist . . . . .	15	Overhaul Kits . . . . .	19
Checklist, Blower Startup . . . . .	15	Overhung Load Calculations and Limitations . . . . .	7
Drive Installation . . . . .	7		
Belt Drive Alignment . . . . .	9	PARTS LISTS AND EXPLODED VIEWS, SECTION 7 . . . . .	20
Driver Location . . . . .	9	Parts Ordering Instructions . . . . .	19
Overhung Load Calculations and Limitations . . . . .	7	Piping . . . . .	9
Driver Location . . . . .	9	Precautions, Safety . . . . .	iv, 13
Factory Remanufactured Blower Program . . . . .	18	Product Support, DuroFlow . . . . .	i
Foreword . . . . .	iii		
Foundation and Base . . . . .	7	Recommended Lubricant . . . . .	10
Gaskets, Inlet and Outlet . . . . .	19	Remanufactured Blower Program, Factory . . . . .	i, 18
GENERAL INFORMATION, SECTION 1 . . . . .	3	Repair Parts . . . . .	18
INSTALLATION, SECTION 2 . . . . .	7		
Installation, Location . . . . .	7	Safety Precautions . . . . .	iv, 13
Key Points for Long Blower Life . . . . .	16	SERVICE OPTIONS, SECTION 6 . . . . .	18
Limitations, Operation . . . . .	13	Startup Checklist, Blower . . . . .	15
Location, Installation . . . . .	7	Storage . . . . .	3
Lubricant, Recommended . . . . .	10	Storage Kits . . . . .	19
Lubricant Order Information, Gardner Denver . . . . .	ii		
LUBRICATION, SECTION 3 . . . . .	10	Trouble Shooting . . . . .	16
Lubrication Instructions . . . . .	10		
Lubrication Service		Warranty . . . . .	24
Air Seal Vent Systems . . . . .	11	Warranty Registration . . . . .	Last Page
Oil Sump Breathing System . . . . .	11		
		YOUR KEY TO TROUBLE FREE SERVICE, INTRODUCTION . . . . .	2

## **LIST OF ILLUSTRATIONS**

### **D300GGD074-A (Ref. Drawing)**

Figure 1-1	Blower Configuration Changes .....	4
Figure 1-2	Outline .....	5
Figure 1-3	Blower Outline Dimension Chart .....	6
Figure 2-1	Belt Drive Overhung Load Limitations .....	8
Figure 2-2	Inlet and Discharge Connectors .....	9
Figure 3-1	Approximate Oil Capacities .....	10
Figure 3-2	AEON PD Synthetic Lubricant .....	10
Figure 3-2	Viscosity Recommendation .....	12
Figure 4-1	Maximum Operating Limitations .....	14

## **EXPLODED VIEWS**

45 Series Blower - 304GGD810 .....	20
45 Series Blower - 305GGD810 - Model 4518 .....	22

**DUROFLOW BLOWERS - 45 SERIES  
MATRIX/MENU**

NOTICE TO CUSTOMER - To find the construction options for your blower unit, FILL IN THE BALANCE OF LETTERS OR NUMBERS FROM YOUR UNIT NAMEPLATE COLUMN NUMBER:

G	G	D		D							
—	—	—	—	—	—	—	—	—	—	—	—
1	2	3	4	5	6	7	8	9	10	11	

FOLLOW THE LINE DOWN AND OVER FROM EACH SPACE THUS FILLED IN TO FIND THE APPROPRIATE CONSTRUCTION OPTION WITH WHICH YOUR MACHINE IS EQUIPPED.

COLUMN 1 - BASIC DESIGNATOR \_\_\_\_\_

COLUMN 2 - PRODUCT FAMILY \_\_\_\_\_

- G. INDUSTRIAL BLOWER

COLUMN 3 - GEAR DIAMETER \_\_\_\_\_

- D. 4.5" - 45 Series

COLUMN 4 - CASE LENGTH \_\_\_\_\_

45 Series

- A. 4"
- B. 6"
- C. 9"
- D. 12"
- E. 18"

COLUMN 5 - CONSTRUCTION \_\_\_\_\_

- A. VERTICAL-TOP HAND-CENTRAL TIMED
- B. VERTICAL-BOTTOM HAND-CENTRAL TIMED
- C. HORIZONTAL-LEFT HAND-CENTRAL TIMED
- D. HORIZONTAL-RIGHT HAND-CENTRAL TIMED

COLUMN 6 - DESIGN VERSION \_\_\_\_\_

COLUMN 7 - ADDITIONAL DESCRIPTION \_\_\_\_\_

- A. STANDARD, NO MODIFICATION
- \* C. LEAK RESISTANT
- \* E. STEP-UP DRIVE

COLUMNS 8 THRU 11 - MODIFICATION NUMBER \*

\* NOT INCLUDED IN THIS PUBLICATION, CONSULT FACTORY.

## **INTRODUCTION**

### **YOUR KEY TO TROUBLE FREE SERVICE**

---

Thank you for investing in DuroFlow quality. The DuroFlow reputation for rugged dependability has been earned by over 70 years of service in demanding, industrial operations where downtime cannot be tolerated and efficient blower performance is expected.

Your DuroFlow blower is a precision engineered blower that has been carefully manufactured and thoroughly tested at the state-of-the-art Gardner Denver Blower Factory in Sedalia, Missouri.

As with other precision machinery, there are several relatively simple installation, operation and mainte-

nance procedures that you must observe to assure optimum blower performance. There is no guesswork in the manufacture of your highly advanced DuroFlow blower and there must be none in preparing the blower to get the job done in the field.

The purpose of this manual is to help you properly install, operate and maintain your DuroFlow blower. It is essential that you review all sections of this manual in preparation for installing your blower. Follow the instructions carefully and you will be rewarded with trouble-free DuroFlow service . . . year in and year out.

## **SECTION 1**

### **GENERAL INFORMATION**

---

#### **INSPECTION**

Before uncrating, check the packing slip carefully to be sure all the parts have been received. All accessories are listed as separate items on the packing slip, and small important accessories such as relief valves can be overlooked or lost. After every item on the packing slip has been checked off, uncrate carefully. Register a claim with the carrier for lost or damaged equipment.

The inlet and discharge openings are fitted with protective covers to prevent dirt and moisture from entering the blower during shipping and installation.

#### **NOTICE**

**Do not remove and dispose of the covers until final checking and installation.**

Covers are lined with a "Corrosion Inhibitor" which will inhibit rust for a period of six months. Retain covers for use in reshipment or relocation of the unit.

Temporarily remove the protective covers and inspect interior of air chamber for foreign material or heavy rusting. Turn driveshaft to assure that lobes rotate smoothly without binding. New blowers may be difficult to turn by hand due to friction of the air seals. Once in motion however, there should be no indication of interference between the rotors and the housing or end-plates. Report any suspected mechanical problems immediately to your authorized DuroFlow distributor.

#### **REMOVING PROTECTIVE MATERIALS AT START-UP**

Blower inlet and discharge are temporarily capped to keep out dirt and other contaminants during shipment. These covers must be removed before start-up.

#### **WARNING**

**Failure to remove covers from blower inlet and discharge prior to start-up will cause machine damage.**

#### **STORAGE**

Your DuroFlow blower was packaged at the factory with adequate protection to permit normal storage for up to six (6) months. Under the best of storage conditions there is still a potential for damage to occur. Extended storage preparation is available from the factory, prior to shipment, at a small additional charge. If the unit is to be stored under adverse conditions or for extended periods of time, additional measures should be taken to prevent unwarrantable damage.

1. Store the blower in a clean, dry area.
2. Make certain inlet and discharge air ports are tightly covered to prevent foreign material from entering the air chamber.
3. All exposed, non-painted surfaces should be protected against rust and corrosion.
4. Make sure all vent breathers are in place.
5. Provide adequate protection to avoid accidental mechanical damage.
6. In high humidity or corrosive environments, additional measures may be required to prevent rusting of the internal surfaces. Mist spraying the impellers and air chamber with a rust preventative will protect these surfaces from rusting. To prevent rusting of gears and bearings, add one pint of VCI oil in each oil reservoir. (Ref. Part Number 28H280 per quart).
7. Rotate shaft by hand weekly to prevent bearings from taking a set and to keep seals soft.


#### **CAUTION**

**Before running the blower, drain the oil and replace to the proper operating level with clean, fresh lubricant.**



#### **WARNING**

**Rotating components will cause severe injury in case of personal contact. Keep hands away from blower inlet and discharge ports.**


## 45 SERIES



VERTICAL TOP ROTATES  
LEFT TO BECOME  
HORIZONTAL LEFT



VERTICAL BOTTOM ROTATES  
LEFT TO BECOME  
HORIZONTAL RIGHT



**SHAFT ROTATION KEY:**      CW = CLOCKWISE  
                                  CCW = COUNTERCLOCKWISE

**NOTE:** When changing configurations be sure to relocate the Oil Fill, Oil Drain and Breather Filters into their proper position. 45 Series blowers require a mounting foot change with a configuration change.

FIGURE 1- 1 - BLOWER MOUNTING CONFIGURATIONS

## 45 SERIES




FIGURE 1- 2 - OUTLINE

BLOWER OUTLINE DIMENSION CHART					
Dimensions	Models				
	4504	4506	4509	4512	4518
A	17.84	21.34	24.34	27.34	33.42
B	16.37	16.37	16.37	16.37	16.37
C	10.50	10.50	10.50	10.50	12.12
D	3.13	4.63	4.63	4.63	4.63
E DIA.	1.4375	1.4375	1.4375	1.4375	1.4375
F	9.75	9.75	9.75	9.75	13.00
G	17.50	17.50	17.50	17.50	17.50
H	4.88	6.88	6.88	9.88	15.88
J	11.50	11.50	11.50	11.50	11.50
K	5.00	7.00	7.00	10.00	16.00
L	11.35	11.35	11.35	11.35	11.35
M	5.62	5.62	5.62	5.62	5.62
N	9.10	9.10	9.10	9.10	9.10
P	10.02	12.52	14.02	15.52	18.52
Q	*	*	*	*	8" FLG
R	2.25	2.25	2.25	2.25	2.25
S	4.88	4.88	4.88	4.88	6.50
T DIA.	.69	.69	.69	.69	.69
U	8.75	8.75	8.75	8.75	8.75
V	2.50	3.50	3.50	5.00	8.00
W	5.75	5.75	5.75	5.75	5.75
X	2.44	3.44	3.44	4.94	7.94

\* See FIGURE 2-2, Page 9, for available connectors.

APPROXIMATE WEIGHT					
MODEL	4504	4506	4509	4512	4518
LBS.	235	260	290	335	470

FIGURE 1- 3 - BLOWER OUTLINE DIMENSION CHART

## SECTION 2 INSTALLATION

### LOCATION

Whenever possible, install the blower in a clean and dry place that is both well lighted and well ventilated. Provide plenty of room for easy inspection and maintenance.

### FOUNDATION AND BASE

For permanent installations we recommend concrete foundations be provided, and the equipment should be grouted to the concrete. Use non-shrinking grout only. It is necessary that a suitable base be used, such as steel combination base under the blower and motor, or a separate sole plate under each. The blower feet must be 100% supported. Before grouting, equipment must be leveled, free of all strains, and anchored so no movement will occur during curing of grout. After grout has completely hardened, a recheck is necessary to compensate for shrinkage. If required, add shims under blower feet after final tightening of foundation anchor bolts to remove strain from the blower housing.

Where jack screws or wedges are used during grouting, they must be backed off or removed before final tightening of anchor bolts.

Where a concrete foundation is not feasible, care must be taken to insure that equipment is firmly anchored to adequate structural members. The blower must be installed on a flat, level surface and bolted down evenly to prevent warping or strain. Internal clearances are very critical and serious damage or failure can result from housing distortion.

### NOTICE

**If the unit is not flat within .002 of an inch, it will be necessary to shim the blower feet at installation.**

### MOUNTING CONFIGURATIONS

All DuroFlow blowers are center timed allowing rotation in either direction.

DuroFlow blowers are shipped in the vertical configuration (horizontal airflow.) If a horizontal configuration is desired, the blower can be laid on its side after repositioning breathers, oil filler drain plugs and mounting feet as indicated in the installation drawing, FIGURE 1- 2, page 5. **To assure proper lubrication, the blower must be laid over in the direction that places the oil sight glass(es) below the horizontal centerline of**

**the blower.** See FIGURE 1- 1, page 4, for additional configuration information.

When converting 45 series blowers from vertical to horizontal configurations, the horizontal mounting feet are required. Order horizontal mounting feet from your DuroFlow Distributor.

The blower must be mounted level with the driveshaft in the horizontal position. The 45 series blowers have interconnected oil sumps and operation in an out-of-level condition will result in inadequate lubricant distribution and subsequent premature blower failure.

### DRIVE INSTALLATION

When selecting a V-belt drive, check to be sure the shaft overhung load limitation is not exceeded.

**Overhung Load Calculations and Limitations** - An excessive overhung condition exists when the belt pull on the blower shaft exceeds the maximum allowable moment listed in "Maximum Allowable Moment" chart in FIGURE 2-1, page 8. Excessive overhung load conditions must be avoided or bearing failure and shaft breakage will result.

### WARNING

**Exceeding overhung load limitations leads to unwarrantable premature bearing failure and shaft breakage.**

The location of the sheave on the blower shaft greatly affects the stress in the shaft. The optimum blower sheave positioning is as close as possible to the blower drive cover, not to exceed dimension "C" shown in maximum allowable moment chart, FIGURE 2-1, page 8.


To calculate the shaft moment for a given V-belt drive arrangement, first calculate the belt pull using the formula for belt pull in FIGURE 2-1, page 8. Insert the calculated belt pull into the formula for calculation of shaft moment in FIGURE 2-1, page 8, to arrive at the calculated shaft moment.

The calculated shaft moment must not exceed the maximum allowable moment listed in the chart, FIGURE 2-1, page 8. If the calculated shaft moment exceeds the maximum allowable moment:

- Increase Sheave Diameters to Reduce Belt Pull
- Use Jackshaft Drive
- Use Direct Coupled or Gearbox Drive

Series	Gear Diameter (Inches)	Dimensions (Inches)			Maximum Allowable Moment (LB-IN)
		A	B	C	
45	4.5	7.38	2.75	.75	3591
* 4504 Only	4.5	5.88	2.75	.75	3591

\* Applies to 4504 only.



#### MAXIMUM ALLOWABLE MOMENT

#### DRIVE SHAFT ILLUSTRATION

Z	Ac										
0.000	1.000	0.250	0.966	0.500	0.926	0.750	0.879	1.000	0.823	1.250	0.751
0.025	0.997	0.275	0.962	0.525	0.922	0.775	0.874	1.025	0.816	1.275	0.742
0.050	0.994	0.300	0.958	0.550	0.917	0.800	0.869	1.050	0.810	1.300	0.734
0.075	0.990	0.325	0.954	0.575	0.913	0.825	0.864	1.075	0.803	1.325	0.725
0.100	0.987	0.350	0.951	0.600	0.908	0.850	0.858	1.100	0.796	1.350	0.716
0.125	0.983	0.375	0.947	0.625	0.904	0.875	0.852	1.125	0.789	1.375	0.706
0.150	0.980	0.400	0.943	0.650	0.899	0.900	0.847	1.150	0.782	1.400	0.697
0.175	0.977	0.425	0.939	0.675	0.894	0.925	0.841	1.175	0.774	1.425	0.687
0.200	0.973	0.450	0.935	0.700	0.889	0.950	0.835	1.200	0.767		
0.225	0.969	0.475	0.930	0.725	0.884	0.975	0.829	1.225	0.759		

#### ARC OF CONTACT FACTORS

$$\text{Belt Pull} = \left[ \frac{2.5 - Ac}{Ac} \right] \left[ \frac{125954 \times HP \times S.F.}{D \times RPM} \right]$$

Key: Ac = Arc of Contact Factor (Refer to Arc of Contact Factors Chart above)

HP = Blower Horsepower for Operating Conditions

S.F. = Actual Drive Service Factor

D = Blower Sheave Pitch Diameter in Inches

RPM = Blower Sheave Speed

Z = Large Sheave Pitch Diameter (in) - Small Sheave Pitch Diameter (in)

Sheave Center Distance (in)

#### CALCULATION OF BELT PULL

$$\text{Shaft Moment (LB-IN)} = \text{Belt Pull} \times \left[ B + C + \left( \frac{\text{Sheave Width}}{2} \right) \right]$$

#### CALCULATION OF SHAFT MOMENT

FIGURE 2-1 - BELT DRIVE OVERHUNG LOAD CALCULATIONS

**Driver Location** - To properly balance the air load stress on the blower drive shaft, locate the driver on the inlet side for a vertical mounted blower and on the shaft side for a horizontal mounted blower.

**Belt Drive Alignment** - Belt drives must be carefully aligned, with the motor and blower sheaves parallel to each other and in the same plane. Belt tension should be carefully adjusted according to the belt manufacturer's recommendations using a Tension Tester.

### **WARNING**

**Overtightening belts produces heavy bearing loads and leads to unwarrantable premature failure.**

On direct drive blowers, align the couplings so that the offset and angular misalignment does not exceed .003" total indicator reading (TIR). Lubricate coupling according to manufacturer's specification. With factory installed drives, proper alignment has been established before shipment. During shipping, handling and installation, it is likely that the alignment has been disturbed and final adjustment must be made before start-up.

### **PIPING**

DuroFlow 45 series, 4504 through 4512 blowers, can accept a variety of inlet and discharge connectors.

Refer to FIGURE 2-2, below, for a listing of available connectors. 4504 through 4512 blowers are shipped without inlet and discharge connectors. Contact your DuroFlow Distributor to order connectors.

The 4518 Series DuroFlow blower has flat face inlet and discharge flanges with ANSI 125 lb. bolt patterns.

When installing the blower, avoid subjecting the inlet and discharge connections to strains caused by misalignment of the connecting pipes. Never allow the blower to carry the weight of the pipe.

Piping strain and misalignment stress will distort the blower during operation, resulting in loss of critical internal clearances. Loss of internal clearances will result in serious machine damage and premature, unwarrantable blower failure.

Whenever possible, install a spool or sleeve-type expansion joint between the blower and the piping. Where a flexible connection is not possible, the weight of the rigid connection and piping must be separately supported, and thermal pipe growth must be accommodated.

### **WARNING**

**Thoroughly clean all system piping internally before connecting to the blower.**

## **DUROFLOW INLET AND DISCHARGE CONNECTORS**

**TWO CONNECTIONS REQUIRED FOR EACH BLOWER**  
NOTE: CONNECTORS ARE REUSABLE

<b>DuroFlow Model</b>	<b>CONNECTOR PART NUMBER</b>					
	<b>4" Line Size Connector (Short)</b>	<b>4" Line Size Connector (Long)</b>	<b>5" Line Size Connector (Short)</b>	<b>5" Line Size Connector (Long)</b>	<b>6" Line Size Connector (Short)</b>	<b>6" Line Size Connector (Long)</b>
4504	N/A	DF141575	N/A	N/A	N/A	N/A
4506	DF137356	DF137357	N/A	N/A	N/A	N/A
* 4509	DF138987	N/A	DF149559	DF137346	N/A	N/A
4512	N/A	N/A	N/A	N/A	DF141748	DF137344

**ALL CONNECTORS HAVE FEMALE THREADED CONNECTIONS.**

\* Use 5" connectors above 3000 RPM on pressure service to keep line losses to a minimum.

**FIGURE 2-2 - INLET AND DISCHARGE CONNECTORS**

## SECTION 3 LUBRICATION

All DuroFlow blowers are splash oil lubricated at both the gear and drive ends. Oil is distributed around the gear housing and drive end chamber by the gears and specially designed oil flingers.

Series	Oil Fill Ports	Vertical Mounting	Horizontal Mounting
45	One Port – Shaft & Gear Ends Interconnected	29 oz.	55 oz.

FIGURE 3-1 - APPROXIMATE OIL CAPACITIES

### RECOMMENDED LUBRICANT

The factory recommended lubricant is AEON PD Synthetic Lubricant. AEON PD is formulated especially for positive displacement blowers to provide maximum protection at any temperature. One filling of AEON PD will last a minimum of 4 times longer than a premium mineral oil, depending on actual operating conditions. AEON PD contains a special additive package designed for greater rust and corrosion protection.

### NOTICE

**Machines are shipped without oil in the sumps. Do not operate before adding lubricant.**

### LUBRICATION INSTRUCTIONS

For 45 series models, the oil fill port is located on the top of the blower at the driveshaft end (see FIGURE 1- 2, page 5). The two oil sumps are connected by a passageway through the housing

Add oil until the level stabilizes at the center of the sight-glass(es). Oil level at the sight glass must be established when the blower is not operating.

Add fresh oil as required to maintain proper level.

### WARNING

**Do not overfill as this will tend to cause excessive heating of the gears, oil to leak through the vent holes, and may damage the unit.**

#### AEON PD Lubricant

Description	Part Number
1 Quart	28G23
Case/12Quarts	28G24
5 Gallon Pail	28G25
55 Gallon Drum	28G28

#### AEON PD Food Grade Lubricant

Description	Part Number
1 Quart	28H97
Case/12Quarts	28H98
5 Gallon Pail	28H99
55 Gallon Drum	28H100

AEON PD Synthetic Lubricant should be drained after 6000 hours of operation. Re-fill with fresh AEON PD oil. If mineral oil is used, perform the above oil-change maintenance every 1500 hours. Recommended service intervals are for normal blower operating conditions. Severe operating conditions may warrant more frequent oil changes. Laboratory analysis of lubricant should be used to help determine the optimum oil change interval.

For best performance and equipment protection, use AEON PD Synthetic Lubricant, which has been specifically formulated for positive displacement blowers. If you choose not to use AEON PD Synthetic Blower Lubricant, select an oil with rust and oxidation inhibitors, anti-foam additives, and the viscosities listed in FIGURE 3-3, page 12. **Do not use an oil that contains EP additives.**

FIGURE 3-2 - AEON PD SYNTHETIC LUBRICANT

## **NOTICE**

**Flush the oil whenever a change is made from one type of oil to another.**

Flush the oil whenever a change is made from one type of oil to another. Drain the current lubricant as thoroughly as possible. Refill with the new lubricant. Fill to normal level of the blower, which is at the middle of the sight glass when the machine is not operating. Run the blower for one hour. Shut off the blower and drain the lubricant completely. Refill the blower again with the new lubricant.

### **Air Seal Vent Systems**

All DuroFlow blowers are designed with a vent opening between the air chamber seal and the oil sump seal that vents to atmosphere any air which escapes from the air chamber.

The vent prevents pressurization of the oil sump and

must be left open to atmosphere. Do not plug these vent holes (see FIGURE 1- 2, page 5).

## **WARNING**

**Do not plug vent holes or oil sumps may pressurize causing loss of oil, excessive heat and serious damage to the machine.**

### **Oil Sump Breathing System**

All DuroFlow blowers are designed to permit their oil systems to breathe freely to prevent pressurization of the oil sumps. Breather filters are required to keep contaminants from entering the oil sumps (see Figure 1-1, page 4).

Breather filters are easily cleaned by washing in commercial solvent and drying with compressed air. Clean at every oil change to assure proper venting.

Blower Discharge Temperature	Ambient Temperature			
	Less than 10° F *	10° F to 32° F **	32° F to 90° F	Greater than 90° F
Less than 32° F (0° C)	ISO 100 ‡	ISO 100 ‡		
32° F to 100° F (0° C to 38° C)	ISO 100 ‡	ISO 100 ‡	ISO 150 ‡	
100° F to 225° F (38° C to 105° C)	ISO 100 ‡	ISO 100 ‡	ISO 150 ‡	ISO 220 ‡
225° F to 300° F (105° C to 149° C)	ISO 150 ‡	ISO 150 ‡	ISO 220 ‡	ISO 220 ‡
Greater than 300° F (149° C)			*** ‡	*** ‡

\* For ambient temperatures less than 10° F, but not less than -20° F, the use of oil sump heaters, heated enclosures or synthetic lubricant is required.

\*\* For ambient temperatures 10° F to 32° F, the use of oil sump heaters, heated enclosures or synthetic lubricant is recommended.

\*\*\* The lubricant viscosity must be 70 SUS minimum at the lubricant operating temperature.

The pour point of the lubricant should be at least 5° to 10° F below the minimum expected ambient temperature.

For continuous operation, where the lubricant temperature exceeds 200° F, synthetic lubricant is recommended.

‡ The recommended operating range for AEON PD Synthetic Lubricant.

**FIGURE 3-3 - VISCOSITY RECOMMENDATION**

## SECTION 4 OPERATION

Future operating problems can be avoided if proper precautions are observed when the equipment is first put into service.

Before starting under power, the blower should be turned over by hand to make certain there is no binding, or internal contact.

### LIMITATIONS

Each size blower has limits on pressure differential, running speed, and discharge temperature which must not be exceeded. These limits are shown in FIGURE 4-1, page 14.

### NOTICE

**Relief valves should be placed as close as possible to the blower inlet on vacuum systems or discharge on pressure systems.**

Check valves must be installed on the discharge side of the blower on a pressure system and on the inlet side of the blower on a vacuum system to eliminate product ingestion resulting from autorotation and blow back during equipment shutdown.

### WARNING

**Operating beyond the specified operating limitations will result in damage to the unit.**

To accurately determine actual blower operating conditions, it is important that all pressure and temperature recordings are made directly at the ports of the blower where these conditions are at their maximum.

Relief valves MUST be used to protect the blower against excessive pressure or vacuum conditions. These valves should be tested at initial start up to be sure they are adjusted to relieve at 2 psi above the maximum allowable pressure or at 2" HG below the maximum allowable vacuum for the blower. Periodic testing of relief valves is suggested to assure that they are functioning.

### SAFETY PRECAUTIONS

1. Do not operate the blower with an open inlet or discharge port.
2. Do not exceed specified vacuum or pressure limitations.
3. Do not operate above or below recommended blower speed range.
4. The blower is not to be used where non-sparking equipment is specified. Contact your DuroFlow Distributor for non-sparking requirements.
5. Do not operate the blower without belt guard or coupling shield properly installed.
6. Do not exceed the manufacturer's specified rim speed limit for sheaves or couplings.
7. The blower and blower discharge piping may be extremely hot and can cause skin burns on contact.
8. Do not exceed the manufacturer's certification levels for vacuum or pressure vessels.

<b>MAXIMUM OPERATING LIMITATIONS</b>				
<b>Size</b>	<b>RPM</b>	<b>Differential Pressure PSI</b>	<b>Dry * Vacuum In HG</b>	<b>Discharge Temperature °F</b>
4504	4000	15	15	350
4506	4000	15	15	350
4509	4000	15	15	350
4512	4000	15	15	350
4518	4000	10	16	325

**DO NOT EXCEED THESE LIMITS**

\* Increased vacuum levels are attainable with water injection. Contact your DuroFlow Distributor.

**NOTICE**

**Blower speed, line losses, elevation, and increased inlet temperatures affect actual blower performance. Care must be taken to consider these factors when designing your system so that blower limitations are not exceeded.**

FIGURE 4-1 - MAXIMUM OPERATING LIMITATIONS

## BLOWER STARTUP CHECKLIST

This startup procedure should be followed during the initial installation and after any shutdown periods or after the blower has been worked on or moved to a new location. It is suggested that the steps be followed in sequence and checked off (  ) in the boxes provided.

- 1. Check to make certain that the blower has been properly lubricated with AEON PD Synthetic Blower Lubricant. Proper oil level cannot be overemphasized. Too little oil will ruin bearings and gears. Too much oil will overheat the lubricant and lead to serious blower damage.
- 2. Check to make sure all oil sump breather filters are installed in their proper location. Oil leakage will occur if they are improperly located.
- 3. Check the unit and all piping for foreign material and clean if required.
- 4. Check the inlet or inline filter to make sure it is not plugged causing dangerous inlet restriction.
- 5. Check the preload of the feet and the alignment of the drive. Feet that are bolted down in a bind can cause case distortion and internal rubbing. A misaligned V-belt drive will reduce belt life. Misaligned couplings place heavy loads on bearings which leads to their premature failure.
- 6. If blower is V-belt driven, check the belt tension. Over-tensioned belts create heavy bearing loads which lead to premature bearing failure.
- 7. If blower is V-belt driven, check for excessive overhung load condition. Loads in excess of maximum allowable overhung load limitations will lead to premature bearing failure and shaft breakage.
- 8. Be sure adequate drive guards are in place to protect the operator from SEVERE PERSONAL INJURY from contact with rotating components.
- 9. Turn the unit over by hand to be sure there is no binding or rotor contact. The 45 series uses piston rings for sealing. When units are new, some resistance to turning the driveshaft by hand will be encountered. After several hours of running, this seal pressure will relieve itself and the blower will be somewhat easier to turn.
- 10. Jog the blower with the motor to check for proper rotation and airflow direction. Listen for unusual noise coming from the blower or motor and make sure the blower coasts smoothly to a stop.
- 11. Start unit and operate for 15 minutes with no load. Check for hot spots on housing or end plates, noise and other indications of interference. Allow the blower to cool to room temperature and re-check oil level. Add oil if necessary. DO NOT OVERFILL.
- 12. Check to be certain that actual blower speed is within allowable limits.
- 13. Apply load and observe operation for the first hour, checking pressure and air discharge temperature:
  - (a) Do not operate blower over manufacturer's specified pressure or vacuum rating.
  - (b) Discharge air temperature should not exceed the maximum allowable temperature.
- 14. Check and retension belts after the first few hours of operation to minimize slippage and belt wear. DO NOT OVERTENSION.
- 15. If mechanical problems are encountered during installation or start-up, notify your nearest DuroFlow Distributor. Never continue to operate your DuroFlow blower if you detect a malfunction, as serious damage can occur. **Do not attempt any internal investigation without factory authorization since this will void the warranty.**

## **SECTION 5**

### **MAINTENANCE AND TROUBLESHOOTING**

Your DuroFlow blower has been designed, manufactured and tested to precise specifications. Every DuroFlow blower is backed by over 70 years of proven performance in the most demanding applications that modern industry can produce. DuroFlow blowers have been designed specifically for long, trouble-free service. Minimal maintenance is required to keep your DuroFlow blower in top operating condition. Your attention to the following key points will insure years of dependable DuroFlow blower performance.

#### **Key Points for Long Blower Life**

1. Use AEON PD Synthetic Blower Lubricant to assure maximum blower protection.
2. The oil level must be checked periodically.

3. Drain and refill the blower with fresh AEON PD Lubricant every 6000 hours of operation, 1500 hours if using mineral based lubricant.
4. Clean the breather filters at every oil change or more often if dust conditions are severe.
5. Service the intake and in-line filters regularly to make sure that air flow restriction does not occur and that foreign material does not enter the blower.
6. If the blower is taken out of service for any reason, be sure to protect all interior surfaces from rusting.

#### **TROUBLE SHOOTING**

No matter how well the equipment is designed and manufactured, there may be times when servicing will be required due to normal wear, the need for adjustment, or various external causes. Whenever

equipment needs attention, the operator or service technician should be able to locate the cause and correct the trouble quickly by following the Troubleshooting Chart given below:

<b>PROBLEM</b>	<b>POSSIBLE CAUSES</b>	<b>SOLUTION</b>
Knocking and excessive mechanical noise.	<ol style="list-style-type: none"><li>1. Unit out of time.</li><li>2. Distortion due to improper mounting or pipe strains.</li><li>3. Excessive pressure differential.</li><li>4. Worn gears.</li><li>5. Worn bearings.</li></ol>	<ol style="list-style-type: none"><li>1. Retime rotors. (See page 18.)</li><li>2. Check mounting alignment and relieve pipe strains.</li><li>3. Reduce to manufacturer's recommended pressure or vacuum. Examine relief valve, re-set if necessary.</li><li>4. Replace timing gears. (See page 18.)</li><li>5. Replace bearings. (See page 18.)</li></ol>
Excessive blower temperature.	<ol style="list-style-type: none"><li>1. Too much oil in gear case.</li><li>2. Too low operating speed.</li><li>3. Plugged filter or silencer.</li><li>4. Excessive pressure differential.</li><li>5. Worn rotors clearances.</li><li>6. Internal contact.</li><li>7. Excessive inlet temperature.</li></ol>	<ol style="list-style-type: none"><li>1. Reduce oil level.</li><li>2. Increase blower speed. Check sheave set</li><li>3. Remove cause of obstruction.</li><li>4. Reduce pressure differential across the blower.</li><li>5. Replace rotors. (See page 18.)</li><li>6. Correct clearances. (See page 18.)</li><li>7. Relocate intake to cooler area.</li></ol>

PROBLEM	POSSIBLE CAUSES	SOLUTION
Rotor contact with housing or endplate.	<ol style="list-style-type: none"> <li>1. Insufficient assembled clearances.</li> <li>2. Case or frame distortion.</li> <li>3. Excessive operating pressure.</li> <li>4. Excessive operating temperature.</li> <li>5. Material ingestion through the blower.</li> </ol>	<ol style="list-style-type: none"> <li>1. Return for Warranty. (See page 18.)</li> <li>2. Remove all mounting and pipe strains.</li> <li>3. Remove cause.</li> <li>4. Remove cause.</li> <li>5. Replace worn inlet and inline filters. Install check valve between blower and first material load point to eliminate blow-back when blower is stopped.</li> </ol>
Lack of CFM delivery.	<ol style="list-style-type: none"> <li>1. Slipping belts.</li> <li>2. Worn clearances.</li> <li>3. Blower RPM too slow.</li> </ol>	<ol style="list-style-type: none"> <li>1. Tighten belts to proper tightness.</li> <li>2. Replace rotors. (See page 18.)</li> <li>3. Increase Blower speed. Check sheave set.</li> </ol>
Excessive bearing or gear wear.	<ol style="list-style-type: none"> <li>1. Improper lubrication.</li> <li>2. Oversized belt drive, over-tightened belts.</li> </ol>	<ol style="list-style-type: none"> <li>1. Correct lubrication level. Replace dirty oil with AEON PD Synthetic Blower Lubricant.</li> <li>2. Re-tension belts to proper tightness. Check drive to eliminate possible overhung load condition.</li> </ol>
Loss of oil from seal vents.	<ol style="list-style-type: none"> <li>1. Worn oil seal.</li> <li>2. Damaged seal sleeve.</li> <li>3. Gear case or drive cover breathers plugged.</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace seals. (See page 17.)</li> <li>2. Replace sleeve. (See page 17.)</li> <li>3. Clean breather filters.</li> </ol>
Loss of oil from breather filters.	<ol style="list-style-type: none"> <li>1. Endplate seal vents plugged.</li> <li>2. Worn oil seal.</li> </ol>	<ol style="list-style-type: none"> <li>1. Clean vents of obstruction. Do not plug seal vents.</li> <li>2. Replace seals. (See page 17.)</li> </ol>
Loss of oil from driveshaft seal.	<ol style="list-style-type: none"> <li>1. Worn oil seal.</li> <li>2. Damaged seal sleeve.</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace seal. (See page 17.)</li> <li>2. Replace sleeve. (See page 17.)</li> </ol>
Excessive vibration.	<ol style="list-style-type: none"> <li>1. Inadequate package design.</li> <li>2. Soft foot.</li> <li>3. Material build-up inside rotors.</li> <li>4. Bearing failure.</li> <li>5. Excessive gear wear.</li> <li>6. Bent shaft.</li> <li>7. Internal mechanical contact.</li> </ol>	<ol style="list-style-type: none"> <li>1. Reinstall base - fill with concrete.</li> <li>2. Shim to eliminate condition.</li> <li>3. Replace worn inlet and inline filters. Install check valve between blower and first material load point to eliminate blow-back when blower is stopped</li> <li>4. Replace bearings.</li> <li>5. Replace gears.</li> <li>6. Replace rotor set.</li> <li>7. See "Rotor Contact" above.</li> </ol>

If you are unable to resolve the problem, contact your DuroFlow Distributor for immediate assistance.

## **SECTION 6**

### **SERVICE OPTIONS**

---

#### **Factory Remanufactured Blower Program**

### **STOP**

You have turned to the service section because you have a blower problem that requires the blower to be mechanically adjusted or repaired. First determine if the blower is still under warranty. Contact your DuroFlow Distributor and provide them with the blower SERIAL NUMBER located on the blower name plate. DuroFlow will promptly handle all warranty claims according to the warranty policy on page 24.

If the blower is out of warranty: The DuroFlow blower is a precision machine that requires special tools and experience to be properly repaired. Before you attempt any in-house repairs on a DuroFlow blower, we recommend that you first contact your authorized DuroFlow Distributor.

If your repair is more serious than the above procedures and involves the repair or replacement of a major blower component, you will benefit greatly by using the **DUROFLOW FACTORY REMANUFACTURED BLOWER EXCHANGE PROGRAM**. See page i for additional information.

### **LOOK**

Look how easy it is to use the DuroFlow factory remanufactured blower program:

1. The moment you detect a major problem, simply contact your DuroFlow Distributor to order your factory remanufactured DuroFlow blower. You only need to supply the blower serial number and model number which are listed on the blower nameplate.
2. Your distributor will immediately ship a factory remanufactured blower from its inventory directly to your attention. Factory remanufactured DuroFlow blowers are backed by a full, new blower warranty . . . 18 months from the date of shipment or 12 months in service, whichever occurs first, and each remanufactured blower incorporates all of the latest design technology and enhancements.
3. When you install your remanufactured DuroFlow unit, simply return the failed blower . . . freight pre-paid . . . to our Indianapolis, IN Remanufacturing

Center for a core credit. Your total cost for a factory remanufactured blower, after core credit, is significantly less than a new machine.

### **NOTICE**

**Inlet and discharge connectors are reusable. Remove connectors from the failed blower before returning the core to the Indianapolis, IN Remanufacturing Center.**

### **LISTEN**

Listen to the sound of your well running plant, not the complaints of your exasperated mechanics when they realize that properly repairing a DuroFlow blower is a much more delicate and difficult process than it originally appeared to be. Listen to the experience of thousands of plant operators who depend upon the DuroFlow remanufactured blower program to save them time, money and frustration. Remember, every DuroFlow factory remanufactured blower is backed with a full new blower warranty - 18 months from the date of shipment or 12 months from the date of start-up, whichever occurs first.

#### **Repair Parts**

If you elect to attempt a repair on your DuroFlow blower make certain you **use genuine DuroFlow original equipment parts** to retain the performance and dependability of your DuroFlow blower.

Factory genuine parts, engineered to original tolerances, are designed for optimum dependability . . . specifically for your blower. Design and material innovations are born from years of experience with hundreds of different blower applications. When you specify factory genuine parts you are assured of receiving parts that incorporate the most current design advancements . . . manufactured in our state-of-the-art blower factory under exacting quality standards.

Prepackaged overhaul kits are available for immediate shipment for all DuroFlow blowers. Kits include all the

normal wearing parts needed to overhaul your DuroFlow blower: Oil seals, air seals, bearings, spacers, gaskets, and Belleville timing spring. Kits do not include inlet and outlet gaskets. Part numbers for overhaul kits and inlet and outlet gaskets are given below.

Refer to Section 7 for additional part numbers as required.

### Parts Ordering Instructions


When ordering parts, indicate the model and serial number from the blower nameplate and identify the blower configuration by referring to Figure 1-3, page 6.

For prompt, professional assistance in selecting the correct repair parts for your DuroFlow blower, contact your Duroflow Distributor who maintains a large inventory of genuine DuroFlow parts.

OVERHAUL KITS	
Model	Part Number
45 Series Overhaul Kit – Design Version “D” All Models .....	306GGD6010
INLET AND OUTLET GASKETS	
Model	Part Number
4504 .....	DF141539
4506 .....	DF135718
4509 .....	DF135717
4512 .....	DF135716
4518 .....	25C2721N
2 Required per Machine	
STORAGE KITS	
45 Series Extended Storage Kit – Design Version “D” 4504 .....	200GGD6015
4506 .....	201GGD6015
4509 .....	202GGD6015
4512 .....	203GGD6015
4518 .....	300GGD6015

## SECTION 7 PARTS LIST AND EXPLODED VIEW

45 SERIES DUROFLOW BLOWER  
EXPLODED VIEW



304GGD810-D  
(Ref. Drawing)


**Order by Part Number and Description. Reference Numbers are for your convenience only.**

Ref. No.	Name of Part	Qty.	Size 4504 GGDA_DA Part No.	Size 4506 GGDB_DA Part No..	Size 4509 GGDC_DA Part No.	Size 4512 GGDD_DA Part No.
1	CYLINDER-AIR .....	1	306GGD002	307GGD002	308GGD002	309GGD002
2	ROTOR GROUP .....	1	301GGD4028	302GGD4028	303GGD4028	304GGD4028
4	HOUSING-BEARING .....	1	312GGD006	312GGD006	312GGD006	312GGD006
5	HOUSING-BEARING .....	1	313GGD006	313GGD006	313GGD006	313GGD006
6	BASE-VERTICAL MOUNTING .....	1	202GGD247	201GGD247	200GGD247	DF135405
**	BRACKET-HORIZONTAL MOUNTING .....	2	DF193168	DF193168	DF193168	DF137804
8	SCREW .....	4	655EE050	655EE050	655EE050	655EE050
9	LOCKWASHER .....	4	95B5	95B5	95B5	95B5
*	PISTON RING .....	12	DF139986	DF139986	DF139986	DF139986
*	CARRIER .....	4	300GGD1148	300GGD1148	300GGD1148	300GGD1148
13	SLINGER .....	4	302GGD173	302GGD173	302GGD173	302GGD173
14	SPACER .....	2	304GGD144	304GGD144	304GGD144	304GGD144
*	LOAD RING .....	2	301GGD778	301GGD778	301GGD778	301GGD778
*	ROLLER BEARING .....	2	12BA213	12BA213	12BA213	12BA213
*	BALL BEARING .....	2	12BA193	12BA193	12BA193	12BA193
18	SPACER .....	2	305GGD144	305GGD144	305GGD144	305GGD144
19	BEARING RETAINER PLATE .....	1	300GGD253	300GGD253	300GGD253	300GGD253
*	SCREW .....	8	75LM262N	75LM262N	75LM262N	75LM262N
21	GEAR KIT .....	1	200GGD6008	200GGD6008	200GGD6008	200GGD6008
22	WASHER .....	1	300GGD244	300GGD244	300GGD244	300GGD244
23	SPACER .....	1	306GGD144	306GGD144	306GGD144	306GGD144
24	SLINGER .....	1	DF188536	DF188536	DF188536	DF188536
25	SLINGER .....	1	DF143095	DF143095	DF143095	DF143095
*	NUT .....	2	50V56	50V56	50V56	50V56
*	LOCKNUT .....	2	50Z8	50Z8	50Z8	50Z8
28	PLUG .....	3	64AA1	64AA1	64AA1	64AA1
29	PLUG .....	4	64AA4	64AA4	64AA4	64AA4
30	BUSHING .....	1	64E27	64E27	64E27	64E27
*	SPRING .....	1	DF181069	DF181069	DF181069	DF181069
33	BREATHER .....	1	DF140867	DF140867	DF140867	DF140867
34	PIN-DOWEL .....	6	62M48	62M48	62M48	62M48
*	SEAL RING .....	4	DF185304	DF185304	DF185304	DF185304
37	SCREW .....	16	655ED170	655ED170	655ED170	655ED170
38	SCREW .....	14	655ED150	655ED150	655ED150	655ED150
39	SCREW .....	2	655ED150D	655ED150D	655ED150D	655ED150D
40	LOCKWASHER .....	32	95B3	95B3	95B3	95B3
41	GEAR COVER .....	1	200GGD602	200GGD602	200GGD602	200GGD602
42	DRIVE COVER .....	1	300GGD477	300GGD477	300GGD477	300GGD477
43	WASHER .....	2	95A1	95A1	95A1	95A1
*	GASKET .....	2	DF135715	DF135715	DF135715	DF135715
45	SIGHT GLASS .....	1	DF137799	DF137799	DF137799	DF137799
*	WEAR SLEEVE .....	1	301GGD1458	301GGD1458	301GGD1458	301GGD1458
*	O-RING .....	2	25BC374	25BC374	25BC374	25BC374
49	GASKET .....	2	DF141539	DF135718	DF135717	DF135716
60	KEY-SQUARE .....	1	118401	105515	105515	105515
*	OIL SEAL .....	1	60DD715	60DD715	60DD715	60DD715
**	PAINT (GDP123A, GRAY, SEMI-GLOSS) ...	Pt.	28H194	28H194	28H194	28H194
**	LIFTING LUG .....	2	201GAF451	201GAF451	201GAF451	201GAF451
**	IDENTIFICATION & INSTRUCTION GROUP .....	1	300GGD4011	300GGD4011	300GGD4011	300GGD4011
**	STORAGE KIT - See page 19 for Part Numbers					
**	OVERHAUL KIT - See page 19 for Part Numbers					

\* Included in Overhaul Kit.

\*\* Not shown on illustration.

**45 SERIES DUROFLOW BLOWER  
EXPLODED VIEW - MODEL 4518 BLOWER**



**305GGD810-D  
(Ref. Drawing)**

**Order by Part Number and Description. Reference Numbers are for your convenience only.**

Ref. No.	Name of Part	Qty.	Size 4518 GGDE_DA Part No.
1	CYLINDER-AIR .....	1	315GGD002
2	ROTOR GROUP .....	1	305GGD4028
4	HOUSING-BEARING .....	1	312GGD006
5	HOUSING-BEARING .....	1	313GGD006
6	BASE-VERTICAL MOUNTING .....	1	200GGD285
**	BRACKET-HORIZONTAL MOUNTING .....	2	200GGD017
8	SCREW .....	4	655EE050
9	LOCKWASHER .....	4	95B5
*	PISTON RING .....	12	DF139986
*	CARRIER .....	4	300GGD1148
13	SLINGER .....	4	302GGD173
14	SPACER .....	2	304GGD144
*	LOAD RING .....	2	301GGD778
*	ROLLER BEARING .....	2	12BA213
*	BALL BEARING .....	2	12BA193
18	SPACER .....	2	305GGD144
19	BEARING RETAINER PLATE .....	1	300GGD253
*	SCREW .....	8	75LM262N
21	GEAR KIT .....	1	200GGD6008
22	WASHER .....	1	300GGD244
23	SPACER .....	1	306GGD144
24	SLINGER .....	1	DF188536
25	SLINGER .....	1	DF143095
*	NUT .....	2	50V56
*	LOCKNUT .....	2	50Z8
28	PLUG .....	3	64AA1
29	PLUG .....	4	64AA4
30	BUSHING .....	1	64E27
*	SPRING .....	1	DF181069
33	BREATHER .....	1	DF140867
34	PIN-DOWEL .....	6	62M48
*	SEAL RING .....	4	DF185304
37	SCREW .....	16	655ED170
38	SCREW .....	14	655ED150
39	SCREW .....	2	655ED150D
40	LOCKWASHER .....	32	95B3
41	GEAR COVER .....	1	200GGD602
42	DRIVE COVER .....	1	300GGD477
43	WASHER .....	2	95A1
*	GASKET .....	2	DF135715
45	SIGHT GLASS .....	1	DF137799
*	WEAR SLEEVE .....	1	301GGD1458
*	O-RING .....	2	25BC374
**	GASKET .....	2	25C2721N
60	KEY-SQUARE .....	1	105515
*	OIL SEAL .....	1	60DD715
**	PAINT (GDP123A, GRAY, SEMI-GLOSS) .....	Pt.	28H194
**	LIFTING LUG .....	2	201GAF451
**	IDENTIFICATION & INSTRUCTION GROUP .....	1	300GGD4011
**	STORAGE KIT - See page 19 for Part Numbers		
**	OVERHAUL KIT - See page 19 for Part Numbers		

\* Included in Overhaul Kit.

\*\* Not shown on illustration.

**GENERAL PROVISIONS AND LIMITATIONS**

Gardner Denver (the "Company") warrants to each original retail purchaser ("Purchaser") of its new products from the Company or its authorized distributor that such products are, at the time of delivery to the Purchaser, made with good material and workmanship. No warranty is made with respect to:

1. Any product which has been repaired or altered in such a way, in the Company's judgment, as to affect the product adversely.
2. Any product which has, in the Company's judgment been subject to negligence, accident, improper storage, or improper installation or application.
3. Any product which has not been operated or maintained in accordance with normal practice and with the recommendations of the Company.
4. Components or accessories manufactured, warranted and serviced by others.
5. Any reconditioned or prior owned product.

Claims for items described in (4) above should be submitted directly to the manufacturer.

**WARRANTY PERIOD**

The Company's obligation under this warranty is limited to repairing or, at its option, replacing, during normal business hours at an authorized service facility of the Company, any part which in its judgment proved not to be as warranted within the applicable Warranty Period as follows.

**BARE BLOWERS**

Basic bare blowers, consisting of all parts within, are warranted for 12 months from date of initial use or 18 months from date of shipment to the first purchaser, whichever occurs first.

Any disassembly or partial disassembly of the blower, or failure to return the "unopened" blower per Company instructions, will be cause for denial of warranty.

**OTHER COMPONENTS**

All other components are warranted for 12 months from date of initial use or 18 months from date of shipment to first purchaser, whichever comes first.

**LABOR TRANSPORTATION AND INSPECTION**

The Company will provide labor, by Company representative or authorized service personnel, for repair or replacement of any product or part thereof which in the

Company's judgment is proved not to be as warranted. Labor shall be limited to the amount specified in the Company's labor rate schedule.

Labor costs in excess of the Company rate schedule amounts or labor provided by unauthorized service personnel is not provided for by this warranty.

All costs of transportation of product, labor or parts claimed not to be as warranted and, of repaired or replacement parts to or from such service facilities shall be borne by the Purchaser. The Company may require the return of any part claimed not to be as warranted to one of its facilities as designated by Company, transportation prepaid by Purchaser, to establish a claim under this warranty.

Replacement parts provided under the terms of the warranty are warranted for the remainder of the Warranty Period of the product upon which installed to the same extent as if such parts were original components thereof.

**DISCLAIMER**

THE FOREGOING WARRANTY IS EXCLUSIVE AND IT IS EXPRESSLY AGREED THAT, EXCEPT AS TO TITLE, THE COMPANY MAKES NO OTHER WARRANTIES, EXPRESSED, IMPLIED OR STATUTORY, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY.

THE REMEDY PROVIDED UNDER THIS WARRANTY SHALL BE THE SOLE, EXCLUSIVE AND ONLY REMEDY AVAILABLE TO PURCHASER AND IN NO CASE SHALL THE COMPANY BE SUBJECT TO ANY OTHER OBLIGATIONS OR LIABILITIES. UNDER NO CIRCUMSTANCES SHALL THE COMPANY BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, EXPENSES, LOSSES OR DELAYS HOWSOEVER CAUSED.

No statement, representation, agreement, or understanding, oral or written, made by any agent, distributor, representative, or employee of the Company which is not contained in this Warranty will be binding upon the Company unless made in writing and executed by an officer of the Company.

This warranty shall not be effective as to any claim which is not presented within 30 days after the date upon which the product is claimed not to have been as warranted. Any action for breach of this warranty must be commenced within one year after the date upon which the cause of action occurred.

Any adjustment made pursuant to this warranty shall not be construed as an admission by the Company that any product was not as warranted.

## **Warranty Registration**

Your DuroFlow blower has been designed and manufactured to provide continuous, trouble-free service, year in and year out.

Follow the simple maintenance procedures outlined in this manual and you will be assured of superior blower performance and years of dependable blower life.

Please register your DuroFlow Blower with our Factory Service & Warranty Department. Complete the warranty registration information below and fax it to Gardner Denver.

**Thanks again for the privilege of serving you with quality from DuroFlow.**

---

**Date:** \_\_\_\_\_

**Your Name:** \_\_\_\_\_

**Your Title:** \_\_\_\_\_

**Your Company:** \_\_\_\_\_

**Address:** \_\_\_\_\_

**City, State, Zip:** \_\_\_\_\_

**Telephone:** \_\_\_\_\_

**Blower Serial Number:** \_\_\_\_\_

**Date of Blower Start-up:** \_\_\_\_\_

**What is your application:** \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

## **NOTES:**



4400 Morris Park Drive  
Charlotte, NC 28227  
Phone: (704) 545-3922

Web: [www.suncopowder.com](http://www.suncopowder.com)  
Email: [info@suncopowder.com](mailto:info@suncopowder.com)  
Fax: (704) 545-8345