

Recommended Maintenance for Mycom Screw Compressor Units (SU)

ACTION		INTERVALS			
		Daily	At 2,500 Hrs. or 3 months	At 5,000 Hrs. or 6 months	At 10,000 Hrs. or year
Daily Inspections	Check and log pressures and temperatures	✓			
	Check oil level and oil filter pressure drop	✓			
	Record run time, motor amps, alarms and failures	✓			
	Check for unusual noise or vibration	✓			
Periodic Inspections	Leak test entire unit			✓	✓
	Check panel set points and calibrate sensors			✓	✓
	Check coupling alignment on compressor			✓	✓
	Check operation and settings for motor starters			✓	✓
	Vibration and oil analysis			✓	✓

Compressor Maintenance Guidelines

Compressor	Shaft Seal	Service when found leaking more than 10-12 drops per minute			
	Slide Valve Actuator			✓	✓
	Thrust Bearings: Check end float			✓	✓
	Thrust Bearings: Dismantle and check, replace if necessary	As needed based on vibration and oil analysis			
	Sleeve Bearings: Dismantle and check, replace if necessary				
Slide Valve Indicator	Verify correct operation and calibrate			✓	✓
Adjust Loading Rate	Set to load from 0% to 100% in 60 to 90 seconds.			✓	✓
Adjust Unloading Rate	Set to unload from 100% to 0% in 60 to 90 seconds.			✓	✓
Check Valves	Confirm proper operation, replace if defective				✓
Suction Strainer	Inspect and clean			✓	✓

Oil System Maintenance Guidelines

Adding/Removing Oil	Add oil with drum oil pump using oil fill connection on oil separator under pressure. Drain oil through oil filter housing or drain valves on separator.	As needed based on daily inspections			
Coalescer Element	Replace if pressure drop exceeds start-up pressure drop by more than 3 psi.	As needed based on pressure drop			
Oil Pump	Dismantle and check, replace parts if necessary			✓	✓
Oil Regulating Valve	Dismantle and clean			✓	✓
Oil Strainer / Filter	If oil filter pressure drop exceeds 15 Psid, clean or replace oil pump strainer and replace filter at oil inlet to the compressor. Record date and run time when these are replaced.	As needed based on daily inspections, pressure drop or oil analysis			
Oil Levels in Oil Separator	Operating Level: 1/4 to 1/3 of upper sight glass	✓			
	Stand-by Level: 1/2 of upper sight glass	✓			
	Minimum Level: oil visible in upper sight glass	✓			
	Maximum Level: not above 1/2 upper sight glass	✓			
	Coalescer end sight glass should be empty	✓			

These guidelines are recommended but it should be understood that the system conditions and the maintenance and operation of this equipment will affect its longevity. The compressor package should be inspected at least annually after the first 10,000 hrs. of operation to ensure safe and continuous service