

Triple and Dual Bagger P.M. List

Daily

- Check the scale for proper weight display. Use a known weight and check to ensure the scale is weighing properly. If not weighing properly then go through the calibration process.

Weekly

- Check gate slides for proper function, make sure the UHMW plastic guides are in operational shape and the gates move with ease and are not bent or damaged.
- Check mechanically the air solenoids in valve cabinet are working properly. The Festo brand of solenoid Weigtech uses has a little silver pin right below the wiring harness that when pushed actuates the solenoid and fires the air cylinder manually.
- Check seals on valve cabinet. Make sure all grommets are tight and the door on the cabinet seals properly to keep moisture from damaging components.
- On the indicator there is a rubber seal on the inside of the front half make sure the seal is inside the groove and make sure the seal is in good condition. Also make sure the screws on the corners are in good shape and are tight but do not overtighten. Check that the grommets on the bottom of the indicator are tight to the indicator and also the caps are tight to the wires. This helps maintain the best defense against moisture inside the indicator and on the control board.
- Check the wires coming from the valve cabinet to the indicator for cuts or tears that could cause interference or not to work at all.
- Check to make sure all wire landings are secure and that no connections have come loose or have been pulled loose.

Monthly

- Go through entire system to make sure all nuts are tight and all bolts are present.
- Grease bearings as needed.