# **Installation of Icarus Verilog and GTKWave**

## Install the tools according to your environment:

- Windows 10/8/7
  - Icarus Verilog and GTKWave
    - ◆ Download page: <a href="http://bleyer.org/icarus/">http://bleyer.org/icarus/</a>
      - 64bit: iverilog-10.1.1-x64\_setup.exe [9.77MB]
      - 32bit: iverilog-10.0-x86\_setup.exe [11.1MB]
      - Install with administrator

#### Ubuntu 18.04


- Icarus Verilog and GTKWave
  - sudo apt-get install verilog gtkwave

### macOS

- Icarus Verilog
  - brew install icarus-verilog
  - Note: brew(Homebrew) install refer to <a href="https://docs.brew.sh/Installation">https://docs.brew.sh/Installation</a>
- GTKWave
  - ◆ Only GUI
    - Download page: <a href="http://gtkwave.sourceforge.net/">http://gtkwave.sourceforge.net/</a>
    - Download link: <a href="http://gtkwave.sourceforge.net/gtkwave-3.3.99.tar.gz">http://gtkwave.sourceforge.net/gtkwave-3.3.99.tar.gz</a>
  - ◆ Use GTKWave on the command line
    - sudo port -v install gtkwave
    - Note: port(MacPorts) install refer to <a href="https://www.macports.org/install.php">https://www.macports.org/install.php</a>

## Verify your installation:

- Files:
  - add.v
  - ♦ add tb.v
- Command:
  - iverilog –o add\_tb.vvp add\_tb.v add.v
  - vvp add\_tb.vvp
  - gtkwave add\_tb.vcd



 More installed information refer to <u>https://iverilog.fandom.com/wiki/Installation\_Guide</u>