NZL: 0800 776 869
E: info@trackme.life
Web: www.trackme.life

Instructions for Spot Messenger Generation 3

This unit has 5 functions which can be operated directly from the unit.

- Firstly, the power button for the unit is located at position 1, top left of the unit.
  - To turn on press and hold the power button (1) until all lights to flash in rotation and start the unit up. The power button (position 2) will flash green, if it flashes red the batteries should be replaced. ONLY 4x ENERGISER LITHIUM OR ENELOOP PRO RECHARGEABLE AAA BATTERIES ARE TO BE USED IN THIS UNIT.
  - To turn off press and hold the power button (1) until the power light (2) flashes rapidly.
- Once turned on the tracking needs to be activated by pushing the footprint button for 5 seconds until it lights up (7). The unit will revert to tracking mode even if other buttons (6 or 8), are pushed to send messages.
- Once done your unit does not need to be touched again, for 7 Days or less the unit will run continuously and has a motion detector built in. If you turn your unit off, you need to restart it as above.
- To send any of the messages a firm push for 5 seconds is required, and the green-light will show. Once the message has successfully sent the unit will revert to tracking mode.
- Lights at positions 3 & 4 are for GPS (3) and message sending (4) these lights should be green for optimal operation and longer battery life. If they are red move the unit to a better view of the sky with the Spot® logo directly up.
  - The best location for these units is high up on the shoulder attached to a pack strap. The unit logo (Spot®) is the transmitter.
- SOS (5) and Help (9) buttons are covered by flaps to prevent accidental activation.
  - Activate Help (9) will send this message to your emergency contacts – "I need HELP at this location, unable to continue please arrange transport - Non-Urgent. No cell coverage."
  - Activate SOS (5) in event of medical assistance or direct threat to life for you or another person. – "I require immediate Medical support at this location." this message will be sent to your emergency contacts and NZRCC (TrackMe Rescue and Response Centre).
  - You can cancel these messages by pressing the button until they flash red, if the emergency is genuine do not cancel this or turn the unit off until the rescue services have arrived.
  - If HELP or SOS are activated, once the emergency has been cleared the unit needs to be switched off and restarted with tracking active.
- Ok Message (6) has a default setting of "Checking in all OK" and is sent to your contacts.
- Custom message (8) is only configured on request and is set at present as "I am checking out for the day, all OK. TrackMe GPS Safety"



Choose TrackMe NZ Trackers to monitor your adventures