# Index

## **Numbers and Symbols**

chargingcontrol lamps	328 330
disconnect and connect	328
electrolyte level	328
replacement	328
A	
ACC	180
Accessories	351
Activating CUPRA CONNECT	245
Adapting the playback volume	261
Adaptive Cruise Control	180
control and warning lamp	185
malfunction	185
operation	181
special driving situations	183
status display	181
System limitations	184
Adjust	
date and time	20
front seats	114
headrest	117
lights	125
seat with memory	118
seats	38
Adjusting the seat belt	44
Air conditioning	135
air recirculation	140
controls	137

rear controls	139
refrigerant oil	358
setting the temperature	139
stationary air conditioning	146
troubleshooting	145
vehicle fluids	358
Air recirculation	140
Airbag system	48
activation	50
control lamp	50
deactivation of the front airbag	52
description	49
front airbags	51
how it works	50
Airbags	48
activating and deactivating	52
centre	. 53
description	49
for the head	55
front	51
side	54
Android Auto™	
disconnecting	253
establish connection	253
menu	252
requirements	252
special characteristics	253
Anti-lock system	166
Anti-theft alarm	101
interior monitoring and anti-tow system	101
trailer	297
Anti-theft alarm system	101
Anti-trap function	
windows	111
Antifreeze	322

Apple CarPlay	
disconnecting	252
establish connection	252
menu	252
requirements	252
special characteristics	252
Applications (apps)	251
Approved spare parts	345
Area View system	173
Aspects to think about before starting the vehic	cle
Assistance call	68
Assistance systems	
adaptive cruise control	180
area view system	173
Auto Hold function	207
Automatic Parking System Plus	218
automatic parking system Plus with remote	
function	223
cruise control	174
driver attention monitor	
drowsiness monitor	21
Emergency Assist	199
emergency braking (Front Assist)	188
front camera	171
front radar	170
general notes	170
lane departure warning (Side Assist)	200
parking aid Plus	209
peripheral view system (Top View Camera) .	229
PreCrash system	
predictive speed adjustment	185
rear radar	172
road signs detection system	26
safety advice	170
speed limiter	175

speed limiter with proactive speed adjustment	Automatic parking system plus with remote	Break recommendation
	function	see Driver attention monitor
system limits	app 224	see Drowsiness monitor
Travel Assist	driving to a parking space	
tyre pressure monitor indicator 342	exiting a parking space	С
tyre pressure monitoring	synchronise	C
ultrasound sensors	Automatic parking system Plus with remote	Camera
Assisted start	function	cleaning the vehicle
Audible warning	Average fuel consumption	Car2X
lights		Car2X communication 240
unbuckled seat belt	D	Car2X limits
Audio warning signals	В	connecting and disconnecting 241
warning and control lamps	Background lighting	troubleshooting 243
Auto Hold	Backrest of the rear seat	Central armrests
Auto Hold function	folding	Central locking 97
Auto Lock (central locking)	raise	anti-theft alarm 101
Auto Unlock	Bag hooks	auto-locking due to involuntary opening 97
Automatic car wash	Battery	central locking button
disconnecting the Auto Hold function 207	Before starting the vehicle	emergency lock
Automatic dipped beam headlight control 120	Belt force limiter	Keyless Access system 94
Automatic parking system	Belt tightening	remote control key 98
angle parking	Bicycle carrier	Change a bulb
description	fitting onto the coverable tow hook 302	Change the wiper blades
leaving a parking space (only when parallel	max. load rating	Changing a wheel
parked)	Blown bulbs	raise the vehicle
parallel parking	change a bulb	subsequent work
parking conditions	Brake fluid	wheel nuts
stop early	Brakes	Changing parts
Automatic Parking System Plus	brake fluid	Changing the battery
display and edit	brake servo	of the vehicle key 93
driving from a parking space	braking assistant	Charging socket
driving to a parking space	electronic parking brake 205	Charging stations
parking as a navigation destination	new brake pads	navigation
programming	Braking assistant	Charging the high-voltage battery
programming	Braking system	charging modes
	warning lamp	charging process display 80
	Brands	emergency unlocking

Connectivity	Cooling system
WLAN access point 249	check the coolant 323
Control and warning lamps	control lamps
12-volt battery	refilling coolant
ACC	Copyright
adaptive cruise control	Cornering light
air conditioning	Correct position
airbag system 50	driver
airbags	passenger 39
anti-lock brake system ABS 168	Cruise control
braking system	Cruise control system
coolant	control lamps
cruise control	operating 175
cruise control (GRA)	CUPRA Assistant
drive system	end
dynamic chassis control (DCC) 164	start
electromechanical steering 161	wake word:
ESC	CUPRA CONNECT 243
ESC in Sport mode	activation
ESC off	CUPRA ID
high-voltage battery 81	deactivate
high-voltage system 81	faults 246
Lane Assist	legal provisions
lane departure warning (Side Assist) 201	users
lights	CUPRA ID
parking brake	Current documentation attached 254
press on the brake	Cybersecurity
seat belt	
speed limiter	D
steering column	
	Dangers of not using the seat belt
	Data label
tyre pressure monitor system	Data transfer
wipers	Deactivating CUPRA CONNECT services 246
Controls on the steering wheel	Deactivation of the front airbag
Cooling	Digital Cockpit
	WLAN access point         249           Control and warning lamps         12-volt battery         330           ACC         185           adaptive cruise control         181           air conditioning         145           airbag system         50           airbags         52           anti-lock brake system ABS         168           braking system         166           coolant         325           cruise control         175           cruise control (GRA)         174           drive system         153,157,159           dynamic chassis control (DCC)         164           electromechanical steering         161           ESC         168           ESC in Sport mode         168           ESC off         168           high-voltage battery         81           high-voltage system         81           Lane Assist         193           lane departure warning (Side Assist)         201           lights         120           parking brake         206           press on the brake         180           seat belt         41           speed limiter         176           <

Disposal	Driving	Electronic Stability Control (ESC)
seat belt tensioners	driving on flooded roads	Emergencies 67
Door cylinder	economical	changing a wheel
Door handle	loaded vehicle	changing the battery 328
Door lock	Racestart program	emergency vehicle towing
Door opening assist (Exit Warning) 232	safe 37	hazard warning lights 66
Doors	trips abroad	jump leads
electric child lock	with the luggage compartment open 150	replace a blown fuse
Download	with trailer	vehicle tool kit
over-the-air updates	Driving mode	Emergency Assist
Drink holder	Driving on flooded roads	problems and solutions
bottle holder	Driving profiles	see Emergency Assist
front	Racestart program	status display
in the rear central armrest 235	Driving with a loaded vehicle	Emergency brake assistance system (Front Assist)
Drive profile	Driving with the luggage compartment open 150	
Drive Profile	Drowsiness monitor	activating and deactivating
Drive profiles	settings 22	dodge assist
selecting a profile	system limits	pedestrian and cyclist recognition 189
Drive system	troubleshooting	status display
brake energy recuperation	warning levels	system limitations
connecting	Duplicate keys	temporarily deactivating
control lamps	Dust and pollen filter	turn-off assist
e-Sound	Dynamic headlight range control	warnings
electronic immobilizer		Emergency braking warning
functions	E	Emergency call
gear selector	E	troubleshooting
leaving the vehicle with the drive system	e-Call	Emergency call service
switched on	Easy Open	Emergency locking of the front passenger door
recuperation of braking energy with the steering	special characteristics	
wheel levers	Eco Assistance	Emergency opening
switching off	Electric devices	driver's door
Driver attention monitor	Electric motor data	Emergency operation
settings 24	Electrolyte	front passenger door
system limits	Electronic differential lock	Energy
troubleshooting	Electronic immobilizer	saving
warning levels	Electronic parking brake	
	control lamps	

Engine coolant	Front bonnet 3	318	Headlight range control	125
check the level	opening and closing	321	Headlights	
exterior	Front camera	171	change a bulb	317
specifications	Front compartment		trips abroad	125
Environment	battery 3	327	Headrest	116
environmental compatibility 359	brake fluid 3	325	adjust	117
recycling of electrical appliances 360	coolant 322, 3	323	removing	117
ESC	opening and closing	321	Heating	135
connecting and disconnecting 168	safety instructions 3	318	High-voltage battery	
electronic stability control (ESC) 166	windscreen washer reservoir	326	bidirectional charging	88
Sport mode	Front passenger airbag		care	75
Event Data Recorder	control lamp	50	charging settings in the infotainment system	86
Exit Warning	Full Link	250	charging with a home energy management	
Exiting a parking space	applications	251	system	89
with the automatic parking system 217	settings 2	251	general settings	87
Exterior lighting	symbols 2	251	safety instructions	. 73
change a bulb	Full-LED headlights	317	solar energy charging	90
Exterior mirrors	Fuses	313	warning lettering	73
driving with a trailer	colour coded 3	314	High-voltage battery charging cable	90
folding	fuse box	315		
heated	preparations for replacing fuses 3	315	I .	
settings	recognise blown fuses 3		•	
External antenna	replace 3	JIJ	i-Size	60
External audio sources			Indicator lamps	
adapting the playback volume 261	G		overview	
			Information call	
F	Gear selector	158	Infotainment	
•	Glass roof		adapt menus	
Fabrics: clean	sunshade blind		Android Auto™	
Factors that have a negative influence on safe	Glass roof sun blind		Apple CarPlay	
driving	Glove compartment	234	assist systems and vehicle settings	
Fastening rings			before first use	
Filling capacities	H		clean	
window washer water		cc	connecting and disconnecting	
Fire 67	Hazard warning lights		customise	
Frequency bands	Head-on collisions and the laws of physics		customised menus	
	Head-up-Display (HUD)	TR	departure menu	

status display 19 spare key 92 fog light status display 15, 19 synchronise 94 headlight range control unlock and lock 98, 103 instrument lighting 126 vehicle key 92 interior lights leaving home main beam assist
--

main beam headlight lever	122	Malfunction	save destination
main beam headlights	120	adaptive cruise control	saved data
reading lights	126	PreCrash system	saved destinations
side lights	120	towing device	select charging stations
switching on and off	120	Mats	suggestions
turn signal lever	122	Mechanical door opening 102	symbols
Loading the luggage compartment		Media Mode	traffic reports
fastening rings	291	equipment	updating navigation data
Loading the vehicle		symbols	use contact details
general advice	288	Memory function	Noise
luggage compartment	288	Microfiber: clean	brakes
positioning the load	288	Mirrors	parking brake 205
positioning the luggage	288	adjusting the exterior mirrors	tyres
roof carrier system	294	anti-dazzle 131	Number of seats
trailer	298	Mobile phones	
trapdoor for transporting long objects	292	Mobility Service	0
Lock and unlock	94	Multimedia	0
in the locking cylinder	103	favourites	Odometer
with the central locking button	99	play 271	partial
Luggage compartment	288	select source	total
electric opening and closing	106		On-board toolkit
enlarge	115	N	One-touch signalling function
features of the electric rear lid	107	N	Online services
luggage compartment lighting	126	Navigation	Opening
opening and closing controlled by sensors (Ea	asy	decrease the navigation map	bonnet
Open)	108	edit route	rear lid
removing and fitting the shelf	289	enter an address for a guide destination 276	windows
variable luggage compartment floor	290	favourite destinations 277	Opening and closing
Luggage compartment floor	290	function: entering destination	bonnet
Lumbar support	114	functions	by remote control 98
		increase the navigation map 274	doors 102
M		learn usage pattern	in the locking cylinder 103
M		limitations	mechanical door opening 102
Main beam assist	123	navigation announcements	rear lid 106
Main beam headlight lever	122	operating the navigation map	rear lid with electric opening and closing 106
		recent destinations	sunshade blind
		route details	

windows 109	Parking systems	Radio 2	266
with the central locking button	automatic brake operation	equipment 2	267
Operation in winter	reverse assist (Rear View Camera) 226	frequency bands	267
salt on the roads	troubleshooting	preset buttons	267
snow chains	Partial odometer	symbols	267
tyres 337	Pedals 39, 149	Traffic information (TP) 2	268
Original accessories	Peripheral view system (Top View Camera) 229	tune station 2	267
Over-the-air updates	menus	type of reception	267
download 239	modes	Radio mode	266
installing software	special characteristics	Radio screen: clean	349
requirements	usage instructions	Radio telephones 3	352
Overview	Places with risk of explosion 282	Rain and light sensor	129
of warning and control lamps 11	Places with special regulations 282	Rain sensor	
overview (left hand drive) 9	Power display	function control	129
overview (right hand drive) 10	Power sockets	Raise the vehicle	340
view of the vehicle from inside 8	trailer 297	Rear Cross Traffic Alert	231
view of the vehicle from the front 6	Power windows	Rear Cross Traffic Alert (RCTA)	231
view of the vehicle from the rear	PreCrash system	Rear fog light	
	Front Assist monitoring system 47	control lamp 1	120
P	malfunction	Rear lid	105
	selecting the driving profile	Rear mounting	
Painting the vehicle	status display	towing device	303
care 348	Predictive speed adjustment 185	Rear radar 1	172
Park assist	activation	Rear View Camera 2	226
fault	driving 186	Rear window wiper 1	128
operating	limitations	Releasing the seat belt	43
parking aid plus	troubleshooting	Remote control key	
see the Automatic Parking System 213	Privacy 247	unlock and lock	98
sensors and camera: clean	settings 247	Repair work 3	351
surroundings warning	Private emergency call service 68	Requirements for Apple CarPlay 2	252
visual indication		Rev counter	15
Parking	R	Reverse assist	
at an angle with the reverse assist		Reverse assist (Rear View)	226
with the automatic parking system 216	Racestart	angle parking 2	
	Racestart Program	check list 2	
	Radar sensors	connecting and disconnecting 2	227

cross traffic	Safety instructions	memory function	118
requirements	central airbag 53	number of seats	39
settings 228	head-protection airbags 55	removing the headrest	117
shown on the display	seat belt tensioners	ventilation	142
usage instructions	side airbags 54	Selling the vehicle	246
Reverse assist system	using child seats	Service	
Road signs	using seat belts	Digital Maintenance plan	344
shown on the display	Screen	inspection	344
Road signs detection system	clean	proof of Service	344
how it works	Seat belt height adjustment	service packages	345
limited operation	Seat belt tensioners	service works	
settings	control lamp 50	terms of use	345
shown on the display	Seat belts	Service interval indicator	20
troubleshooting	adjusting the seat belt	Service intervals	. 21
warning levels	adjustment 43	Service Menu	
windscreen damage	automatic retractor, tensioner and belt force	restart Trip	20
Roof carrier	limiter	service interval indicator	20
fix the crossbars	control lamp	vehicle identification number	20
Roof carrier system	maintenance and disposal of seat belt	Service Mobility	346
Roof rack	tensioners	Set of vehicle keys	92
Rotation direction	protective function	Snow chains	338
tyres	purpose	Sound settings	260
Running in	safety instructions	Spare parts	351
new brake pads	seat belt height adjustments	Special characteristics	
new tyres	unfastened	Android Auto™	253
	Seat heating	Apple CarPlay	252
c	Seat ventilation	high pressure cleaning equipment	301
S	Seats	peripheral view system (Top View Camera) .	230
Safe 99, 156	adjusting the headrests	trailer mode	299
Safe driving	armrest	Speed limiter	175
Safe security system	backrest of the rear seat	control lamps	176
troubleshooting 100	electric settings	indication on display	
Safety	fitting the headrest	operating	
child safety 56	heating	Speed limiter with proactive speed adjustment	
child seats	incorrect positions		
safe driving	manual adjustment	troubleshooting	
Safety equipment	•	3 · · · · · · · · · · · · · · · · · · ·	-

Speed symbol	333	Energy recuperation levers	159	vertical load on the tow hitch	294
Stabilisation of the towing vehicle and trailer		heating	144	weights	366
combination 30	00	Steering wheel heating	144	Technical modifications	352
Stationary air conditioning 1	.46	Storage compartment	234	Telephone	
activate 1	147	glove compartment	234	connecting	283
connecting 1	.46	on-board documentation	234	contacts	285
programming 1	147	Storage compartment accessories		favourites	285
switching off 1	.46	see Storage	234	pairing a mobile phone	283
Status display		Storage of accident data	357	phone book	285
adaptive cruise control 1	181	Storing objects	288	send messages	284
date and time	20	bag hooks	291	speed dial buttons	285
doors, front bonnet and rear lid open	19	fastening rings	291	switching off	282
Drive Profile	L62	loading the trailer	298	to call	284
Eco Assistance	179	positioning the load	288	Telephone interface	281
Emergency Assist 1	.99	positioning the luggage	288	equipment	281
Emergency brake assistance system (Front		roof carrier	292	places with risk of explosion	282
Assist)	.88	roof carrier system 292,	, 294	symbols	281
instrument cluster	19	trailer	294	Time	
odometer	19	trailer mode	299	adjust	. 20
outside temperature	19	trapdoor for transporting long objects	292	Top Tether	. 63
PreCrash system	48	Sun blind	133	Top Tether System	. 63
range	19	Sun protection	133	Top View Camera	
road signs	26	Switching off		see the Peripheral view system (Top View	
service intervals	21	telephone	282	Camera)	229
speed limiter	175	Switching the ignition on/off	154	Torque	
speed warning	19	Symbols		wheel nuts	341
Travel Assist	94	see Warning and control lamps	. 11	Touch screen	257
tyre pressure monitoring	342	System settings	260	Touch zones	257
warning and information messages	20			Tow cable	, 297
Steering		т		Tow hook	
control lamp 1	161	1		control lamp	301
electromechanical steering	161	Tail lights		unlocking electrically	301
Steering wheel		change a bulb	317	Towable loads	
adjust	113	Technical data		loading the trailer	298
controls	112	electric motor data			
		vehicle dimensions	368		

Towing device		unlocking the tow hook electrically 30	801	tread wear indicators	335
fitting a bicycle carrier	302	vertical load on the tow hitch 294, 29	98	tyre pressure	334
fitting later	303	Trailer mode		useful life	334
malfunction	297	see Trailer 29	94		
tow hook with electric unlocking	301	Transportation of children 5	56	U	
Towing the vehicle		Trapdoor for transporting long objects 29	92	U	
emergency towing	310		94	Ultrasound sensors	173
front towline anchorage		connecting and disconnecting	.96	Unlock and lock	94
prior steps		lane change assist	197	by remote control	98
rear towline anchorage		_	.98	doors 1	102
tow bar	309	see Travel Assist	94	with the central locking button	99
tow cable		status display		USB	253
towing prohibited		Trips abroad		USB port	253
Traction control		headlights		User administration	248
Traffic information		Troubleshooting			
Traffic information (TP)		3	00	V	
Traffic programme		Travel Assist	98	•	
see TP (traffic information)	268	Turn signal lever		Vanity mirror	133
Trailer		Turning off the lights	20	Variable luggage compartment floor 2	290
adjusting the headlights			20	Vehicle	
anti-theft alarm		Tyre pressure		data label 3	366
connecting		Tyre pressure monitor system		electric motor data	367
exterior mirrors		Tyre pressure monitor systems	7-7-5	identification data 3	366
hitching			342	interior view	. 8
LED tail lights		Tyre profile		lending or selling 2	246
_		Tyre tread depth		overview (left hand drive)	. 9
loadingmalfunction				overview (right hand drive)	10
		Tyre wear		raise 3	340
power socket		Tyres		unlocking and locking (Keyless Access)	94
retrofitting a towing bracket				vehicle ID number 3	366
stabilisation of the towing vehicle and trailer		change		view from behind	. 7
combination		directional tread pattern		view from the front	. 6
tail lights		for winter		Vehicle care	
technical requirements		foreign objects inserted	332	wiper blade service position	305
tow cable	,	new tyres		Vehicle conservation	
towable loads		snow chains	338	Vehicle conservation products	
trailer mode	299	speed symbol		Vehicle dimensions	
				verificie difficiatoria	500

Vehicle information       35         Vehicle location       246         Vehicle seats       39         Vehicle settings       33         Vehicle sound       157         Vehicle tool kit       305         Ventilation       135         Vertical load on the tow hitch       294         loading the trailer       298         Voice control       Android Auto™       253         Siri™ (Apple CarPlay™)       252         Volume       set for external audio sources       261	Wheels change changing new wheels removing and attaching snow chains wheel nuts Window controls Window washer system Window washer system Check filling quantities refill Windows	335 333 341 338 336 109 326 326 326 326 109	Wiper and rear window wiper blades cleaning the vehicle service position Wiper blades cleaning the vehicle replacement WLAN	306 306
W       Warning lamps     11       overview     11       Warning triangle     66       Warshing the vehicle     354       cleaning the exterior     348       high pressure cleaning equipment     347       interior cleaning     349       special care     349       special characteristics     108       Weights     366       Wheel balance     334       Wheel nuts     336       anti-theft device     339       caps     339       loosen     339       torque     341       Wheel spanner     305	anti-trap function automatic opening/closing automatic operation comfort close function comfort open function Windscreen heating Windscreen heating Windscreen washer Windscreen wipers control lamps lift the blade rain and light sensor reposition the blade service position special characteristics wiper lever Winter tyres	110 110 109 109 144 144 128 129 305 129 305 129 305 128 128		

SEAT S.A. is permanently concerned about continuous development of its types and models. For this reason we ask you to understand, that at any given time, changes regarding shape, equipment and technique may take place on the car delivered. For this reason no right at all may derive based on the data, drawings and descriptions in this current handbook.

All texts, illustrations and standards in this handbook are based on the status of information at the time of printing. Except for error or omission, the information included in the current handbook is valid as of the date of closing print.

Re-printing, copying or translating, whether total or partial is not allowed unless SEAT allows it in written form.

SEAT reserves all rights in accordance with the "Copyright" Act.

All rights on changes are reserved.



© SEAT S.A. - Reprint: 15.11.24



TAVASCAN English

Edition: (11.24) 5FL012720AC



5FL012720AC