

RvTK — Full Tool Documentation

Version: 0.9.2.1

Supported Revit Versions: 2022, 2023, 2024, 2025, 2026, 2027

Contact: RvTK.info@gmail.com

Add-in ID: 53b4cbeb-3c1e-42a8-bece-bdd89a590993

Contents

1. Overview
 2. Installation & Trial Period
 3. Settings
 4. RvTK Command Centre
 5. Utilities Panel
 6. BIM Suite Panel
 7. Tools Panel
 8. Structural Suite Panel
 9. Standards & CDE Panel
 10. Experimental Panel (WIP)
 11. Feedback Panel
 12. Tips & Notes
-

Overview

RvTK is a Revit add-in for structural engineering and BIM workflows. It adds a dedicated **RvTK** ribbon tab to Revit, containing seven panels covering quality assurance, drawing management, structural tools, standards links, and CDE integrations.

All tools are accessible from the **RvTK** ribbon tab. Some tools are available from the Revit Start screen (no open document required); most require an open project.

Icons across each panel are colour-coded by panel. You can customise these colours in **RvTK Settings** → **Appearance**.

Installation & Trial Period

Installation

Run RvTK installer.exe and follow the prompts. Restart Revit after installation.

Development Trial

RvTK is distributed under a 35-day development trial. During this period all tools are fully available. When the trial expires, tools are disabled — contact RvTK.info@gmail.com to discuss continued or team access.

- No activation key is required during the trial period — the add-in runs fully featured from the moment it is installed.
- To continue using RvTK after the trial ends, get in touch at RvTK.info@gmail.com.

Settings

Button: RvTK Settings — Utilities panel

Availability: Available at the Revit start screen (no document needed)

Opens the RvTK Settings window with the following tabs:

Tab	Contents
General	Default behaviours, startup toggles
Appearance	Per-panel ribbon icon colour (hue picker per panel)
Licence	Trial status, licence key entry
Custom Links	Configure up to 8 custom reference links for the Standards & CDE panel
Pile Parameters	Configure the parameter names used by Pile Coordinates (Easting, Northing, Elevation, Mark)
Tab Colours	Customise the Tab Colouring light and dark palettes

Panels that can be hidden: Structural Suite and Experimental can be toggled off in Settings → Appearance if not needed.

RvTK Command Centre (Dockable Panel)

Button: RvTK — top of the Utilities split button

Availability: Always (including Revit start screen)

The Command Centre is a dockable panel that docks alongside the Revit Properties or Project Browser panels. It provides:

- Quick-access buttons for frequently used commands
- Navigation shortcuts (Find Sheet, Find View, Find Parent View)
- Drawing/display tools (Orient Section Box, Orient View, Dimension Grids/Levels, Flip Grids/Levels)
- Selection tools (Pick Detail Elements, Pick Model Elements, Pick Linked Elements)
- Measurement tools (Line Length, Volume, Count Rebar, Point Delta)
- DWG tools (Greyscale DWG, Revert Greyscale, Open DWG, Reload DWG, Hide DWG Layer)
- Sheet navigation (Page Back / Page Forward — walks through sheets in natural sort order)

How to use: Click the RvTK button to toggle the panel open or closed. Drag it to dock anywhere in the Revit interface.

The Command Centre hosts tools that are not on the ribbon — if a tool is missing from the ribbon, check the Command Centre first.

Navigation Tools (Command Centre)

Tool	Description
Find Sheet	Switches the active view to the sheet that hosts the current view. Shows a message if the view is not placed on any sheet.
Find View	Opens the view behind a selected (or clicked) viewport on a sheet. With multiple viewports selected, shows a picker.
Find Parent View	If the active view is a dependent view (crop region), jumps to its primary view.
Page Back / Forward	Navigates to the previous or next sheet, sorted by sheet number (natural sort — e.g. S-01, S-02, S-10 rather than S-01, S-10, S-02).

Open Sheet — search for and open any sheet by number or name. Open View — search for and open any view by name. Open Parent View — navigate to the sheet or parent view containing the active view. Orient Section Box — rotate a 3D view's section box to face its own normal. Orient View — orient the active 3D view to look directly at a picked face. Page Backward / Page Forward — step through sheets in Project Browser order.

Drawing & Display Tools (Command Centre)

Tool	Description
Orient Section Box	Rotates the 3D section box to align with a picked face. Pick any model face.
Orient View	Sets the 3D view direction to look straight at a picked face.
Dim Grids	Automatically places linear dimensions across grid bubbles in the active view.
Dim Levels	Automatically places dimensions on level elevations in a section or elevation view.
Flip Grids	Flips grid bubble text (alternates head/tail ends) in the active view.
Grid Bubble Ends	Toggles grid bubbles between one end and both ends.
Flip Levels	Flips level text orientation in the active view.

Dimension Gridlines — auto-place dimensions across all gridlines in the active view. Dimension Levels — auto-place dimensions across all levels in the active view. Flip Grid Bubbles — toggle which end of selected grids shows a bubble. Flip Level Bubbles — toggle which end of selected levels shows a bubble. Toggle Grid 2D/3D — switch selected grids between 2D and 3D extents.

Selection Tools (Command Centre)

Tool	Description
Pick Detail Elements	Selects all 2D detail elements (detail lines, filled regions, text, symbols) visible in the active view.

Pick Model Elements	Selects all 3D model elements visible in the active view.
Pick Grouped Elements	Selects elements that belong to a group.
Pick Linked Elements	Selects elements from linked models visible in the active view.

Pick Detail Elements — select only detail-level elements from a window selection. Pick Model Elements — select only model elements from a window selection. Pick Grouped Elements — select all members of any groups in a window selection. Pick Linked Elements — select elements from Revit link instances in the active view. Select Untagged — select all elements in the active view that lack a tag. Tag Matcher — colour-code tags and the elements they tag for visual verification. MWrite / MRead / MAppend / MDelete — named selection memory slots for saving and restoring element selections across commands.

Measurement Tools (Command Centre)

Tool	Description
Line Length	Measures and displays the total length of selected lines or curves.
Volume	Calculates and reports the total volume of selected elements.
Count Rebar	Counts rebar in the selection and reports quantities by mark and bar size.
Point Delta	Pick two points to get the X, Y, Z and total distance between them.

Line Length — sum total length of selected curve elements (detail lines, model lines). Volume — sum total volume of selected host elements (walls, floors, columns) in m³. Count Rebar — tally rebar quantities from selected text notes or rebar tags. Point Delta — measure the horizontal distance, vertical offset, total distance, and bearing between two picked points.

DWG Tools (Command Centre)

Tool	Description
Greyscale DWG	Converts a selected DWG import/link to greyscale for printing.
Revert Greyscale	Reverts a greyscale DWG back to its original colours.
Open DWG	Opens the selected DWG file in an external editor (AutoCAD or default handler).
Reload DWG	Reloads the selected DWG from disk to pick up external changes.
Hide DWG Layer	Hides specific layers within a DWG import/link.

Grey Scale DWG — convert a selected DWG import/link to greyscale overrides. Revert Grey Scale — remove greyscale overrides from a DWG. Open DWG in AutoCAD — open the source DWG file directly in AutoCAD. Reload DWG — reload a DWG link from disk. Hide DWG Layer — hide a specific layer in a selected DWG import. Open Forma (EU / GBR) — open ACC / Forma in a browser. Open Central / Local Model Location — open model folders in Windows Explorer.

Utilities Panel

The Utilities panel (neutral/greyscale icons) contains global app controls.

RvTK Split Button

RvTK (Command Centre Toggle)

What it does: Opens or closes the RvTK Command Centre dockable panel.

How to use: Click once to open, click again to close.

Documentation

What it does: Opens the RvTK documentation.

How to use: Click to open.

RvTK Settings

What it does: Opens the full RvTK Settings window (see [Settings](#) above).

How to use: Click to open.

Stacked Buttons

Light / Dark Mode

What it does: Instantly switches Revit's UI theme between Light and Dark. Works on Revit 2024+. The button icon updates to show the current state (sun = currently dark, click for light; moon = currently light, click for dark).

How to use: Click to toggle the theme.

Note: Requires Revit 2024 or later. A message is shown on earlier versions.

Sync Views

What it does: A toggle that synchronises the zoom level across views. When enabled, switching from one view to another carries the current zoom rectangle across — useful for keeping multiple plans or sections at the same scale/position as you navigate.

How to use: Click to enable (icon turns coloured); click again to disable (icon turns grey).

Note: State is saved between Revit sessions — it will restore as active on next startup if it was enabled when Revit closed. Syncs plan → plan, section → section, and sheet → sheet. Does not cross between model space and sheet space.

Tab Colouring

What it does: Assigns a unique background colour to each open document's view tabs in the Revit UI. Makes it easy to identify which document a view belongs to when multiple models are open. Supports separate light and dark colour palettes (customisable in Settings).

How to use: Click to enable; click again to disable. Colours refresh automatically when documents are opened or closed.

Note: State is saved between Revit sessions.

BIM Suite Panel

The BIM Suite panel (teal icons) contains quality assurance, view management, schedule/DWG tools, and document transmittal tools.

Model Guardian Split Button

Model Guardian

What it does: Opens the Model Guardian window — a dashboard showing recently opened Revit models, filtered to the current Revit version. Displays local path, central path, last open date, and warning count at the time of opening. Allows you to re-open any listed model directly.

How to use: Click to open. Available from the Revit start screen — no open document needed.

Note: Model Guardian records are automatically updated in the background each time a document is opened. Warning counts are captured at open time.

Model Health Check

What it does: Scans the open model for common issues — duplicate elements, orphaned elements, and invalid/corrupt elements. Provides a summary report with element counts. Offers an option to isolate problem elements in a 3D view for inspection.

How to use: Click to run. Review the results window. Click **Isolate** to open a 3D view with flagged elements isolated.

Requires: Open project.

Clash Detection

What it does: An interactive clash detection tool that checks for geometric collisions between selected elements or categories. Identifies element-to-element intersections within the model (including linked models).

How to use: Click to open the Clash Detection window. Select the categories or element pairs to check, then run the clash scan. Review results in the list; click a result to navigate to the clash.

Requires: Open project.

Internal Comments

What it does: Lists all TextNote elements in the model that are marked as "Internal Comments" (flagged by content prefix or a dedicated parameter). Displays them with priority levels — P1 (red), P2 (amber), P3 (green) — so outstanding model notes and coordination comments can be tracked and resolved.

How to use: Click to open. Review the list; click a row to navigate to the comment in the model. Resolve or delete comments directly from the panel.

Requires: Open project.

Spelling Auditor

What it does: Spell-checks all TextNote elements in the model. Detects misspellings and duplicate consecutive words using a built-in dictionary. Reports issues with the offending text and its location.

How to use: Click to run. Review the results list. Double-click a result to navigate to the TextNote. Correct the spelling directly in Revit.

Requires: Open project.

Align Viewports Split Button

Align Viewports

What it does: Aligns multiple viewports on a sheet using a reference grid. Ensures consistent viewport positioning across sheets — particularly useful for matching viewport origins when multiple sheets share the same grid layout.

How to use: Open the sheet containing the viewports to align. Click **Align Viewports**. Select a reference viewport, then select the viewports to align. The tool repositions selected viewports to match the reference.

Requires: Open project. Active view must be a sheet.

Transfer View Filters

What it does: Copies view filter settings (visibility/graphics overrides, filter rules) from one source view to one or more target views. Saves the manual effort of re-applying the same filter configuration to multiple views.

How to use: Click to open. Select the source view. Select the target views. Click **Transfer**. Filters and their override settings are copied.

Requires: Open project.

Sheet Generator

What it does: Creates multiple sheets at once from a pasted list of sheet numbers and names. Supports tab-delimited input (SheetNumber[TAB]SheetName) copied directly from Excel. Optionally parses ISO 19650 7-part or 8-part drawing numbers and pre-fills discipline, originator, and other titleblock parameters automatically.

How to use:

13. Click Sheet Generator.
14. Paste your sheet list (tab-delimited, one sheet per line) or type the numbers/names manually.
15. Select a titleblock family.
16. Click **Create Sheets**.

Tip: Copy a two-column table from Excel (Sheet No. | Sheet Name) and paste directly into the window.

Requires: Open project.

Viewport Manager

What it does: A batch editor for viewports placed on sheets. Allows editing of Detail Number, View Name, Title on Sheet, and sheet placement for multiple viewports simultaneously — without having to open each sheet individually.

How to use: Click to open. The grid lists all placed viewports. Edit cells directly; changes are committed on confirm.

Requires: Open project.

SyncXL Split Button

SyncXL

What it does: Bidirectional synchronisation between Revit schedules and Excel. Export any schedule to an Excel spreadsheet; edit the data externally; then import it back to update parameter values in the model.

How to use:

- **Export:** Select a schedule, click **Export**, choose a save location.
- **Import:** Click **Import**, browse to the modified Excel file. The tool maps rows back to elements by the schedule's key parameter and updates values.

Requires: Open project.

DWG Manager

What it does: Lists all DWG imports and links in the model — including which view each instance belongs to, whether it is a link or import, and its workset. Allows navigation to the owner view and management of view-specific DWG instances.

How to use: Click to open. The list shows every DWG in the model. Select a row and click **Go To** to navigate to the owning view.

Requires: Open project.

Transmittal Split Button

Drawing Exporter

What it does: Batch exports sheets to PDF or image formats. Provides control over which sheets are included, PDF settings (page size, orientation, colour/black-and-white), output folder, and file naming. Maintains a revision history log.

How to use:

17. Click **Drawing Exporter**.
18. Select sheets from the list (filter by revision, sheet number, or discipline).
19. Set output format and folder.
20. Click **Export**.

Requires: Open project.

Register Exporter

What it does: Exports a Document Register (drawing register) to Excel or CSV. Captures sheet number, sheet name, revision, status, issue date, and other title-block parameters for all sheets in the model. Useful for issuing a transmittal or maintaining a drawing index.

How to use: Click **Register Exporter**. Select the sheets to include and the output format. Click **Export** and choose a save location.

Requires: Open project.

ISO 19650 Compliance

What it does: Validates sheet numbers and file names against ISO 19650 naming conventions. Checks for compliance with the 7-part or 8-part drawing number format and reports any non-compliant entries.

How to use: Click to run. Review the compliance report. Non-compliant sheets are listed with the specific issue (missing field, incorrect format, etc.).

Requires: Open project.

Revision Manager

What it does: A full revision workflow manager with 8 actions:

Action	Description
Add revision to sheets	Adds a selected revision to one or more sheets
Remove revision from sheets	Removes a revision from selected sheets
Turn off revision clouds	Hides all revision clouds in the model
Mark as Issued	Marks selected revisions as issued
Create sheet set	Creates a sheet set containing all sheets with a selected revision
Find sheets with revision	Lists all sheets that contain a given revision
Copy revisions to other documents	Copies revision definitions to linked or other open documents
Edit revision properties	Edit revision number, date, description, and issued

How to use: Click **Revision Manager** to open the window. Select an action from the list, configure the options, and click **Run**.

Requires: Open project.

Auto Rev Cloud

What it does: Automatically places revision clouds on elements that have changed. Monitors element geometry and parameter changes live, and generates revision clouds around changed elements in the relevant views. Tracks change history for audit purposes.

How to use: Click to open. Select the revision to associate clouds with. Run the scan. Review proposed clouds and confirm placement.

Requires: Open project.

Strip Model

What it does: Removes all annotation from the model — TextNotes, dimensions, tags, filled regions, and detail lines — leaving a clean structural core. Useful for preparing a model for export, coordination, or handover without annotation noise.

How to use: Click **Strip Model**. A confirmation dialog lists what will be removed. Confirm to proceed. This action is **irreversible without undo** — ensure you have a backup or are working on a copy of the model.

Requires: Open project.

Tools Panel

The Tools panel (forest green icons) contains element selection, pinning, numbering, and geometry tools.

QSelect

What it does: An advanced element selector. Filter elements by category, then by parameter, then by parameter value — with visual colour-coding using pastel swatches. Supports creating Revit view filters from the selection criteria.

Workflow:

21. **Step 1 — Category:** Pick a category from the dropdown (filtered to categories present in the active view).
22. **Step 2 — Parameter:** Check one or more parameters to filter by.
23. **Step 3 — Values:** Select the parameter values to match. Choose **New Selection**, **Add to Selection**, or **Remove from Selection**.
24. **Step 4 — Colour:** Assign pastel colour overrides to each value group in the active view for visual differentiation.

Additional options:

- **Create View Filter:** Converts the current QSelect criteria into a Revit view filter (visible in Visibility/Graphics → Filters).

Requires: Open project. Run from within a plan, section, elevation, or 3D view for best results.

Pin References

What it does: Pins selected elements to prevent accidental movement. Equivalent to Revit's native pin but applied in batch to the current selection.

How to use: Select the elements you want to pin, then click **Pin References**.

Requires: Open project.

Sequential Numbering

What it does: Automatically assigns sequential numbers to a selection of elements (e.g. beams, columns, piles). Numbers are applied to a specified parameter in the order elements are picked or sorted.

How to use: Click **Sequential Numbering**. Select elements in the order you want them numbered (or use a filter). Specify the target parameter and starting number. Click **Apply**.

Requires: Open project.

Batch Join

What it does: Joins or unjoins multiple element pairs at once. Useful when you need to apply geometry joins across a large number of structural elements without doing each pair manually.

How to use: Select the elements to join/unjoin. Click **Batch Join**. Choose **Join** or **Unjoin** and confirm.

Requires: Open project.

Structural Suite Panel

The Structural Suite panel (blue icons) contains pile foundation tools, beam geometry tools, rebar quantities, and reference links. This panel can be hidden in Settings if not required.

Pile Coordinates Split Button

Pile Coordinates

What it does: Calculates real-world Easting, Northing, and Elevation (E/N/Z) for all pile foundation elements in the model. Uses the Project Base Point and Survey Point to convert from Revit internal coordinates. Values are written back to configurable parameters (Easting, Northing, Elevation) on each pile family instance.

Updates are applied **live** via a Document Model Updater (DMU) — if a pile is moved in the model, its coordinate parameters update automatically without re-running the tool.

How to use: Click **Pile Coordinates** to run a full update of all piles. Results are written to the pile parameters configured in **Settings** → **Pile Parameters**.

Configuration: Set parameter names in Settings → Pile Parameters:

- Pile keyword (used to filter family types containing "pile")
- Easting parameter name
- Northing parameter name
- Elevation parameter name
- Mark parameter name

Requires: Open project. Project Base Point and Survey Point must be set correctly.

Locate Piles in OS Maps

What it does: Opens Ordnance Survey Maps in a browser, centred on the pile coordinates calculated by Pile Coordinates. Useful for verifying real-world pile locations against site plans.

How to use: Run **Pile Coordinates** first to ensure coordinates are up to date, then click **Locate Piles in OS Maps**.

Requires: Open project with piles.

Pile Cap Alignment

What it does: Detects and reports pile caps that are misaligned with the piles beneath them. Flags pile caps whose centre does not coincide with the expected pile position within a configurable tolerance.

How to use: Click **Pile Cap Alignment**. Review the misalignment report. Navigate to each flagged cap and correct its position.

Requires: Open project.

Split Beam Split Button

Split Beam

What it does: Splits a beam at one or more user-selected planes (grids, reference planes, or level planes). Replaces the single beam with two shorter beams meeting at the split point.

How to use: Select the beam to split. Click **Split Beam**. Pick the plane or grid to split at. The beam is divided and both halves retain the original type and parameters.

Requires: Open project.

Trim / Extend Beam

What it does: Trims or extends beams to a selected plane, grid, or face. Provides a 3D visualisation of the proposed trim/extend before committing. Supports extending short beams or trimming beams that overshoot a grid line.

How to use: Select one or more beams. Click **Trim/Extend Beam**. Pick the target plane or grid. Confirm the preview before applying.

Requires: Open project.

Quantities

What it does: Calculates rebar spacing and quantities for selected elements. Useful for prefabrication schedules, cut lists, and drawing annotations. Reports bar size, spacing, count, and total length.

How to use: Select elements containing rebar (or select rebar directly). Click **Quantities**. Review the quantities table; copy to clipboard or export if needed.

Requires: Open project.

References Split Button

Blue Book

What it does: Opens the Steel Construction Institute (SCI) Blue Book — the online steel section properties and capacity tables — in your default browser.

URL: <https://www.steelforlifebluebook.co.uk/>

How to use: Click to open. Available at all times (no document required).

Green Book

What it does: Opens the SCI P358 Green Book — the design guide for composite beams — as a PDF.

How to use: Click to open the Green Book PDF. Available at all times.

Standards & CDE Panel

The Standards & CDE panel (soft purple icons) contains engineering standards links and Common Data Environment (CDE) platform integrations.

Standards Split Button

IMI Framework

What it does: Opens the IMI BIM Framework website — a reference for BIM implementation guidance — in your default browser.

URL: <https://www.bimframework.info/>

How to use: Click to open.

Custom Reference Links (Links 1–8)

What it does: Up to 8 configurable custom links. Each link can open a URL (website, SharePoint, CDE) or a network folder path. Labels and tooltips are configurable in Settings → Custom Links. Supports %ProjectFolder% and %ModelFolder% tokens, which are substituted with the current model's project or model folder path at click time.

How to use: Configure links in **Settings** → **Custom Links**. Each link appears as a button in the Standards split button once configured.

Tip: Use %ModelFolder% to create a link that always opens the folder containing the current model.

CDE Platforms Split Button

Forma (EU)

What it does: Opens Autodesk Forma (EU region — ACC EU). If the current model is a cloud model with ACC hub/project IDs, navigates directly to the project dashboard. Otherwise opens the ACC EU home page.

How to use: Click to open. Available at all times.

Forma (GBR)

What it does: Opens Autodesk Forma / ACC in the GBR region (acc.gbr.autodesk.com). Behaves identically to Forma (EU) but targets the GBR server.

How to use: Click to open.

Dalux

What it does: Opens the Dalux defect tracking and FM platform in your default browser.

URL: <https://app.dalux.com/>

How to use: Click to open.

4Projects

What it does: Opens the 4Projects collaboration and document management platform in your default browser.

URL: <https://www.4projects.com/>

How to use: Click to open.

Local Model Location

What it does: Opens the folder containing the locally saved Revit file in Windows File Explorer.

How to use: Click to open Explorer at the local model folder.

Shift+click: Shows the full file path in a dialog instead of opening Explorer.

Note: Shows a message if the model has not been saved locally.

Central Model Location

What it does: Opens the folder containing the central (workshared) model in Windows File Explorer.

How to use: Click to open Explorer at the central model folder. Available only for workshared models.

Shift+click: Shows the full central model path in a dialog.

Note: Shows a message if the model is not workshared.

Experimental Panel (WIP)

The Experimental panel (warm orange icons) contains tools that are under active development. These tools may change behaviour or be promoted to a permanent panel in future versions. This panel can be hidden in Settings → Appearance.

All tools are accessed via the **WIP Tools** pulldown button.

WIP Tools Pulldown

Place Baseplates

What it does: Automatically places baseplate families at the foot of structural columns. Detects column base locations and inserts the configured baseplate family instance at each one.

How to use: Click **Place Baseplates**. Select the columns (or use all columns in the model). Choose the baseplate family and type. Confirm placement.

Status: Work in progress — verify results before issuing.

Requires: Open project.

ES Viewer (Extensible Storage Viewer)

What it does: Inspects Extensible Storage (ES) data attached to elements in the model. Lists all registered ES schemas and displays the data stored under each schema for selected elements. Useful for debugging add-in data, checking what RvTK or other add-ins have written to elements.

How to use: Click **ES Viewer**. Select an element in the model. The viewer shows all schemas and their field values for that element.

Availability: Works on any open document (project or family).

Match View Range

What it does: Copies the view range settings (top clip offset, cut plane, bottom offset, view depth) from one source view to one or more target views. Ensures consistent plan view ranges across multiple plans without manual entry.

How to use: Click **Match View Range**. Select the source view from the dropdown. Select the target views. Click **Apply**.

Requires: Open project.

Revision Vault

What it does: Archives revision clouds and tracking data for audit and record purposes. Intended to provide a revision cloud history that persists beyond the live model state.

Status: Work in progress — functionality may be limited.

Requires: Open project.

Transfer Parameters

What it does: Copies parameter values from one element to one or more target elements of the same or compatible category. Useful for propagating type-level or instance-level parameter values in bulk.

How to use: Click **Transfer Parameters**. Select the source element. Select the parameters to transfer. Select target elements. Click **Apply**.

Availability: Works on any open document (project or family).

Feedback Panel

The Feedback panel (red icons) provides a direct channel to submit feedback or report issues.

Send Feedback

What it does: Opens a feedback form or email dialog to contact the RvTK team. Use this to report bugs, request features, or ask questions.

How to use: Click **Send Feedback**. Fill in the form and submit. Alternatively it opens your default email client addressed to RvTK.info@gmail.com.

Availability: Always available, including from the Revit start screen.

Tips & Notes

Shift+Click behaviours

Several tools have a secondary behaviour when **Shift is held** while clicking:

Tool	Normal click	Shift+click
Local Model Location	Open folder in Explorer	Show path in dialog
Central Model Location	Open folder in Explorer	Show path in dialog

Toggle states that persist between sessions

- **Sync Views** — if enabled when Revit closes, it re-enables automatically on next startup.
- **Tab Colouring** — same behaviour; restored automatically on startup.

Panel visibility

The **Structural Suite** and **Experimental** panels can be hidden via **Settings** → **Appearance** if they are not relevant to your workflow. Hidden panels are restored by re-enabling them in Settings.

Panel icon colours

Each panel has a distinct icon hue (teal, forest green, blue, purple, red, orange). These can be customised in **Settings** → **Appearance** using a colour picker per panel. Third-party logos (Dalux, 4Projects, Blue Book, Green Book, IMI Framework) are exempt from hue recolouring and always display in their original colours.

Error logging

Unexpected errors are written to:

```
%AppData%\RvTK\rvtk.log
```

Include this file when reporting bugs via Send Feedback.

Supported Revit versions

Revit Year	Supported
2022	Yes
2023	Yes
2024	Yes (Light/Dark Mode toggle available)
2025	Yes
2026	Yes

Note: Light/Dark Mode toggle requires Revit 2024 or later.