

Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY

WARNING:

NEVER LOWER OR RAISE RACK UNTIL BOOMS ARE FULLY EXTENDED. SERIOUS PROPERTY DAMAGE OR PERSONAL

INJURY MAY RESULT.

WARNING:

DURING STORAGE, GASES CAUSED BY REACTIVE CHEMICALS LEFT IN THE PUMPING SYSTEM MAY PRODUCE PRESSURE. THE COMPLETE DE-ICER SYSTEM SHOULD REMAIN EMPTY. OPEN THE ON-LOAD VALVE, THE OFF-LOAD VALVE, THE BY-PASS VALVE, AND ALL DRAIN VALVES TO ALLOW THE PUMPING SYSTEM AND PRODUCT TANK TO VENT TO THE ATMOSPHERE.

- 1. Off-Load the product tank (if necessary).
- 2. At the base of the product pump, open the small valve and drain the pumping assembly.
- 3. Drain the booms (See Figure 13).
 - a. From the control console, open the boom shut -off valves.
 - b. On a level surface, extend the booms and raise them slightly.
 - c. At the hinge end of each boom, open the small valve and drain the boom hoses.
 - d. At the end of the rack, open the small valve and drain the rack hose.
- 4. Drain the Y-Strainers by removing Y-Strainer caps and screens and reinstall.
- Drain the Hose Reel assembly.
- 6. Drain the Flusher Assembly.
 - a. Open the Flusher Valves and drain the flusher assembly. (Valve handles must be manually opened and closed at the front of the truck & on the left & right side of the truck.)
 - b. Open the small valves on the flusher manifolds and drain the manifolds.
- 7. Close all of the drain valves.



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY

C. Clean the Unit

Consult the manufacturer of de-icing chemicals or liquids other than de-icing chemicals about the reactive status of those chemicals. Use each chemical manufacturer's recommended guideline (detergents or methods) for cleaning equipment of their chemicals.

- 1. Fill the product tank with the specific chemical manufacturer's cleaning solution.
- 2. Agitate the cleaning solution through the product tank.
 - Se the De-Icer unit Valve Handle Positions to Agitate liquids. (See Figure 14)

VALVE A.	BYPASS	SILVER	OPEN
VALVE B.	SUMP	RED	OPEN
VALVE C.	SUCTION	BLUE	CLOSED
VALVE D	PRESSURE	BLACK	CLOSED

b. Procedure

CAUTION:

Never engage hydraulic pump when engine speed is more than 1200 rpm.

1. Switch hydraulic pump switch to On.

CAUTION:

Do not run product pump dry. Excessive heat and component wear will cause pump failure.


- 2. Switch the product pump switch to On if applicable.
- On the Computer Console, turn the Master Switch on and hold the Increase/Decrease Switch in the Increase Position. The System will begin pumping at the spray bar pressure displayed on the Console.
- 4. Increase the engine speed to operating RPM.

Note:

Product pump speed varies directly with the vehicle engine RPM.



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY



Valve Positions For Agitation

Valve A	Bypass	Open
Valve B	Sump	Open
Valve C	Suction	Closed
Valve D	Pressure	Closed
Valve E	Pressure/Nozzles	Closed



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY

- 3. Reset the Valve Handles to Spray and alternate spraying ithe cleaning solution through the booms and nozzles, flushers, and the hose reel.
- 4. When the product tank is empty or spraying is complete, release the Increase/Decrease switch and turn off the Master Switch.
- D. Rinse the Unit using only water.

To prevent detergent residue from drying or crystallizing in the system, one or more complete tanks of clean water should be flushed through the unit.

- 1. Fill the product tank with clean water.
- 2. Agitate water through the product tank.
- 3. Reset the Valve Handles to Spray and alternate spraying at least one complete tank of water through the booms and nozzles, flushers, and the hose reel.
- 4. When the product tank is empty or spraying is complete, shut down the unit.
- E. Empty all water from the unit.
 - 1. Off-Load the product tank (if necessary).
 - 2. At the base of the product pump, open the small valve and drain the pumping assembly.
 - Drain the Y-Strainers by removing Y-Strainer caps and screens and reinstall.
 - 4. Drain the Booms, Flusher Assembly, and the Hose Reel Assembly as needed.
- F. During storage, the system should remain empty. Open the On-Load valve, the Off-Load valve, the By-Pass valve, and all drain valves to allow the pumping system and product tank to vent to the atmosphere.
- G. Use a high pressure washer with detergent to clean all outside surfaces of the tank, booms, pumping system, and running gears.



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY

13. Product Pump

Open the product pump drain valve and all of the manifold valves to empty the product pump and eliminate condensation.

14. Pressure Relief

A. General

While vehicle engine is not running, pressures in the pneumatic and hydraulic systems may be reduced by the following steps.

Note:

Pressure relief procedures are performed while the "hydraulic pump" switch is in the OFF position.

B. Primary Hydraulic System

On the computer Console, turn the Master Switch on and hold the Increase/Decrease Switch in the Increase Position. (This opens the PWM Valve to relieve oil pressure in the primary hydraulic system.)

C. Secondary Hydraulic System

- 1. Turn "HYDRAULIC PUMP" switch OFF.
- Operate all boom and nozzle switches that control secondary hydraulic valve banks. (This will relieve hydraulic oil pressure in the secondary hydraulic hoses.)

D. Pneumatic System

- 1. Close air supply shut off valve.
- 2. Relieve air pressure by operating all boom and nozzle functions which control hydraulic valve banks.
- 3. Open drain on air filter.
- 4. Set parking brake.
- 5. Empty all vehicle chassis air tank(s).



Appendix A Application Rate Table 1



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY

Constants

Unit: Ohare (Shop Unit #35)

Date: 10-20-2013

Batts I.D. 99482

Boom 1 Cal: 240

Boom 2 Cal: 120

Boom 3 Cal: 240

Speed Cal: 750

Meter Cal: 720

Valve Cal: 63


Rate 1 Cal: 1.0 Gallon

Rate 2 Cal: 0.5 Gallon



Appendix B Periodic Maintenance Table 1





De-Icer Pro Wiring Diagram Figure 11(Sheet 2)

- 22



9

Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY


₩ YM Ø βŞ <u>←</u>m 10 4 Gλ Pur o ЬA 18 -B25 ص 日ド 18 Right Boom Continued from Sheet 2. Continued to Sheet 4. B13 Cab Safety Light Junction Box B24+B26 Rack 823 (pine) BackUp brown 5 Left Tum (yellow) Hight Tum (green) Tal/Market 0 5 0 Boom Spot Lights O 0 0 <u>10</u> Left Boom ЧМ HQ-BK Wh-BK B34-4-B35 Tank Spot Lights 18 ру Gr

> De-Icer Pro Wiring Diagram Figure 11(Sheet 3)



<u>...</u>


Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY



Continued to Sheet 5.








De-Icer Pro Wiring Diagram Figure 11(Sheet 5)







De-Icer Pro Wiring Diagram Figure 11(Sheet 6)



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY

DETAILED PARTS LIST

1. General

This section contains and explanation of each column in the detailed parts list. Illustrations and detailed parts lists of all assemblies and subassemblies used in the Delcer.

A. Figure and Item Number

This column provides a cross-reference between the parts listed and the illustrations. To find a view of the part listed and its visual relationship to the assembly, locate the figure and item number in the list, then refer to the indicated illustration and locate the part by its item number. To find a part number and description in the parts list, locate the part on an illustration, note the item number, then refer to the parts list and locate the applicable part number and description.

B. Part Number

This column lists the part number necessary for ordering repair parts.


C. Nomenclature


This column lists the description of each item in the parts list. The identifying noun or key word is the first word in the nomenclature column. The remainder of this column contains an expanded description to assist in completely identifying the item.

D. Units Per Assembly

This column indicates the quantity of each part required to complete the next higher assembly.








Final Assembly Figure 1





_	ElO/	PRIMARY	NOMENCLATURE	UNIT
	FIG/	PART NO.	NOWENCEATORIE	PER
	NO	PART NO.		ASSY
	INO			
ı				
	1-		Final Assembly, Batts	1
			De-Icer Pro	
	1		Truck/Chassis	1
	2		De-Icer Tank/Frame Assembly	1
			(See Fig. 2)	
	3		Pump Installation, De-Icer	1
			(See Fig. 3)	
	4	003200991	Pump Assembly, De-Icer	1
			(See Fig. 4)	
1	5		Shut-Off Valve Installation, De-Icer	1 1
			(See Fig. 5)	
	6		Boom Plumbing Installation, De-Icer	1
			(See Fig. 6)	
	7		Cab Control Console Assembly	1
-			(See Fig. 8)	
	•	025005078	Console, Batts Control (See Fig. 8)	1
	-	003401001	Console, DjSC 100 (See Fig. 8)	1
	8		Electromagnetic Clutch Assembly	1
			(See Fig. 10)	
	9		De-Icer Hydraulic System	1
			(See Fig. 11)	
	10		De-Icer Electrical Assembly	1
			(See Fig. 17)	
	•			
1				
			9	
			g	
	1		<u> </u>	





De-Icer Tank/Frame Assembly Figure 2




Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY

FIG/ ITEM NO	PRIMARY PART NO.	NOMENCLATURE	UNIT PER ASSY
2- 1 2 3 4 5 6 7 8 9 10 - 11 12 13 14 15 16 17 18	007404000 012600024 025000030 025000002 025000002 025000003 012602012 012602008 012601402 012600009 025002084 025002085 057668661 025002030 025000150 025000149 075500241 025000175	De-Icer Tank/Frame Assembly Frame, Truck Tank, De-Icer Product Cylinder/Horizontal Height Adjuster Rack, Boom Boom, Tilt-Wing Pin, Boom Hinge Break Back, Right Side Break Back, Left Side Cylinder, 12 Boom Swing IN & OUT Cylinder, 8 Boom Lift UP & DOWN Pin, Cylinder Pin, Cylinder Cotter Fender, Left Side Rear Fender, Right Side Rear Kit, Mud Flap Bracket, Tank Tie Down Bracket, Boom Transport Latch, Boom Transport Bracket Cylinder, Air, Boom Transport Bracket Guard, Air Cylinder, Boom Transport Bracket Protector, Boom Rack Nozzle (Optional)	1 1 1 1 1 1 2 2 10 20 1 1 4 6 2 2 2 1

-Item Not Illustrated





De-Icer / Flusher Pro Pump Installation Figure 3






FIG/ ITEM NO	PRIMARY PART NO.	NOMENCLATURE	UNIT PER ASSY
3- 1 2 3 4 5 6 - 7 8 9 10 11 - 12 - 13 13 A 14 A 15 16 17 18 19	003200052 025002015 025002062 025002002 010800058 010800064 025002004 025002024 025002073 009700275 003700172FT 003700400 003700171FT 003700300 046400001 046400002 046400003 046400004 009500050 025002055 025002080 025002097 025002099	Pump Installation, De-Icer/ Flusher Pump Assembly, 8200 F-HD Flange, 4 Suction Hose Barb Manifold, Suction Extension Flange, 3 Male Valve Coupler, 3 Cam-Lok Cap, Cam-Lok Flange, 3 Female Valve Flange, 3 Femsure Hose Barb Manifold, Pressure Union Nipple, 3/8 Pipe Hex Hose, 4 Suction Clamp, 4 Hose Hose, 3 Pressure Clamp, 3 Hose Valve, 4 Butterfly Handle, Valve(State Color) Valve, 3 Butterfly Handle, Valve(State Color) Valve, 3/8 Ball, Stainless, Pipe Thread Manifold, Flusher Extension Manifold, Primary Flusher Extension Manifold, Pressure Extension Manifold, Pressure Extension	1 1 1 1 2 2 2 4 1 1 1 AR 2 AR 4 1 1 3 3 1 1 1 1 1

-Item Not Illustrated



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY




Pump Assembly Figure 4



FIG/ ITEM NO	PRIMARY PART NO.	NOMENCLATURE	UNIT PER ASSY
4- 1 2 3 4 6 7 8 9 10 11 12 13 14 15 18 19 20 21 22 23 24 25 26	003200991 003201071 003201053 003201057 003200587 003201075 Not Available 003201064 003201062 Not Available 003201069 003201069 003201063 Not Available 003201066 003201068 003201056 003201068 003201072 003201072 003201073 003201074 003201067	Pump Assembly, 8200 F-HD Plug, Pipe Volute Impeller, 8 DIA. O-Ring, Flange Bolt & Nut, Flange O-Ring, Cover Plate Plate, Cover Seal, Shaft Stud Nut Pedistal Assembly Housing, Bearing Screw, Cap Bolt & Nut Snap Ring Lock Nut Seal Assembly, Rotary Sleeve O-Ring, Shaft Shaft Bearing, Small Bearing, Large Spacer	1211166214411111111



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY





De-lcer Shut-Off Valve Installation Figure 5



FIG/ ITEM NO	PRIMARY PART NO.	NOMENCLATURE	UNIT PER ASSY
5-	058212548	De-Icer Shut-Off Valve Installation Valve, 3 Electric / Pneumatic Butterfly Flange, 3 Female Valve Bushing, 3 X 2 Reducer Nipple, 2 NPT Close Strainer Assembly, "Y" 2 Strainer Housing 2 O-Ring Filter Cap Barb, 2 Male Thread X 1- 1/2 Shank Clamp, 2 Hose Hose, 1-1/2 Pressure Elbow, 90 Degree 2 Street	1
1	046400011		3
2	025002004		3
3	008900376		3
4	008900313		3
5	010800032		3
-	010800103		3
-	010800031		3
6	010800099		3
7	003700200		6
8	003700164FT		AR
9	008900524		1







De-Icer Boom Plumbing Installation Figure 6






Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY

FIG/ ITEM NO	PRIMARY PART NO.	NOMENCLATURE	UNIT PER ASSY
6- 1 2 3 4 5	055412400 055412402 025000027 008900523 008900443 008900312 010800097	Boom Plumbing Installation, De-Icer Boom Plumbing Kit, (Consists of items 1 through 14) Boom, Tilt Wing Eibow, 90 degree 1-1/2 Street Tee, 1-1/2 X 1-1/2 NPT Nipple, 1-1/2 Close Barb, 1-1/2 Male Thread X	1 2 2 3 2 2 2 2
6	003700164FT 003700028 008900442 004900031 004900300 000500101 000500102 010200012 010200004 003300058 003300054 008900468 008900651 004800041	1-1/2 Male Shank Hose, 1-1/2 Pressure Clamp, Hose # 28 Tee, 1-1/2 X 3/4 Reducer U-Bolt 2-1/2 Nut & Washer, 1/4 Valve, Nozzle Check Kit, Nozzle Check Valve, Rebuild Connector, Nozzle Quick Adapter, Nozzle Nozzle, Size RA 60 Nozzle, Size RA 40 Plug, 1-1/2 NPT Bushing, 1-1/2 x 3/8 Reducer NPT Valve, 3/8 Petcock	AR 40 20 46 92 20 AR 20 20 20 20 2
	Pr		

-Item Not Illustrated



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY



De-Icer/Flusher Manifold Assembly Figure 7





FIG/ ITEM NO	PRIMARY PART NO.	NOMENCLATURE	UNIT PER ASSY
7- 1 2-3 4 5 6-7 8 9 10 11 12 13 14 15 16 17	025002144 003700171FT 003700300 025002145 008900376 009100009 003700170FT 003700200 007800004 025002146 046400011 025002151 008900313 004800036 008900601 045800007 012602012 025025084 025025085	Manifold Assembly, De-Icer / Flusher Manifold, Flusher Tank Hose, 3 Clamp, Hose 3 Manifold, Cab Bushing, 3 x 2 Reducer Barb, 2" Hose Hose, 2 Rigid Clamp, Hose 2 Elbow, 2 Female Swivel Manifold, Front Tee Flusher Valve, 3 Electric / Pneumatic Butterfly Manifold, Front Flusher Nipple, 2 NPT Close Nut, 2, Jam Elbow, 45 degree 2 Nozzle, Flusher Fan Cylinder, 12 Front Tee Flusher Mount, Tee Flusher Manifold Table, Tee Flusher Manifold	1 1 AR 4 1 1 2 AR 2 1 1 2 4 8 4 4 1 1 1

-Item Not Illustrated










ſ	FIG/	PRIMARY PART NO.	NOMENCLATURE	UNIT
L	NO			ASSY
	8-		Cab Control Console Assembly	1
	1	025005078	Console, Batts Control	
	-	012900103	Breaker, 15Amp Circuit	5
	-	012900104	Breaker, 20 Amp Circuit	1
ı	2	003401001	Console, DiCCS 100 Control	i
	3	003401002	Console, DjCMS 100 Monitor	i
ı	4	003401007	Switch, Module	1
ı	5	S9980X	Lamp, Console	2
1	6	025005066	Electrical Bundle, Boom	l <u>1</u>
ı			#5500, 192 LG	
l	7	025005068	Electrical Bundle, Electrical Lighting 264 LG	1
	8	025005076	Electrical Bundle, Boom Shut - Off #3300, 216 LG	1
ı	9	012900105	Switch, SPDT, White Center Return Rocker	
ı	10	012900106	Switch, SPDT, Black Center Return Rocker	
	11	012900101	Switch, SPST, 20Amp	1
	12	012900102	Light, Red Warning 24V	1
	13	012900110	Switch, Center Return SPDT, 20Amp	1
ı	14	012900107	Switch, SPST, Black Rocker	9
ı			w/ Indicator	
ı	15	012900108	Switch, SPST, White Rocker	2
1			w/ Indicator	
l	16	025005077	Electrical Bundle, Flusher Shut - Off #4400, 216 LG	1
	-	025005082	Kit, Decal, De-Icer / Flusher, DjCCS / DjCMS Console	1
ı				
			=	i
ĺ				
		10		
			¥0;	İ

-Item Not Illustrated



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY




Electromagnetic Clutch Assembly Figure 11





FIG/ ITEM NO	PRIMARY PART NO.	NOMENCLATURE	UNIT PER ASSY
11 1 2 3 4 5	007700308 030300001 030300003 030300002 075500007	Power Take-Off Installation Assembly, Power Take-Off Flange, Yoke 1 1/4 Key Shaft, Drive w/ Cross & Bearings Flange, Yoke 7/8 Spline Pump, Hydraulic	1 1 1 1
	5 g		
	\$	é e	
	3) %		
	5.	÷	





De-Icer Hydraulic Assembly Figure 12





FIG/ ITEM NO	PRIMARY PART NO.	NOMENCLATURE	UNIT PER ASSY
12- 1	025025069	Hydraulic Assembly, De-Icer Hydraulic Reservoir Tank 50 Gal.	1
2 3 4 5 6 7 8 9	025700003 025700005 025700004 025700002 009700331 008900312 008900630 008900584	Gauge, Sight Temp Cap, Fill Vent, Breather Dip Stick, Magnetic Busing, 2 x 1-1/2, Reducer Nipple, 1-1/2 Close Valve, 1 1/2 NPT Gate Barb, 1 1/2 Hose x 1 1/2 Male Thd	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
10 11 12	003700200 007600151FT. 075500257	Clamp, Hose Hose, Suction 1 1/2" x 78" Barb, 1 1/2 Female Jic x 1 1/2 Male Hose	AR AR 1
13 14	075500218 075500007	Elbow, 1 1/2 O-Ring Pipe x 1 1/2 Jic Pump, Hydraulic PTO Assembly	1 1 1
15	007700308 030300001 030300003 030300002 075500258	Assembly, Power Take-Off Flange, Yoke 1 1/4 Key Shaft, Drive w/ Cross & Bearings Flange, Yoke 7/8 Spline Adapter, 1 1/2 Male O-ring x 1 Female Pipe	1 1 1 1
16 17	075500259 021800509FT	Elbow, Male 90, 3/4 Jic x 1 Male Pipe Hose, 3/4" High Pressure Hydraulic, A. Length 176" C. Length 204" B. Length 27 "	1 AR
18 19	075500210 075500213	Tee, Swivel, 3/4 Female Jic x 3/4 Male Jic Adapter, Swivel, 3/4 Female Jic x 3/8 Male Jic	3 3
20 21 22 23	009700434 009700287 021800204 075500228	Swivel, 3/8 Female Jic x 3/8 Female Pipe Bushing, 3/8 x 1/4 Reducer Guage, 0-5,000 Lbs., Silicon Filled Elbow, Male 90, 3/4 Jic x 3/4 O-ring Boss	1 1 1 3

⁻Item Not Illustrated





FIG/	PRIMARY	NOMENCLATURE	UNIT
ITEM	PART NO.		PER
NO			ASSY
12-		Hydraulic Assembly, De-Icer (Continued)	1
24	075500222	Adapter, 1 Male O-ring x	2
		3/4 Female O-ring	
25	075500108	Assembly, Hydraulic Manifold Valve	1
26	021800508FT	Hose, 3/4" Hydraulic Pressure	AR
		A. Length 156" C. Length 60"	
		B. Length 252" D. Length 240"	
27	075500217	Bushing, 1 O-Ring x 3/4 Pipe	1
28	009700107	Elbow, Male, 90, 3/4 Tube x 3/4 Pipe	7
29	003402224	Servo, Hydraulic	1
30	009700304	Plug, 3/4 Hex Head	1
31	009700281	Nipple, Hex, 3/4"	1
32	009700326	Coupling, 3/4	1
33	075500231	Elbow, 90 Bent Tube, 1 Flange x 3/4 Male Jic	2
34	075500230	Flange Set, 1 O-ring Anchor	2
35	075500029	Motor, Hydraulic	1
36	003200991	Pump, Assembly 8200	1
37	075500202	Adapter, 3/4 Female Pipe x 3/4 Male O-ring	2
38	009700021	Connector, Male 3/4 Jic x 3/4 Pipe	1
39	075500205	Nipple, Hex 3/8 Jic x 3/8 O-Ring	2
40	021800504FT	Hose, 3/8° Hydraulic Pressure	AR
	-	A. Length 20 " D. Length 176"	
}		B. Length 80 * E. Length 144*	
		C. Length 12 "-	
41	075500226	Adapter, 1/4 Female Pipe x	2
١		3/8 Male O-ring	
42	009700096	Elbow, 90, 3/8 Tube x 1/4 Pipe	2
43	075500256	Nipple, Hex 1/4 Jic x 1/4 O-Ring, Restricted	1 2
44	075500234	Connector, 5/8 Str x 3/8 Jic	1
45	075500110	Block,5-Station Control Valve	5
-	075500109	Solenoid, Valve Spool	5 10
	075500235	Connector, 1/2 Str x 1/4 Jic	i
	075500236	Plug, 5/8 Str	1
46	009700302	Plug, Hex Head, 3/8 Bushing, 5/8 Str x 1/4 Pipe Reducer	1
46 47	075500237 009700207		1
48	009700207	Elbow, 1/4 Str Swivel, 1/4	1
49	021800201	Gauge, 0-3000 PSI, Silicone Filled	1
45	V2 1000201	Gauga, 0-0000 FGI, GIIIWHA FIIIM	•
L		<u> </u>	

⁻Item Not Illustrated




Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY

FIG/ ITEM NO	PRIMARY PART NO.	NOMENCLATURE	UNIT PER ASSY	
12- 50 51 52 53 54 55 56 57 58 59 60 61	009700013 009700248 009700297 007700040 009700284 008900629 009700330 009700296 008900506 008900310 008900628	Hydraulic Assembly, De-Icer (Continued) Connector, 3/8 Tube x 1/2 Pipe Tee, Male Run, 3/4 Bushing, 1 1/4 x 3/4 Reducer Element, Return Line Filter Gauge, 0-145 PSI Nipple, 1-1/4 Hex Valve, 1-1/4 N.P.T. Gate Bushing, 1 x 1/2 Reducer Bushing, 1 x 1/2 Reducer Cross, 1 Nipple, 1 Close Valve, 1 N.P.T. Gate	1 1 1 1 1 2 1 2 1 2 1	



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY



Front Flusher Cylinder

De-Icer Boom Cylinder Hydraulic Hose Installation Figure 13






FIG/ ITEM	PRIMARY PART NO.	NOMENCLATURE	UNIT PER
NO			ASSY
13- 1 2 3 4 - 5 6 7 8	007600153FT 007600153FT 007600153FT 007600153FT 007600153FT 007600153FT 007600153FT	De-Icer Boom Cylinder Hydraulic Hose Installation Hose, Hydraulic 1/4 X Hose, Left Boom Lift 102 LG Hose, Left Boom Lift 102 LG Hose, Right Boom Lift 102 LG Hose, Right Boom Lift 102 LG Hose, Hydraulic 1/4 X Hose, Left Boom Swing 66 LG Hose, Left Boom Swing 66 LG Hose, Right Boom Swing 102 LG Hose, Right Boom Swing 102 LG	1 AR 1 1 AR 1 1 AR 1 AR
9 10 11 - 12 13 14 15 16	007600153FT 007600153FT 007600153FT 009700411 075500110 075500109 075500117 012602008 012602012	Hose, Hydraulic 1/4 X Hose, Front Flusher 300 LG Hose, Front Flusher 300 LG Hose, Boom 240 LG Union, 1/4 Bulkhead Block,5-Station Control Valve Solenold, Valve Spool Valve, Pressure Relief Cylinder, 8 Boom Lift UP & DOWN Cylinder, 12 Boorn Swing IN & OUT Cylinder, 12 Front Flusher	AR 1 8 8 1 5 3 2 2



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY



Boom Swing Cylinder Flow Control Installation Figure 14






FIG/ ITEM NO	PRIMARY PART NO.	NOMENCLATURE	UNIT PER ASSY
14-	055621040	Boom Swing Cylinder Flow Control Installation	1.
1 2 3 4	012602012 009700287 009700221 012300013	Cylinder, 12 Boom Swing IN & OUT Bushing, 3/8 X 1/4 NPT Reducer Elbow, 90 degree 1/4 NPT Valve, Flow Control 1/4 NPT	2 2 1 1
			S ₁
		E	
į	¥i.		
	91		
		E#	
		es .	



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY



Boom Lift Cylinder Pressure Relief Installation Figure 15







FIG/ ITEM NO	PRIMARY PART NO.	NOMENCLATURE	UNIT PER ASSY
15- 1 2 3 4 5 6 7 8	007600153FT 007600153FT 012602008 009700287 009700245 017400003 009700323 007600153FT	Boom Lift Cylinder Pressure Relief Installation Hose, Boom Lift Hose, Boom Lift Cylinder, 8 Boom Lift UP & DOWN Bushing, 3/8 X 1/4 NPT Reducer Tee, 1/4 NPT Male Run Valve, Pressure Relief Coupler, 1/4 Female Hose, 10 3/4 LG O.A.	1 1 1 AR 2 1 1 AR
U.	IJ		



Batts Inc. · P.O. Box 1 · 108 South Main St. · Advance, IN. 46102 · 1-888-7RUNWAY





De-Icer Electrical Assembly Figure 16






	FIG/ ITEM NO	PRIMARY PART NO.	NOMENCLATURE	UNIT PER ASSY
	16-	025005078 551840 B2803A1 S9980X CB6377 CB6321 003401001 004800101 004800102 003410006	De-Icer Pro Electrical Assembly Console, Batts Control Switch, SPST, 20Amp Light, Red Warning 24V Lamp, Console Breaker, 15Amp Circuit Breaker 20Amp Circuit Console Switch, SPDT, 20Amp Center Return Switch, SPST,20Amp Push Button Sensor, Ground Speed	1 1 4 1 2 5 1 1
	- 2 3	003410005 017400002 5200C	Transducer, Application Rate Clutch, Electromagnetic 12 VDC 200 FT LB Bar, Tank Three Light	1 1
	4 5 6 7	004803501 B60A B60R 025002086 008703502	Light, Tank Swivel Spot Light, Tank Marker, Amber Light, Tank Marker, Red Box, Tail Light Lens, Red, Tail Light	2 2 2 2 2
	8 9	008703503 004800003 004800004	Lens, Clear, Back Up Light, Boom Spot Light, Red Rectangular Clearance	2 2 10
	10 - -	004800017 004800021 004800022	Light, Amber Rectangular Clearance (If Applicable) Light, Red Oval Clearance, Fender (If Applicable) Light, Amber Oval	2 AR AR
	11	029700009 029700007	Clearance, Fender (If Applicable) Light, Cab Safety Strobe Mount, Safety Light Bar	1
L		X		

De-Icer Pro



Batts Inc. • P.O. Box 1 • 108 South Main St. • Advance, In. 46102 • 1-888-7RUNWAY




DIMENSIONS IN INCHES

Α	В	С	AE	BG	CA
76"	51"	N/A	75"	23"	132''
CE	CW	FD	FH	OA	ОН
206"	35"	3.5"	12"	28'8"	10'5"
WB	SHF	SHR	TDF	TDR	UCA
207"	30"	30"	22.5"	22.5"	89''
TRACK	WIDTH				
96"	10'8"				

De-Icer Pro



Batts Inc. • P.O. Box 1 • 108 South Main St. • Advance, In. 46102 • 1-888-7RUNWAY



DIMENSIONS IN INCHES

CL	CS	HD	QT	TD	UE
43"	83"	9"	192"	69"	49"
WT	AOC	OHT	OTU	OWT	OWU
N/A	16"	9'10''	204''	69"	10'8"
SFD	TOA	TSL			
N/A	31'3"	130"]		

De-icer Pro DI-4000 Series SCS 440 Batts Inc. • P.O. Box 1 - 108 South Main St. • Advance, IN. 46102 • 1-888-7RUNWAY

ESTIMATED WEIGHTS,

	FRONT	REAR	TOTAL
TRUCK	8,140 lb	4,700 lb	12,840 lb
EQUIPMENT	500 lb	5,160 lb	5,660 lb
Unit Complete	8,640 lb	9,860 lb	18,500 lb
Gross	11,140 lb	26,540	37,680 lb

WATER ONLY