



Convert the resistor valur from the windvane sensor in voltage. It will be convert in degree by the microcontroler. vane_v+D U301A vane_sig D **D**Udir LMV358 vane_v-D-GND GND The two 100 Ohms resistors are the blink band from the windvane. With these we can't have short circuit between supply in the blink band. AGPLv3 LONGUET Gilles ALEEA Sheet: /F2 windvane/ File: F2_windvane.sch Title: Windvane function Size: A4 Date: 2016-10-16
KiCad E.D.A. kicad 4.0.2+dfsg1-2bpo8+1-stable Rev: A Id: 3/6





