### **Overview**

This Host MSD example supports the UFI and SCSI U-disk device.

The application prints the attached device information when the U-disk device is attached. The application executes UFI commands to test the attached device.

## **System Requirement**

#### Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for a specific device
- Personal Computer(PC)

### **Software requirements**

• The project path is:

<SDK\_Install>/boards/<board>/usb\_examples/usb\_host\_msd\_command/<RTOS>/<toolchain>.

Note

The RTOSes are bare metal or FreeRTOS OS.

# **Getting Started**

### **Hardware Settings**

• The Jumper settings: 1-2, J4 1-2, J27 1-2 and remove all jumpers from J35 for micro USB connector. 1-2, J4 1-2, J27 2-3, and remove all jumpers from J35 for using TWR-SER mini USB connector.

#### Prepare the example

- 1. Download the program to the target board.
- 2. Power off the target board and power on again.
- 3. Connect devices to the board.

Note

For detailed instructions, see the appropriate board User's Guide.

# Run the example

- 1. Connect the board UART to the PC and open the COM port in a terminal tool.
- 2. Plug in the hub or U-disk device to the board. The attached information prints out in the terminal.
- 3. The test information prints in the terminal, "success" prints when one command succeeds and "fail" prints when one command fails. The test completes when there is a command fail or all the tests are done.

The following figure is an example for attaching one U-disk device.

```
host init done
mass storage device attached:pid=0x312bvid=0x125f address=1
......test start.....
get max logical units...success, logical units: 0
test unit ready...success, unit status: ready
request sense...success
inquiry...success
read capacity...success, last logical block:30344191 block length:512
read(10)...success
write(10)...success
.....test done.....
```

Figure 1: Attach U-disk device

4. To test throughput, set the MSD\_THROUGHPUT\_TEST\_ENABLE to (1) in te file host\_msd\_command.h. An additional 64 K RAM is required to test the throughput. The macro is only supported on the TWR-K65F180M Tower System module and IAR.

The following figure is a throughput test example for attaching one U-disk device.

```
host init done
mass storage device attached:pid=0x312bvid=0x125f address=1
.....test start.....
get max logical units....success, logical units: 0
test unit ready....success, unit status: ready
request sense....success
inquiry...success
read capacity...success, last logical block:30344191 block length:512
read(10)...success
write (10) ... success
throughput test:
   write 51200KB data the speed is 18102 KB/s
   read 51200KB data the speed is 38011 KB/s
   write 51200KB data the speed is 17993 KB/s
   read 51200KB data the speed is 37904 KB/s
   .....test done.....
```

Figure 2: Throughput test

### Note

Throughput test only supports the TWR-K65F180M Tower System module.