

Batocera v42 Display Setup

Setup & Troubleshooting Reference

Raspberry Pi 5 Micro HDMI Port and USB-A Port

Connector wiring - 2 wires only

Port on Display	Pi 5 Port	Function
HDMI Port (HDMI Vertical to Micro HDMI Straight 0.2m 20 pin FPC Cable)	Micro HDMI	Display Signal
Micro USB Port	USB-A Port (Touch)	Power + Touch

1. Batocera Configuration

1.1 Edit config.txt:

Mount drive with edit rights:

```
| mount -o remount,rw /boot
```

Edit this file on Batocera Alt + F5 or via SSH:

```
| nano /boot/config.txt
```

Scroll to the bottom and add these lines:

```
| hdmi_force_hotplug=1
| config_hdmi_boost=10
| hdmi_group=2
| hdmi_mode=87
| hdmi_cvt 1024 600 60 6 0 0 0
| hdmi_drive=1
```

Save with Ctrl+O, exit with Ctrl+X.

Save overlay

```
| batocera-save-overlay
```

Shutdown

```
| shutdown -h now
```

Wait for the Pi to fully power off, then swap to the 7" display and power back on.

Batocera should come up at 1024×600. If the image looks overscan (edges cut off), you may need to add this on `config.txt`:

```
| disable_overscan=1
```

Save with Ctrl+O, exit with Ctrl+X.

Shutdown and replug.

2. Problems Faced

- Was first thinking to use Waveshare 5 inch DSI Display, 800 × 480 IPS Capacitive Touch, but BATocera doesn't support DSI display so had to switch to a HDMI display, and 5" 800x480 resolution was a little too small for gaming and other work, so switched to Waveshare 7 inch HDMI Display 1024 x 600 IPS Capacitive Touch Screen.