# Marvelmind C library and example

Version 2016.08.11

## 1. About the library

Marvelmind C library provides an example of building the system for receiving coordinates from Marvelmind mobile beacons by user's software running on supported operating systems:

- Microsoft Windows
- GNU/Linux (including Raspberry Pi)
- Mac OS X

Archive contains a simple example of library usage (example.c):

## 2. Building the example

To build the example on GNU/Linux or another \*nix-OS you need to have installed GCC. Then unpack the archive, change directory to unpacked library and run make in console. Then you can execute ./marvelmind\_example to watch data from Marvelmind beacon being received.

Pre-built example for Microsoft Windows is included in the archive. If you want to rebuild it, you may use integrated development environment (such a MS Visual Studio, Code::Blocks etc.): create empty console project and add 3 source files (example.c, marvelmind.h, marvelmind.c) into the project and run build. You may need to change the project settings to successfully build it.

#### 3. Command line options of the example

```
You may specify another serial port as command line argument. For example:

marvelmind_example /dev/ttyACM2

or for Microsoft Windows:

marvelmind_example.exe COM4

Use prefix \\.\if serial port number is bigger than 9:

marvelmind_example.exe \\.\COM10
```

#### 4. Using the library

Example of library usage see in the file example.c. You can use the library in your own projects by adding file marvelmind.c into build, including marvelmind.h:

```
#include "marvelmind.h"
and your code may follow the sequence:
```

4.1. Call createMarvelmindHedge to allocate memory for library structure (struct MarvelmindHedge). You need to call it before any other usage of the library



- 4.2. Modify some variables in created structure, if needed. For example, you can change serial port filename or/and baudrate, enable verbose messages or use some another features, list of them you can found in file marvelmind.h
- 4.3. Call startMarvelmindHedge to tell library to start collecting and parsing data received from Marvelmind beacon
- 4.4. Get the data: call getPositionFromMarvelmindHedge to get 3-axis coordinates of connected beacon or call printPositionFromMarvelmindHedge to print it on console output. You can repeat this step
- 4.5. After usage call stopMarvelmindHedge to stop the collecting thread
- 4.6. Call destroyMarvelmindHedge to free memory, used by Marvelmind library

