DATABASE CODING TABLE

BEIJING/Capital

	CODING	TABLE					BEIJING	
Path	Waypoint	Fly	Magnetic	Turn	Altitude	IAS	VPA/TCH	Navigation
Terminator	ID	over	Course(°)	Direction	(m)	(kt)	VI AZ TON	Specification
RWY36R Runw	ay Transition							
CF	AA131		001		<u>1200</u>			RNAV1
TF	AA152				2100			RNAV1
TF	AA158							RNAV1
TF	AA173				2400			RNAV1
Common								
IF	AA173				2400			RNAV1
TF	AA176				<u>5700</u>			RNAV1
TF	ELKUR				<u>5700</u>			RNAV1
	<u>'</u>		RWY36L/	36R SID ELK	UR-9Z			1
RWY36L Runw	ay Transition							
СА			001		160			RNAV1
DF	AA111			L				RNAV1
TF	AA112				1200			RNAV1
TF	AA129				2100			RNAV1
TF	AA113				2700			RNAV1
TF	AA116				<u>4500</u>			RNAV1
TF	AA119							RNAV1
TF	DXG				6000			RNAV1
RWY36R Runw	ay Transition							
CF	AA131		001		1200			RNAV1
TF	AA132				<u>1800</u>			RNAV1
TF	AA133				3000			RNAV1
TF	AA138				5100			RNAV1
TF	AA118							RNAV1
TF	DXG				6000			RNAV1
Common	I							-
IF	DXG				6000			RNAV1
TF	ELKUR				5700			RNAV1
	l .	R	 WY01/36L/36F	R SID OMDEK				
RWY01 Runway	Transition							
CA			001		230			RNAV1
DF	AA171			R				RNAV1
TF	AA172			13	1800			RNAV1
					1200			
TF	AA177				.200			RNAV1
TF	AA178				2100			RNAV1
TF	AA134				4800			RNAV1
TF	AA134				1000			RNAV1
 Changes: New cho								NIVAVI