# MEDIATEK

# **Customization Guide**

**Customization Guide** 

**Customer Support** 

**Root Integrity Check** 

Doc No: CS6000-BC6A-CGD-V1.0EN

Version: V1.0

Release date: 2017-01-27

Classification: internal

© 2008 - 2017 MediaTek Inc.

This document contains information that is proprietary to MediaTek Inc.

Unauthorized reproduction or disclosure of this information in whole or in part is strictly prohibited.

Specifications are subject to change without notice.

Classification:internal

Root Integrity Check
Customization Guide

### MediaTek Inc.

### Postal address

No. 1, Dusing 1st Rd. , Hsinchu Science Park, Hsinchu City, Taiwan 30078

### MTK support office address

No. 1, Dusing 1st Rd. , Hsinchu Science Park, Hsinchu City, Taiwan 30078

### Internet

http://www.mediatek.com/

This document contains information that is proprietary to Media Tek Inc. Unauthorized reproduction or disclosure of this information in whole or in part is strictly prohibited





**Customer Support Root Integrity Check Document Revision History** 

# **Document Revision History**

Revision	Date	Author	Description	
V1.0	2016-12-29	Haohsiang	Initial Release	( \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \

# MEDIATEK

# **Table of Contents**

		Revision History	
Tab	le of Co	ntents	
Liste	of Tab	les	r
1		oduction	
•	iiiti		
	1.1	Purpose	6
	1.2	Who Should Read This Document	<del>(</del>
	1.3	How to Use This Manual	6
		1.3.1 Terms and Conventions	6
2	Rofo	rences	
3	How	to use Root Integrity Check	8
4	Abbr	reviations	9
5		omization	
	5.1	Source Code Organization	10
	5.2	How to add common root apk for check ?	10
	5.3	How to set the encrypt key for protect checksum results?	10
	5.4	How to add ignore check file?	10

# MEDIATEK

# **Lists of Tables**

Table 1-2. Chapter Overview	6
Table 1-3. Conventions	6
Table 4-1 Abbreviations	



## Introduction

Root integrity check function checks handset whether has been modify (root) or not. This function is in Android recovery mode

#### 1.1 **Purpose**

This document provides the programming guidelines for the root integrity check. It describes how to use this function on the Android platform.

#### 1.2 Who Should Read This Document

This document is primarily intended for:

Engineers with technical knowledge of the handset firmware has been modify

#### 1.3 **How to Use This Manual**

This segment explains how information is distributed in this document, and presents some cues and examples to simplify finding and understanding information in this document. Table 1-1 presents an overview of the chapters and appendices in this document.

Table 1-1. Chapter Overview

#	Chapter	Contents
1	Introduction	Describes the scope and layout of this document.
2	References	References website
3	Use root integrity check	Describe how to use root integrity check
4	Abbreviations	Abbreviations
5	Customization	Customization

#### 1.3.1 **Terms and Conventions**

This document uses special terms and typographical conventions to help you easily identify various information types in this document. These cues are designed to simply finding and understanding the information this document contains.

Table 1-2. Conventions

Convention	Usage	Example
[1]	Serial number of a document in the order of appearance in the References topic	Look up Chapter 2: System Architecture in [1]
F	Important	

Unauthorized reproduction or disclosure of this information in whole or in part is strictly prohibited

This document contains information that is proprietary to MediaTek Inc.



# 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- [1] MTK Company Profile, <a href="http://brandclips.mediatek.inc/uploads/Company-profile-1H-2016">http://brandclips.mediatek.inc/uploads/Company-profile-1H-2016</a> 0418-Lite-final.pptx
- [2] MTK Word Template, <a href="http://brandclips.mediatek.inc/uploads/Microsoft-Office-Word-Oct-2014.rar">http://brandclips.mediatek.inc/uploads/Microsoft-Office-Word-Oct-2014.rar</a>
- [3] The Android Multimedia Audio Driver, http://dms.mediatek.inc/



Customer Support

Root Integrity Check

3 How to use Root Integrity Check

# 3 How to use Root Integrity Check

This chapter describes how to use root integrity check.

Go to Recovery mode: Press Power key continuously then press VOLUP key

Select Root integrity check item: Press VOLUP to "Root integrity check" item then press power key

**Results:** If handset doesn't modify anything, it print "System check SUCCESS", otherwise it indicate which file has been modified, created or deleted.

This document contains information that is proprietary to MediaTek Inc.

Unauthorized reproduction or disclosure of this information in whole or in part is strictly prohibited

Unauthorized reproduction or disclosure of this information in whole or in part is strictly prohibited



# 4 Abbreviations

Please note the abbreviations and their explanations provided in Table 4-1. They are used in many fundamental definitions and explanations in this document and are specific to the information that this document contains.

Table 4-1. Abbreviations

Abbreviations	Explanation	
MTK	MediaTek, Asia's largest fabless IC design company.	

Unauthorized reproduction or disclosure of this information in whole or in part is strictly prohibited



## 5 Customization

This chapter first gives a brief description of the root integrity check customization.

## **5.1** Source Code Organization

- 1. bootable/recovery/root\_check.cpp
- 2. bootable/recovery/root\_check.h
- build/tools/releasetools/rootcheck.py

## 5.2 How to add common root apk for check?

Add apk name to array file\_to\_check[] in bootable/recovery/root\_check.cpp

We already add some root apk as followings:

- 1. supersu.apk
- 2. superroot.apk
- superuser.apk
- 4. busybox.apk

## 5.3 How to set the encrypt key for protect checksum results?

Modify decrypt key root\_check\_key variable in bootable/recovery/root\_check.cpp , default is 15.

Modify encrypt key ENCRYPT\_KEY in build/tools/releasetools/rootcheck.py, default is 15.

# 5.4 How to add ignore check file?

Add apk name to array file\_to\_pass [] in bootable/recovery/root\_check.cpp

We already add some ignore files as followings:

- 1. recovery-from-boot.p
- 2. install-recovery.sh
- recovery\_rootcheck
- 4. build.prop
- S\_ANDRO\_SFL.ini
- 6. recovery.sig
- 7. Atlbin
- 8. .drbin