

# everyday genius

# 7668 Customization Bring-up SOP

Version: 1.0

Release date: 2019-10-169

© 2015 - 2019 MediaTek Inc.

This document contains information that is proprietary to MediaTek Inc. ("MediaTek") and/or its licensor(s). MediaTek cannot grant you permission for any material that is owned by third parties. You may only use or reproduce this document if you have agreed to and been bound by the applicable license agreement with MediaTek ("License Agreement") and been granted explicit permission within the License Agreement ("Permitted User"). If you are not a Permitted User, please cease any access or use of this document immediately. Any unauthorized use, reproduction or disclosure of this document in whole or in part is strictly prohibited. THIS DOCUMENT IS PROVIDED ON AN "AS-IS" BASIS ONLY. MEDIATEK EXPRESSLY DISCLAIMS ANY AND ALL WARRANTIES OF ANY KIND AND SHALL IN NO EVENT BE LIABLE FOR ANY CLAIMS RELATING TO OR ARISING OUT OF THIS DOCUMENT OR ANY USE OR INABILITY TO USE THEREOF. Specifications contained herein are subject to change without notice.







Specifications are subject to change without notice.



## **Document Revision History**

Revision	Date	Description	
1.0	2019-08-30	Initial Draft	
			20



### **Table of Contents**

Doc	ument	Revision History		3
				/
1.				
-	1.1			
	1.2	References		5
2.	CON	SYS bring-up Contents		6
	2.1	Proiect Config		6
	2.2	Kernel Config	<u> </u>	7
	2.3	DTS Config		7
	2.4	Gpio config		7
	2.6	coex config		10
	2.5	Check list		11



#### 1. Introduction

The purpose of this document is CONSYS MT7668 configurate and bringup.

### 1.1 Purpose

The purpose of this document is CONSYS MT6631 configurate and bringup.

MT6631 is a 4-in-1 connectivity RF chip which contains front-ends of a 2.4GHz Wi-Fi and Bluetooth transceiver, a 5GHz Wi-Fi transceiver. Definitions, Acronyms and Abbreviations

WMT: Wireless Management Task

#### 1.2 References

N/A

#### 1.3 Overview

Section 1 is Project Config

Section 2 is Kernel Config

Section 3 is DwS Config

Section 4 is gpio config

Section 5 is check list

Section 6 coex config



#### 2. CONSYS bring-up Contents

#### 2.1 Project Config

#### File path:

- device/project name/
- Configuration item:
- ProjectConfig.mk, modify below config for mt7668

```
MTK_BT_CHIP = MTK_CONSYS_MT8167

MTK_COMBO_CHIP = CONSYS_8167

MTK_COMBO_CHIP = MT7668
```

• BoardConfig.mk, add below statement at the end of BoardConfig.mk

```
ifeq ($(MTK_WLAN_SUPPORT), yes)
```

```
ifeq ($(MTK_COMBO_CHIP), MT7668)
```

WIFI\_DRIVER\_FW\_PATH\_PARAM :=

WIFI DRIVER FW PATH STA:=

WIFI\_DRIVER\_FW\_PATH\_AP:=

WIFI\_DRIVER\_FW\_PATH\_P2P:=

WIFI DRIVER STATE CTRL PARAM :=

WIFI\_DRIVER\_STATE\_ON :=

WIFI\_DRIVER\_STATE\_OFF :=

endif

endif

- Configuration item:
  - · init.project.rc, add below statement at the end of BoardConfig.mk
    - # WiFi
    - mkdir /data/misc/wifi 0770 wifi wifi
    - mkdir /data/misc/wifi/sockets 0770 wifi wifi
    - mkdir /data/misc/wpa supplicant 0770 wifi wifi
    - # Wlan
    - service wpa\_supplicant /vendor/bin/hw/wpa\_supplicant \
    - -iwlan0 -Dnl80211 -c/data/misc/wifi/wpa\_supplicant.conf \
    - -I/vendor/etc/wifi/wpa\_supplicant\_overlay.conf -N \
    - -ip2p0 -Dnl80211 -c/data/misc/wifi/p2p\_supplicant.conf

e/data/misc/wifi/entropy.bin \

- -I/vendor/etc/wifi/p2p\_supplicant\_overlay.conf \
  - O/data/misc/wifi/sockets -g@android:wpa wlan0
  - # we will start as root and wpa\_supplicant will switch to user wifi
  - # after setting up the capabilities required for WEXT
  - # user wifi
- # group wifi inet keystore

© 2015 - 2019 MediaTek Inc.

Page 6 of 12



- class main
- socket wpa\_wlan0 dgram 660 wifi wifi
- disabled
- oneshot

If the configuration already exist in this file, please don't add it again.

#### 2.2 Kernel Config

For example, kernel-4.9/arch/arm64/configs/tb8768p1\_64\_bsp\_defconfig File path:

- kernel-4.4/arch/arm64/configs/[project]\_debug\_defconfig
- kernel-4.4/arch/arm64/configs/[project]\_defconfig

#### Configuration item:

modify below config for mt7668

```
CONFIG MMC MTK COMM SDIO=Y

CONFIG_MTK_COMBO_CHIP_CONSYS_8167=Y | CONFIG_MTK_COMBO_CHIP_MT7668=Y

CONFIG MTK BTIF=Y
```

If the configuration already exist in this file, please don't add it again.

#### 2.3 DTS Config

For example, kernel-4.9/arch/arm64/boot/dts/mediatek/tb8768p1\_64\_bsp.dts File path:

- vendor/mediatek/proprietary/bootable/bootloader/lk/target/[project\_name]/dct/dct/codeg en.dws
- vendor/mediatek/proprietary/bootable/bootloader/preloader/custom/[project\_name]/dct/d ct/codegen.dws
- Tool path:
  - alps/vendor/mediatek/proprietary/scripts/dct/DrvGen.exe
- According to the Schematic and GPIO table, Customer need to modify codegen.dws file.

#### 2.4 Gpio config

- File path:
- kernel-4.4/arch/arm64/boot/dts/mediatek/(project).dts
- Configuration item:
- · Remove 8167 internal consys settings from dts file

```
&reserved_memory {

#address-cells = <2>;
```



```
#size-cells = <2>;
        ranges;
        consys-reserve-memory {
                 compatible = "mediatek,consys-reserve-memory";
                 no-map;
                 size = <0.0x200000>;
                 alignment = <0 0x200000>;
        };
};
&consys {
        pinctrl-names = "default", "gps_lna_state_init", "gps_lna_state_oh", "gps_lna_state_ol";
        pinctrl-0 = <&consys_pins_default>;
        pinctrl-1 = <&gpslna pins init>;
        pinctrl-2 = <&gpslna_pins_oh>;
        pinctrl-3 = <&gpslna pins ol>;
        vcn18-supply = <&mt6392_vcn18_reg>;
        vcn35-supply = <&mt6392_vcn35_reg>;
        status = "okay";
};
```

- File path:
- kernel-4.4/arch/arm64/boot/dts/mediatek/[project].dts
- Configuration item:
- Remove 8167 internal consys settings from dts file

```
/* CONSYS GPIO Settings - Start */
consys_pins_default: default {
};

/* CONSYS GPIO Settings - End */

/* CONSYS GPIO Settings - Start */
gpslna_pins_init: gpslna@0 {
};
gpslna_pins_oh: gpslna@1 {
};
gpslna_pins_ol: gpslna@2 {
};
/* CONSYS GPIO Settings - End */
```

- File path:
- kernel-4.4/arch/arm64/boot/dts/mediatek/[project].dts
- Configuration item:
- Firstly verify the device connect with which host (MSDC1 or MSDC2)
- Add sdio vmmc settings to dts file



**Confidential B** 

Add mmc2 settings to dts file for MSDC2

```
class {
    pinctrl-names = "default", "state uhs", "state dat1", "state eint";
    pinctrl-0 = <a box of state dat1", "state eint";
    pinctrl-1 = <a box of state dat1 = state dat1", "state eint";
    pinctrl-2 = <a box of state dat1 = state dat
```

- Configuration item:
  - Add mmc1 settings to dts file for MSDC1
  - Cause MSDC1 prepare for SD card, so must overwrite the head.

```
pinctrl-names = "default", "state uhs", "state dat1", "state eint";
pinctrl-0 =
pinctrl-1 = <€mmc
pinctrl-2 = <&mmc1 pins dat1>;
pinctrl-3 = <&mmc1 dat1 eint>;
eint-gpios = ($pio 107 0>;
status = "ok
bus-width = <4>;
max-frequency = <2000000000;
cap-sd-highspeed;
sd-uhs-sdr50;
sd-uhs-sdr104;
keep-power-in-suspend;
enable-sdio-wakeup;
vmmc-supply = <&sdio fixed 3v3>;
cap-sdio-irq;
non-removable;
```

Configuration item:





- According to the Schematic and GPIO table, mt7668 connected to the AP GPIO num
- Add mmc2 pinctrl for MSDC2

```
<mark>mmc2 pins_dat1: mmc2</mark> dat1 {
       pins dat1 {
                pinmux = <MT816
                input-enable;
                drive-strength = <MTK DRIVE
                bias-pull-up = <MTK PUPD
mmc2 dat1 eint:
                 pinmux = <MT8167 PIN 71 MSDC2 DAT1 FUNC GPIO71>;
                input-enable;
                bias-pull-up = <MTK PUPD SET R1RO 10>;
```

- Configuration item:
  - According to the Schematic and GPIO table, mt7668 connected to the AP GPIO num
     Add mmc1 pinctrl for MSDC1

#### 2.6 coex config

Solution	wifi.cfg	eFuse	Note
FDD	1. "FddPerPkt 0" 2. "CoexModeCtrl 1"	0x3E[6] = 0	Default sol

© 2015 - 2019 MediaTek Inc.

Page 10 of 12



TDD 1. "FddPerPkt 0"
2. "CoexModeCtrl 2"

3. 0x3E[6] = 1
 4. (0x3D[1:0] = 1 for SPDT)

6. **Te**s

```
mmc1 pins_dat1: mmc1 dat1 {
    pins_dat1 {
        pinmux = <NT8167 PIN_107_MSDC1_DAT1 FUNC_MSDC1_DAT1>;
        input-enable;
        drive-strength = <NTK_DRIVE_SmA>;
        bias-pull-up = <NTK_PUPD_SET_RIRO_10>;
};

mmc1_dat1 eint: Bat1 eint {
    pins_dat1 {
        pinmux = <NT8167_PIN_107_MSDC1_DAT1_FUNC_GPI0107>;
        input-enable;
        bias-pull-up = <NTK_PUPD_SET_RIRO_10>;
};
```

### 2.5 Check list

• Before bring up, customer should check below items to confirm mt7668 has been built in. out/target/product/[project]/vendor/lib/modules/wlan\_drv\_gen4\_mt7668.ko out/target/product/[project]/vendor/lib/modules/btmtksdio.ko out/target/product/[project]/vendor/firmware/EEPROM\_MT7668.bin out/target/product/[project]/vendor/firmware/mt7668\_patch\_e2\_hdr.bin out/target/product/[project]/vendor/firmware/TxPwrLimit\_76x8.dat out/target/product/[project]/vendor/firmware/wifi.cfg







out/target/product/[project]/vendor/firmware/bt.cfg (optional) out/target/product/[project]/vendor/firmware/WIFI\_RAM\_CODE\_MT7668.bin out/target/product/[project]/vendor/firmware/WIFI\_RAM\_CODE2\_SDIO\_MT7668.bin out/target/product/[project]/vendor/etc/init/init.wlan\_mt7668\_drv.rc out/target/product/[project]/vendor/etc/init/init.btmtksdio.rc