

SCALES

MAIN MENU		
1	Sensor	
2	Units	
3	Scales	
4	Measure	
5	Alarms	
6	Inputs	
7	Outputs	
8	Settings	
9	Help	
10	Exit	
11	Back	
12	Forward	
13	Cancel	

SCALES		
1	FS1 g/s	4908.7
2	B.qty dm3	1.00000
3	FS2 g/s	4908.7
4	Pls1=g	1000.00
5	Tpls1=ms	0050.0
6	Pls2=g	1000.00
7	Tpls2=g	0050.0
8	Frq1=Hz	1000.00
9	Frq2=Hz	1000.00

3.1	Full scale flow rate 1
3.2	Batching quantity
3.3	Full scale flow rate 2
3.4	Pulse value on channel 1
3.5	Duration of the pulse generated on channel 1
3.6	Pulse value on channel 2
3.7	Duration of the pulse generated on channel 2
3.8	Full scale frequency for channel 1 (0.1Hz-1000.0Hz)
3.9	Full scale frequency for channel 2 (0.1Hz-1000.0Hz)

MEASURES

MAIN MENU		
1	Sensor	
2	Units	
3	Scales	
4	Measure	
5	Alarms	
6	Inputs	
7	Outputs	
8	Settings	
9	Help	
10	Exit	
11	Back	
12	Forward	
13	Cancel	

MEASURES		
1	Damping	SMART
2	Cut-off= %	00.1
3	DT Min.	ON
4	T1HC enable	ON
5	T1HC	OFF

4.1	Measure filter
4.2	Low flow zero threshold: 0-25% of full scale value
4.3	Automatic calibration verify
4.4	Automatic change of measurement range
4.5	High immunity inputs

ALARMS

MAIN MENU		
1	Sensor	
2	Units	
3	Scales	
4	Measure	
5	Alarms	
6	Inputs	
7	Outputs	
8	Settings	
9	Help	
10	Exit	
11	Back	
12	Forward	
13	Cancel	

ALARMS		
1	Max+ = dm3/s	OFF
2	Max- = dm3/s	OFF
3	Min+ = dm3/s	OFF
4	Min- = dm3/s	OFF
5	Hysteresis=%	03
6	mA v.alarm=%	000
7	Hz v.alarm=%	000

5.1	Maximum value alarm set for direct flow rate
5.2	Maximum value alarm set for reverse flow rate
5.3	Minimum value alarm set for direct flow rate
5.4	Minimum value alarm set for reverse flow rate
5.5	Hysteresis threshold set for the minimum and maximum flow rate alarms
5.6	Current output value in case of failure
5.7	Frequency output value in case of alarms

INPUTS

MAIN MENU		
1	Sensor	
2	Units	
3	Scales	
4	Measure	
5	Alarms	
6	Inputs	
7	Outputs	
8	Settings	
9	Help	
10	Exit	
11	Back	
12	Forward	
13	Cancel	

INPUTS		
1	T+ reset	OFF
2	P+ reset	OFF
3	T- reset	OFF
4	P- reset	OFF
5	Count lock	OFF
6	Meas.lock	OFF
7	Calibration	OFF
8	Range change	OFF

6.1	Total direct (positive) flow totalizer reset enable
6.2	Partial direct (positive) flow totalizer reset enable
6.3	Total reverse (negative) flow totalizer reset enable
6.4	Partial reverse (negative) flow totalizer reset enable
6.5	Totalizer counting lock command
6.6	Measure zero lock command
6.7	Calibration external command
6.8	Range change external command

OUTPUTS

MAIN MENU	
1-Sensor	
2-Units	
3-Scales	
4-Measure	
5-Alarms	
6-Inputs	
7-Outputs	
8-Communication	
9-Display	
10-Data logger	
11-Functions	
12-Settings	
13-Exit	
OUTPUTS	
10-Out1	PULSES+
11-Out2	PULSES-
12-Out mA1	4_22 +/-
13-Out mA2	4_22 +/-
A1S	4.9087
A2S	4.9087

7.1	Output 1 functions
7.2	Output 2 functions
7.3	Choice of the function and the range of current output n.1
7.4	Choice of the function and the range of current output n.2
7.5	Full Scale value for analog out1
7.6	Full Scale value for analog out2

COMMUN.

MAIN MENU	
1-Sensor	
2-Units	
3-Scales	
4-Measure	
5-Alarms	
6-Inputs	
7-Outputs	
8-Communication	
9-Display	
10-Data logger	
11-Functions	
12-Settings	
13-Exit	
COMMUNICATION	
10-HART pr.	05
11-HART O. C.	ON
12-Dev. Addr	001
13-Speed=bps	9600
Parity=	NO
Delay=ms	00
C. timeout	2

8.1	HART packet byte preambles
8.2	HART bus output control
8.3	Device communication address number
8.4	MODBUS link speed
8.5	MODBUS link parity
8.6	MODBUS reply delay
8.7	Maximum delay between chars (frames) MODBUS



DISPLAY

MAIN MENU	
1-Sensor	
2-Units	
3-Scales	
4-Measure	
5-Alarms	
6-Inputs	
7-Outputs	
8-Communication	
9-Display	
10-Data logger	
11-Functions	
12-Settings	
13-Exit	
DISPLAY	
Language	EN
Contrast	5
Disp.time=s	020
D.rate=Hz	5
Disp. Fn.	1
Disp.lock	ON
Part. Tot	ON
Neg. Tot.	ON
Net tot.	ON
Disp.date	ON
Quick start	ON

9.1	Choice of the language
9.2	Display contrast
9.3	Display/keyboard inactivity time
9.4	Display updating frequency: 1-2-5-10 Hz
9.5	Display function number
9.6	Display function selection lock
9.7	Partial totalizer enable
9.8	Negative totalizer enable
9.9	Net totalizer enable
9.10	Time and date display enable
9.11	Quick start menu visualization

DATA LOGGER

DATA LOGGER		
D.logger en.	ON	10.1 Data logger enabling
Meas. units	ON	10.2 Measure units recording enable
Field separat.	;	10.3 Field separator character
Decimal separat.	.	10.4 Decimal separator character
Interv.	01:01:00	10.5 Sampling interval
Log T+	ON	10.6 Enable logging of total direct totalizer
Log P+	ON	10.7 Enable logging of partial direct totalizer
Log T-	ON	10.8 Enable logging of total reverse totalizer
Log P-	ON	10.9 Enable logging of partial reverse totalizer
Log TN	ON	10.10 Enable logging of total net totalizer
Log PN	ON	10.11 Enable logging of partial net totalizer
Log Q (UM)	ON	10.12 Enable logging of flow rate in measure unit
Log Q (%)	ON	10.13 Enable logging of flow rate in percentage
Log AL.EV	ON	10.14 Enable logging of alarm events
Log STR	ON	10.15 Enable logging of sensor test results
Log BTS	ON	10.16 Enable logging of board temperature
Log IBV	ON	10.17 Enable logging of internal board voltage
Log EDC	ON	10.18 Enable logging of electrodes DC voltage
Log EAC	ON	10.19 Enable logging of electrodes AC voltage
Log EIZ	ON	10.20 Enable logging of electrodes impedance
Log SCV	ON	10.21 Enable logging of sensor coils value
4-Outputs		
8-Communication		
9-Display		
10-Data logger		
11-Functions		
12-Diagnostic		
13-System		

FUNCTIONS

FUNCTIONS		
T+ reset		11.1 Execute immediate reset of total direct totalizer
P+ reset		11.2 Execute immediate reset of partial direct totalizer
T- reset		11.3 Execute immediate reset of total reverse totalizer
P- reset		11.4 Execute immediate reset of partial reverse totalizer
Load Sens. F. def		11.5 Load sensor factory default
Load Conv. F. def		11.6 Load converter factory default
Save Sens. F. def		11.7 Save sensor factory default values
Save Conv. F. def		11.8 Save converter factory default values
Calibration		11.9 Execute immediate internal circuit calibration
9-Display		
10-Data logger		
11-Functions		
12-Diagnostic		
13-System		

DIAGNOSTIC

DIAGNOSTIC		
Self test		12.1 Self test diagnostic function
Test display		12.2 Function tests physical display
Sens. verify		12.3 Sensor verify diagnostic function
Flow sim. =	ON	12.4 Flow rate simulation enabling
Display measures		12.5 Display internal measured value
Disp. Comm. Vars		12.6 Display comm. diagnostic values
Display graphs		12.7 Display measure as graphs
Gen. sens. set		12.8 Generic sensor parameters set
SD card info		12.9 Sd card status informations
Firmware info		12.10 Firmware version/revision
S/N=	999001	12.11 Board serial number
WT=	002:21:00 : 22	12.12 Total working time
4-Outputs		
9-Display		
10-Data logger		
11-Functions		
12-Diagnostic		
13-System		

SYSTEM

SYSTEM		
Dayl. Saving =	ON	13.1 Daylight saving time change
Time zone =	h+01.00	13.2 Localized time zone
	2016/04/04-16:07	13.3 System date and time
L1 code =	*****	13.4 Access level 1 code
L2 code =	*****	13.5 Access level 2 code
L3 code =	*****	13.6 Access level 3 code
L4 code =	*****	13.7 Access level 4 code
L5 code =	*****	13.8 Access level 5 code
L6 code =	*****	13.9 Access level 6 code
Restr. Access=	ON	13.10 Restricted access level
	010.011.012.013	13.11 Device IP network address
	010.011.012.014	13.12 Client IP network address
	255.255.255.000	13.13 Network mask
HT	0.96469	13.14 Calibration coefficient KT
HS	1.00000	13.15 Calibration coefficient KF
HR	1.00000	13.16 Calibration coefficient KR
DAC1	(°C)	13.17 DAC1 out 4mA calibration point
DAC1	(°C)	13.18 DAC1 out 20mA calibration point
DAC2	661	13.19 DAC2 out 4mA calibration point
DAC2	3327	13.20 DAC2 out 20mA calibration point
Stand-by	3453	13.21 Stand-by
FW update	14718	13.22 firmware update
9-Display		
10-Data logger		
11-Functions		
12-Diagnostic		
13-System		

FUNCTIONS DESCRIPTION



Here below the explanation on how the rows of menu are described.

Menu visualized on the converter (from 1 to 13)
MENU 1 - SENSOR

(POS. 1.1) <i>Sensor Model</i>	[S. model xxx]	AL4	[SMODL]
		Access level	MCP command
		Convert request1	
		Synthetic description of the function	

The following picture describes where to find the name of the MCP functions in MCP-software. More info see MCP manual.

The screenshot shows the MCPPro software interface. On the left, a 'Function list' window displays a tree structure of functions under the 'Menu' tab. The 'Menu' tab is selected, showing a list of functions including 'Sensor', 'Units', 'Scales', and various output and pulse value functions. A specific function, '[Channel 1 pulse volume value]', is highlighted, and its details are shown below it, including 'OP1PV? : 1,104:MCPI ACCESS LEVEL NOT VALID' and 'OP1PV= : 1,104:MCPI ACCESS LEVEL NOT VALID'. On the right, a larger window shows the 'MCP' command editor. It has a text input field with 'OP1PV=' and a '6 char' indicator. Below the input field, there are buttons for 'I' and 'A'. A callout box points to the input field with the text: 'Line editor for the insertion and execution of MCP commands.'

MENU 1 - SENSOR

(POS. 1.1) <i>Sensor model</i>	[S. model xxx]	AL4	[SMODL]
---------------------------------------	-----------------------	------------	----------------

Enter the first two characters of the serial number of the sensor as on the sensor label.

(POS. 1.2) <i>Lining Type</i>	[Lining= UNSPEC.]	AL4	[LIMAT]
--------------------------------------	--------------------------	------------	----------------

Flow sensor lining material type. (PFA; PU-TDI; ALON; PEEK; HR; PP; PA-11; PTFE-HT; PTFE)

(POS. 1.3) <i>Type of sensor</i>	[S. type= FULL BORE]	AL4	[STYPE]
---	-----------------------------	------------	----------------

Select the sensor type of full-bore or insertion.

(POS. 1.4) <i>Unit type</i>	[U.type= METRIC]	AL4	[SUTYP]
------------------------------------	-------------------------	------------	----------------

Select type of measure unit of sensor's parameter. Values metric or imperial (inch).

(POS. 1.5) <i>Diameter</i>	[Diam.= mm xxx]	AL4	[PDIMV]
-----------------------------------	------------------------	------------	----------------

Select the nominal diameter of the sensor (0-2500). ND is written on the sensor label.

(POS. 1.6) <i>KA</i>	[KA= + xx.xxx]	AL4	[CFFKA]
-----------------------------	-----------------------	------------	----------------

KA factor: calibration coefficient

(POS. 1.7) <i>KA -</i>	[KA= - xx.xxx]	AL4	[CFKAN]
-------------------------------	-----------------------	------------	----------------

KA factor: calibration coefficient for negative flow. This function is showed only if at least 1 negative KL value is set.

(POS. 1.8) <i>KZ</i>	[KZ= +/- xxxxx]	AL4	[CFFKZ]
-----------------------------	------------------------	------------	----------------

Calibration Factor. KZ

(POS. 1.9) <i>KD</i>	[KD= +/- xxxxx]	AL4	[CFFKD]
-----------------------------	------------------------	------------	----------------

Calibration Dynamic Factor.

(POS. 1.10) <i>Insertion position</i>	[Ins.position= x]	AL4	[SIPOS]
--	--------------------------	------------	----------------

This function is active with POS.1.3 on "Insertion". See the insertion sensor manual for more details

(POS. 1.11) <i>KP dynamic</i>	[KP dynamic= ON/OFF]	AL4	[CFFKP]
--------------------------------------	-----------------------------	------------	----------------

This function is active with POS.POS. 1.3 see page 27 set on insertion. See manual of insertion sensor for more details

(POS. 1.12) <i>Ki</i>	[Ki= +/- xx.xxx]	AL4	[CFFKI]
------------------------------	-------------------------	------------	----------------

This function is active with POS. 1.3 see page 27 set on insertion. See manual of insertion sensor for more details

(POS. 1.13) <i>Kp</i>	[Kp = +/- xxxxx]	AL4	[SIDKP]
------------------------------	-------------------------	------------	----------------

This function is active with POS. 1.3 see page 27 set on insertion. See manual of insertion sensor for more details

(POS. 1.14) <i>KC</i>	[KC= +/- xx.xxx]	AL4	[CFFKC]
------------------------------	-------------------------	------------	----------------

Calibration Factor. This function is activated if the sensor model is NOT present on the sensors table standard parameters

(POS. 1.15) <i>Coils Ex.Current</i>	[C.Curr.= mA xxx.x]	AL4	[CEXCC]
--	----------------------------	------------	----------------

Excitation coils current. This function is activated if the sensor model is NOT present on the sensors table standard parameters

(POS. 1.16) <i>C. Reg. PB</i>	[C.Reg.PB= xxx]	AL4	[CRPRB]
--------------------------------------	------------------------	------------	----------------

Current regulator parameter. This function is activated if the sensor model is NOT present on the sensors table standard parameters

(POS. 1.17) <i>C. Reg. DK</i>	[C.Reg. DK = xxx]	AL4	[CRDER]
--------------------------------------	--------------------------	------------	----------------

Current regulator parameter. This function is activated if the sensor model is NOT present on the sensors table standard parameters

(POS. 1.18) <i>Preamplifier</i>	[Preamplif.= ON]	AL4	[PREIN]
--	-------------------------	------------	----------------

This function enable/disable the presence of the preamplifier. The use of the preamplifier inhibit the possibility to use BIV and Empty Pipe Detection.

(POS. 1.19) <i>S. Freq.</i>	[S.Freq.= Hz xx]	AL4	[SFREQ]
------------------------------------	-------------------------	------------	----------------

Measure sampling frequency. This function is activated if the sensor model is NOT present on the sensors table standard parameters.

(POS. 1.20) <i>Empty Pipe Detection</i>	[E.P.Detect= ON]	AL4	[EPDEN]
--	-------------------------	------------	----------------

Enables the empty pipe detection function. This function is useful to keep the meter lock to zero when the pipe become empty.

(POS. 1.21) <i>Empty pipe thr.</i>	[R max= Kohm xxxx]	AL4	[EPDTH]
---	---------------------------	------------	----------------

Maximum resistance value at the inputs (electrodes) determine the empty pipe condition. This feature is enabled only if the "1.19" page 27 Empty Pipe Detection is ON.

(POS. 1.22) <i>Electrodes cleaning</i>	[El. cleaning=AVG]	AL4	[ELCLN]
---	---------------------------	------------	----------------

This function is useful to keep the electrodes clean; the allowed values are: OFF, minimum, average and maximum. It is **not recommended** to use this function when the liquid has a conductivity less than 100µS/cm (**set to OFF**).

(POS. 1.23) <i>Sensor Cable</i>	[S.cable=m xxx]	AL4	[SCALN]
--	------------------------	------------	----------------

Length of cable between sensor and converter on separate version.

(POS. 1.24) <i>Signal error delay</i>	[S.err.delay=m xxx]	AL4	[SEALT]
--	----------------------------	------------	----------------

Delay before generating error. This function is useful to prevent unexpected lock to zero of measure caused by sporadic events (empty pipe, excitation error, signal error)

(POS. 1.25) <i>Sensor verify</i>	[Sens. verify= OFF]	AL3	[ASVFE]
---	----------------------------	------------	----------------

Enable the Automatic sensor verification (see BIV optional function).

(POS. 1.26) Zero point calibration [Zero point cal.]

This feature appears only when the process conditions are as follow:

- measure filters recommended (Damping) set to SMART 2 second / 5 second
- stable flow rate and lower than 0.1% of the absolute scale (10 m/s)
- It must have elapsed at least 10 minutes after the last significant change of flow rate

When the above conditions are met, the zero point calibration function will appears on the display, press the "Enter / ESC" and automatically the procedure will start.

NOTICE: Be sure that the the sensor is completely full of liquid and perfectly still. Even subtle movements of the fluid can cause significant errors, therefore proceed with great care.

(POS. 1.27) Coefficient KL [KL=XX +/- XXXXXXXXXX] AL4 [SETKL]

Linearization coefficient for negative flow, reserved to the service. This command is only showed if SMODL = 000.

MENU 1 - SENSOR: ONLY MCP FUNCTIONS**Sensor Coils Time A [MCP ONLY] AL4 [SCTMA]**

Reference sensor coil time A

Sensor Coils Time B [MCP ONLY] AL4 [SCTMB]

Reference sensor coil time B

Sensor Coils Resistance [MCP ONLY] AL4 [SCRES]

Reference sensor coil resistance

Resistance E1 [MCP ONLY] AL4 [SE1RR]

Resistance value of E1 electrodes

Resistance E2 [MCP ONLY] AL4 [SE2RR]

Resistance value E2 electrodes

Sensor Coils Temperature Reference [MCP ONLY] AL4 [SCTRF]

sensor data reference temperature. Temperature measured on the coils of the sensor at the time of saving the instrument reference data for B.I.V. function The temperature value in degrees Celsius, which owns the sensor.

Note: the temperature must be estimated on the basis of the place of the sensor installation.

MENU 2 - UNITS

WARNING: The totalizer value is updated and changed depending on the setting of unit value. The scale change may cause accuracy loss depending of rounding up. For example, if T +=0,234 liters with 3 decimals, it become T +=0.001 m³ losing 0.234 liters in rounding up.

(POS. 2.1) <i>Diameter</i>	[Diam.= mm]	AL2	[SDIUM]
-----------------------------------	--------------------	------------	----------------

Sensor diameter unit of measure (mm or inch)

(POS. 2.2) <i>S.cable length unit of m. type</i>	[S.Cable= m]	AL2	[SCAUM]
---	---------------------	------------	----------------

Sensor cable length for separate version. Select m or foot.

(POS. 2.3) <i>Flow rate unit of m. type</i>	[FR unit= METRIC]	AL2	[FRMUT]
--	--------------------------	------------	----------------

Flow rate type measure unit. Select metric or not metric (Imperial units)

(POS. 2.4) <i>Pulse 1 unit of m. type</i>	[PL1 unit= METRIC]	AL2	[PL1UT]
--	---------------------------	------------	----------------

This function is active with POS. 7.1 see page 29 enable.

This function changes the choice of measure unit POS. 3.4 see page 28

Pulse 1 type measure unit: metric or not metric (Imperial units).

(POS. 2.5) <i>Pulse 2 unit of m. type</i>	[PL2 unit= METRIC]	AL2	[PL2UT]
--	---------------------------	------------	----------------

This function is active with POS. 7.2 see page 29 enable.

This function changes the choice of measure unit POS. 3.6 see page 28

Pulse 2 type measure unit: metric or not metric Imperial units).

(POS. 2.6) <i>Totalizer direct unit of m. type</i>	[T+ unit= METRIC]	AL2	[TTPUT]
---	--------------------------	------------	----------------

Setting total direct totalizer measure unit type: metric or not metric Imperial units).

This function changes the values measure unit on POS. 2.7 see page 27

(POS. 2.7) <i>Totalizer direct unit of measure</i>	[T+ unit= dm³]	AL2	[TTPUM]
---	----------------------------------	------------	----------------

Setting total direct totalizer measure unit.

This function visualized on visualization pages.

(POS. 2.8) <i>Totalizer direct Deci.Point pos.</i>	[T+ D.P.= x]	AL2	[TTPDP]
---	---------------------	------------	----------------

Setting total direct totalizer decimal point position.

Example: T+D.P.= 3 visualized value T+dm³ 0.000 / T+D.P.= 2 visualized value T+dm³ 0.00

(POS. 2.9) <i>Total. Part. direct unit of m. type</i>	[P+ unit= METRIC]	AL2	[TPPUT]
--	--------------------------	------------	----------------

This function is active with POS. 9.7 see page 29 enable.

Setting partial direct totalizer measure unit type: metric or not metric (Imperial units).

This function changes the values measure unit on POS. 2.10 see page 27 .

It is visualized on visualization pages.

(POS. 2.10) <i>Total. Partial+ unit of measure</i>	[P+ unit= dm³]	AL2	[TPPUM]
---	----------------------------------	------------	----------------

Setting partial direct totalizer measure unit.

This function visualized on visualization pages.

(POS. 2.11) Total. Part direct Dec. Point pos.	[P+ D.P.= x]	AL2	[TPPDP]
---	---------------------	------------	----------------

Setting partial direct totalizer decimal point position.

Example: P+D.P.= 3 visualized value P+dm³ 0.000 / P+D.P.= 2 visualized value P+dm³ 0.00

(POS. 2.12) Total. T reverse unit of m. type	[T- unit= METRIC]	AL2	[TTNUT]
---	--------------------------	------------	----------------

This function is active with POS. 9.8 see page 29, enabled.

Setting total reverse totalizer measure unit type: metric or not metric (Imperial units).

This function changes the values measure unit on POS. 2.13 see page 27.

It is visualized on visualization pages.

(POS. 2.13) Total. T reverse unit of meas.	[T- unit= dm³]	AL2	[TTNUM]
---	----------------------------------	------------	----------------

Setting total reverse totalizer measure unit.

This function visualized on visualization pages.

(POS. 2.14) Total. T reverse Dec. Point Pos.	[T- D.P.= x]	AL2	[TTNDP]
---	---------------------	------------	----------------

Setting total reverse totalizer decimal point position.

Example: T- D.P.= 3 visualized value T- dm³ 0.000

T- D.P.= 2 visualized value T- dm³ 0.00

(POS. 2.15) Total. Part reverse unit of m. type	[P- unit= METRIC]	AL2	[TPNUT]
--	--------------------------	------------	----------------

This function is active with POS. 9.8 see page 29, enable.

Setting partial reverse totalizer measure unit type: metric or not metric (Imperial units).

This function changes the values measure unit on POS. 2.16 see page 27

It is visualized on visualization pages.

(POS. 2.16) Total. Part reverse unit of measure	[P- unit= dm³]	AL2	[TPNUM]
--	----------------------------------	------------	----------------

Setting partial reverse totalizer measure unit.

This function visualized on visualization pages.

(POS. 2.17) Tot Part. reverse Dec. Point Pos.	[P- D.P.= x]	AL2	[TPNDP]
--	---------------------	------------	----------------

Setting partial reverse totalizer decimal point position.

Example: P- D.P.= 3 visualized value P-dm³ 0.000

P- D.P.= 2 visualized value P-dm³ 0.00

(POS. 2.18) Temperature unit of measure	[Temp. unit= C°]	AL2	[TMPUT]
--	-------------------------	------------	----------------

Setting temperature measure unit.

(POS. 2.19) Mass units enable	[Mass units= ON/OFF]	AL2	[MSSUE]
--------------------------------------	-----------------------------	------------	----------------

Enable or Disable the selection of mass unit of full scale set.

(POS. 2.20) Specific Gravity coeffic.	[Sg= Kg/dm³ x.xxxx]	AL2	[VMSGC]
--	---------------------------------------	------------	----------------

Setting specific gravity coefficient. This Function is active with POS. 2.19 see page 27, enable.