Advance:
\$1,0,0,0#
\$0, 0, 0, 0#
Back:
\$2,0,0,0#
\$0, 0, 0, 0#
Left:
\$3, 0, 0, 0#
\$0, 0, 0, 0#
Right:
\$4, 0, 0, 0#
\$0, 0, 0, 0#
Left shake:
\$Servo, LRL#
\$Servo, LRS#
Right shake:
\$Servo, LRR#
\$Servo, LRS#
Rocker up:
\$Servo, UD180#\$Servo, UD180#\$Servo, UD180#
\$Servo, UD180#
¥002.10, 0020011
Rocker down:
\$Servo, UD071#\$Servo, UD024#\$Servo, UD000#
\$Servo, UD000#

Note: The value range of the last three digits of the for rocker slider UD is $0^{\sim}180$