

1. Pre-Operation: Essential Reading

In the factory-installed system image, JupyterLab comes pre-installed and pre-configured with a password.

JupyterLab operates on port 8888 and launches automatically upon system startup.

To access JupyterLab, ensure that your PC is connected to the same network as the mainboard. Simply enter the mainboard's IP address followed by `:8888` into your web browser's address bar, then press Enter. Upon your first login, you will be prompted to enter a password; the password is `yahboom`.