

APP Control Program

Temporarily Disable

Simply close the APP program terminal window or execute the following command:

```
cd ~/rosmaster && ./kill_YahboomArm.sh
```

Disable Auto-start on Boot

Factory default is disabled. It is recommended to keep this setting and enable it when needed. Otherwise, it may cause resource occupation and prevent running other cases.

```
rm -rf /home/yahboom/.config/autostart
```

Enable Auto-start on Boot

```
cp /home/yahboom/rosmaster/YahboomArm.desktop /home/yahboom/.config/autostart
```