Patrol

1. Program function description

After the program is started, open the patrol route set by the dynamic parameter setter and click "switch" on the GUI interface. The car will move according to the set patrol route. During the operation, the radar will work at the same time. If obstacles are detected within the detection range, will stop.

2. Program code reference path

The source code of this function is located at,

#pi4version

/home/pi/cartographer_ws2/src/yahboom_laser/yahboom_laser_Patrol_RS200.py

#pi5version

/root/yahboomcar_ws/src/yahboom_laser/yahboom_laser/laser_Patrol_RS200.py

3. Program startup

3.1. Start command

PI4 version driver:


For multi-machine communication ID modification, please refer to the tutorial: 14. Radar mapping navigation\6. Obtaining the status of the mechanical dog in the ROS2 environment\Acquiring the real joint data of the mechanical dog in the ROS2 environment.pdf

The mechanical dog chassis and radar have been set to start automatically at boot. If you find that they have not started, please enter in the terminal.


sudo systemctl restart YahboomStart.service

Since the mechanical dog chassis does not have an odometer, we can use cartographer to publish the odometer data, so we need a navigation module.


Open the virtual machine, enter the password: yahboom and press the Enter key to enter the system desktop.




Enter the desktop system and open the folder.



Then double click on the cartoros2 folder




Then right-click in an empty space of the folder and select Open in Terminal



Then enter the following command in the terminal to activate the environment


After completing the input, press the Enter key.




Then enter the command

```
ros2 launch yahboom_bringup Navigation_bringup.launch.py
map_yaml:=/home/yahboom/cartoros2/data/maps/mymap.yaml
map:=/home/yahboom/cartoros2/data/maps/mymap.pbstream
```

Where map_yaml is the yaml file of the map, and map is the pbstream file of the map.



Then press the Enter key to navigate.



If the radar and chassis are started, you need to enter in the terminal of the mechanical dog:

```
cd /home/pi/cartographer_ws2
source install/setup.bash
#Start patrol program Radar MS200
ros2 run yahboom_laser laser_Patrol_RS200
```

PI5 version driver:

For multi-machine communication ID modification, please refer to the tutorial: 14. Radar mapping navigation\6. Obtaining the status of the mechanical dog in the ROS2 environment\Acquiring the real joint data of the mechanical dog in the ROS2 environment.pdf

Open a terminal in the root directory of the Raspberry Pi and enter the following command to enter docker:

```
./run_humble.sh

pi@raspberrypi:~ $ ./run_humble.sh
access control disabled, clients can connect from any host
root@raspberrypi:/# cd
root@raspberrypi:~# ls
core DOGZILLALib py_install_V0.0.1 yahboomcar_ws YDLidar-SDK
root@raspberrypi:~#
```


Then enter the following command in the docker terminal to start the radar data:

```
ros2 launch bringup Navigation_bringup.launch.py
```

Then enter the command to run the patrol program, ** (PI5 version needs to enter the same docker to run, please refer to "Introduction and Use of Radar" for steps)**

```
#Start radar obstacle avoidance program Radar MS200
ros2 run yahboom_laser laser_Patrol_RS200
```


You need to open the virtual machine, enter the password: yahboom and then press the Enter key to enter the system desktop.



Enter the desktop system and open the folder.




Then right-click in an empty space of the folder and select Open in Terminal



Then enter the command,

```
ros2 launch yahboom_dog_cartographer localization_imu_odom.launch.py
load_state_filename:=/home/yahboom/yahboomcar_ws/maps/test1.pbstream
```

The name is the map name is test1, and the map data is test1.pbstream** (note that the map needs to be built in advance, because patrols need to use odom, and the map needs to be built before it can be provided)**



Then press the Enter key to start the patrol function.


```
yahboom@yahboom-virtual-machine: ~
                                                               Q
/ahboom@yahboom-virtual-machine:~$ ros2 launch yahboom dog cartographer localiza
tion imu odom.launch.py load state filename:=/home/yahboom/yahboomcar ws/maps/te
st1.pbstream
[INFO] [launch]: All log files can be found below /home/yahboom/.ros/log/2024-04
-28-15-51-48-410819-yahboom-virtual-machine-5272
[INFO] [launch]: Default logging verbosity is set to INFO
[INFO] [cartographer_node-1]: process started with pid [5273]
[cartographer_node-1] [INFO] [1714290708.635245656] [cartographer logger]: I0428
15:51:48.000000 5273 configuration_file_resolver.cc:41] Found '/home/yahboom/y
ahboomcar_ws/install/yahboom_dog_cartographer/share/yahboom_dog_cartographer/config/dog_2d.lua' for 'dog_2d.lua'.
[cartographer_node-1] [INFO] [1714290708.635670480] [cartographer logger]: I0428
15:51:48.000000 5273 configuration_file_resolver.cc:41] Found '/opt/ros/humble
share/cartographer/configuration_files/map_builder.lua' for 'map_builder.lua'.
[cartographer_node-1] [INFO] [1714290708.635701732] [cartographer logger]: I0428
15:51:48.000000 5273 configuration_file_resolver.cc:41] Found '/opt/ros/humble
/share/cartographer/configuration_files/map_builder.lua' for 'map_builder.lua'.
[cartographer_node-1] [INFO] [1714290708.635796758] [cartographer logger]: I0428
15:51:48.000000 5273 configuration_file_resolver.cc:41] Found '/opt/ros/humble
/share/cartographer/configuration_files/pose_graph.lua' for 'pose_graph.lua'.
[cartographer_node-1] [INFO] [1714290708.635833456] [cartographer logger]: I0428
15:51:48.000000 5273 configuration_file_resolver.cc:41] Found '/opt/ros/humble
/share/cartographer/configuration_files/pose_graph.lua' for 'pose_graph.lua'.
[cartographer_node-1] [INFO] [1714290708.636119230] [cartographer logger]: I0428
```

3.2. View the topic communication node diagram

Set the parameter size through the dynamic parameter adjuster, terminal input, ** (PI5 version needs to run in the same docker, please refer to "Introduction and Use of Radar" for steps)**

```
ros2 run rqt_reconfigure rqt_reconfigure
```

Each parameter of the dynamic parameter regulator is explained as follows:



Parameter name	Parameter meaning		
odom_frame	Odometer coordinate system		
base_frame	Base coordinate system		
circle_adjust	Circle angular speed adjustment coefficient		
Switch	Gameplay switch		
Command	Patrol Route		
Set_loop	Set loop		
ResponseDist	Radar obstacle avoidance response distance		
LaserAngle	Radar scanning angle		
Linear	Linear speed		
Angular	Angular velocity		
Length	Straight line test distance		
RotationTolerance	Steering error tolerance		
RotationScaling	Rotation scaling coefficient		

After the program starts, in the GUI interface of the dynamic parameter adjuster interface, enter any of the following routes in the Comand column:

- LengthTest: straight line test
- Circle: circular route patrol
- Square: Square route patrol
- Triangle: Triangular route patrol

After selecting the route, click on the blank space to write the parameters, and then click the Switch button to start patrolling. If loop is set, you can loop the last route for patrol. If loop is false, it will stop after completing the patrol.

4. Core source code analysis

The implementation source code of this code is to subscribe to the TF transformation of odom and base_footprintf, so that you can know "how long you have walked" at any time, and then issue speed instructions according to the set route. Taking Triangle as an example, we will analyze it here.

```
#Set the patrol route and enter the self.Triangle function
self.command_src = "Triangle"
triangle = self.Triangle()
#Parse with part of self.Triangle code,
def Triangle(self):
    if self.index == 0:
        print("Length")
        step1 = self.advancing(self.Length) #Start with a straight line and
walk through one side of the triangle
```

```
\#sleep(0.5)
         if step1 == True:
             #self.distance = 0.0
             self.index = self.index + 1;
             self.Switch =
rclpy.parameter.Parameter('Switch', rclpy.Parameter.Type.BOOL, True)
             all_new_parameters = [self.Switch]
             self.set_parameters(all_new_parameters)
elif self.index == 1:
             print("Spin")
             step2 = self.Spin(120)#Then change the direction, turn to 120,
triangle 3*120=360
             #sleep(0.5)
             if step2 == True:
                 self.index = self.index + 1;
                 self.Switch =
rclpy.parameter.Parameter('Switch',rclpy.Parameter.Type.BOOL,True)
                 all_new_parameters = [self.Switch]
                 self.set_parameters(all_new_parameters)
#After completing the following 3 loops, the triangle patrol is completed, mainly
looking at the self.advancing and self.Spin functions. After these two functions
are executed, True will be returned.
  def advancing(self, target_distance):
     #The following is to obtain the xy coordinates, calculate them with the
coordinates of the previous moment, and calculate how far you have gone
     #The way to obtain xy coordinates is to monitor the tf transformation of
odom and base_footprint. For this part, please refer to the self.get_position()
function.
self.position.x = self.get_position().transform.translation.x
     self.position.y = self.get_position().transform.translation.y
     move_cmd = Twist()
     self.distance = sqrt(pow((self.position.x - self.x_start), 2) +
                          pow((self.position.y - self.y_start), 2))
     self.distance *= self.LineScaling
     print("distance: ",self.distance)
     self.error = self.distance - target_distance
     move_cmd.linear.x = self.Linear
     if abs(self.error) < self.LineTolerance:</pre>
         print("stop")
         self.distance = 0.0
         self.pub_cmdVel.publish(Twist())
         self.x_start = self.position.x;
         self.y_start = self.position.y;
         self.Switch =
rclpy.parameter.Parameter('Switch',rclpy.Parameter.Type.BOOL,False)
         all_new_parameters = [self.Switch]
         self.set_parameters(all_new_parameters)
         return True
     else:
         if self.Joy_active or self.warning > 10:
             if self.moving == True:
                 self.pub_cmdVel.publish(Twist())
                 self.moving = False
                 print("obstacles")
              else:
```

```
#print("Go")
                 self.pub_cmdVel.publish(move_cmd)
self.moving = True
return False
def Spin(self,angle):
         self.target_angle = radians(angle)
         #The following is to obtain the pose and calculate how many degrees you
have turned. To obtain the pose, you can refer to the self.get_odom_angle
function. It is also obtained by monitoring the TF transformation of odom and
base_footprint.
         self.odom_angle = self.get_odom_angle()
         self.delta_angle = self.RotationScaling *
self.normalize_angle(self.odom_angle - self.last_angle)
         self.turn_angle += self.delta_angle
         print("turn_angle: ",self.turn_angle)
         self.error = self.target_angle - self.turn_angle
         print("error: ",self.error)
         self.last_angle = self.odom_angle
        move_cmd = Twist()
         if abs(self.error) < self.RotationTolerance or self.Switch==False:</pre>
             self.pub_cmdVel.publish(Twist())
             self.turn_angle = 0.0
             '''self.Switch =
rclpy.parameter.Parameter('Switch',rclpy.Parameter.Type.BOOL,False)
             all_new_parameters = [self.Switch]
             self.set_parameters(all_new_parameters)'''
             return True
         if self.Joy_active or self.warning > 10:
             if self.moving == True:
                 self.pub_cmdVel.publish(Twist())
                 self.moving = False
                 print("obstacles")
         else:
             if self.Command == "Square" or self.Command == "Triangle":
                 #move_cmd.linear.x = 0.2
                 move_cmd.angular.z = copysign(self.Angular, self.error)
             elif self.Command == "Circle":
                 length = self.Linear * self.circle_adjust /
self.Length#circle_adjust here is the coefficient of the rotation angle. It can
be understood that the larger the length, the larger the radius of the circle.
                 #print("length: ",length)
                 move_cmd.linear.x = self.Linear
                 move_cmd.angular.z = copysign(length, self.error)
                 #print("angular: ",move_cmd.angular.z)
                 '''move_cmd.linear.x = 0.2
                 move_cmd.angular.z = copysign(2, self.error)'''
             self.pub_cmdVel.publish(move_cmd)
         self.moving = True
```