## Movelt precautions and control of the real machine

Follow the previous steps to install the virtual machine. After decompressing the system files, open the virtual machine and use it. The environment has been set up and the relevant code has been placed in the Ubuntu system, in the file path /home/dofbot/dofbot\_ws/src directory.

## 1. Control the real machine

Configure multi-machine communication

Just refer to the distributed communication tutorial in ros basics

• Using Raspberry Pi as host

roslaunch dofbot\_config demo.launch #Virtual machine side
rosrun dofbot\_moveit 00\_dofbot\_move.py #Host side

The corresponding relationship between the robotic arm servo and the joints: from the lowest end of the robotic arm to the end of the gripper.

Robotic arm servo	joint	joint
The first servo	joint1	joint1
Second servo	joint2	joint2
The third servo	joint3	joint3
The fourth servo	joint4	joint4
The fifth servo	joint5	joint5
Servo that controls the gripper	grip_joint	Gripper

## 2. Start the robotic arm

- When using the robot arm to move randomly to control a real machine, pay attention to the movement of the robot arm. Try to keep no objects next to the robot arm, because random movement will cause random walking.
- Scene Design: You can design the scene yourself and then import it.
- When movelt is run and combined with the real machine case, there are non-corresponding
  actions. It may be because the previous control program has not been completely closed. You
  can try using Ctrl+C to interrupt the program, or simply close the terminal to shut down the
  previous process more completely.

## 3. MovelT startup

The Movelt simulation environment starts slowly, so wait patiently and observe the terminal. An error occurs as shown in the figure below. The solution is as shown in the figure. If the terminal reports an error and the motion planning library is not loaded, click [Reset] in the lower left corner and reload. At first, it is during the loading process. Don't rush to click [Reset]. If you click it before loading is complete, the system will reload and it will not start.





