

QR code recognition

1. First determine whether the version of the image transmission module is the AI version firmware. **If you already know the firmware version, you can ignore this step** and use the **wifi_ver** command to query, as shown in the figure below

```
[2024-08-06 14:53:29.948]# SEND ASCII>
wifi_ver
[2024-08-06 14:53:30.010]# RECV ASCII>
YAHBOOM VerSion:AI_V0.5.0
```

2. Switch the mode to the QR code recognition mode. Use the following command to send **ai_mode:5** through the serial assistant. After successful configuration, the module will restart and print the current firmware version. You can start QR code recognition, as shown in the figure

```
[2024-08-06 15:03:04.205]# SEND ASCII>
ai_mode:5
[2024-08-06 15:03:04.341]# RECV ASCII>
ESP-ROM:esp32s3-20210327
Build:Mar 27 2021
rst:0x3 (RTC_SW_SYS_RST),boot:0x8 (SPI_FAST_FLASH_BOOT)
Saved PC:0x40375a0c
SPIWP:0xee
mode:DIO, clock div:1
load:0x3fce3818,len:0x514
load:0x403c9700,len:0x4
load:0x403c9704,len:0xb58
load:0x403cc700,len:0x2a8c
entry 0x403c98fc

[2024-08-06 15:03:04.886]# RECV ASCII>
[0:32mI (549) cpu_start: Multicore app [0m
[0:32mI (549) esp_psram: Found 2MB PSRAM device [0m
[0:32mI (550) esp_psram: Speed: 80MHz [0m
[0:32mI (550) cpu_start: Pro cpu up. [0m
[0:32mI (554) cpu_start: Starting app cpu, €
[2024-08-06 15:03:07.070]# RECV ASCII>
YAHBOOM AI VerSion:AI_V0.5.0
```

Note: If the current mode is already the QR code recognition mode, the module only returns ok

```
[2024-08-06 15:05:32.444]# SEND ASCII>
ai_mode:5
[2024-08-06 15:05:32.503]# RECV ASCII>
OK
```

3. Start recognizing QR codes If recognized, the recognition result will be sent out through the serial port.

The specific content is **\$Recognition result#**

Note: You need to open the screen to start recognition. If the screen is closed in the middle, the recognition will also be closed.

QR code



Result:



Serial port information:

```
$goahead#$goahead#$goahead#$goahead#$goahead#$goahead#$goahead#$goahead#$goahead#  
$goahead#$goahead#$goahead#$goahead#$goahead#$goahead#$goahead#$goahead#$goahead#  
$goahead#$goahead#$goahead#$goahead#$goahead#
```