

Must-read for use

YOLOv11 environment is located in Docker, users need to have a certain understanding of Docker to use it smoothly!

Note: Only USB cameras can be used in Docker to run real-time detection cases!

Enter Docker

```
sh ~/yolov11_dcoker.sh
```

