

How to log into system by PuTTY

1. Determine the IP address of your board.

Method 1: Directly during the installation of the system, open a command terminal by **ctr+Alt+T** in the interface.

Then we need to enter: ifconfig


Find the IP address of the corresponding wired network card eth0. If you have a wireless network card, please see the address under wlan.

Method 2:

You can log in to the wireless router management system and find the IP address of your Jetson Nano board.

2.Open **PuTTY** software, input IP address and port(22). The default system has the ssh service enabled.

For example: My IP address is 192.168.1.176



Next, we need to click "open", and click "Yes"





3.Enter the login name we entered in the installation system, (for exmaple: login name is nano.)



Then we need to input password to enter system.



