QR code recognition

QR code recognition

- 1. Install dependencies
- 2. Create a QR code
- 3. Parsing QR code
 - 3.1. USB camera
 - 3.2 CSI Camera


Frequently asked questions

'PIL.Image' has no attribute 'Resampling'

QR code (Quick Response Code) is a matrix barcode composed of squares that can be used to store various information.

1. Install dependencies

```
sudo apt install libzbar-dev -y
sudo pip3 install qrcode pyzbar
```




2. Create a QR code

```
cd ~/qr_code_recognition

python3 qrcode_create.py
```

After running the command, enter the information hidden in the QR code: The generated image is located in the /home/jetson/qr_code_recognition/figures folder




3. Parsing QR code

3.1. USB camera

cd ~/qr_code_recognition


python3 qrcode_parsing_usb.py



3.2 CSI Camera

cd ~/qr_code_recognition

python3 qrcode_parsing_csi.py



Frequently asked questions

'PIL.Image' has no attribute 'Resampling'

sudo pip3 install --upgrade pillow