

Voice Interaction Hardware Connection (ReadMe)

To run the voice interaction feature, you must use the AI large-model voice module included in the AI large-model package for the Jetson Orin series motherboards.

Wiring Diagram:

