Get Started Quickly

Get Started Quickly
1. First Boot
    1.1. Prerequisites
        Before First Use: Update the Mainboard Bootloader First
    1.2. Boot the System
2. System Environment
    2.1. Basic Information
    2.2. Jupyter Lab
    2.3. Label Studio
    2.4. Open WebUI
3. Precautions

1. First Boot

Start from the factory image — ideal for beginners: try every case without setting up the environment yourself.

1.1. Prerequisites

Before First Use: Update the Mainboard Bootloader First

The factory mainboard uses the **JetPack 6.2** bootloader by default. The currently shipped solid-state drive uses the **JetPack 7.2.1** system. After receiving the mainboard, customers cannot directly install the shipped solid-state drive and power on to boot; the QSPI/UEFI bootloader of the mainboard must first be updated to a version matching JetPack 7.2.1, otherwise the solid-state drive may not be recognized, the system may reboot repeatedly, or it may stay on the boot screen.

First complete the corresponding **JetPack 7.2.1 / SUPER bootloader update** in Chapter 2, and after confirming that the bootloader update is successful, install the shipped solid-state drive to boot the system. The current tutorial entry is "Chapter 2 Mainboard Basics → 07. Writing the SUPER Bootloader (Must Read)", which contains the QSPI/UEFI update instructions for JetPack 7.2.1;

Recommended order:

1. Check the mainboard module, carrier board model, and current JetPack version.
2. Update the QSPI/UEFI bootloader according to the **JetPack 7.2.1 / SUPER bootloader update** tutorial in Chapter 2.
3. Shut down and disconnect the power, install the shipped solid-state drive, and then boot the mainboard.
4. After entering the system, configure the monitor, network, and VNC as described later in this chapter.

Version appearance differences:

Usage steps:

Notes:

1. Writing the JP7.2.1 bootloader: corresponding tutorial 【Chapter 2 Mainboard Basics: 07. Writing the SUPER Bootloader (Must Read)】
2. SSD expansion: corresponding tutorial 【Chapter 2 Mainboard Basics: SSD Expansion】

1.2. Boot the System

Once the mainboard is equipped with the solid-state drive, network card, antenna, and DP data cable (connected to the monitor), you can use the matching DC power adapter to boot the mainboard system.

Jetson Orin series mainboards require a monitor connection to properly display the system desktop. For first-time use, it is recommended that users connect an external monitor and configure VNC remote access.

Note: According to user feedback, some users can achieve VNC remote access using a graphics card emulator and a virtual desktop; this content is not within the scope of the tutorial!

2. System Environment

2.1. Basic Information

System username: jetson

System password: yahboom

2.2. Jupyter Lab

Host access: http://localhost:8888/

LAN access: http://mainboard IP:8888/

Access password: yahboom

2.3. Label Studio

Host access: http://localhost:8080/

LAN access: http://mainboard IP:8080/

Access account: yahboom

Access password: yahboom@163.com

2.4. Open WebUI

Host access: http://localhost:8080/

LAN access: http://mainboard IP:8080/

Access username: yahboom
Access email: yahboom@163.com
Access password: yahboom

3. Precautions

- Label Studio and Open WebUI occupy the same port; if one of the containers is running, ensure that the other is shut down!
- Due to software version iterations and different user environments, we cannot ensure that everyone can successfully build the environment, but the only thing we can provide is a complete system image. If users encounter environment problems and cannot solve them by themselves, please use the factory image we provide to study the tutorials.