Edge Recognition - Grayscale Image

Edge Recognition - Grayscale Image

Example Results

Code Overview

Importing Modules

Setting the Image Size

Initialize the camera

Initialize the display module

Initialize the media manager and start the camera

Set edge detection parameters

Image processing and edge detection

Resource release

Parameter adjustment instructions

Example Results

Run the example code in this section [Source Code/06.cv_lite/7.grayscale_find_edges.py]

In this section, we will use the cv_lite extension module to implement grayscale image edge detection (Canny algorithm) on an embedded device.



Code Overview

Importing Modules

```
import time, os, sys, gc
from machine import Pin
from media.sensor import * # Camera interface
from media.display import * # Display interface
from media.media import * # Media manager
import _thread
import cv_lite # cv_lite extension module (including edge detection)
import ulab.numpy as np # NumPy-like ndarray for MicroPython
```

Setting the Image Size

```
image_shape = [480, 640] # Height x Width
```

Define the image resolution to 480x640 (Height x Width), width), the camera and display module will be initialized based on this size later.

Initialize the camera

```
sensor = Sensor(id=2, width=1280, height=960, fps=90)
sensor.reset()
sensor.set_framesize(width=image_shape[1], height=image_shape[0])
sensor.set_pixformat(Sensor.GRAYSCALE) # Set to grayscale image output /
Grayscale mode
```

- Initialize the camera, set the resolution to 1280x960 and the frame rate to 90 FPS.
- Resize the output frame to 640x480 and set it to grayscale mode (single-channel image, saves memory and computing resources, suitable for edge detection).

Initialize the display module

Initialize the display module, using the ST7701 driver chip, with a resolution consistent with the image size. to_ide=True indicates that the image will be simultaneously transmitted to the IDE for virtual display, and quality=50 sets the image transmission quality.

Initialize the media manager and start the camera

```
MediaManager.init()
sensor.run()
```

Initialize the media resource manager and start the camera to capture the image stream.

Set edge detection parameters

```
threshold1 = 50 # Lower threshold
threshold2 = 80 # Upper threshold
clock = time.clock() # Start FPS timer
```

- [threshold1: The lower threshold for Canny edge detection, used to control the detection of weak edges.
- threshold2: The upper threshold for Canny edge detection, used to control the detection of strong edges. A larger value results in fewer edges being detected.
- clock: Used to calculate the frame rate.

Image processing and edge detection

```
while True:
   clock.tick()
   # Capture a frame
    img = sensor.snapshot()
    img_np = img.to_numpy_ref() # Get ndarray reference
   # Perform edge detection by calling the cv_lite extension
   # Returns edge image ndarray
    edge_np = cv_lite.grayscale_find_edges(
        image_shape, img_np, threshold1, threshold2)
    # Wrap ndarray as image for display
    img_out = image.Image(image_shape[1], image_shape[0], image.GRAYSCALE,
                         alloc=image.ALLOC_REF, data=edge_np)
    # Show edge image
   Display.show_image(img_out)
   # Cleanup and print FPS
   gc.collect()
    print("edges:", clock.fps())
```

- Image Capture: Acquire an image frame using sensor.snapshot() and convert it to a NumPy array reference using to_numpy_ref().
- **Edge Detection**: Call <code>cv_lite.grayscale_find_edges()</code> to perform Canny edge detection, returning a NumPy array of grayscale edge images.
- Image Packaging and Display: Pack the edge detection result into an image object and display it on the screen or in an IDE virtual window.
- **Memory Management and Frame Rate Output**: Call gc.collect() to clean up memory and print the current frame rate using clock.fps().

Resource release

```
sensor.stop()
Display.deinit()
os.exitpoint(os.EXITPOINT_ENABLE_SLEEP)
time.sleep_ms(100)
MediaManager.deinit()
```

Parameter adjustment instructions

- **threshold1**: Low threshold. A smaller value can detect more weak edges, but may introduce noise. It is recommended to start adjusting from 50.
- [threshold2 : High threshold. A larger value can detect fewer strong edges, which is suitable for noisy environments. Increasing this value can reduce false edges.