

Download Program Precautions

Download Program Precautions

1. Flashing Interface
2. Preparation Before Flashing
3. MicroPython Program Flashing Requirements
4. Conflict Between MakeCode and MicroPython Cases
5. Red Searchlight Blinking During Flashing

1. Flashing Interface

- The flashing interface is located on the Micro:bit main board, not the Charging port on the expansion board.

2. Preparation Before Flashing

- Before flashing, it is recommended to turn off the car expansion board power switch (switch it to OFF). After the flashing is successful, disconnect the Micro:bit data cable.

3. MicroPython Program Flashing Requirements

- Before flashing a MicroPython program, you must first write "LASTBIT.hex" to the corresponding drive letter of the Micro:bit, and then use Mu Editor to flash the MicroPython example program. Otherwise, the following error will occur:

```
ImportError: no module named 'lastbit'.
```

4. Conflict Between MakeCode and MicroPython Cases

- There is a conflict between MakeCode graphics library cases and MicroPython cases. If the Micro:bit was last downloaded with a MakeCode graphics driver, you need to rewrite "LASTBIT.hex" to the corresponding drive letter of the Micro:bit before flashing the MicroPython program this time.

5. Red Searchlight Blinking During Flashing

- During flashing, the car is powered through the microusb, and a low-voltage alarm may occur. After flashing, unplug the microusb, power off, then turn on the car power switch again and power it through the battery.