

0. Voice Interaction Hardware Connection (Must Read)

To enable voice interaction, you must use the AI large-scale voice module included in the AI large-scale package that comes with the motherboard. **The Raspberry Pi 5 1GB version does not have this package and cannot run voice interaction cases.**

Wiring Diagram:

