

Voice Interaction Hardware Connection (Must Read)

To run the voice interaction function, you must use the AI Large Model Voice Module included in the AI Large Model Package that comes with the RDK S600 motherboard.

Set up the relevant environment for the Large Model function package. For setup details, please refer to Offline Large Model (Text Interaction) -> 1. AI Large Model Environment Deployment.

Wiring Diagram:

