

Voice Interaction Hardware Connection (Must Read)

To run the voice interaction function, you must use the AI large model voice module included in the AI large model package that comes with the motherboard.

Wiring diagram:

