FAQ

- FAQ

1. **Raspberry Pi mainboard** — when starting mapping/navigation, RViz2, etc., no visualization interface appears? - The Raspberry Pi must first start the ROS 2 Humble container in the VNCZ desktop environment; the container cannot be started in an SSH or similar environment. Use `humble down` to shut down the previous container first, then use `humble exec` in VNC to

restart the ros2 humble container.

2. When filling in the Tongyi API-KEY in Dify, it keeps prompting rate limiting and the API-KEY cannot be verified? - Models on the Bailian platform may be discontinued or their interfaces updated; simply click the plugin to update it to the newest version

