Tips for using Raspberry PI 5

Tips for using Raspberry PI 5

Display
Remote login
powered by

Display

- 1. You can connect the power cord of the display first, and then the HDMI cable. If the order is reversed, the screen may remain black after the wiring is completed.
- 2. If you power on the Raspberry Pi 5 first, log in remotely, and then connect to the screen, a remote crash may occur. At this time, you can restart Raspberry Pi 5.

Remote login

When the Raspberry Pi is connected to the display screen, if you log in to the desktop system remotely, the resolution of the picture will be based on the screen resolution. Even if the resolution is changed in the system, it will not take effect.

If you want the modified resolution to take effect when the display is connected, you need to unplug the display and then restart the Raspberry Pi.

When the resolution modification of the Raspberry Pi takes effect, if an external display is connected, the resolution of the remote desktop system will become the same as the screen resolution.

powered by

If the power adapter used is not 5.1V/5A. After powering on, the system will display a low voltage reminder, which will limit the current of peripheral devices to 600mA.

