0. Voice Interaction Hardware Connection (Must Read)

To enable voice interaction, you must use the AI large-scale voice module included in the AI large-scale package that comes with the motherboard.

Wiring Diagram: