

2.2.1 Drive buzzer

The hardware part is not shown in detail. The following is an introduction to API functions:

Buzzer_control (1) #Buzzer on Buzzer_control (0) #Buzzer off

Code path:

/home/pi/Yahboom_Project/2Hardware_Control_cuorse/1_Buzzer.ipynb

Import Raspblock Drive library

from Raspblock import Raspblock

robot = Raspblock() # get object

robot.Buzzer_control(1) # buzzer on

robot.Buzzer_control(0) # buzzer off

del robot # The object needs to be released after use, otherwise, when the next program needs to use this object module, it will be occupied and will become unusable